

# Sun Server X4-2

## Service Manual



Part No.: E38041-07  
May 2014

Copyright © 2013, 2014, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT END USERS. Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

---

Copyright © 2013, 2014, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT END USERS. Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. UNIX est une marque déposée d'The Open Group.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.



Adobe PostScript

# Contents

---

**Using This Documentation** xi

**About the Sun Server X4-2** 1

Product Description 1

About Controls and Connectors 2

Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives 3

Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive 4

Server Back Panel View 5

About Server and Component Status Indicators 6

Server General Status Indicators 7

Server Fan Status Indicators 9

Storage Drive Status Indicators 10

Power Supply Status Indicators 11

Network Management Port Status Indicators 11

Ethernet Ports Status Indicators 12

Motherboard Status Indicators 13

DDR3 DIMM Fault Status Indicators 13

Processor Fault Status Indicators 14

Fault Remind Status Indicator 14

STBY PWRGD Status Indicator 14

About System Components 15

Illustrated Parts Breakdown	15
Customer-Replaceable Units	17
Field-Replaceable Units	18
Battery Module	19

## **Troubleshooting the Server 21**

Service Troubleshooting Task List	21
Diagnostic Tools	22
▼ Gather Service Information	24
▼ Locate the Server Serial Number	25
Inspecting the System	25
▼ Troubleshoot Power Problems	26
▼ Inspect the Server Externally	26
▼ Inspect Internal Server Components	26

## **Preparing for Service 29**

Safety Precautions	29
FRU TLI Auto-Update	30
Safety Symbols	30
Electrostatic Discharge Safety	31
Required Tools	32
Preparing the Server for Component Replacement	33
Powering Down the Server	33
▼ Power Down Server Gracefully Using the Oracle ILOM CLI	34
▼ Power Down Server Gracefully Using the Oracle ILOM Web Interface	35
▼ Power Down Server Gracefully Using the Power Button	36
▼ Use the Power Button for Immediate Shutdown	36
▼ Use the Oracle ILOM CLI for Immediate Shutdown	37
▼ Use the Oracle ILOM Web Interface for Immediate Shutdown	38

- ▼ Disconnect Cables From the Server 39
- ▼ Extend the Server to the Maintenance Position 39
- ▼ Remove the Server From the Rack 41
- ▼ Take Antistatic Measures 42
- ▼ Open the Server Fan Door 43
- ▼ Remove the Server Top Cover 43

## **Servicing CRUs That Do Not Require Server Power-Off 45**

### Servicing Storage Drives (CRU) 45

Storage Drives Hot-Plug Conditions 46

HDD or SSD Failure and RAID 46

Storage Drive Status Indicators 47

- ▼ Remove a Storage Drive 47
- ▼ Install a Storage Drive 49

### Servicing Fan Modules (CRU) 50

- ▼ Remove a Fan Module 51
- ▼ Install a Fan Module 54

### Servicing Power Supplies (CRU) 55

Power Supply Status Indicators 56

- ▼ Remove a Power Supply 57
- ▼ Install a Power Supply 59

## **Servicing CRUs That Require Server Power-Off 61**

### CRU Locations 61

### Servicing the DIMMs (CRU) 62

DIMM and Processor Physical Layout 64

DIMM Population Example for Optimal System Performance 65

DIMM Population Order for Single-Processor Systems 66

DIMM Population Order for Dual-Processor Systems 66

DIMM Population Rules	67
DIMM Rank Classification Labels	69
Inconsistencies Between DIMM Fault Indicators and the BIOS Isolation of Faulty DIMMs	70
Using the Fault Remind Button	70
▼ Identify and Remove a Faulty DIMM	71
▼ Install a DIMM	73
Servicing PCIe Risers (CRU)	74
PCIe Riser Location and Differences	75
▼ Remove a PCIe Riser From PCIe Slot 1 or 2	76
▼ Install a PCIe Riser Into PCIe Slot 1 or 2	78
▼ Remove a PCIe Riser From PCIe Slots 3 and 4	80
▼ Install a PCIe Riser Into PCIe Slots 3 and 4	82
Servicing PCIe Cards (CRU)	84
PCIe Slot Characteristics	85
▼ Remove a PCIe Card From PCIe Slot 1 or 2	86
▼ Install a PCIe Card in PCIe Slot 1 or 2	87
▼ Remove a PCIe Card From PCIe Slot 3	87
▼ Install a PCIe Card in PCIe Slot 3	88
▼ Remove the Internal HBA Card From PCIe Slot 4	89
▼ Install the Internal HBA Card in PCIe Slot 4	90
Servicing the DVD Drive (CRU)	91
▼ Remove the DVD Drive	91
▼ Install the DVD Drive	93
Servicing the Internal USB Flash Drives (CRU)	94
Servicing the Oracle System Assistant USB Flash Drive	94
▼ Remove an Internal USB Flash Drive	95
▼ Install an Internal USB Flash Drive	95
Servicing the Battery (CRU)	96

- ▼ Remove the Battery 97
- ▼ Install the Battery 98

## **Servicing FRUs 99**

FRU Locations 99

Servicing Processors (FRU) 100

    Selecting the Correct Processor Removal/Replacement Tool 102

    ▼ Remove a Processor 106

    ▼ Install a Processor 112

Servicing the Disk Backplane (FRU) 117

    Disk Backplane Configurations 118

    ▼ Remove the Disk Backplane 119

    ▼ Install the Disk Backplane 122

Servicing the Front Indicator Module (FRU) 125

    ▼ Remove the Front Indicator Module 125

    ▼ Install the Front Indicator Module 127

Servicing the Motherboard (FRU) 127

    ▼ Remove the Motherboard 128

    ▼ Install the Motherboard 135

Servicing the SAS Cables (FRUs) 138

    ▼ Remove Storage Drive SAS Cables 139

    ▼ Install Storage Drive SAS Cables 141

## **Returning the Server to Operation 143**

Removing and Installing Server Filler Panels 143

    ▼ Remove and Install Filler Panels 144

▼ Install the Server Top Cover 145

▼ Remove Antistatic Measures 146

▼ Reinstall the Server Chassis Into the Rack 146

- ▼ Return the Server to the Normal Rack Position 148
- ▼ Reconnect Data Cables and Power Cords 149
- ▼ Power On the Server 150

### **Identifying the Server Ports 153**

- Gigabit Ethernet Ports 153
- Network Management Port 154
- Serial Management Port 155
- Video Connector 157
- USB Ports 158

### **Setting Up BIOS Configuration Parameters 161**

- Managing the BIOS Configuration 161
- Accessing the BIOS Setup Utility 162
  - BIOS Setup Utility Menus 162
  - BIOS Key Mappings 163
    - ▼ Access BIOS Setup Utility Menus 164
    - ▼ Navigate BIOS Setup Utility Menus 165
- Using Legacy or UEFI BIOS 167
  - Selecting Legacy BIOS or UEFI BIOS Boot Mode 167
  - Switching Between Legacy BIOS and UEFI BIOS 168
  - UEFI BIOS Boot Mode Advantages 169
  - Configuration Utilities for Add-In Cards 169
- Using BIOS for Resource Allocation 170
  - Legacy Option ROM Allocation 170
  - I/O Resource Allocation 171
- Common BIOS Setup Utility Tasks 172
  - ▼ Verify BIOS Factory Default Settings 172
  - ▼ Select Legacy BIOS or UEFI BIOS Boot Mode 173

- ▼ Select the Boot Device 175
- ▼ Configure iSCSI Virtual Drives 176
- ▼ Enable or Disable Oracle System Assistant 184
- ▼ Configure TPM Support 186
- ▼ Configure SP Network Settings 189
- ▼ Configure Option ROM Settings 192
- ▼ Configure I/O Resource Allocation 193
- ▼ Exit BIOS Setup Utility 194

### **BIOS Setup Utility Menu Options 197**

- BIOS Main Menu Selections 198
- BIOS Advanced Menu Selections 203
- BIOS IO Menu Selections 213
- BIOS Boot Menu Selections 217
- UEFI Driver Control Menu Selections 221
- BIOS Save & Exit Menu Selections 225

### **Monitoring Components and Identifying SNMP Messages 227**

- Monitoring Component Health and Faults Using Oracle ILOM 227
- Monitoring System Components 228
  - System Chassis Components 229
  - Cooling Unit Components 231
  - Disk Backplane Components 232
  - Memory Device Components 232
  - Power Unit Components 233
  - Processor Components 235
  - System Board Components 235
  - System Firmware Components 237
  - Hard Disk Drive Components 238

Identifying SNMP Trap Messages	239
Generic Host Events	240
Environmental Events	240
Hard Disk Drive Events	242
Power Events	243
Fan Events	246
Memory Events	248
Entity Presence Events	253
Physical Presence Events	254

<b>Index</b>	<b>257</b>
--------------	------------

# Using This Documentation

---

This service manual explains how to remove and replace parts in the Sun Server X4-2, and how to troubleshoot and maintain the system.

This document is intended for system administrators, network administrators, and service technicians who have an understanding of server systems.

This section describes how to get the latest software and firmware, documentation and feedback, and support and accessibility information.

- “Getting the Latest Software and Firmware” on page xi
- “About This Documentation” on page xii
- “Related Documentation” on page xii
- “Feedback” on page xii
- “Access to Oracle Support” on page xiii

---

## Getting the Latest Software and Firmware

Firmware, drivers and other hardware-related software for each Oracle x86 server, server module (blade), and blade chassis are updated periodically.

You can obtain the latest software in one of three ways:

- Oracle System Assistant – This is a factory-installed option for Oracle x86 servers. It has all the tools and drivers you need and is built into the server.
- My Oracle Support: <http://support.oracle.com>
- Physical media request

For more information, see the *Sun Server X4-2 Installation Guide*, “Getting Server Firmware and Software Updates” on page 31.

---

## About This Documentation

This documentation set is available in both PDF and HTML formats. The information is presented in topic-based organization (similar to online help) and therefore does not include chapters, appendices, or section numbering.

A PDF document that includes all information on a particular topic (such as hardware installation or product notes) can be generated by clicking the PDF button in the upper left corner of an HTML page.

---

## Related Documentation

Documentation	Link
All Oracle documentation	<a href="http://www.oracle.com/documentation">http://www.oracle.com/documentation</a>
Sun Server X4-2	<a href="http://www.oracle.com/goto/X4-2/docs">http://www.oracle.com/goto/X4-2/docs</a>
<i>Oracle X4 Series Servers Administration Guide</i>	<a href="http://www.oracle.com/goto/x86AdminDiag/docs">http://www.oracle.com/goto/x86AdminDiag/docs</a>
Oracle Integrated Lights Out Manager (ILOM) 3.1	<a href="http://www.oracle.com/goto/ILOM/docs">http://www.oracle.com/goto/ILOM/docs</a>
Oracle Hardware Management Pack 2.2	<a href="http://www.oracle.com/goto/OHMP/docs">http://www.oracle.com/goto/OHMP/docs</a>

---

## Feedback

You can provide feedback on this documentation at:

<http://www.oracle.com/goto/docfeedback>

---

# Access to Oracle Support

Oracle customers have access to electronic support through My Oracle Support. For information, visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> or visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> if you are hearing impaired.



# About the Sun Server X4-2

---

These sections describe the controls, connectors, status indicators, system components, and replaceable components of the server.

Description	Links
Review the product description.	<a href="#">“Product Description” on page 1</a>
Learn about server controls and connectors.	<a href="#">“About Controls and Connectors” on page 2</a>
Learn about server and component status indicators.	<a href="#">“About Server and Component Status Indicators” on page 6</a>
Learn about system components.	<a href="#">“About System Components” on page 15</a>

---

## Product Description

The Sun Server X4-2 is an enterprise-class, one rack unit (1U) server. It supports the following components:

- Up to two Intel processors. Processors with the following capabilities are supported:
  - 2.7 GHz, 12-core, 130W
  - 3.0 GHz, 10-core, 130W
  - 2.6 GHz, 8-core, 95W
  - 2.6 GHz, 6-core, 80W
  - 2.5 GHz, 4-core, 80W
- Up to 8 DIMMs per processor for a maximum of 16 DDR3 DIMMs and a maximum of 512 GB of memory on dual-processor systems. DIMM sizes of 8 GB, 16 GB, and 32 GB are supported.

---

**Note** – A maximum of eight DIMMs for a maximum of 256 GB are supported in single-processor systems.

---

- Four PCIe Gen3 slots in dual-processor systems: three external slots and one internal. PCIe slot 1, which is an external slot, is nonfunctional in single-processor systems.
- Storage drive configurations can include both hard disk drives (HDDs) or solid state drives (SSDs). Supported storage drive configurations include:
  - Eight 2.5-inch hot-pluggable SAS HDDs/SATA SSDs
  - Four 2.5-inch hot-pluggable SAS HDDs/SATA SSDs with DVD
- Two hot-pluggable, redundant power supplies.
- An on-board Oracle Integrated Lights Out Manager (Oracle ILOM) service processor (SP) based on the AST2300 chip.
- The Oracle System Assistant server setup tool, which is embedded on a preinstalled USB flash drive.

---

## About Controls and Connectors

The following sections describe the controls, indicators, connectors, and drives located on the front and rear panels.

- [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3](#)
- [“Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4](#)
- [“Server Back Panel View” on page 5](#)


### Related Information

- [“About Server and Component Status Indicators” on page 6](#)
- [“About System Components” on page 15](#)
- [“Illustrated Parts Breakdown” on page 15](#)

# Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives

The following figure shows the controls, status indicators (LEDs), connectors, and drives on the front panel of a Sun Server X4-2 configured with eight 2.5-inch storage drives.

**FIGURE:** Front Panel View of a Server With Eight 2.5-inch Drives



## Figure Legend

- |   |   |    |  |
|---|---|----|--|
| 1 | Product Serial Number (PSN) label and Radio Frequency Identification (RFID) tag | 10 | System Over Temperature Warning LED: amber   |
| 2 | Locator LED/Locator button: white   | 11 | Storage drive 0  |
| 3 | USB 2.0 connectors (2)  | 12 | Storage drive 1  |
| 4 | Service Required LED: amber   | 13 | Storage drive 2  |
| 5 | Power/OK LED: green   | 14 | Storage drive 3  |
| 6 | Power button  | 15 | Storage drive 4  |
| 7 | SP OK LED: green  | 16 | Storage drive 5  |
| 8 | Top Fan Fault LED: amber  | 17 | Storage drive 6  |
| 9 | Rear Power Supply (PS) Fault LED: amber   | 18 | Storage drive 7 (In Oracle Engineered Systems, storage drive 7 might be populated with a remote battery module for the host bus adapter (HBA) card.) |


## Related Information

- “Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4
- “Server Back Panel View” on page 5

## Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive

The following figure shows the controls, status indicators (LEDs), connectors, and drives on the front panel of a Sun Server X4-2 configured with four 2.5-inch storage drives and a SATA DVD drive.

**FIGURE:** Front Panel View of a Server With Four 2.5-inch Drives and SATA DVD Drive



### Figure Legend

1	Product Serial Number (PSN) label and Radio Frequency Identification (RFID) tag	9	Rear Power Supply Fault LED: amber
2	Locator LED/Locator button: white	10	System Over Temperature Warning LED: amber
3	USB 2.0 connectors (2)	11	Storage drive 0 (optional)
4	Service Required LED: amber	12	Storage drive 1
5	Power/OK LED: green	13	Storage drive 2

**Figure Legend** (Continued)

---

6	Power button	14	Storage drive 3
7	SP OK LED: green	15	SATA DVD drive
8	Top Fan Fault LED: amber	16	Not applicable

---


**Related Information**

- [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3](#)
- [“Server Back Panel View” on page 5](#)

## Server Back Panel View

The following figure shows the Sun Server X4-2 back panel and the location of power supplies, status indicators (LEDs), connectors, and PCIe slots.

**FIGURE:** Server Back Panel View



**Figure Legend**

---

1	Power Supply (PS) 0	9	Oracle Integrated Lights Out Manager (ILOM) service processor (SP) network management 10/100BASE-T port (NET MGT)
2	Power Supply (PS) 0 status indicators: Service Required LED: amber AC OK LED: green	10	Serial management (SER MGT)/RJ-45 serial port
3	Power Supply (PS) 1	11	Network (NET) 100/1000/10000 port: NET 3 (Nonfunctional in single-processor systems.)

---

**Figure Legend** (Continued)

---

4	Power Supply (PS) 1 status indicators: Service Required LED: amber, AC OK LED: green	12	Network (NET) 100/1000/10000 port: NET 2 (Nonfunctional in single-processor systems.)
5	System status indicators: Locator LED: white, Service Required LED: amber, Power/OK LED: green	13	Network (NET) 100/1000/10000 port: NET 1
6	PCIe card slot 1 (Nonfunctional in single-processor systems.)	14	Network (NET) 100/1000/10000 port: NET 0
7	PCIe card slot 2	15	USB 2.0 connectors (2)
8	PCIe card slots 3 and 4 (Slot 4 is the primary host bus adapter (HBA) card slot. This slot is internal and is not visible from the rear of the server. The server supports a maximum of one HBA card for controlling and managing the server storage drives.)	16	DB-15 video connector

---

---

**Note** – All of the PCIe slots comply with the PCI Express 3.0 specification and can accommodate 25 watt PCIe3 cards.

---

### Related Information

- [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3](#)
- [“Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4](#)
- [“About System Components” on page 15](#)

---

## About Server and Component Status Indicators

These sections describe the status indicators (LEDs) located on the front and rear of the server, including those found on components and ports.

- [“Server General Status Indicators” on page 7](#)
- [“Server Fan Status Indicators” on page 9](#)
- [“Storage Drive Status Indicators” on page 10](#)

- “Power Supply Status Indicators” on page 11
- “Network Management Port Status Indicators” on page 11
- “Ethernet Ports Status Indicators” on page 12
- “Motherboard Status Indicators” on page 13

### **Related Information**

- “About Controls and Connectors” on page 2
- “Service Troubleshooting Task List” on page 21

## Server General Status Indicators

There are seven, system-level status indicators (LEDs), some of which are located on both the server front panel and the server back panel.

**TABLE:** Server General Status Indicators

Status Indicator Name	Icon/Label	Colors	State Meaning
Locator LED and button		White	<ul style="list-style-type: none"> <li>• OFF – Server is operating normally.</li> <li>• FAST BLINK – Use Oracle ILOM to activate this LED to enable you to locate a particular system quickly and easily.</li> <li>• Pressing the Locate button will toggle the LED fast blink on or off.</li> </ul>
Service Required		Amber	<ul style="list-style-type: none"> <li>• OFF – The server is operating normally.</li> <li>• STEADY ON – A fault is present on server. This LED lights whenever a fault indicator lights for a replaceable component on the server.</li> </ul> <p><b>Note</b> - The lighting of this indicator is always accompanied by a system console message that includes a recommended service action.</p>
Power/OK		Green	<p>Indicates the operational state of the chassis. This indicator can be in the following states:</p> <ul style="list-style-type: none"> <li>• OFF – AC power is not present or the Oracle ILOM boot is not complete.</li> <li>• STEADY BLINK – Standby power is on, but the chassis power is off and the Oracle ILOM SP is running.</li> <li>• SLOW BLINK – Startup sequence has been initiated on the host. This pattern should begin soon after you power on the server. This status indicates either: (1) POST code checkpoint tests are running on the server host system, or (2) the host is transitioning from the powered-on state to the standby state on shutdown.</li> <li>• STEADY ON – The server is powered on, and all host POST code checkpoint tests are complete. The server is in one of the following states: 1) the server host is booting the operating system (OS), 2) the server host is running the OS.</li> </ul>
SP OK		Green	<ul style="list-style-type: none"> <li>• OFF – Service processor (SP) is not running.</li> <li>• SLOW BLINK – SP is booting.</li> <li>• STEADY ON – SP is fully operational.</li> </ul>

**TABLE:** Server General Status Indicators (*Continued*)

Status Indicator Name	Icon/Label	Colors	State Meaning
Top Fan	TOP FAN	Amber	Indicates that one (or more) of the internal fan modules has failed. <ul style="list-style-type: none"> <li>• OFF – Indicates steady state; no service is required.</li> <li>• STEADY ON – Indicates service required; service the fan modules,</li> </ul>
Rear Power Supply Fault	REAR PS	Amber	Indicates that one of the server power supplies has failed. <ul style="list-style-type: none"> <li>• OFF – Indicates steady state; no service is required.</li> <li>• STEADY ON – Indicates service required; service the power supply.</li> </ul>
System Over Temperature Warning		Amber	<ul style="list-style-type: none"> <li>• OFF – Normal operation; no service is required.</li> <li>• STEADY ON – The system is experiencing an overtemperature warning condition.</li> </ul> <p><b>Note</b> - This is a warning indication, not a fatal overtemperature. Failure to correct this might result in the system overheating and shutting down unexpectedly.</p>

### Related Information

- [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3](#)
- [“Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4](#)
- [“Server Back Panel View” on page 5](#)

## Server Fan Status Indicators

Each fan module has one bicolored status indicator (LED). The LEDs are located on the chassis mid-wall adjacent to and aligned with the fan modules and are visible when the top cover fan door is open.

**TABLE:** Server Fan Status Indicators

Status Indicator Name	Icon	Color	State Meaning
Fan Status	None	Bicolored: Amber/Green	<ul style="list-style-type: none"> <li>• Amber – The fan module is faulty. The front TOP FAN LED and the front and rear panel Service Required LEDs are also lit if the system detects a fan module fault.</li> <li>• Green – The fan module is correctly installed and operating within specification.</li> </ul>

## Related Information

- “Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3
- “Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4
- “Server Back Panel View” on page 5
- “Servicing Fan Modules (CRU)” on page 50

## Storage Drive Status Indicators

There are three status indicators (LEDs) on each drive.

**TABLE:** Server Front Storage Drive Indicators

Status Indicator Name	Icon	Color	State Meaning
OK to Remove		Blue	<ul style="list-style-type: none"><li>• STEADY ON – The storage drive can be removed safely during a hot-plug operation.</li><li>• OFF – The storage drive has not been prepared for removal.</li></ul>
Service Required		Amber	<ul style="list-style-type: none"><li>• OFF – The storage drive is operating normally.</li><li>• STEADY ON – The system has detected a fault with the storage drive.</li></ul>
OK/Activity		Green	<ul style="list-style-type: none"><li>• OFF – Power is off or the installed drive is not recognized by the system.</li><li>• STEADY ON – The drive is engaged and is receiving power.</li><li>• STEADY BLINK – There is disk activity. The LED blinks on and off to show activity.</li></ul>

## Related Information

- “Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3
- “Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4
- “Server Back Panel View” on page 5
- “Servicing Storage Drives (CRU)” on page 45

# Power Supply Status Indicators

There are two status indicators (LEDs) on each power supply. These indicators are visible from the rear of the server.

**TABLE:** Server Power Supply Indicators

Status Indicator Name	Icon	Color	State Meaning
AC OK/DC OK		Green	<ul style="list-style-type: none"><li>• OFF – No AC power is present.</li><li>• SLOW BLINK – Normal operation. Input power is within specification. DC output voltage is not enabled.</li><li>• STEADY ON – Normal operation. Input AC power and DC output voltage are within specification.</li></ul>
Service Required		Amber	<ul style="list-style-type: none"><li>• OFF – Normal operation. No service action is required.</li><li>• STEADY ON – The power supply (PS) has detected a PS fan failure, PS overtemperature, PS over current, or PS over or under voltage.</li></ul>

## Related Information

- [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3](#)
- [“Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4](#)
- [“Server Back Panel View” on page 5](#)
- [“Servicing Power Supplies \(CRU\)” on page 55](#)

# Network Management Port Status Indicators

The server has one 10/100BASE-T Ethernet management domain interface, labeled NET MGT. There are two status indicators (LEDs) on this port. These indicators are visible from the rear of the server.

**TABLE:** Network Management Port Status Indicators

---

Status Indicator Name	Location	Color	State and Meaning
Link speed	Top left	Bicolored: Amber/Green	<ul style="list-style-type: none"><li>• Amber ON – 10BASE-T link.</li><li>• Green ON – 100BASE-T link.</li><li>• OFF – No link or link down.</li><li>• FLASHING – No function.</li></ul>
Activity	Top right	Green	<ul style="list-style-type: none"><li>• ON – No function.</li><li>• OFF – No activity.</li><li>• FLASHING – Packet activity.</li></ul>

---

### Related Information

- [“Network Management Port” on page 154](#)
- [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3](#)
- [“Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4](#)
- [“Server Back Panel View” on page 5](#)
- [“Servicing Power Supplies \(CRU\)” on page 55](#)

## Ethernet Ports Status Indicators

The server has four Ethernet ports (NET 3, NET 2, NET 1, and NET 0). There are two status indicators on each port. These indicators are visible from the rear of the server.

---

**Note** – Ethernet ports NET 2 and NET 3 are nonfunctional in single-processor systems.

---

**TABLE:** Gigabit Ethernet Port Status Indicators

Status Indicator Name	Location	Color	State and Meaning
Activity	Top left	Green	<ul style="list-style-type: none"><li>• ON – No function.</li><li>• OFF– No activity.</li><li>• FLASHING – Packet activity.</li></ul>
Link speed	Top right	Bicolored: Amber/Green	<ul style="list-style-type: none"><li>• Amber ON— 100BASE-T link.</li><li>• Green ON– 1000/10GBBASE-T link.</li><li>• OFF – No link or link down.</li><li>• FLASHING – No function.</li></ul>

### Related Information

- [“Gigabit Ethernet Ports” on page 153](#)
- [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3](#)
- [“Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4](#)
- [“Server Back Panel View” on page 5](#)
- [“Servicing Power Supplies \(CRU\)” on page 55](#)

## Motherboard Status Indicators

The motherboard and modules that are installed on the motherboard contain several status indicators (LEDs), which are described in the following sections:

- [“DDR3 DIMM Fault Status Indicators” on page 13](#)
- [“Processor Fault Status Indicators” on page 14](#)
- [“Fault Remind Status Indicator” on page 14](#)
- [“STBY PWRGD Status Indicator” on page 14](#)

## DDR3 DIMM Fault Status Indicators

Each of the 16 DDR3 DIMM sockets on the motherboard has an amber fault status indicator (LED) associated with it. If Oracle ILOM determines that a DIMM is faulty, pressing the Fault Remind button on the motherboard signals the service processor to light the fault LEDs associated with the faulted DIMMs.

## Processor Fault Status Indicators

The motherboard includes a fault status indicator (LED) adjacent to each of the two processor sockets. These LEDs indicate when a processor is faulty. For example, if on reboot the BIOS detects that there are uncorrectable processor errors recorded in the machine check architecture (MCA) registers left over from the previous boot, then the BIOS and Oracle ILOM work together to record and diagnose these errors. If it is determined that a processor is faulty, pressing the Fault Remind button on the motherboard signals the service processor to light the fault LED associated with the faulted processor.

## Fault Remind Status Indicator

This status indicator (LED) is located next to the Fault Remind button and is powered from the super capacitor that powers the fault LEDs on the motherboard. This LED lights to indicate that the fault remind circuitry is working properly in cases where no components have failed and, as a result, none of the component fault LEDs illuminate.

## STBY PWRGD Status Indicator

The service instructions for all server internal components require that all AC power be removed from the power supplies prior to removing the server top cover. This green status indicator (LED) is labeled STBY PWRGD and is located on the rear of the server near PCIe slot 2.

---

**Note** – If a PCIe card is installed in PCIe slot 2, this LED might not be visible.

---

The STBY PWRGD LED lights to inform the service technician that the motherboard is receiving standby power from at least one of the power supplies. This LED is provided to help prevent service actions on the server internal components while the AC power cords are installed and power is being supplied to the server.

### Related Information

- [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives” on page 3](#)
- [“Front Panel Controls and Indicators on a System With Four 2.5-inch Drives and DVD Drive” on page 4](#)
- [“Server Back Panel View” on page 5](#)
- [“Illustrated Parts Breakdown” on page 15](#)

---

# About System Components

These sections describe the components of the server:

- [“Illustrated Parts Breakdown”](#) on page 15
- [“Customer-Replaceable Units”](#) on page 17
- [“Field-Replaceable Units”](#) on page 18
- [“Battery Module”](#) on page 19


## **Related Information**

- [“Servicing CRUs That Do Not Require Server Power-Off”](#) on page 45
- [“Servicing CRUs That Require Server Power-Off”](#) on page 61
- [“Servicing FRUs”](#) on page 99

## Illustrated Parts Breakdown

The following figure identifies the major components of the server.

**FIGURE:** Server Illustrated Parts Breakdown



**Figure Legend**

<p><b>1</b> Server chassis for eight 2.5-inch storage drives</p>	<p><b>10</b> DIMMs  <b>Note:</b> A maximum of eight DIMMs are supported in single-processor systems and the DIMMs must be installed in sockets associated with processor 0 (P0). No DIMM filler panels are required in vacant DIMM sockets associated with processors 0 (P0) or 1 (P1).</p>
<p><b>2</b> Server chassis for four 2.5-inch storage drives and DVD drive</p>	<p><b>11</b> Battery</p>
<p><b>3</b> SATA DVD drive</p>	<p><b>12</b> PCIe cards and the internal HBA card  <b>Note:</b> PCIe slot 1 is nonfunctional in single-processor systems.</p>

**Figure Legend** (Continued)

---

<b>4</b>	Four and eight 2.5-inch storage drive configurations (In Oracle Engineered Systems, storage drive 7 in eight-drive systems might be populated with a remote battery module for the HBA card.)	<b>13</b>	Top cover
<b>5</b>	Front indicator module for server with four or eight 2.5-inch storage drives	<b>14</b>	PCIe riser
<b>6</b>	Disk backplanes	<b>15</b>	USB flash drives
<b>7</b>	Fan modules	<b>16</b>	Processor heatsinks <b>Note:</b> In single-processor systems, neither a heatsink nor a processor socket filler are installed in the processor socket 1 (P1). To protect the delicate processor socket pins, the cover that comes on the motherboard from manufacturing is left in place.
<b>8</b>	Chassis mid-wall	<b>17</b>	Motherboard
<b>9</b>	Processors <b>Note:</b> There is only one processor in single-processor systems and that processor is located in processor socket 0 (P0).	<b>18</b>	Power supplies

---

## Customer-Replaceable Units

The following table lists the customer-replaceable units (CRUs) in the server and directs you to the replacement instructions.

---

<b>CRU</b>	<b>Description</b>	<b>Replacement Instructions</b>
Battery	Lithium coin-cell battery that powers the CMOS BIOS and real-time clock.	<a href="#">“Servicing the Battery (CRU)” on page 96</a>
DIMMs	Add or replace memory in the system.	<a href="#">“Servicing the DIMMs (CRU)” on page 62</a>
Storage drives	Supports SAS hard-disk drives (HDDs) or SATA solid-state drives (SSDs) and a DVD drive. <ul style="list-style-type: none"><li>• Four-drive configuration contains four 2.5-inch storage drives and a DVD drive</li><li>• Eight-drive configuration contains eight 2.5-inch storage drives</li></ul> <b>Note</b> - In Oracle Engineered Systems, storage drive 7 in eight-drive systems might be populated with a remote battery module for the HBA card. The battery module is not a customer-replaceable unit.	<a href="#">“Servicing Storage Drives (CRU)” on page 45</a>

---

CRU	Description	Replacement Instructions
DVD drive	DVD drive on configurations with four 2.5-inch storage drives.	<a href="#">“Servicing the DVD Drive (CRU)” on page 91</a>
Fan modules	Contains four fan modules for cooling the motherboard assembly and installed components.	<a href="#">“Servicing Fan Modules (CRU)” on page 50</a>
PCIe cards	Optional add-on cards that can expand the functionality of the server.	<a href="#">“Servicing PCIe Cards (CRU)” on page 84</a>
PCIe risers	Houses and connects the PCIe cards.	<a href="#">“Servicing PCIe Risers (CRU)” on page 74</a>
Power supplies	Two fully redundant AC power supplies.	<a href="#">“Servicing Power Supplies (CRU)” on page 55</a>

### Related Information

- [“Field-Replaceable Units” on page 18](#)
- [“Illustrated Parts Breakdown” on page 15](#)
- [“Servicing CRUs That Do Not Require Server Power-Off” on page 45](#)
- [“Servicing CRUs That Require Server Power-Off” on page 61](#)

## Field-Replaceable Units

The following table lists the field-replaceable units (FRUs) in the server and directs you to the replacement instructions.

FRU	Description	Replacement Instructions
Processor	Carries out the instructions of the system.	<a href="#">“Servicing Processors (FRU)” on page 100</a>
Disk backplane	Serves as the interface between storage drives and the host bus adapter (HBA) card.	<a href="#">“Servicing the Disk Backplane (FRU)” on page 117</a>
Front indicator module (FIM)	Contains the front panel controls, indicators, and USB ports.	<a href="#">“Servicing the Front Indicator Module (FRU)” on page 125</a>
Motherboard assembly	Provides connectors for the fans, DIMMs, processor(s), PCIe risers, and internal USB ports, and power supplies.	<a href="#">“Servicing the Motherboard (FRU)” on page 127</a>
Internal HBA SAS controller cables	Serve to connect the disk backplane to the the internal host bus adapter (HBA) card.	<a href="#">“Servicing the SAS Cables (FRUs)” on page 138</a>

### Related Information

- [“Customer-Replaceable Units” on page 17](#)
- [“Illustrated Parts Breakdown” on page 15](#)
- [“Servicing FRUs” on page 99](#)

## Battery Module

In Oracle Engineered Systems, storage drive 7 might be populated with a remote battery module for the host bus adapter (HBA) card.



---

**Caution** – The battery module is not a customer-replaceable unit (CRU) and should not be removed or replaced by customers. The battery module should be removed or replaced only by Oracle field service personnel.

---

The battery module is hot-pluggable and provides the backup power subsystem for the Sun Storage 6 Gb SAS PCIe RAID Internal Host Bus Adapter (HBA): SG-SAS6-R-INT-Z. It enables Oracle field service personnel to replace the battery at the end of its service life without requiring the server to be powered off.

### Related Information

- [“Servicing Storage Drives \(CRU\)” on page 45](#)



# Troubleshooting the Server

---

These sections introduce the diagnostic tools and strategies available to help you diagnose problems with the system.

Description	Links
Review the tasks used to locate a specific problem with the system.	<a href="#">“Service Troubleshooting Task List” on page 21</a>
Understand the diagnostic system indicators, utilities, and commands available.	<a href="#">“Diagnostic Tools” on page 22</a>
Gather information about the system to help a service engineer or technician work on your system.	<a href="#">“Gather Service Information” on page 24</a>
Locate the server serial number.	<a href="#">“Locate the Server Serial Number” on page 25</a>
Inspect the system methodically to locate a faulty component or components.	<a href="#">“Inspecting the System” on page 25</a>

## Related Information

- [“About the Sun Server X4-2” on page 1](#)
- [“Preparing for Service” on page 29](#)
- [“Returning the Server to Operation” on page 143](#)

---

## Service Troubleshooting Task List

Use the list in following table as a sequence for troubleshooting the server.

**TABLE:** Troubleshooting Task List

No.	Description	Section or Document
1	Gather initial service information.	<a href="#">“Gather Service Information” on page 24</a>
2	Investigate power-on problems.	<a href="#">“Troubleshoot Power Problems” on page 26</a>
3	Perform external visual inspection and internal visual inspection.	<a href="#">“Inspect the Server Externally” on page 26</a> <a href="#">“Inspect Internal Server Components” on page 26</a>
4	View service processor logs and sensor information.	Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at: <a href="http://www.oracle.com/goto/ILOM/docs">http://www.oracle.com/goto/ILOM/docs</a>
5	Run diagnostics.	<i>Oracle x86 Servers Diagnostics, Applications, and Utilities Guide for Servers With Oracle ILOM 3.1</i> at: <a href="http://www.oracle.com/goto/x86AdminDdiag/docs">http://www.oracle.com/goto/x86AdminDdiag/docs</a>

### Related Information

- [“About the Sun Server X4-2” on page 1](#)
- [“Diagnostic Tools” on page 22](#)

---

## Diagnostic Tools

There are a variety of diagnostic tools, commands, and indicators you can use to monitor and troubleshoot the server:

- **LEDs** – These indicators provide a quick visual notification of the status of the server and of some of the CRUs and FRUs.
- **Oracle ILOM firmware** – This firmware is located on the service processor and provides a comprehensive service portal using a command-line interface (CLI) and browser user interface (BUI) for
  - lights-out management capabilities (such as remote power-on, power-off, etc.)
  - monitoring the health of the environmental subsystem (such as power, fans, temperature, cover interlock, etc.),
  - and fault management and automated diagnosis capabilities during server initialization (such as QuickPath Interconnect code and Memory Reference code) and server runtime

- **Pc-Check** – Accessed through Oracle ILOM, the DOS-based Pc-Check utility tests motherboard components such as processor, memory, and I/O, as well as ports and slots. If enabled through Oracle ILOM, this utility will run each time the system powers on. For information about Pc-Check, refer to the *Oracle X86 Servers Diagnostics, Applications, and Utilities Guide for Servers With Oracle ILOM 3.1* at <http://www.oracle.com/goto/x86AdminDiag/docs>.
- **SNMP**– Simple Network Management Protocol (SNMP) traps are generated by the SNMP agents that are installed on the SNMP devices being managed by Oracle ILOM. Oracle ILOM receives the SNMP traps and converts them into SNMP event messages that appear in the event log.
- **POST** – Power-on self-test (POST) performs diagnostics on system components upon system power-on and resets to ensure the integrity of those components. POST messages are displayed and logged in the BIOS event logs. POST works with Oracle ILOM to take faulty components offline, if needed.
- **Oracle Solaris OS Diagnostic Tools**
  - **Oracle Solaris OS Predictive Self-Healing (PSH)** – The PSH technology provides automated diagnosis of error events encountered with the processor, memory subsystem, and integrated I/O subsystem during runtime. The ability of PSH to off-line faulty processors and retire memory pages during runtime enhances system availability and prevents future interruptions. The Oracle Solaris OS PSH technology in conjunction with ILOM and BIOS provide extensive fault management architecture for placing processors offline and disabling DIMMs.
  - **Log files and console messages** – These items provide the standard Oracle Solaris OS log files and investigative commands that can be accessed and displayed on the device of your choice.
  - **Oracle VTS software** – This application exercises the system, provides hardware validation, and discloses possible faulty components with recommendations for repair.

The LEDs, Oracle ILOM, Oracle Solaris OS PSH, and many of the log files and console messages are integrated. For example, Oracle Solaris software will display a detected fault, log it, pass information to Oracle ILOM where it will be logged, and, depending on the fault, might cause one or more LEDs to light.

## Related Information

- [“About the Sun Server X4-2” on page 1](#)
- Oracle Solaris OS documentation set at:
  - Oracle Solaris 10 1/13 information library at:  
[http://docs.oracle.com/cd/E26505\\_01/index.html](http://docs.oracle.com/cd/E26505_01/index.html)
  - Oracle Solaris 11.1 information library at:  
[http://docs.oracle.com/cd/E26502\\_01/index.html](http://docs.oracle.com/cd/E26502_01/index.html)

- Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at:  
<http://www.oracle.com/goto/ILOM/docs>
- *Oracle x86 Servers Diagnostics, Applications, and Utilities Guide for Servers With Oracle ILOM 3.1* at:  
<http://www.oracle.com/goto/x86AdminDiag/docs>
- Oracle VTS documentation set at:  
<http://docs.oracle.com/cd/E19719-01/index.html>

---

## ▼ Gather Service Information

The first step in determining the cause of a problem with the server is to gather information for the service call paperwork or the onsite personnel. Follow these general guidelines when you begin troubleshooting.

### 1. Collect information about the following items:

- Events that occurred prior to the failure
- Whether any hardware or software was modified or installed
- Whether the server was recently installed or moved
- How long the server exhibited symptoms
- The duration or frequency of the problem

### 2. Document the server settings before you make any changes.

If possible, make one change at a time in order to isolate potential problems. In this way, you can maintain a controlled environment and reduce the scope of troubleshooting.

### 3. Note the results of any change that you make. Include any errors or informational messages.

### 4. Check for potential device conflicts before you add a new device.

### 5. Check for version dependencies, especially with third-party software.

### Related Information

- [“Diagnostic Tools”](#) on page 22
- [“Locate the Server Serial Number”](#) on page 25

---

## ▼ Locate the Server Serial Number

- **To locate the server serial number, do one of the following:**
  - From the front of the server, look at the left side of the front panel to locate the server serial number. The serial number is located on the Radio-frequency identification (RFID) tag on the front panel, next to the general status indicators. For illustrations of the server front panel, see [“About Controls and Connectors”](#) on page 2.
  - Refer to the service label that is attached to the top cover of the server. This label includes the serial number.
  - Locate the yellow Customer Information Sheet (CIS) attached to your server packaging. This sheet includes the serial number.
  - From the Oracle ILOM command-line interface (CLI), enter the `show /System` command or go to the System Information Summary page in the Oracle ILOM web browser interface.

### **Related Information**

- [“Diagnostic Tools”](#) on page 22
- [“Gather Service Information”](#) on page 24

---

## Inspecting the System

Controls that have been improperly set and cables that are loose or improperly connected are common causes of problems with hardware components. Follow these procedures to locate common problems with the system.

- [“Troubleshoot Power Problems”](#) on page 26
- [“Inspect the Server Externally”](#) on page 26
- [“Inspect Internal Server Components”](#) on page 26

### **Related Information**

- [“About the Sun Server X4-2”](#) on page 1
- [“Preparing for Service”](#) on page 29

## ▼ Troubleshoot Power Problems

1. **If the server is powered off, power on the server.**  
See [“Power On the Server”](#) on page 150.
  - If the server powers on, go to [“Inspect the Server Externally”](#) on page 26.
  - If the server does not power on, go to [Step 2](#).
2. **Check that power cords are attached firmly to the server power supplies and to the power source.**

### **Related Information**

- [“Power On the Server”](#) on page 150
- [“Inspect the Server Externally”](#) on page 26
- [“Servicing Power Supplies \(CRU\)”](#) on page 55

## ▼ Inspect the Server Externally

1. **Inspect the external status indicators (LEDs), which can indicate component malfunctions.**  
For the LED locations and descriptions of their behavior, see [“About Server and Component Status Indicators”](#) on page 6.
2. **Verify that nothing in the server environment is blocking airflow or making a contact that could short out power.**
3. **If the problem is not evident, continue with the next section, [“Inspect Internal Server Components”](#) on page 26.**

### **Related Information**

- [“About the Sun Server X4-2”](#) on page 1
- [“Inspect Internal Server Components”](#) on page 26

## ▼ Inspect Internal Server Components

1. **Power down the server from main power mode to standby power mode.**
  - Graceful power down – Notify users and gracefully power down the system.
  - Immediate power down – Power down the system quickly.See [“Powering Down the Server”](#) on page 33 for instructions.

2. **Disconnect the AC power cables from the server, extend the server to the maintenance position, and remove the server top cover.**  
See [“Preparing the Server for Component Replacement”](#) on page 33.
3. **Inspect the internal status indicators (LEDs), which can indicate component malfunction.**  
For the LED locations and descriptions of their behavior, see [“Motherboard Status Indicators”](#) on page 13.  
To light these LEDs, press and hold down the Fault Remind button, which is located on the motherboard. For more information on the Fault Remind button, see [“Using the Fault Remind Button”](#) on page 70.
4. **Verify that there are no loose or improperly seated components.**
5. **Verify that all cables inside the system are firmly and correctly attached to their appropriate connectors.**
6. **Verify that any components that you ordered separately and were not installed at the factory are qualified and supported.**  
Check with your customer representative for information about which PCIe cards and DIMMs are supported.
7. **Check that the installed DIMMs comply with the supported DIMM population rules and configurations.**  
For more information, see [“DIMM Population Rules”](#) on page 67.
8. **Return the server to operation.**  
See [“Returning the Server to Operation”](#) on page 143.
9. **Press and release the Power button on the server front panel.**  
When the main power is applied to the server, the Power/OK indicator next to the Power button blinks slowly until the OS is ready. When the OS is ready, the Power/OK indicator remains lit. For more information about the indicator, see [“Server General Status Indicators”](#) on page 7.
10. **If the problem with the server is not evident, then log in to either the Oracle ILOM Fault Management Shell or Oracle Solaris service portal and use the fault management command `fmadm faulty` to list any faults that might be present on the server.**  
For instructions, see the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.

### **Related Information**

- [“Preparing for Service”](#) on page 29
- [“About Server and Component Status Indicators”](#) on page 6

- “Returning the Server to Operation” on page 143

# Preparing for Service

---

These sections describe safety considerations and provide prerequisite procedures and information to replace components within the server.

Description	Links
Understand the safety precautions, understand the server FRU top-level indicator, understand the safety symbols, and take ESD precautions prior to removing or installing parts in the server.	<a href="#">“Safety Precautions” on page 29</a> <a href="#">“FRU TLI Auto-Update” on page 30</a> <a href="#">“Safety Symbols” on page 30</a> <a href="#">“Electrostatic Discharge Safety” on page 31</a>
Assemble the required tools.	<a href="#">“Required Tools” on page 32</a>
Before working with components within the server, power down the server and prepare for servicing.	<a href="#">“Preparing the Server for Component Replacement” on page 33</a>

## Related Information

- [“Returning the Server to Operation” on page 143](#)

---

## Safety Precautions

For your protection, observe the following safety precautions when setting up your equipment:

- Follow all standard cautions, warnings, and instructions marked on the equipment and described in the online *Sun Server X4-2 Safety and Compliance Guide* and in the printed *Important Safety Information for Oracle’s Hardware Systems*.
- Ensure that the voltage and frequency of your power source match the voltage and frequency inscribed on the equipment’s electrical rating label.
- Follow the electrostatic discharge safety practices as described in [“Electrostatic Discharge Safety” on page 31](#).

- Disconnect both power supply cords before servicing components.

### Related Information

- “Safety Symbols” on page 30
- “Electrostatic Discharge Safety” on page 31

---

## FRU TLI Auto-Update

Oracle ILOM includes a top-level indicator (TLI) auto-update feature that ensures that the TLI stored in the server field-replaceable units (FRUs) is always correct. The TLI, which is unique to each server, is used to track the server service entitlement and warranty coverage. When a server requires service, the server TLI is used to verify that the warranty on the server has not expired.

The TLI is stored in the FRUID (field-replaceable unit identifiers) of these components: power supply 0 (PSU 0), motherboard (MB), and disk backplane (DBP).

The TLI components stored in each component FRUID include:

- Product name
- PPN (product part number)
- PSN (product serial number)

When a server FRU that contains the TLI is removed and a replacement module installed, the TLI of the replacement module is programmed by Oracle ILOM to contain the same TLI as the other two modules.

---

## Safety Symbols

The following symbols might appear in this book. Note their meanings.



---

**Caution** – There is a risk of personal injury or equipment damage. To avoid personal injury or equipment damage, follow the instructions.

---



---

**Caution** – The surface of the component is hot. Avoid contact. Surfaces are hot and might cause personal injury if touched.

---



---

**Caution** – Hazardous voltages are present. To reduce the risk of electric shock and danger to personal health, follow the instructions.

---

### Related Information

- [“Safety Precautions” on page 29](#)
- [“Electrostatic Discharge Safety” on page 31](#)

---

## Electrostatic Discharge Safety

Devices that are sensitive to electrostatic discharge (ESD), such as the motherboard, PCIe cards, drives, processors, and memory cards require special handling.



---

**Caution** – The boards and drives contain electronic components that are extremely sensitive to static electricity. Ordinary amounts of static electricity from clothing or the work environment can destroy components. Do not touch the components along their connector edges.

---

Do the following when handling ESD-sensitive components:

- Use an antistatic wrist strap.

Wear an antistatic wrist strap and use an antistatic mat when handling components such as drive assemblies, boards, or cards. When servicing or removing server components, attach an antistatic strap to your wrist and then to a metal area on the chassis. Then disconnect the power cords from the server. Following this practice equalizes the electrical potentials between you and the server.

---

**Note** – An antistatic wrist strap is not included in the Ship Kit for the server. However, antistatic wrist straps are included with options and components.

---

- Use an antistatic mat.

Place ESD-sensitive components such as the motherboard, memory DIMMs, and other printed circuit boards on an antistatic mat. The following items can be used as an antistatic mat:

- An antistatic bag used to wrap an Oracle replacement part
- An Oracle ESD mat (orderable item)
- A disposable ESD mat (shipped with some replacement parts or optional system components)

### **Related Information**

- [“Safety Precautions” on page 29](#)
- [“Safety Symbols” on page 30](#)
- [“Preparing the Server for Component Replacement” on page 33](#)
- [“Returning the Server to Operation” on page 143](#)

---

## Required Tools

The server can be serviced with the following tools:

- Antistatic wrist strap
- Antistatic mat
- No. 2 Phillips screwdriver

### **Related Information**

- [“Preparing for Service” on page 29](#)
- [“Servicing CRUs That Do Not Require Server Power-Off” on page 45](#)
- [“Servicing CRUs That Require Server Power-Off” on page 61](#)
- [“Servicing FRUs” on page 99](#)

---

# Preparing the Server for Component Replacement

Before you can remove and install components that are inside the server, you must perform the procedures in the following tasks:

---

**Note** – When replacing the storage drives or power supplies, not all of these procedures are necessary. See the replacement tasks for those components for more information.

---

- [“Powering Down the Server” on page 33](#)
- [“Disconnect Cables From the Server” on page 39](#)
- [“Extend the Server to the Maintenance Position” on page 39](#)
- [“Remove the Server From the Rack” on page 41](#)
- [“Take Antistatic Measures” on page 42](#)
- [“Remove the Server Top Cover” on page 43](#)

## Related Information

- [“Returning the Server to Operation” on page 143](#)

## Powering Down the Server

To determine how you want to power off the server, view the options in the following table:

---

Description	Link
Power down the server gracefully to save all data and to prevent data from being corrupted. Performing a graceful shutdown ensures that the system is ready for restart.	<ul style="list-style-type: none"><li>• <a href="#">“Power Down Server Gracefully Using the Oracle ILOM CLI” on page 34</a></li><li>• <a href="#">“Power Down Server Gracefully Using the Oracle ILOM Web Interface” on page 35</a></li><li>• <a href="#">“Power Down Server Gracefully Using the Power Button” on page 36</a></li></ul>

---

Description	Link
If the server is not responding, or you must shut down the server quickly, perform an immediate shutdown.	<ul style="list-style-type: none"> <li>• “Use the Power Button for Immediate Shutdown” on page 36</li> <li>• “Use the Oracle ILOM CLI for Immediate Shutdown” on page 37</li> <li>• “Use the Oracle ILOM Web Interface for Immediate Shutdown” on page 38</li> </ul>

### Related Information

- “Power On the Server” on page 150

## ▼ Power Down Server Gracefully Using the Oracle ILOM CLI

Performing a graceful shut down ensures that all of your data is saved and the system is ready for restart.

### 1. Log in to the server as superuser or equivalent.

Depending on the nature of the problem, you might want to view the system status or the log files or run diagnostics before you shut down the system. For more information, see the Oracle ILOM 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>

### 2. Notify affected users that the server will be powered down.

### 3. Save any open files, and quit all running applications.

Refer to your application documentation for specific information on these processes.

### 4. Log in to the Oracle ILOM command-line interface (CLI) using an Administrator account.

For instructions, see the *Sun Server X4-2 Installation Guide*, “Log In to Oracle ILOM Remotely Using the CLI” on page 91.

### 5. At the Oracle ILOM prompt, shut down the operating system:

```
-> stop /System
```

If the system is running the Oracle Solaris OS, refer to the Oracle Solaris system administration documentation for additional information.

### 6. Disconnect the power cords and data cables from the server.

See “Disconnect Cables From the Server” on page 39.

### Related Information

- “Power Down Server Gracefully Using the Oracle ILOM Web Interface” on page 35
- “Power Down Server Gracefully Using the Power Button” on page 36
- “Use the Power Button for Immediate Shutdown” on page 36
- “Power On the Server” on page 150

## ▼ Power Down Server Gracefully Using the Oracle ILOM Web Interface

### 1. Log in to the server as superuser or equivalent.

Depending on the nature of the problem, you might want to view the system status or the log files or run diagnostics before you shut down the system. For more information, see the Oracle ILOM 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.

### 2. Notify affected users that the server will be powered down.

### 3. Save any open files and quit all running applications.

Refer to your application documentation for specific information about these processes.

### 4. Log in to the Oracle ILOM web interface using an Administrator account.

For instructions, see the *Sun Server X4-2 Installation Guide*, “Log In to Oracle ILOM Remotely Using the Web Interface” on page 89.

The Oracle ILOM web interface System Information > Summary page appears.

### 5. In the left pane, click Host Management > Power Control, and select Graceful Shutdown and Power Off from the Action list.

### 6. Click Save and then click OK.

The host server performs an orderly power shutdown.

### 7. Disconnect the power cords and data cables from the server.

See “Disconnect Cables From the Server” on page 39.

### Related Information

- “Power Down Server Gracefully Using the Oracle ILOM CLI” on page 34
- “Power Down Server Gracefully Using the Power Button” on page 36
- “Use the Power Button for Immediate Shutdown” on page 36
- “Power On the Server” on page 150

## ▼ Power Down Server Gracefully Using the Power Button

---

**Note** – You can use the Power button on the front of the server to power down the server gracefully.

---

### 1. Press and quickly release the Power button on the front panel.

This action causes ACPI-enabled operating systems to perform an orderly shutdown of the operating system. Servers not running ACPI-enabled operating systems shut down to standby power mode immediately.

When main power is off, the Power/OK LED on the front panel will begin flashing, indicating that the server is in standby power mode. See [“Server General Status Indicators”](#) on page 7.

### 2. Disconnect the power cords and data cables from the server.

See [“Disconnect Cables From the Server”](#) on page 39.



---

**Caution** – When you press the Power button to enter standby power mode, power is still directed to the service processor remote management subsystem and power supply fans. To completely power off the server, you must disconnect the power cords from the power supplies.

---

### Related Information

- [“About Controls and Connectors”](#) on page 2
- [“Power Down Server Gracefully Using the Oracle ILOM CLI”](#) on page 34
- [“Power Down Server Gracefully Using the Oracle ILOM Web Interface”](#) on page 35
- [“Use the Power Button for Immediate Shutdown”](#) on page 36
- [“Power On the Server”](#) on page 150

## ▼ Use the Power Button for Immediate Shutdown



---

**Caution** – You might corrupt your system data during an immediate power down, so only use this procedure to power down the server after attempting the graceful power down procedure.

---

1. **Press and hold the Power button for four seconds to force the main power off and to enter standby power mode.**

When main power is off, the Power/OK LED on the front panel will begin flashing, indicating that the server is in standby power mode. See [“Server General Status Indicators”](#) on page 7.

2. **Disconnect the power and data cables from the server.**

See [“Disconnect Cables From the Server”](#) on page 39.



---

**Caution** – When you press the Power button to enter standby power mode, power is still directed to the service processor remote management subsystem and power supply fans. To completely power off the server, you must disconnect the power cords from the power supplies.

---

#### **Related Information**

- [“About Controls and Connectors”](#) on page 2
- [“Power Down Server Gracefully Using the Oracle ILOM CLI”](#) on page 34
- [“Power Down Server Gracefully Using the Oracle ILOM Web Interface”](#) on page 35
- [“Power Down Server Gracefully Using the Power Button”](#) on page 36
- [“Power On the Server”](#) on page 150
- [“Use the Oracle ILOM CLI for Immediate Shutdown”](#) on page 37
- [“Use the Oracle ILOM Web Interface for Immediate Shutdown”](#) on page 38

## ▼ Use the Oracle ILOM CLI for Immediate Shutdown



---

**Caution** – You might corrupt your system data during an immediate power down, so only use this procedure to power down the server after attempting the graceful power down procedure.

---

1. **Log in to the Oracle ILOM command-line interface (CLI) using an Administrator account.**

Oracle ILOM displays the default command prompt (->), indicating that you have successfully logged in to Oracle ILOM.

2. **From the CLI prompt, type the following command:**

```
-> stop -f /System
```

The server powers down immediately.

### 3. Disconnect the power and data cables from the server.

See [“Disconnect Cables From the Server”](#) on page 39.



---

**Caution** – When the server is powered down, it enters standby power mode. In standby power mode, power is still directed to the service processor remote management subsystem and power supply fans. To completely power off the server, you must disconnect the power cords from the power supplies.

---

#### Related Information

- [“Use the Power Button for Immediate Shutdown”](#) on page 36
- [“Use the Oracle ILOM Web Interface for Immediate Shutdown”](#) on page 38

## ▼ Use the Oracle ILOM Web Interface for Immediate Shutdown



---

**Caution** – You might corrupt your system data during an immediate power down, so only use this procedure to power down the server after attempting the graceful power down procedure.

---

### 1. Log in to the Oracle ILOM web interface using an Administrator account.

The Oracle ILOM web interface System Information page appears.

### 2. In the left pane, click Host Management > Power Control, and select Immediate Power Off in the Actions list.

### 3. Click Save, and then click OK.

The server powers down immediately.

### 4. Disconnect the power and data cables from the server.

See [“Disconnect Cables From the Server”](#) on page 39.



---

**Caution** – When the server is powered down, it enters standby power mode. In standby power mode, power is still directed to the service processor remote management subsystem and power supply fans. To completely power off the server, you must disconnect the power cords from the power supplies.

---

#### Related Information

- [“Use the Power Button for Immediate Shutdown”](#) on page 36
- [“Power Down Server Gracefully Using the Oracle ILOM CLI”](#) on page 34

## ▼ Disconnect Cables From the Server



---

**Caution** – The system supplies standby power to the circuit boards when the power cords are connected even when the system is powered off.

---

1. Label all cables connected to the server.
2. Disconnect the power cords from the rear of the server.
3. Disconnect all data cables from the rear of the server.

### **Related Information**

- [“Server Back Panel View” on page 5](#)
- [“Powering Down the Server” on page 33](#)
- [“Remove the Server From the Rack” on page 41](#)
- [“Reconnect Data Cables and Power Cords” on page 149](#)

## ▼ Extend the Server to the Maintenance Position

The following components can be serviced with the server in the maintenance position:

- Storage drives
- Fan modules
- Power supplies
- DVD drive module
- PCIe risers
- PCIe cards
- DDR3 DIMMs
- Internal USB flash drives
- Motherboard battery
- Processors
- Disk backplane
- FIM (front indicator module)
- Motherboard
- SAS cables

If the server is installed in a rack with extendable slide-rails, use this procedure to extend the server to the maintenance position.

1. To prevent the rack from tipping forward when the server is extended, extend all rack anti-tilt devices.



---

**Caution** – To reduce the risk of personal injury, stabilize the expansion rack cabinet and extend all anti-tilt devices before extending the server from the rack.

---

For instructions for stabilizing the rack, see the *Sun Server X4-2 Installation Guide*, “Stabilize the Rack for Installation” on page 43.

2. Verify that no cables will be damaged or will interfere when the server is extended.

Although the cable management arm (CMA) that is supplied with the server is hinged to accommodate extending the server, you should ensure that all cables and cords are capable of extending.

3. To release the slide-rails locks, pull down on the flip-down handles, which are located on the sides of the server front panel (see [FIGURE: Slide-Rail Release Latches on page 41 \[callout 1\]](#)).


---

**Note** – The slide-rail locks are located behind the flip-down handles on the front of the server. The slide-rail locks are released when the flip-down handles are pulled down.

---

The server is now in the extended maintenance position.

**FIGURE:** Slide-Rail Release Latches



**Figure Legend**

- 
- |   |                        |
|---|------------------------|
| 1 | Slide-rail lock        |
| 2 | Slide-rail release tab |
- 

4. Slowly pull the server out of the rack until the slide-rails latch.

#### **Related Information**

- [“Disconnect Cables From the Server”](#) on page 39
- [“Remove the Server From the Rack”](#) on page 41
- [“Reinstall the Server Chassis Into the Rack”](#) on page 146

## ▼ Remove the Server From the Rack



---

**Caution** – The server weighs approximately 18.0 kg (40.0 lbs). Two people are required to dismount and carry the chassis.

---

1. **Disconnect all the cables and power cords from the server.**
2. **Remove the cable management arm (CMA).**
  - For instructions for removing the second-generation CMA, see the *Sun Server X4-2 Installation Guide*, “Remove the Second-Generation Cable Management Arm” on page 64.

- For instructions for removing the first-generation CMA, see the *Sun Server X4-2 Installation Guide*, “Install the First-Generation Cable Management Arm” on page 69 and perform the installation steps in reverse order.

**3. Extend the server to the maintenance position.**

For instructions, see “Extend the Server to the Maintenance Position” on page 39.

**4. From the front of the server, pull the green slide-rail release tabs toward the front of the server, and pull the server out of the rack until it is free of the rack rails.**

A slide-rail release tab is located on each slide-rail (see [FIGURE: Slide-Rail Release Latches on page 41](#) [callout 2]).

---

**Note** – To pull the green slide-rail release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the server.

---

**5. Set the server on a sturdy work surface.**

**Related Information**

- “Disconnect Cables From the Server” on page 39
- “Take Antistatic Measures” on page 42
- “Extend the Server to the Maintenance Position” on page 39
- “Reinstall the Server Chassis Into the Rack” on page 146

## ▼ Take Antistatic Measures

**1. Prepare an antistatic surface on which to set parts during removal and installation.**

Place electrostatic discharge (ESD)-sensitive components such as the printed circuit boards on an antistatic mat. The following items can be used as an antistatic mat:

- An antistatic bag used to wrap a replacement part
- An Oracle ESD mat (orderable item)
- A disposable ESD mat (shipped with some replacement parts or optional system components)

**2. Attach an antistatic wrist strap.**

When servicing or removing server components, attach an antistatic strap to your wrist and then to a metal area on the chassis. Then disconnect the power cords from the server.

---

**Note** – An antistatic wrist strap is not included in the Ship Kit for the server. However, antistatic wrist straps are still included with options and components.

---

### Related Information


- [“Remove Antistatic Measures”](#) on page 146

## ▼ Open the Server Fan Door

Servicing the server fan modules and other components located in the front of the server, such as the front indication module, the DVD drive, and disk backplanes, requires that the fan door be opened. It is also easier to remove the server top cover if you open the fan door first.

- **To open the server fan door, slide the fan door latches to the front of the server and swing the door up to the open position.**

**FIGURE:** Opening the Server Fan Door



### Related Information

- [“Take Antistatic Measures”](#) on page 42
- [“Remove the Server Top Cover”](#) on page 43

## ▼ Remove the Server Top Cover

Servicing most of the server components requires that the top cover be removed.




---

**Caution** – If the top cover is removed without first removing the AC power cords, the server host shuts down immediately and an event is logged to indicate that the chassis top cover has been removed.

---

1. Ensure that the AC power cords are disconnected from the server power supplies.
2. To open the server fan door, slide the fan door latches toward the front of the server and swing the door up to the open position.
3. To open the server top cover, press and hold down the top cover release buttons and use the recessed areas to slide the top cover toward the rear of the server about 0.5 inches (12.7 mm) [1].

**FIGURE:** Removing the Server Top Cover



4. Lift the cover off the chassis and set it aside [2].

#### **Related Information**

- [“Take Antistatic Measures”](#) on page 42
- [“Install the Server Top Cover”](#) on page 145

# Servicing CRUs That Do Not Require Server Power-Off

---

The following sections describe how to service customer-replaceable units (CRUs) that do not require you to power off the server.

Description	Links
Service the storage drives.	<a href="#">“Servicing Storage Drives (CRU)” on page 45</a>
Service the fan modules.	<a href="#">“Servicing Fan Modules (CRU)” on page 50</a>
Service the power supplies.	<a href="#">“Servicing Power Supplies (CRU)” on page 55</a>

## Related Information

- [“Servicing CRUs That Require Server Power-Off” on page 61](#)
- [“Servicing FRUs” on page 99](#)

---

## Servicing Storage Drives (CRU)

These sections describe how to remove and install storage drives:

In addition to the service procedures included here, you can see animations that show how to remove and install the storage drives.

[PLAY the ANIMATION](#)

To play the Sun Server X4-2 Service Animations go to:

[http://docs.oracle.com/cd/E36975\\_01/html/E49470/index.html](http://docs.oracle.com/cd/E36975_01/html/E49470/index.html)

See the following procedures:

- [“Storage Drives Hot-Plug Conditions”](#) on page 46
- [“HDD or SSD Failure and RAID”](#) on page 46
- [“Storage Drive Status Indicators”](#) on page 47
- [“Remove a Storage Drive”](#) on page 47
- [“Install a Storage Drive”](#) on page 49

### Related Information

- [“Removing and Installing Server Filler Panels”](#) on page 143

## Storage Drives Hot-Plug Conditions

The solid-state drives (SSDs) or hard-disk drives (HDDs) in the server are hot-pluggable, but this capability depends on how the drives are configured. To hot-plug a drive you must be able to take the drive offline before you can remove it. When you take the drive offline, you prevent any application from accessing the drive and remove the logical software links to the drive.

The following situations inhibit the ability to perform hot-plugging of a drive:

- The drive provides the operating system, and the operating system is not mirrored on another drive.
- The drive cannot be logically isolated from the online operations of the server.

If either of the above drive restrictions is true, then you must shut down the system before you replace the drive. See [“Powering Down the Server”](#) on page 33.

---

**Note** – Replacing a drive does not require removing the server from a rack.

---

### Related Information

- [“Remove a Storage Drive”](#) on page 47
- [“Install a Storage Drive”](#) on page 49

## HDD or SSD Failure and RAID

A single storage drive failure does not cause a data failure if the storage drives are configured as a mirrored RAID 1 volume (optional). The storage drive can be removed, and when a new storage drive is inserted, the contents are automatically


rebuilt from the rest of the array with no need to reconfigure the RAID parameters. If the replaced storage drive was configured as a hot-spare, the new storage drive is automatically configured as a new hot-spare.

For instructions for configuring RAID on the server, refer to the *Sun Server X4-2 Installation Guide*, “Configuring Server Drives for OS Installation” on page 113.

## Storage Drive Status Indicators

The following figure and table describe the storage drive status indicators (LEDs).

**FIGURE:** Storage Drive Status Indicators



**TABLE:** Storage Drive Status Indicators

Legend	LED	Color	State Meaning
1	OK to Remove	Blue	<ul style="list-style-type: none"> <li>• STEADY ON – The storage drive can be removed safely during a hot-plug operation.</li> <li>• OFF – The storage drive has not been prepared for removal.</li> </ul>
2	Service Required	Amber	<ul style="list-style-type: none"> <li>• OFF – The storage drive is operating normally.</li> <li>• STEADY ON – The system has detected a fault with the storage drive.</li> </ul>
3	OK/Activity	Green	<ul style="list-style-type: none"> <li>• OFF – Power is off or the installed drive is not recognized by the system.</li> <li>• STEADY ON – The drive is engaged and is receiving power.</li> <li>• STEADY BLINK – There is disk activity. The LED blinks on and off to show activity.</li> </ul>

## ▼ Remove a Storage Drive

### 1. Prepare the system for the drive removal.

See “Take Antistatic Measures” on page 42.

## 2. Identify the location of the drive that you want to remove.

The following illustrations show the location of the drives and the internal system software designations for the drives.

**FIGURE:** Drive Location and Numbering on a Server With Four 2.5-inch Drives and a DVD Drive



---

			DVD
HDD0	HDD1	HDD2	HDD3

---

**FIGURE:** Drive Location and Numbering on a Server With Eight 2.5-inch Drives



---

HDD4	HDD5	HDD6	HDD7
HDD0	HDD1	HDD2	HDD3

---



**Caution** – In Oracle Engineered Systems, storage drive 7 (HDD7) on an eight-drive system might be populated with a remote battery module for the host bus adapter (HBA). The battery module is not a customer-replaceable unit (CRU) and should not be removed or replaced by customers. The battery module should be removed or replaced only by Oracle field service personnel. For more information, refer to [“Battery Module” on page 19](#).

---

## 3. Type the operating system commands required to stop the server from using the drive.


**Note** – The blue OK to Remove LED on the storage drive might not light, as support for this varies depending on the operating system in use.

---

The exact commands required depend on the configuration of your drives. Unmount file systems or issue RAID commands as needed.

4. On the drive you plan to remove, push the latch release button to open the drive latch.

**FIGURE:** Locating the Hard Disk Drive Release Button and Latch



**Caution** – The latch is not an ejector. Do not open the latch too far to the right. Doing so can damage the latch.

5. Grasp the latch and pull the drive out of the drive slot.
6. Consider your next steps:
  - If you are replacing the drive, continue to [“Install a Storage Drive”](#) on page 49.
  - If you are not replacing the drive, install a filler panel in the empty drive slot to maintain proper airflow and perform administrative tasks to configure the server to operate without the drive.

#### **Related Information**

- [“Storage Drive Status Indicators”](#) on page 47
- [“Storage Drives Hot-Plug Conditions”](#) on page 46
- [“HDD or SSD Failure and RAID”](#) on page 46
- [“Install a Storage Drive”](#) on page 49

## ▼ Install a Storage Drive


1. Remove the replacement drive from its packaging and place the drive on an antistatic mat.

2. If necessary, remove the drive filler panel.

3. Align the replacement drive with the drive slot.

The drive is physically addressed according to the slot in which it is installed. It is important to install a replacement drive in the same slot as the drive that was removed.

4. Slide the drive into the slot until the drive is fully seated [1].



5. Close the drive latch to lock the drive in place [2].

6. Perform administrative tasks to reconfigure the drive.

The procedures that you perform at this point depend on how your data is configured. You might need to partition the drive, create file systems, load data from backups, or have the drive updated from a RAID configuration.

### Related Information

- [“Storage Drive Status Indicators” on page 47](#)
- [“Storage Drives Hot-Plug Conditions” on page 46](#)
- [“HDD or SSD Failure and RAID” on page 46](#)
- [“Remove a Storage Drive” on page 47](#)

---

## Servicing Fan Modules (CRU)

The fan modules are located in the front of the server.

In addition to the service procedures included here, you can see animations that show how to remove and install the fans.

**PLAY the ANIMATION**

To play the Sun Server X4-2 Service Animations go to:

[http://docs.oracle.com/cd/E36975\\_01/html/E49470/index.html](http://docs.oracle.com/cd/E36975_01/html/E49470/index.html)

See the following procedures:

- “Remove a Fan Module” on page 51
- “Install a Fan Module” on page 54

### Related Information

- “Open the Server Fan Door” on page 43

## ▼ Remove a Fan Module

You do not have to power off the server to service the fan modules.

You should not begin this procedure unless you have a replacement fan and you are ready to install it right away.

### 1. Extend the server to the maintenance position.

See “Extend the Server to the Maintenance Position” on page 39.

### 2. To access the fan modules, open the server fan door.

See “Open the Server Fan Door” on page 43.



---


**Caution** – Close the server fan door within 60 seconds to maintain adequate airflow to properly cool the server. Leaving the door open for more than 60 seconds, while the server is running, might cause the server to overheat and shut down.

---

### 3. Identify the faulty fan module.

Each fan module has a status indicator (LED). If the LED is lit amber, the fan has failed. The LEDs are located on the chassis mid-wall adjacent to and aligned with the fan modules, as shown in the following figure:

**FIGURE:** Server Fan Status Indicator



Status Indicator Name	Color	State Meaning
Fan Status	Bicolored: Amber/Green	<ul style="list-style-type: none"> <li>Amber – The fan module is faulty. The front TOP FAN LED and the front and rear panel Service Required LEDs are also lit if the system detects a fan module fault.</li> <li>Green – The fan module is correctly installed and operating within specification.</li> </ul>

**4. Remove the faulty fan module.**

- a. Using your thumb and forefinger, grasp the fan module in the finger recesses located in the plastic between the fans.
- b. Lift the fan module straight up and out of the chassis.




---

**Caution** – When removing a fan module, do not rock it back and forth. Rocking the fans module can cause damage to the motherboard connectors.

---

**FIGURE:** Removing a Fan Module



**5. Set the fan module aside.**



---

**Caution** – Do not service any other components in the fan compartment unless the system is shut down and the power cords are removed.

---

**6. Consider your next step:**

- If you removed the fan assembly as part of another procedure, return to that procedure.
- Otherwise, continue to [“Install a Fan Module” on page 54](#).


**Related Information**

- [“Install a Fan Module” on page 54](#)

## ▼ Install a Fan Module

1. Remove the replacement fan module from its packaging and place it on an antistatic mat.
2. With the fan door open, position the replacement fan module into the server.  
The fan modules are keyed to ensure that they are installed in the correct orientation.

**FIGURE:** Installing a Fan Module



3. Press down on the fan module and apply firm pressure to fully seat the fan module.
4. Verify that the fan status LED that aligns with the replaced fan module is lit green.
5. Close the fan door.
6. Verify that the Top Fan Fault LED on the front of the server and the Service Required LEDs on the front and rear of the server are extinguished.  
See [“About Server and Component Status Indicators”](#) on page 6 for more information about identifying and interpreting system indicators.
7. Consider your next step:
  - If you installed the fan module as part of another procedure, return to that procedure.

- Otherwise, return the server to operation.  
See [“Returning the Server to Operation”](#) on page 143.

### Related Information

- [“Remove a Fan Module”](#) on page 51

---

## Servicing Power Supplies (CRU)

The redundant power supplies on the server support concurrent maintenance, which enables you to remove and replace a power supply without shutting down the server, provided that the other power supply is online and working.

The server supports model A256 (600 watt) power supplies. The A256 power supply unit (PSU) provides conversion from the AC lines to the system, accepting ranges from 100-240 volts AC (VAC). These PSUs are designed to be hot-swappable, and in most cases will provide fully redundant “1+1” power, allowing the system to suffer the loss of a PSU or an AC feed with no loss to system availability.

In maximally configured systems, it is possible that the worst-case power consumption of the system could exceed the capacity of a single PSU. The PSUs provide an over-subscription mode, which allows the system to operate with fault-tolerance even with modest excursions beyond the rated capacity of a single PSU. This over-subscription support is accomplished using hardware signaling between the PSU and motherboard circuitry, which can force the system to throttle maximally CPU and memory power in the event that a PSU is lost. The resulting power savings will be enough to allow the system to continue to run (in a lower-performance state) until the power problem is resolved.

The following indicators are lit when a power supply fault is detected:

- Front and rear Service Required LEDs
- Amber Service Required LED on the faulty power supply
- Rear Power Supply Fault LED located on the server front panel (see [“Front Panel Controls and Indicators on a System With Eight 2.5-inch Drives”](#) on page 3)

If a power supply fails and you do not have a replacement available, leave the failed power supply installed to ensure proper airflow in the server.

In addition to the service procedures included here, you can see animations that show how to remove and install the power supplies.

## PLAY the ANIMATION

To play the Sun Server X4-2 Service Animations go to:

[http://docs.oracle.com/cd/E36975\\_01/html/E49470/index.html](http://docs.oracle.com/cd/E36975_01/html/E49470/index.html)

See the following sections for more information:

- “Power Supply Status Indicators” on page 56
- “Remove a Power Supply” on page 57
- “Install a Power Supply” on page 59


### Related Information

- “About Server and Component Status Indicators” on page 6
- “Powering Down the Server” on page 33

## Power Supply Status Indicators

Each power supply contains two status indicators (LEDs) on the back panel. The following figure and table provide a description of the power supply status indicators.

**FIGURE:** Power Supply Status Indicators



**TABLE:** Server Power Supply Indicators

Legend	Status Indicator Name	Icon	Color	State Meaning
1	AC OK/DC OK		Green	<ul style="list-style-type: none"><li>• OFF – No AC power is present.</li><li>• SLOW BLINK – Normal operating. Input power is within specification. DC output voltage is not enabled.</li><li>• STEADY ON – Normal operation. Input AC power and DC output voltage are within specification.</li></ul>
2	Service Required		Amber	<ul style="list-style-type: none"><li>• OFF – Normal operation; no service required.</li><li>• STEADY ON – The power supply (PS) has detected a PS fan failure, PS overtemperature, PS over current, or PS over/under voltage.</li></ul>

## ▼ Remove a Power Supply

### 1. Identify which power supply requires replacement.

A lit amber Service Required LED on a power supply indicates that a failure was detected. You can also use the Oracle ILOM `show faulty` command at the Oracle ILOM prompt (->) to identify a power supply failure.

Alternatively, to list all known faults in the server, log into the Oracle Solaris OS and issue the `fmadm faulty` command, or log into the Oracle ILOM service processor from the Oracle ILOM Fault Management Shell and issue the `fmadm faulty` command.

---

**Note** – The fans of a failed power supply might still be spinning when the system is powered on. You can remove a power supply while the fans are still spinning.

---

### 2. Gain access to the rear of the server where the faulty power supply is located.

### 3. If the cable management arm (CMA) is installed, disconnect both CMA left-side connectors and move the CMA out of the way.

For instructions for disconnecting the CMA left-side connectors, see the *Sun Server X4-2 Installation Guide*, “Remove the Second-Generation Cable Management Arm” on page 64 or *Sun Server X4-2 Installation Guide*, “Install the First-Generation Cable Management Arm” on page 69 as applicable.




---

**Caution** – When disconnecting the CMA left-side connectors, be sure to use your arm to support the CMA so that it does not hang down under its own weight and stress the right-side connectors; otherwise, the CMA might be damaged. You must continue to support the CMA until you have reconnected both of the left-side connectors.

---

4. Disconnect the power cord from the faulty power supply.
5. Grasp the power supply handle and push the power supply latch to the left [1].

**FIGURE:** Removing a Power Supply



**Figure Legend**

- 
- |   |                      |
|---|----------------------|
| 1 | Power Supply 0 (PS0) |
| 2 | Power Supply 1 (PS1) |
- 

6. Pull the power supply out of the chassis [2].



---

**Caution** – Whenever you remove a power supply, you should replace it with another power supply; otherwise, the server might overheat due to improper airflow.

---

7. Continue to “Install a Power Supply” on page 59.

#### **Related Information**

- “Server Back Panel View” on page 5
- “Power Supply Status Indicators” on page 56
- “Install a Power Supply” on page 59

## ▼ Install a Power Supply




---

**Caution** – Always replace a faulty power supply with a power supply of the same type.

---

1. Remove the replacement power supply from its packaging and place it on an antistatic mat.
2. Align the replacement power supply with the empty power supply slot [1].
3. Slide the power supply into the bay until it is fully seated [2].  
You will hear an audible click when the power supply fully seats.



4. Reconnect the power cord to the power supply.
5. Verify that the amber LED on the replaced power supply and the Service Required LEDs are not lit on the front and rear panels.

---

**Note** – After you have replaced Power Supply 0, you must reset the Oracle ILOM service processor (SP) to propagate the FRU top-level indicator (TLI) data to the new power supply. For instructions on resetting the SP, see the Oracle Integrated Lights Out Manager (ILOM) 3.1 Configuration and Maintenance Guide at <http://www.oracle.com/goto/ILOM/docs>. Power Supply 1 does not contain FRU TLI data, and therefore does not require an SP reset after replacement.

---

6. If you disconnected the two CMA left-side connectors, reconnect the connectors.  
For instructions for reconnecting the CMA left-side connectors, see *Sun Server X4-2 Installation Guide*, “Install the Second-Generation Cable Management Arm” on page 52 or *Sun Server X4-2 Installation Guide*, “Install the First-Generation Cable Management Arm” on page 69 as applicable.

**Related Information**

- [“Server Back Panel View” on page 5](#)
- [“Power Supply Status Indicators” on page 56](#)
- [“Remove a Power Supply” on page 57](#)

# Servicing CRUs That Require Server Power-Off

---

These sections describe how to service customer-replaceable units (CRUs) that require you to power off the server.

Description	Use
Learn about the locations of the CRUs.	<a href="#">“CRU Locations” on page 61</a>
Service the DIMMs.	<a href="#">“Servicing the DIMMs (CRU)” on page 62</a>
Service the PCIe Risers.	<a href="#">“Servicing PCIe Risers (CRU)” on page 74</a>
Service the PCIe cards.	<a href="#">“Servicing PCIe Cards (CRU)” on page 84</a>
Service the DVD drive.	<a href="#">“Servicing the DVD Drive (CRU)” on page 91</a>
Service the internal USB flash drives.	<a href="#">“Servicing the Internal USB Flash Drives (CRU)” on page 94</a>
Service the battery.	<a href="#">“Servicing the Battery (CRU)” on page 96</a>

## Related Information


- [“Servicing CRUs That Do Not Require Server Power-Off” on page 45](#)
- [“Servicing FRUs” on page 99](#)

---

## CRU Locations

The CRU locations are shown in the following figure.

**FIGURE:** CRU Locations



**Figure Legend**

1	DVD drive (CRU)	5	Internal HBA card (CRU) (installs in slot 4 on PCIe riser for slots 3 and 4)
2	DIMMS (CRUs) <b>Note:</b> A maximum of eight DIMMs are supported in single-processor systems and the DIMMs must be installed in DIMM sockets associated with the P0 processor socket.	6	PCIe card (CRU) (installs in slot 3 on PCIe riser for slots 3 and 4)
3	Battery (CRU)	7	PCIe riser for slot 1 (CRU) (nonfunctional in single-processor systems)
4	PCIe riser for slots 3 and 4 (CRU)	8	USB flash drives (CRU)

## Servicing the DIMMs (CRU)

This section describes how to remove and install DIMMs.

In addition to the service procedures included here, you can see animations that show how to remove and install DIMMs.

**PLAY the ANIMATION**

To play the Sun Server X4-2 Service Animations go to:

[http://docs.oracle.com/cd/E36975\\_01/html/E49470/index.html](http://docs.oracle.com/cd/E36975_01/html/E49470/index.html)

The Sun Server X4-2 supports a variety of DDR3 DIMM configurations that can include quad-rank (QR), dual-rank (DR), and single-rank (SR) DDR3 DIMMs.

---

**Note** – While single-rank DIMMs can be installed in the Sun Server X4-2, Oracle does not offer any single-rank DIMMs for purchase, either as factory-installed options or as separately orderable options.

---



---

**Caution** – These procedures require that you handle components that are sensitive to electrostatic discharge. This sensitivity can cause the components to fail. To avoid damage, ensure that you follow antistatic practices as described in “[Take Antistatic Measures](#)” on page 42.

---



---

**Caution** – Ensure that all power is removed from the server before removing or installing DDR3 DIMMs, or damage to the DDR3 DIMMs might occur. You must disconnect all power cables from the system before performing these procedures.

---

The following sections provide information to assist you when replacing or upgrading a DIMM:

- “[DIMM and Processor Physical Layout](#)” on page 64
- “[DIMM Population Example for Optimal System Performance](#)” on page 65
- “[DIMM Population Rules](#)” on page 67
- “[DIMM Rank Classification Labels](#)” on page 69
- “[Inconsistencies Between DIMM Fault Indicators and the BIOS Isolation of Faulty DIMMs](#)” on page 70
- “[Using the Fault Remind Button](#)” on page 70
- “[Identify and Remove a Faulty DIMM](#)” on page 71
- “[Install a DIMM](#)” on page 73



## Related Information

- “DIMM Population Example for Optimal System Performance” on page 65
- “DIMM Population Rules” on page 67
- “DIMM Rank Classification Labels” on page 69
- “Inconsistencies Between DIMM Fault Indicators and the BIOS Isolation of Faulty DIMMs” on page 70

# DIMM Population Example for Optimal System Performance

This section provides an example of how to populate the DIMM sockets to achieve optimal system performance.


---

**Note** – Not all possible configurations are shown here.

---

The following figure shows the order in which the DIMM sockets should be populated in dual-processor systems. In single-processor systems, you should follow the same order except that you should not install DIMMs in the DIMM sockets associated with processor 1 (P1) socket, because the P1 DIMM sockets are nonfunctional.

**FIGURE:** DIMM Population Order



For more information on populating the DIMMs, see the following sections:

- “DIMM Population Order for Single-Processor Systems” on page 66
- “DIMM Population Order for Dual-Processor Systems” on page 66

## DIMM Population Order for Single-Processor Systems

In single-processor systems, DIMMs should only be installed into DIMM sockets associated with processor 0 (P0) starting with P0 D0, first filling the blue sockets and then the white. This DIMM population order is illustrated in [FIGURE: DIMM Population Order on page 65](#).

The following table describes the order in which the DIMM sockets should be populated in single-processor systems. The figure callouts in column two of the table refer to the callouts in [FIGURE: DIMM Population Order on page 65](#).

**TABLE:** DIMM Population Order for Single-Processor Systems

Population Order	Figure Callouts	DIMMs Sockets for Processor 0 (P0)
<b>Fill the blue sockets first</b>		
First	1	D0
Second	3	D2
Third	5	D5
Fourth	7	D7
<b>Then fill the white sockets</b>		
Fifth	9	D1
Sixth	11	D3
Seventh	13	D4
Eighth	15	D6

## DIMM Population Order for Dual-Processor Systems

In dual-processor systems, DIMMs should be installed into DIMM sockets starting with P0 D0 and then alternating between sockets associated with processor 0 (P0) and matching sockets for processor 1 (P1), first filling the blue sockets and then the white. This DIMM population order is illustrated in [FIGURE: DIMM Population Order on page 65](#).

The following table describes the order in which the DIMM sockets should be populated in dual-processor systems. The figure callouts in columns two and four of the table refer to callouts in [FIGURE: DIMM Population Order on page 65](#).

**TABLE:** DIMM Population Order for Dual-Processor Systems

Population Order	Figure Callouts	DIMM Sockets for Processor 0 (P0)	Figure Callouts	DIMM Sockets for Processor 1 (P1)
<b>Fill the blue sockets first</b>				
First	1	Fill D0 first	2	Then D0
Second	3	Fill D2 first	4	Then D2
Third	5	Fill D5 first	6	Then D5
Fourth	7	Fill D7 first	8	Then D7
<b>Then fill the white sockets</b>				
Fifth	9	Fill D1 first	10	Then D1
Sixth	11	Fill D3 first	12	Then D3
Seventh	13	Fill D4 first	14	Then D4
Eighth	15	Fill D6 first	16	Then D6

## DIMM Population Rules

The DIMM population rules for the server are as follows:

- In dual-processor systems, all DIMM sockets can have either a DIMM or DIMM filler panel installed.

---

**Note –** In dual-processor systems, DIMM filler panels are not required in sockets that do not have DIMMs installed.

---

- In single-processor systems, all DIMM sockets associated with processor 0 (P0) socket can have either a DIMM or DIMM filler panel installed. DIMM sockets associated with processor 1 (P1) socket must remain empty, that is, neither DIMMs nor DIMM filler panel should be installed.

---

**Note –** In single-processor systems, DIMM filler panels are not required in sockets that do not have DIMMs installed.

---

- A single DIMM configuration is supported.
- Do not populate DIMM sockets next to an empty processor socket. Each processor contains a separate memory controller.

- Each processor has four channels and can support two DIMMs per channel for a maximum of eight quad-rank (QR) Load Reduced DIMMs (LRDIMMs), dual-rank (DR) DIMMs, or single-rank (SR) DIMMs.
- The server supports 32-GB QR LRDIMMs in addition to 8-GB and 16-GB Registered DIMMs (RDIMMs).
- You cannot mix LRDIMMs and RDIMMs in the same server. If you choose to install 32-GB QR LRDIMMs in the server, you cannot install any 8-GB or 16-GB single-rank or dual-rank RDIMMs.
- If you are installing a mix of RDIMM sizes (for example, 8-GB and 16-GB), install the larger RDIMMs first, then the smaller RDIMMs, until all of the RDIMMs are installed.
- If you are installing QR LRDIMMs within a channel, populate the blue sockets prior to populating the white sockets.

---

**Note** – While the processor used in the server supports four modes of operation—Independent Channel Mode, Lockstep Channel Mode, Mirrored Channel Mode, and, Device Tagging Mode—the server supports the Independent Channel Mode only.

---

---

**Note** – Each processor (P0, P1) has eight associated DIMM sockets, numbered D0, D1, D2, D3, D4, D5, D6, and D7.

---

- DIMMs should be installed into DIMM sockets starting with P0 D0 and alternating between sockets associate with P0 and matching sockets for P1, first filling the blue sockets and then the white. For an example of a configuration that follows this rule, see [“DIMM Population Example for Optimal System Performance” on page 65](#).
- For maximum performance, apply the following rules:
  - The best performance is ensured by preserving symmetry. For example, add four of the same kind of DIMMs, one per memory channel, and if the server has two processors, ensure that both processors have the same size of DIMMs installed in the same manner.
  - For optimal performance, the memory installation should be identical across both sockets. Populate each socket with QR, DR, or SR DIMMs in sets of four, one per memory channel.
- All memory installed in the system will operate at the same speed. DIMM operational speed, or frequency, is limited to the lowest speed determined by each of the following factors:
  - Maximum memory frequency supported by processor
  - Maximum memory frequency supported by the installed DIMMs
  - Memory configuration within a channel

The table below lists the memory speed limitations associated with all the possible combinations of DIMMs within an individual memory channel.

Blue Socket	White Socket	Speed
Quad-rank LRDIMM	Empty	1600 MT/s
Dual-rank DIMM	Empty	1600 MT/s
Single-rank DIMM	Empty	1600 MT/s
Quad-rank LRDIMM	Quad-rank LRDIMM	1600 MT/s
Dual-rank DIMM	Dual-rank DIMM	1600 MT/s
Dual-rank DIMM	Single-rank DIMM	1600 MT/s
Single-rank DIMM	Single-rank DIMM	1600 MT/s

## DIMM Rank Classification Labels

DIMMs come in a variety of ranks: single, dual, or quad. Each DIMM is shipped with a label identifying its rank classification. The following table identifies the label corresponding to each DIMM rank classification:

**TABLE:** DIMM Rank Classifications Labels

Rank Classification	Label
Quad-rank LRDIMM	4Rx4
Dual-rank DIMM	2Rx4
Single-rank DIMM	1Rx4

**Note –** While single-rank DIMMs can be installed in the Sun Server X4-2, Oracle does not offer any single-rank DIMMs for purchase, either as factory-installed options or as separately orderable options.

## Inconsistencies Between DIMM Fault Indicators and the BIOS Isolation of Faulty DIMMs

When a single DIMM is marked as faulty by Oracle ILOM (for example, `fault.memory.intel.dimm.training-failed` is listed in the SP Event Log), BIOS might disable the entire memory channel that contains the faulty DIMM as failing, that is, up to two DIMMs. As a result, the memory available to the operating system is reduced. However, when the Fault Remind button is pressed, only the fault status indicator (LED) associated with the faulty DIMM lights. The fault LED for the other DIMM in the memory channel remains off. Therefore, you can correctly identify the faulty DIMM.


When the faulty DIMM is replaced, the memory available to the operating system returns to normal. If the DIMM fault message in Oracle ILOM is not cleared under Open Problems, you must manually clear the fault in Oracle ILOM. For instructions for manually clearing a DIMM fault, see the procedure "Clear Faults for Undetected Replaced or Repaired Hardware Components" in the *Oracle Integrated Lights Out Manager (ILOM) 3.1 User's Guide* in the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.

## Using the Fault Remind Button

When the Fault Remind button is pressed, an LED located next to the Fault Remind button lights green to indicate that there is sufficient voltage present in the fault remind circuit to light any fault LEDs that were lit due to a failure. If this LED fails to light when you press the Fault Remind button, it is likely that the capacitor powering the fault remind circuit has lost its charge. This can happen if the Fault Remind button is pressed for a long time with fault LEDs lit or if power has been removed from the server for more than 15 minutes.

The following figure shows the location of the Fault Remind button.

**FIGURE:** Fault Remind Button Location



## ▼ Identify and Remove a Faulty DIMM

### 1. Prepare the server for service.

- a. Power off the server, and disconnect the power cords from the power supplies.

See [“Powering Down the Server”](#) on page 33

- b. Extend the server to the maintenance position.

See [“Extend the Server to the Maintenance Position”](#) on page 39.

- c. Attach an antistatic wrist strap to your wrist and then to a metal area on the chassis.


See [“Take Antistatic Measures”](#) on page 42.

- d. Remove the server top cover.

See [“Remove the Server Top Cover”](#) on page 43.

2. Identify and note the location of the faulty DDR3 DIMM by pressing the Fault Remind button on the motherboard (see [“Using the Fault Remind Button”](#) on page 70).

Faulty DDR3 DIMMs are identified with a corresponding amber LED on the motherboard.



- If the DIMM fault LED is off, the DIMM is operating properly.
- If the DIMM fault LED is on (amber), then the DIMM is faulty and should be replaced.

3. To remove the faulty DIMM do the following:

- a. Rotate both DIMM socket ejectors outward as far as they will go.

The DIMM is partially ejected from the socket (See [FIGURE: DIMM Socket Release and Alignment](#) on page 73).

- b. Carefully lift the DIMM straight up to remove it from the socket.

4. Replace each faulty DIMM with either another DIMM of the same rank size (quad rank, dual rank, or single rank) or leave the socket empty.


---

**Note** – DIMM filler panels are optional and not required.

---

For DIMM replacement instructions, see [“Install a DIMM”](#) on page 73.

**FIGURE:** DIMM Socket Release and Alignment



**Figure Legend**

- 
- |   |                       |
|---|-----------------------|
| 1 | DIMM connector socket |
| 2 | DIMM connector key    |
| 3 | DIMM ejector lever    |
- 

## ▼ Install a DIMM

1. **Unpack the replacement DDR3 DIMM and place it on an antistatic mat.**
2. **Ensure that the replacement DDR3 DIMM matches the size of the DIMM it is replacing.**

You must not replace a dual-rank DIMM with a quad-rank DIMM and vice versa. If you violate this rule, the performance of the server might be adversely affected. For DIMM socket population rules, see [“DIMM Population Rules”](#) on page 67.
3. **Install a DIMM.**
  - a. **Ensure that the ejector tabs are in the open position.**
  - b. **Align the notch in the replacement DIMM with the connector key in the connector socket.**

The notch ensures that the DIMM is oriented correctly.

- c. **Push the DDR3 DIMM into the connector until the ejector tabs lock the DIMM in place.**

If the DIMM does not easily seat into the connector socket, verify that the notch in the DIMM is aligned with the connector key in the connector socket. If the notch is not aligned, damage to the DIMM might occur.

4. **Repeat [Step 3](#) until all replacement DDR3 DIMMs are installed.**

5. **Return the server to operation.**

- a. **Install the server top cover.**

See “[Install the Server Top Cover](#)” on page 145.

- b. **Close the fan door.**

- c. **Return the server to the normal rack position.**

See “[Return the Server to the Normal Rack Position](#)” on page 148.

- d. **Reconnect the power cords to the server power supplies and reconnect the data cables.**

See “[Reconnect Data Cables and Power Cords](#)” on page 149.

- e. **Power on the server.**

See “[Power On the Server](#)” on page 150.

Verify that the Power/OK status indicator is steady on.

6. **(Optional) Use Oracle ILOM to clear server DDR3 DIMM faults.**

DDR3 DIMM faults are automatically cleared after a new memory DIMM has been installed. If you need to manually clear DDR3 DIMM faults, refer to the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.

---

## Servicing PCIe Risers (CRU)

This section describes how to remove and install the PCIe risers.

In addition to the service procedures included here, you can see animations that show how to remove and install the PCIe risers.

**PLAY the ANIMATION**

To play the Sun Server X4-2 Service Animations go to:

[http://docs.oracle.com/cd/E36975\\_01/html/E49470/index.html](http://docs.oracle.com/cd/E36975_01/html/E49470/index.html)

PCIe cards in all slots are installed on vertical risers. You must remove the relevant riser to remove and replace a PCIe card. You must remove all three PCIe risers when replacing the motherboard.



---

**Caution** – These procedures require that you handle components that are sensitive to electrostatic discharge. This sensitivity can cause the components to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Take Antistatic Measures”](#) on page 42.

---



---

**Caution** – Ensure that all power is removed from the server before removing or installing PCIe risers, or damage to the PCIe cards installed in the risers might occur. You must disconnect all power cables from the system before performing these procedures.

---

The following sections provide information to assist you in servicing PCIe risers:

- [“PCIe Riser Location and Differences”](#) on page 75
- [“Remove a PCIe Riser From PCIe Slot 1 or 2”](#) on page 76
- [“Install a PCIe Riser Into PCIe Slot 1 or 2”](#) on page 78
- [“Remove a PCIe Riser From PCIe Slots 3 and 4”](#) on page 80
- [“Install a PCIe Riser Into PCIe Slots 3 and 4”](#) on page 82


### Related Information

- [“Servicing PCIe Cards \(CRU\)”](#) on page 84

## PCIe Riser Location and Differences

The PCIe riser that installs in PCIe slots 3 and 4 is different than the risers in PCIe slots 1 and 2. The riser for slots 3 and 4 supports two cards: a standard PCIe card and an internal HBA card. Do not attempt to install the PCIe riser for PCIe slots 3 and 4 in slots 1 or 2, and vice versa.

**FIGURE:** PCIe Riser Locations



**Figure Legend**

- 
- 1 PCIe riser and installed PCIe card in slot 1 (This slot is nonfunctional in single-processor systems.)
  - 2 PCIe riser and installed PCIe card in slot 2
  - 3 PCIe riser and installed cards (2) in slots 3 and 4 (this riser contains the internal HBA card.)  
**Note:** This riser is different from the risers in slots 1 and 2.
- 

**Related Information**

- [“PCIe Slot Characteristics” on page 85](#)


## ▼ Remove a PCIe Riser From PCIe Slot 1 or 2

---

**Note** – PCIe slot 1 is nonfunctional in single-processor systems.

---

1. Prepare the server for service.
  - a. Power off the server and disconnect the power cords from the power supplies.  
See “Powering Down the Server” on page 33.
  - b. Extend the server to the maintenance position.  
See “Extend the Server to the Maintenance Position” on page 39.
  - c. Attach an antistatic wrist strap to your wrist and then to a metal area on the chassis.  
See “Take Antistatic Measures” on page 42.
  - d. Remove the server top cover.  
See “Remove the Server Top Cover” on page 43.
2. Select the PCIe riser that you want to remove.  
See “PCIe Slot Characteristics” on page 85.
3. If a PCIe card is installed in the riser, disconnect any external or internal cables from the card.
4. Lift the green-tabbed latch on the rear of the server chassis next to the applicable PCIe slot to release the rear bracket on the PCIe card [1].



---

**Note** – If the riser does not have a PCIe card installed, then lift the latch to release the PCIe slot filler panel.

---

5. Lift the green-tabbed riser release lever on the PCIe riser with one hand and use your other hand to remove the riser from the motherboard connector [2, 3].
6. If there is a PCIe card installed in the riser, place the riser on an antistatic mat and note the slot in which the PCIe riser was originally installed; otherwise, set the PCIe riser aside.

#### **Related Information**

- [“Install a PCIe Riser Into PCIe Slot 1 or 2” on page 78](#)

## ▼ Install a PCIe Riser Into PCIe Slot 1 or 2

---

**Note** – PCIe slot 1 is nonfunctional in single-processor systems.


---

---

**Note** – The PCIe riser in slots 3 and 4 is different than the PCIe risers in slots 1 and 2. Do not attempt to install a PCIe riser from slot 1 or 2 into PCIe slots 3 and 4 and vice versa.

---

1. Determine into which slot you will install the PCIe riser.
2. Retrieve the PCIe riser and any PCIe cards attached to it.
3. Raise the green-tabbed release lever on the PCIe riser to the open (up) position [1].
4. Gently press the riser into the motherboard connector until it is seated, and then press the green-tabbed release lever on the PCIe riser to the closed (down) position [2].



5. If there is a PCIe card installed in the riser, reconnect any external or internal cables to the card.
6. Close the green-tabbed latch on the rear of the server chassis next to the applicable PCIe slot to secure the rear bracket on the PCIe card to the server chassis [3].

---

**Note** – If the riser does not have a PCIe card installed, install a PCIe slot filler panel and close the green-tabbed latch to secure the filler panel.

---

7. Return the server to operation.
  - a. Install the server top cover.  
See “Install the Server Top Cover” on page 145.
  - b. Close the fan door.
  - c. Return the server to the normal rack position.  
See “Return the Server to the Normal Rack Position” on page 148.
  - d. Reconnect the power cords to the server power supplies and reconnect the data cables.  
See “Reconnect Data Cables and Power Cords” on page 149.

**e. Power on the server.**

See “Power On the Server” on page 150.

Verify that the Power/OK status indicator is steady on.

**8. Use Oracle ILOM to clear the server PCIe riser fault.**

If the PCIe riser fault message in Oracle ILOM is not cleared under Open Problems, you must manually clear the fault in Oracle ILOM. For instructions for manually clearing a PCIe riser fault, see the procedure “Clear Faults for Undetected Replaced or Repaired Hardware Components” in the *Oracle Integrated Lights Out Manager (ILOM) 3.1 User’s Guide* in the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at

<http://www.oracle.com/goto/ILOM/docs>.

**Related Information**

- “Remove a PCIe Riser From PCIe Slot 1 or 2” on page 76

## ▼ Remove a PCIe Riser From PCIe Slots 3 and 4

**1. Prepare the server for service.**

**a. Power off the server and disconnect the power cords from the power supplies.**

See “Powering Down the Server” on page 33

**b. Extend the server to the maintenance position.**

See “Extend the Server to the Maintenance Position” on page 39.

**c. Attach an antistatic wrist strap to your wrist and then to a metal area on the chassis.**

See “Take Antistatic Measures” on page 42.

**d. Remove the server top cover.**

See “Remove the Server Top Cover” on page 43.


**2. If there is a PCIe card installed in the riser, disconnect any external or internal cables.**

---

**Note** – Do not disconnect the SAS cable from the internal host bus adapter card until after you have removed the riser from the server.

---

**3. Open the green-tabbed latch located on the rear of the server chassis next to PCIe slot 3 to release the rear bracket on the PCIe card [1].**




---

**Note** – If the riser does not have a PCIe card installed in slot 3, then lift the latch to release the PCIe slot 3 filler panel.

---

4. To release the riser from the motherboard connector, lift the green-tabbed lease lever on the PCIe riser to the open position [2].
5. Slide the plastic PCIe card retainer, which is mounted on the side of the chassis, toward the front of the server to release the card(s) installed in the riser [3].
6. Grasp the riser with both hands and remove it from the server [4].
7. Disconnect the SAS storage drive (HDD) cables from the internal HBA card installed in PCIe slot 4 [5].

---

**Note** – If the server has four or fewer storage drives, the SAS cable for HDDs 0-3 will be the only one installed.

---

8. Place the riser on an antistatic mat.

### Related Information


- “Install a PCIe Riser Into PCIe Slots 3 and 4” on page 82

## ▼ Install a PCIe Riser Into PCIe Slots 3 and 4

**Note** – The PCIe riser in slots 3 and 4 is different than the PCIe risers in slots 1 and 2. Do not attempt to install a PCIe riser from slot 1 or 2 into PCIe slots 3 and 4 and vice versa.

1. Retrieve the PCIe riser and any PCIe cards attached to it.
2. Reconnect the SAS cable(s) to the internal host bus adapter card [1].

Be sure to connect the SAS cable for storage drives 0 through 3 (HDDs 0-3) to the connector that is farthest from the riser in which the HBA card is installed; otherwise, the server will incorrectly identify the storage drives when it is powered on.



3. Raise the green-tabbed release lever on the PCIe riser to the open (up) position, and then gently press the riser into the motherboard connector until it is seated [2].

4. **Ensure that the rear bracket on the internal HBA card in PCIe slot 4 is connected to the slot in the server chassis side wall.**  
If the bracket is not connected, remove the riser and reposition it so that the rear bracket connects to the side wall, and then gently press the riser into the motherboard connector.
5. **Slide the plastic PCIe card retainer, which is mounted on the side of the chassis, toward the back of the server to secure the card(s) installed in the riser [3].**
6. **Press the green-tabbed release lever on the PCIe riser to the closed (down) position [4].**
7. **To secure the rear bracket on the PCIe card to the server, close the green-tabbed latch on the rear of the server chassis [5].**

---

**Note** – If the riser does not have a PCIe card installed in slot 3, install a PCIe slot filler panel and close the green-tabbed latch to secure the PCIe slot filler panel.

---

8. **If there is a PCIe card installed in slot 3 of the riser, reconnect any external or internal cables to the card.**
9. **Return the server to operation.**
  - a. **Install the server top cover.**  
See “Install the Server Top Cover” on page 145.
  - b. **Close the fan door.**
  - c. **Return the server to the normal rack position.**  
See “Return the Server to the Normal Rack Position” on page 148.
  - d. **Reconnect the power cord to the server power supply and the data cables.**  
See “Reconnect Data Cables and Power Cords” on page 149.
  - e. **Power on the server.**  
See “Power On the Server” on page 150.  
Verify that the Power/OK status indicator is steady on.
10. **Use Oracle ILOM to clear the server PCIe riser fault.**  
If the PCIe riser fault message in Oracle ILOM is not cleared under Open Problems, you must manually clear the fault in Oracle ILOM. For instructions for manually clearing a PCIe riser fault, see the procedure “Clear Faults for Undetected Replaced or Repaired Hardware Components” in the *Oracle Integrated Lights Out Manager (ILOM) 3.1 User’s Guide* in the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.

## Related Information

- “Remove a PCIe Riser From PCIe Slots 3 and 4” on page 80

---

# Servicing PCIe Cards (CRU)

These sections describe how to remove and install PCIe cards. Refer to your PCIe card documentation for complete software and cabling information about your card.

In addition to the service procedures included here, you can see animations that show how to remove and install the PCIe cards.

**PLAY the ANIMATION**

To play the Sun Server X4-2 Service Animations go to:

[http://docs.oracle.com/cd/E36975\\_01/html/E49470/index.html](http://docs.oracle.com/cd/E36975_01/html/E49470/index.html)



---

**Caution** – These procedures require that you handle components that are sensitive to electrostatic discharge. This sensitivity can cause the components to fail. To avoid damage, ensure that you follow antistatic practices as described in “Take Antistatic Measures” on page 42.

---



---

**Caution** – Ensure that all power is removed from the server before removing or installing PCIe cards. You must disconnect all power cables from the system before performing these procedures.

---

---

**Note** – For a complete list of supported PCIe cards, see the *Sun Server X4-2 Product Notes* at <http://www.oracle.com/goto/X4-2/docs>.

---

The following sections provide information to assist you when servicing PCIe cards:

- “PCIe Slot Characteristics” on page 85
- “Remove a PCIe Card From PCIe Slot 1 or 2” on page 86
- “Install a PCIe Card in PCIe Slot 1 or 2” on page 87
- “Remove a PCIe Card From PCIe Slot 3” on page 87
- “Install a PCIe Card in PCIe Slot 3” on page 88
- “Remove the Internal HBA Card From PCIe Slot 4” on page 89

- [“Install the Internal HBA Card in PCIe Slot 4” on page 90](#)

### Related Information

- [“Servicing PCIe Risers \(CRU\)” on page 74](#)

## PCIe Slot Characteristics

There are three external and one internal PCIe slots available in the Sun Server X4-2. The external slots support optional, standard PCIe cards and are numbered 1, 2, and 3 from left to right when you view the server from the rear. The internal slot, which installs on the riser in PCIe slots 3 and 4, supports a required internal SAS controller HBA card. For a view of the rear panel that shows PCIe slot numbering, see [“Server Back Panel View” on page 5](#).

---

**Note** – PCIe slot 1 is nonfunctional in single-processor systems.

---



---

**Note** – All of the PCIe slots comply with the PCI Express 3.0 specification and can accommodate 25 watt PCIe cards.

---

The following table lists the characteristics and requirements of the PCIe slots.

Slot Number	Supported PCIe Card Types	Supported PCIe Specifications	Slot Connector Width/PCI Express Lanes
1	Low-profile cards only	PCIe 1.0, PCIe 2.0, PCIe 3.0	x16 mechanical/x16 electrical
2	Low-profile cards only	PCIe 1.0, PCIe 2.0, PCIe 3.0	x16 mechanical/x8 electrical
3 and 4	Low-profile cards only	PCIe 1.0, PCIe 2.0, PCIe 3.0	x8 mechanical/x8 electrical

### Related Information

- [“Server Back Panel View” on page 5](#)

## ▼ Remove a PCIe Card From PCIe Slot 1 or 2

---

**Note** – PCIe slot 1 is nonfunctional in single-processor systems.


---

### 1. Remove the PCIe riser from the server.

For instructions, see [“Remove a PCIe Riser From PCIe Slot 1 or 2”](#) on page 76.

### 2. Remove the PCIe card from the PCIe riser.

- a. Hold the riser in one hand and use your other hand to carefully pull the PCIe card connector out of the riser.
- b. Disconnect the rear bracket that is attached to the PCIe card from the rear of the PCIe riser.



### 3. Place the PCIe card on an antistatic mat.



---

**Caution** – Whenever you remove a PCIe card, you should replace it with another PCIe card or a PCIe filler panel. Installing PCIe filler panels in vacant PCIe slots helps reduce the level of electromagnetic interference (EMI) emitted by the server. For instructions for installing a PCIe filler panel, see [“Removing and Installing Server Filler Panels”](#) on page 143.

---


## ▼ Install a PCIe Card in PCIe Slot 1 or 2

---

**Note** – PCIe slot 1 is nonfunctional in single-processor systems.

---

1. Retrieve the PCIe card and riser you to install.
2. Insert the rear bracket that is attached to the PCIe card into the PCIe riser.
3. Hold the riser in one hand and use your other hand to carefully insert the PCIe card connector into the Riser.




4. Install the PCIe riser into the server.  
For instructions, see [“Install a PCIe Riser Into PCIe Slot 1 or 2”](#) on page 78.

## ▼ Remove a PCIe Card From PCIe Slot 3

1. Remove the PCIe riser from the server.  
For instructions, see [“Remove a PCIe Riser From PCIe Slots 3 and 4”](#) on page 80
2. Remove the PCIe card from the riser.
  - a. Hold the riser in one hand and use your other hand to carefully remove the PCIe card connector from the riser.

- b. Disconnect the rear bracket attached to the PCIe card from the rear of the PCIe riser.



3. Place the PCIe card on an antistatic mat.




---

**Caution** – Whenever you remove a PCIe card, you should replace it with another PCIe card or a PCIe filler panel. Installing PCIe filler panels in vacant PCIe slots helps reduce the level of electromagnetic interference (EMI) emitted by the server. For instructions for installing PCIe filler panels, see [“Removing and Installing Server Filler Panels”](#) on page 143.

---

## ▼ Install a PCIe Card in PCIe Slot 3

1. Retrieve the PCIe card and riser you to install.
2. Insert the rear bracket that is attached to the PCIe card into the PCIe riser.
3. Hold the riser in one hand and use your other hand to carefully insert the PCIe card connector into the riser.



**4. Install the PCIe riser.**

For instructions, see [“Install a PCIe Riser Into PCIe Slots 3 and 4”](#) on page 82.


## ▼ Remove the Internal HBA Card From PCIe Slot 4

**1. Remove the PCIe riser from slots 3 and 4.**

For instructions, see [“Remove a PCIe Riser From PCIe Slots 3 and 4”](#) on page 80.

**2. Remove the internal host bus adapter card from the riser.**


- a. Hold the riser in one hand and use your other hand to carefully remove the card from slot 4 of the riser.
- b. Disconnect the rear bracket attached to the PCIe card from the rear of the PCIe riser.



3. Place the PCIe card on an antistatic mat.

## ▼ Install the Internal HBA Card in PCIe Slot 4

1. Retrieve the host bus adapter (HBA) card and riser you to install.
2. Insert the rear bracket that is attached to the internal HBA card into the rear connector on the PCIe riser.
3. Insert the internal HBA card connector into the bottom connector on the riser.



#### 4. Install the PCIe riser.

For instructions, see [“Install a PCIe Riser Into PCIe Slots 3 and 4”](#) on page 82.

---

## Servicing the DVD Drive (CRU)

---

**Note** – The DVD drive is only available in the four-drive systems.

---

The DVD drive is accessible from the front panel of the system.

---



**Caution** – These procedures require that you handle components that are sensitive to electrostatic discharge. This sensitivity can cause the components to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Take Antistatic Measures”](#) on page 42.

---



**Caution** – Ensure that all power is removed from the server before removing or installing the DVD drive or damage to the drive might occur. You must disconnect all power cables from the system before performing these procedures.

---

The following procedures are provided in this section:

- [“Remove the DVD Drive”](#) on page 91.
- [“Install the DVD Drive”](#) on page 93.

#### Related Information


- [“Disconnect Cables From the Server”](#) on page 39
- [“Extend the Server to the Maintenance Position”](#) on page 39
- [“Open the Server Fan Door”](#) on page 43

### ▼ Remove the DVD Drive

1. Remove any media from the DVD drive.
2. Prepare the server for service.

- a. Power off the server and disconnect the power cords from the power supplies.  
See [“Powering Down the Server”](#) on page 33.
  - b. Extend the server to the maintenance position.  
See [“Extend the Server to the Maintenance Position”](#) on page 39.
  - c. Attach an antistatic wrist strap to your wrist and then to a metal area on the chassis.  
See [“Take Antistatic Measures”](#) on page 42.
  - d. Remove the server top cover.  
See [“Remove the Server Top Cover”](#) on page 43.
3. Locate the DVD drive [1].
  4. Disconnect the cable from the rear of the DVD [2].

**FIGURE:** Removing the DVD Drive



5. To disengage the DVD drive from the chassis, press and hold the release tab on the rear of the DVD drive up slightly [3].
6. Gently push the DVD drive toward the front of the server, slide it out of the server, and place it on an antistatic mat [4].
7. Place the DVD drive on an antistatic mat.

#### **Related Information**

- [“Install the DVD Drive” on page 93](#)

## ▼ Install the DVD Drive

1. Push the DVD drive into the chassis until the release tab on the rear of the DVD drive engages the chassis with an audible click (see [FIGURE: Removing the DVD Drive on page 92](#) [4]).
2. Reconnect the DVD drive cable [2].
3. Return the server to operation.
  - a. **Install the server top cover.**  
See [“Install the Server Top Cover” on page 145](#).
  - b. **Close the fan door.**
  - c. **Return the server to the normal rack position.**  
See [“Return the Server to the Normal Rack Position” on page 148](#).
  - d. **Reconnect the power cords to the server power supplies and reconnect the data cables.**  
See [“Reconnect Data Cables and Power Cords” on page 149](#).
  - e. **Power on the server.**  
See [“Power On the Server” on page 150](#).  
Verify that the Power/OK status indicator is steady on.

#### **Related Information**

- [“Remove the DVD Drive” on page 91](#)

---

# Servicing the Internal USB Flash Drives (CRU)



---

**Caution** – These procedures require that you handle components that are sensitive to static discharge. This sensitivity can cause the component to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Take Antistatic Measures”](#) on page 42.

---



---

**Caution** – Ensure that all power is removed from the server before removing or installing a flash drive or damage to the drive might occur. You must disconnect all power cables from the system before performing these procedures.

---

The following procedures are provided in this section:

- [“Servicing the Oracle System Assistant USB Flash Drive”](#) on page 94
- [“Remove an Internal USB Flash Drive”](#) on page 95
- [“Install an Internal USB Flash Drive”](#) on page 95

## Related Information

- [“Extend the Server to the Maintenance Position”](#) on page 39
- [“Remove the Server Top Cover”](#) on page 43

## Servicing the Oracle System Assistant USB Flash Drive

If the Oracle System Assistant software is corrupted on the USB flash drive, you should try to repair it before replacing the USB flash drive.


For instructions for troubleshooting and repairing Oracle System Assistant, see the Oracle System Assistant troubleshooting information in the *Oracle X4 Series Servers Administration Guide* at <http://www.oracle.com/goto/x86AdminDiag/docs>.

## ▼ Remove an Internal USB Flash Drive

The server can be equipped with up to two internal USB flash drives. Before you remove a the USB flash drive on which Oracle System Assistant is installed, review [“Servicing the Oracle System Assistant USB Flash Drive”](#) on page 94

1. **Prepare the server for service.**
  - a. **Power off the server and disconnect the power cords from the power supplies.**  
See [“Powering Down the Server”](#) on page 33
  - b. **Extend the server to the maintenance position.**  
See [“Extend the Server to the Maintenance Position”](#) on page 39.
  - c. **Attach an antistatic wrist strap to your wrist and then to a metal area on the chassis.**  
See [“Take Antistatic Measures”](#) on page 42.
  - d. **Remove the server top cover.**  
See [“Remove the Server Top Cover”](#) on page 43.
2. **To access the USB flash drives, remove the USB flash drive cover [1].**

**FIGURE:** Removing an Internal USB Flash Drive



3. **Grasp the USB flash drive and pull it out of the internal USB port [2].**

## ▼ Install an Internal USB Flash Drive

1. **Unpack the replacement USB flash drive.**

2. Insert the USB flash drive into the internal USB port (see [FIGURE: Removing an Internal USB Flash Drive](#) on page 95 [2]).
3. Install the USB flash drive cover [1].
4. Return the server to operation.
  - a. Install the server top cover.  
See “[Install the Server Top Cover](#)” on page 145.
  - b. Close the fan door.
  - c. Return the server to the normal rack position.  
See “[Return the Server to the Normal Rack Position](#)” on page 148.
  - d. Reconnect the power cords to the server power supplies and reconnect the data cables.  
See “[Reconnect Data Cables and Power Cords](#)” on page 149.
  - e. Power on the server.  
See “[Power On the Server](#)” on page 150.  
Verify that the Power/OK status indicator is steady on.
5. If the USB flash drive that you replaced was the Oracle System Assistant USB flash drive, you need reinstall Oracle System Assistant on the new USB flash drive. For instructions, see the procedures for restoring Oracle System Assistant in the *Oracle X4 Series Servers Administration Guide* at <http://www.oracle.com/goto/x86AdminDiag/docs>.

---

## Servicing the Battery (CRU)

The battery maintains system time when the server is powered off and a time server is unavailable. If the server fails to maintain the proper time when the server is powered off and not connected to a network, replace the battery.



---

**Caution** – Ensure that all power is removed from the server before removing or installing the battery. You must disconnect the power cables from the system before performing these procedures.

---

The following procedures are provided in this section:

- “[Remove the Battery](#)” on page 97

- “Install the Battery” on page 98

### Related Information

- “Extend the Server to the Maintenance Position” on page 39
- “Remove the Server Top Cover” on page 43

## ▼ Remove the Battery

### 1. Prepare the server for service.

- a. Power off the server and disconnect the power cords from the power supplies.  
See “Powering Down the Server” on page 33.

- b. Extend the server to the maintenance position.

See “Extend the Server to the Maintenance Position” on page 39.

- c. Attach an antistatic wrist strap to your wrist and then to a metal area on the chassis.


See “Take Antistatic Measures” on page 42.

- d. Remove the server top cover.

See “Remove the Server Top Cover” on page 43.

2. To dislodge the battery from the retainer, place your finger under the side of the battery nearest the rear of the server [1] and gently lift the battery up and out of the retainer [2].

FIGURE: Removing the Battery



## ▼ Install the Battery

1. **Unpack the replacement battery.**
2. **Press the new battery into the battery retainer with the positive side (+) facing up** (see [FIGURE: Removing the Battery on page 97\[1\]](#)).
3. **If the service processor is configured to synchronize with a network time server using the Network Time Protocol (NTP), the Oracle ILOM clock will be reset as soon as the server is powered on and connected to the network; otherwise, proceed to the next step.**
4. **If the service processor is not configured to use NTP, you must do the following:**
  - a. **Reset the Oracle ILOM clock using the Oracle ILOM CLI or the web interface.**

For instructions, see the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at: <http://www.oracle.com/goto/ILOM/docs>.
  - b. **Use the BIOS Setup Utility to reprogram the host clock.**

For the BIOS Main menu screen that supports this procedure, see the *Oracle X4 Series Servers Administration Guide* at <http://www.oracle.com/goto/x86AdminDiag/docs>.
5. **Return the server to operation.**
  - a. **Install the server top cover.**

See “[Install the Server Top Cover](#)” on page 145.
  - b. **Close the fan door.**
  - c. **Return the server to the normal rack position.**

See “[Return the Server to the Normal Rack Position](#)” on page 148.
  - d. **Reconnect the power cords to the server power supplies and reconnect the data cables.**

See “[Reconnect Data Cables and Power Cords](#)” on page 149.
  - e. **Power on the server.**

See “[Power On the Server](#)” on page 150.

Verify that the Power/OK status indicator is steady on.

---

**Note** – On first boot, use the BIOS Setup utility to reset the server host time.

---

# Servicing FRUs

---

The following sections describe how to service field-replaceable units (FRUs). You must power down the system and disconnect the AC power cords from the server before servicing any of these components.

---

**Note** – Only Oracle authorized service personnel should service FRUs.

---

Description	Link
Identify FRU locations.	<a href="#">“FRU Locations” on page 99</a>
Service the processor(s).	<a href="#">“Servicing Processors (FRU)” on page 100</a>
Service the disk backplane.	<a href="#">“Servicing the Disk Backplane (FRU)” on page 117</a>
Service the front indicator module.	<a href="#">“Servicing the Front Indicator Module (FRU)” on page 125</a>
Service the motherboard.	<a href="#">“Servicing the Motherboard (FRU)” on page 127</a>
Service the server SAS cables.	<a href="#">“Servicing the SAS Cables (FRUs)” on page 138</a>

---

## Related Information


- [“Servicing CRUs That Do Not Require Server Power-Off” on page 45](#)
- [“Servicing CRUs That Require Server Power-Off” on page 61](#)

---

## FRU Locations

The locations of the FRUs are shown in the following figure.

**FIGURE:** FRU Locations



**Figure Legend**

---

1	Heatsink(s) <b>Note:</b> In single-processor systems, neither a heatsink nor a processor socket filler are installed in the socket for processor 1 (P1). To protect the delicate processor socket pins, the cover that comes on the motherboard from manufacturing is left in place.	4	Front Indicator Module (FIM) (FRU)
2	Processor(s) (FRU) <b>Note:</b> In single-processor systems, the processor is installed in socket 0 (P0).	5	Disk backplane (FRU)
3	Motherboard (FRU)	6	Not applicable

---

## Servicing Processors (FRU)

This section describes how to remove and install the processors.

In addition to the service procedures included here, you can see animations that show how to remove and install the processors.

**PLAY the ANIMATION**

To play the Sun Server X4-2 Service Animations go to:

[http://docs.oracle.com/cd/E36975\\_01/html/E49470/index.html](http://docs.oracle.com/cd/E36975_01/html/E49470/index.html)



---

**Caution** – Ensure that all power is removed from the server before removing or installing a processor. You must disconnect the power cables from the server before performing these procedures.

---



---

**Caution** – These procedures require that you handle components that are sensitive to electrostatic discharge. This sensitivity can cause the components to fail. To avoid damage, ensure that you follow antistatic practices as described in “[Take Antistatic Measures](#)” on page 42.

---

---

**Note** – On single-processor systems, neither a heatsink nor a processor filler cover are installed in the processor socket 1 (P1). To protect the delicate processor socket pins, the cover that comes on the motherboard from manufacturing is left in place.

---

These following sections provide information to assist you when replacing a processor:

- “[Selecting the Correct Processor Removal/Replacement Tool](#)” on page 102
- “[Remove a Processor](#)” on page 106
- “[Install a Processor](#)” on page 112

#### **Related Information**

- “[Disconnect Cables From the Server](#)” on page 39
- “[Take Antistatic Measures](#)” on page 42
- “[Remove the Server From the Rack](#)” on page 41
- “[Remove the Server Top Cover](#)” on page 43

# Selecting the Correct Processor Removal/Replacement Tool



---

**Caution** – The correct processor removal/replacement tool must be used to remove and replace a processor; otherwise, the processor or the processor socket might be damaged.

---

Selecting the correct processor removal/replacement tool is a two-step process. First you determine the size of the processor that is being replaced, then you select the removal/replacement tool that fits that size.

The processors supported by the Sun Server X4-2 come in two sizes. The processors with 10 or fewer cores are smaller than the processors with 12 cores. You can determine the size of the processor that you are going to remove and replace in either of two ways:

- Use Oracle Integrated Lights Out Manager (ILOM) to display processor information.

For instructions for using Oracle ILOM to display processor information, see the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library.


Or

- Visually check the size of the processor installed in the server.

This requires that you remove the processor heatsink and open the processor independent loading mechanism (ILM) assembly that holds the processor in the socket. For instructions, see [“Remove a Processor” on page 106](#). This is the same procedure that you will use when you remove the processor.

If you choose to visually check the size of the processor, refer to the next two figures to see how to distinguish the smaller processors from the larger processors. [FIGURE: Smaller Processor Installed in a Motherboard Processor Socket on page 103](#) shows a smaller processor installed. Notice that the right and left edges of the processor are within the boundaries of the processor alignment brackets.

**FIGURE:** Smaller Processor Installed in a Motherboard Processor Socket




**Figure Legend**

- 
- 1 Processor alignment brackets
  - 2 Processor left and right edges are within alignment bracket boundaries
- 

**FIGURE:** Larger Processor Installed in a Motherboard Processor Socket on page 104 shows a larger processor installed. Notice that the right and left edges of the processor extend beyond the boundaries of the processor alignment brackets.

**FIGURE:** Larger Processor Installed in a Motherboard Processor Socket




**Figure Legend**

- 
- 1** Processor alignment brackets
  - 2** Processor left and right edges extend beyond alignment bracket boundaries
- 

After you have determined the size of the processor installed in your server, select the correct processor removal/replacement tool. Like the processors, the processor removal/replacement tool also comes in two sizes. The tool for the smaller processors (processors with 10 or fewer cores) is color-coded green. The tool for the larger processors (12-core processors) is color-coded pink. See [FIGURE: Color-Coded Processor Removal/Replacement Tools](#) on page 105.

**FIGURE:** Color-Coded Processor Removal/Replacement Tools



**Figure Legend**

- 
- 1 Green, color-coded removal/replacement tool for the smaller processors—models E5-2609 V2 (4-core), E5-2630 V2 (6-core), E5-2650 V2 (8-core), and E5-2690 V2 (10-core)
  - 2 Pink, color-coded removal/replacement tool for the larger processor—model E5-2697 V2 (12-core)
- 



**Caution** – The pink color-coded processor removal/replacement tool must be used only with the larger processor (the 12-core processor). Likewise, the green color-coded removal/replacement tool must be used only with smaller processors (the 4-, 6-, 8-, and 10-core processors); otherwise, the processor or the processor socket might be damaged.

---

The following table provides an easy reference for matching a processor (by number of cores or model number) to the correct processor removal/replacement tool.

**TABLE:** Processor Model Numbers by Number of Cores

Processor Cores	Processor Model Number	Processor Removal/Replacement Tool Color Code
4-core	E5-2609 V2	Green
6-core	E5-2630 V2	
8-core	E5-2650 V2	
10-core	E5-2690 V2	
12-core	E5-2697 V2	Pink

**Note** – The correct processor removal/replacement tool is included in the box with the replacement processor. Additionally, both removal/replacement tools ship with replacement motherboards.

## ▼ Remove a Processor



**Caution** – Processors should be removed only by an Oracle qualified service technician.



**Caution** – Processor removal and replacement must be done using the correct removal/replacement tool; otherwise, damage might result to the processor or the processor socket. For information on how to select the correct removal/replacement tool, see [“Selecting the Correct Processor Removal/Replacement Tool”](#) on page 102.



**Caution** – Be careful not to touch the processor socket pins. The processor socket pins are very fragile. A light touch can bend the processor socket pins and damage the board beyond repair. Always use the processor removal/replacement tool to remove and replace the processor.

### 1. Prepare the server for service.

- a. **Power off the server and disconnect the power cords from the power supplies.**

See [“Powering Down the Server”](#) on page 33.

**b. Extend the server to the maintenance position.**

See “Extend the Server to the Maintenance Position” on page 39.

**c. Attach an antistatic wrist strap to your wrist, and then to a metal area on the chassis.**

See “Take Antistatic Measures” on page 42.

**d. Remove the server top cover.**

“Remove the Server Top Cover” on page 43.

**2. Identify the location of the faulty processor by pressing the Fault Remind button on the motherboard.**

---

**Note** – When the Fault Remind button is pressed, a LED located next to the Fault Remind button lights green to indicate that there is sufficient voltage present in the fault remind circuit to light any fault LEDs that were lit due to a failure. If this LED fails to light when you press the Fault Remind button, it is likely that the capacitor powering the fault remind circuit has lost its charge. This can happen if the Fault Remind button is pressed for a long time with fault LEDs lit or if power has been removed from the server for more than 15 minutes.

---


The processor fault LEDs are located next to the processor(s).

- If the processor fault LED is off, then the processor is operating properly.
- If the processor fault LED is on (amber), then the processor is faulty and should be replaced.

---


**Note** – Processor 0 (P0) is on the left side when viewing the server from the front.

---



3. Gently press down on the top of the heatsink to counteract the pressure of the captive spring-loaded screws that secure the heatsink to the motherboard and loosen the four Phillips captive screws in the heatsink for the processor [1].

Using a No. 2 Phillips screwdriver, turn the screws counterclockwise alternately one and one half turns until they are fully removed.



4. To separate the heatsink from the top of the processor, gently twist the heatsink left and right, while pulling upward, and then lift off the heatsink and place it upside down on a flat surface [1].

A thin layer of thermal grease separates the heatsink and the processor. This grease acts as an adhesive.

---

**Note** – Do not allow the thermal grease to contaminate the work space or other components.

---

5. Use an alcohol pad to clean the thermal grease from the underside of the heatsink.

Be careful not to get the thermal grease on your fingers.



---

**Caution** – Failure to clean the heatsink prior to removing the processor could result in the accidental contamination of the processor socket or other components. Also, be careful not to get the grease on your fingers as this could result in contamination of components.

---

6. Disengage the processor ILM assembly hinge lever on the right side of the processor socket (viewing the server from the front) by pushing down on the lever and moving it to the side away from the processor, and then rotating the lever upward [2].
7. Disengage the processor ILM assembly load lever on the left side of the processor socket (viewing the server from the front) by pushing down on the lever and moving it to the side away from the processor, and then rotating the lever upward [2].
8. To lift the processor ILM assembly load plate off of the processor socket, rotate the ILM hinge lever on the right side of the processor toward the closed position (the ILM load plate is lifted up as the hinge lever is lowered toward the closed position) and carefully swing the ILM load plate to the fully open position [3].



---

**Caution** – Whenever you remove a processor, you should replace it with another processor and reinstall the processor heatsink; otherwise, the server might overheat due to improper airflow. For instructions for installing a processor, see [“Install a Processor”](#) on page 112.

---

9. To remove the processor from the processor socket, acquire the correct processor removal/replacement tool and perform the following steps:



---

**Caution** – Before removing the processor, ensure that you are using the correct color-coded processor removal/replacement tool. For information on how to select the correct processor removal/replacement tool, see [“Selecting the Correct Processor Removal/Replacement Tool”](#) on page 102.

---

- a. Locate the button in the center of the top of the processor removal/replacement tool and press it to the down position (see [FIGURE: Removing a Processor](#) on page 111 [1]).

- b. Properly position the tool over the processor socket and lower it into place over the processor socket [2].

To properly position the tool over the processor socket, rotate the tool until the green or pink triangle (depending on which color-coded tool is being used) on the side of the tool is facing the front of the server and it is over the left side of the processor socket when viewing the server from the front.

- c. Press the release lever on the tool to release the center button and engage the processor [3].

An audible click indicates that the processor is engaged.

- d. Grasp the tool by the sides and remove it from the server [4].
- e. Turn the tool upside down and verify that it contains the processor [5].
- f. While holding the processor tool up side down, press the center button on the tool to release the processor [5].
- g. Carefully grasp the processor by the front and back edges, lift it out of the tool and place it with the circuit side down (the installed orientation) on a clean antistatic mat [6].



---

**Caution** – Ensure that the antistatic mat is clean and free of debris; otherwise, the processor pins might be damaged.

---

- h. Carefully clean the thermal grease off the top of the processor.




---

**Caution** – The following figure shows the green color-coded processor removal/replacement tool. If you are removing a 12-core processor, you must use the pink color-coded processor removal/replacement tool; otherwise, damage might result to the processor or the processor socket. For information on how to select the correct processor removal/replacement tool, see [“Selecting the Correct Processor Removal/Replacement Tool”](#) on page 102.

---

FIGURE: Removing a Processor



### Related Information

- [“Install a Processor” on page 112](#)

## ▼ Install a Processor



---

**Caution** – Processors should be installed only by an Oracle qualified service technician.

---



---

**Caution** – Processor removal and replacement must be done using the correct removal/replacement tool; otherwise, damage might result to the processor or the processor socket. For information on how to select the correct removal/replacement tool, see [“Selecting the Correct Processor Removal/Replacement Tool”](#) on page 102.

---



---

**Caution** – Be careful not to touch the processor socket pins. The processor socket pins are very fragile. A light touch can bend the processor socket pins and damage the board beyond repair. Always use the processor removal/replacement tool to remove and replace the processor.

---

1. **Attach an antistatic wrist strap to your wrist, and then to a metal area on the chassis.**

See [“Take Antistatic Measures”](#) on page 42.

2. **Unpack the replacement processor and place it on an antistatic mat.**

3. **Ensure that the replacement processor is identical to the processor that was removed.**

For a description of the processors supported by the server, see the *Sun Server X4-2 Installation Guide*, [“Server Components”](#) on page 20.

4. **Ensure that the two processor ILM assembly levers and the ILM assembly load plate are in the fully open position.**

For instructions for opening the processor ILM assembly levers and the load plate, see [Step 6](#) through [Step 8](#) of [“Remove a Processor”](#) on page 106.

5. **To install the replacement processor into the processor removal/replacement tool, acquire the correct removal/replacement tool and perform the following steps:**



---

**Caution** – Before installing the processor, ensure that you are using the correct color-coded processor removal/replacement tool. For information on how to select the correct processor removal/replacement tool, see [“Selecting the Correct Processor Removal/Replacement Tool”](#) on page 102.

---

- a. **Press the button in the center of the tool to the down position** (see [FIGURE: Installing a Processor on page 114 \[1\]](#)).
- b. **Turn the tool upside down, grasp the processor by its front and back edges and position the processor (circuit side up) in the tool so that the triangle on the corner of the processor aligns with the triangle on the side of the processor removal/replacement tool [2].**
- c. **Lower the processor into the tool and press the tool release lever to release the center button and engage the processor [3].**  
An audible click indicates that the processor is locked in place.
- d. **Properly position the tool over the processor socket and lower it into place [4].**  
To properly position the tool in the processor socket, rotate the tool until the green or pink triangle (depending on which color-coded tool is being used) on the side of the tool is facing the front of the server and it is over the left side of the processor socket (when viewing the server from the front) and lower the tool into the processor socket.
- e. **Press the center button in the tool down to release the processor so that it is installed in the socket [5].**
- f. **Remove the processor removal/replacement tool [6].**




---

**Caution** – The following figure shows the green color-coded processor removal/replacement tool. If you are installing a 12-core processor, you must use the pink color-coded processor removal/replacement tool; otherwise, damage might result to the processor or the processor socket. For information on how to select the correct processor removal/replacement tool, see [“Selecting the Correct Processor Removal/Replacement Tool” on page 102](#).

---

**FIGURE:** Installing a Processor




**6. Visually check the alignment of the processor in the socket.**

When properly aligned, the processor sits flat in the processor socket.



**Caution** – Do not press down on the processor. Irreparable damage to the processor or motherboard might occur from excessive downward pressure. Do not forcibly seat the processor into the socket. Excessive downward pressure might damage the socket pins.

7. Swing the processor ILM assembly load plate into the closed position [1].  
Ensure that the load plate sits flat around the periphery of the processor.



8. Engage the processor ILM assembly load lever on the left side of the socket (viewing the server from the front) by rotating it downward and slipping it under the catch [2].
9. Engage the processor ILM assembly hinge lever on the right side of the socket (viewing the server from the front) by rotating it downward and slipping it under the catch [2].
10. Use the syringe (supplied with the new or replacement processor) to apply approximately 0.1 ml of thermal grease to the center of the top of the processor.  
To measure 0.1 ml of thermal grease, use the graduated scale on the thermal grease syringe.

---

**Note** – Do not distribute the grease; the pressure of the heatsink will do so for you when you install it.

---

11. **Inspect the heatsink for dust and lint.**  
Clean the heatsink if necessary.

12. Orient the heatsink so that the screws line up with the mounting posts [3].

---

**Note** – The processor heatsink is not symmetrical.

---

13. Carefully position the heatsink on the processor, aligning it with the mounting posts to reduce movement after it makes initial contact with the layer of thermal grease [3].



---

**Caution** – Avoid moving the heatsink after it has contacted the top of the processor. Too much movement could disturb the layer of thermal grease, causing voids, and leading to ineffective heat dissipation and component damage.

---

14. Tighten the four Phillips screws with a No. 2 Phillips screwdriver alternately one-half turn until fully seated.

15. Return the server to operation.

a. Install the server top cover.

See [“Install the Server Top Cover”](#) on page 145.

b. Close the server fan door.

c. Return the server to the normal rack position.

See [“Return the Server to the Normal Rack Position”](#) on page 148.

d. Reconnect the data cables and reconnect the power cords to the server power supplies.

See [“Reconnect Data Cables and Power Cords”](#) on page 149.

e. Power on the server.

See [“Power On the Server”](#) on page 150.

Verify that the Power/OK status indicator is steady on.

16. Use Oracle ILOM to clear server processor faults.

Refer to the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library for more information about the following steps.

- a. To show server faults, log in to the server as root using the Oracle ILOM CLI, and type the following command to list all known faults on the server:

```
-> show /PS/faultmgmt
```

The server lists all known faults, for example:

```
-> show /PS/faultmgmt  
Targets:  
  0 (/SYS/MB/P0)  
Properties:  
Commands:  
  cd  
  show
```

Alternatively, to list all known faults in the server, log into the Oracle Solaris OS and issue the `fmadm faulty` command, or log into the Oracle ILOM service processor from the Oracle ILOM Fault Management Shell and issue the `fmadm faulty` command.

- b. To clear the fault identified in Step 16.a, type the following command:

```
-> set /System/MB/P0 clear_fault_action=true
```

For example:

```
-> set /System/MB/P0 clear_fault_action=true  
Are you sure you want to clear /SYS/MB/P0 9y/n)? y  
Set 'clear_fault_action' to 'true'
```

Alternatively, to clear all known faults in the server, log into the Oracle Solaris OS and issue the `fmadm repair` command, or log into the Oracle ILOM service processor from the Oracle ILOM Fault Management Shell and issue the `fmadm repair` command.

### Related Information

- [“Remove a Processor” on page 106](#)

---

## Servicing the Disk Backplane (FRU)

This section describes how to remove and install a disk backplane.

In addition to the service procedures included here, you can see animations that show how to remove and install a disk backplane.

## PLAY the ANIMATION

To play the Sun Server X4-2 Service Animations go to:

[http://docs.oracle.com/cd/E36975\\_01/html/E49470/index.html](http://docs.oracle.com/cd/E36975_01/html/E49470/index.html)



---

**Caution** – Ensure that all power is removed from the server before removing or installing a disk backplane. You must disconnect the power cables from the server before performing these procedures.

---

- “Disk Backplane Configurations” on page 118
- “Remove the Disk Backplane” on page 119
- “Install the Disk Backplane” on page 122


### Related Information

- “Disconnect Cables From the Server” on page 39
- “Take Antistatic Measures” on page 42
- “Extend the Server to the Maintenance Position” on page 39
- “Open the Server Fan Door” on page 43

## Disk Backplane Configurations

The server has one or two disk backplanes depending on the number of storage drives installed. On servers with four or fewer storage drives, only one disk backplane is needed. Servers with five or more storage drives require two disk backplanes. The following figure shows a configuration with two disk backplanes, DBP0 and DBP1. Storage drives 0 through 3 plug into DBP0. Storage drives 4 through 7 plug into DBP1.

**FIGURE:** Disk Backplane Configurations



## ▼ Remove the Disk Backplane

---

**Note** – A server with four or fewer storage drives has only one disk backplane.

---

1. **Prepare the server for service.**
  - a. **Power off the server and disconnect the power cords from the power supplies.**  
See [“Powering Down the Server”](#) on page 33.
  - b. **Extend the server to the maintenance position.**  
See [“Extend the Server to the Maintenance Position”](#) on page 39.
  - c. **Attach an antistatic wrist strap to your wrist, and then to a metal area on the chassis.**  
See [“Take Antistatic Measures”](#) on page 42.
  - d. **Open the server fan door to gain access to the disk backplanes.**
2. **Pull each storage drive out far enough to disengage it from the disk backplane.**  
See [“Remove a Storage Drive”](#) on page 47.

---

**Note** – It is not necessary to completely remove the storage drives from the server; simply pull them out far enough to disengage them from the disk backplane. If you do remove the storage drives from the server, make a note of their locations so that you can reinstall them in the same locations.

---

**3. Remove all four fan modules.**

See [“Remove a Fan Module”](#) on page 51.

**4. Starting with the top disk backplane if servicing a server with two disk backplanes, disconnect the SAS cable from each disk backplane [1].**


See [FIGURE: Removing the Disk Backplane](#) on page 121.

---

**Note** – If you are going to remove and replace both disk backplanes, before disconnecting any backplane cables, make a note of, or tag, which cables connect to the top disk backplane and which cables connect to the bottom disk backplane for reference when you install the replacement disk backplanes.

---

FIGURE: Removing the Disk Backplane



5. Disconnect the disk backplane power cable from the disk backplane [2].
6. Disconnect the disk backplane LED cable from the disk backplane [3].
7. If the server has a DVD drive, disconnect the DVD drive power cable from the disk backplane [4].

---

**Note** – Servers with a DVD drive have only one disk backplane.

---

8. Using just your thumb and fingers, loosen the two captive thumb screws that secure the disk backplane to the chassis [5].
9. Slide the backplane toward the front of the server to release it from the three mushroom-shaped standoffs and lift it out of the chassis [6].
10. Place the disk backplane on an antistatic mat.
11. If the server has a second disk backplane, repeat [Step 4](#) through [Step 10](#) to remove it.


#### **Related Information**

- [“Install the Disk Backplane”](#) on page 122

## ▼ Install the Disk Backplane

1. Starting with the bottom disk backplane if servicing a server with two disk backplanes, lower the backplane into the server and position it to engage the three mushroom-shaped standoffs [1].

**FIGURE:** Installing the Disk Backplane



2. Using just your thumb and fingers, tighten the two captive thumb screws to secure the disk backplane to the chassis [2].
3. If the server has a DVD drive, reconnect the DVD drive power cable to the disk backplane [3].
4. Reconnect the disk backplane LED cable to the disk backplane [4].
5. Reconnect the disk backplane power cable to the disk backplane [5].

6. Reconnect the SAS cable to the disk backplane [6].
7. If the server has more than four storage drives, repeat all of the preceding steps (with the exception of [Step 3](#), which directs you to reconnect the DVD drive power cable) to install the second disk backplane.  
A server that has two disk backplanes does not have a DVD drive installed.
8. Reinstall all of the storage drives into the storage drive cage.  
See [“Install a Storage Drive”](#) on page 49.
9. Install all four fan modules.  
See [“Install a Fan Module”](#) on page 54.
10. Return the server to operation.
  - a. Close the server fan door.
  - b. Return the server to the normal rack position.  
See [“Return the Server to the Normal Rack Position”](#) on page 148.
  - c. Reconnect the data cables to the server and reconnect the power cords to the server power supplies.  
See [“Reconnect Data Cables and Power Cords”](#) on page 149.
  - d. Power on the server.  
See [“Power On the Server”](#) on page 150.  
Verify that the Power/OK status indicator is steady on.

---

**Note – IMPORTANT:** After replacing disk backplane 0 (DBP0), you must manually program the product serial number (PSN) into the new disk backplane. This is necessary because DBP0 is the primary member of a select group of components for maintaining the PSN for service entitlement. On systems with two disk backplanes, disk backplane 1 (DBP1) does *not* have this requirement. To propagate the FRU top-level indicator (TLI) data to the new DBP0, you must reset the Oracle ILOM service processor (SP). For instructions on resetting the SP, see the Oracle Integrated Lights Out Manager (ILOM) 3.1 Configuration and Maintenance Guide at <http://www.oracle.com/goto/ILOM/docs>

---

### Related Information

- [“Remove the Disk Backplane”](#) on page 119

---

# Servicing the Front Indicator Module (FRU)



---

**Caution** – Ensure that all power is removed from the server before removing or installing a front indicator module. You must disconnect the power cables from the server before performing these procedures.

---

Follow these procedures to remove and install the front indicator module (FIM).

- [“Remove the Front Indicator Module” on page 125](#)
- [“Install the Front Indicator Module” on page 127](#)

## Related Information

- [“Disconnect Cables From the Server” on page 39](#)
- [“Remove the Server From the Rack” on page 41](#)
- [“Take Antistatic Measures” on page 42](#)
- [“Open the Server Fan Door” on page 43](#)

## ▼ Remove the Front Indicator Module

1. **Prepare the server for service.**
  - a. **Power off the server and disconnect the power cords from the power supplies.**  
See [“Powering Down the Server” on page 33](#).
  - b. **Extend the server to the maintenance position.**  
See [“Extend the Server to the Maintenance Position” on page 39](#).
  - c. **Attach an antistatic wrist strap to your wrist, and then to a metal area on the chassis.**  
See [“Take Antistatic Measures” on page 42](#).
2. **To remove the top cover from the storage drive cage, do the following:**
  - a. **Remove the six Phillips screws from the top of the storage drive cage [1].**  
There are three Phillips screws on each side of the storage drive cage.


b. Open the server fan door.

See “Open the Server Fan Door” on page 43.

c. To remove the storage drive cage cover, slide it forward (toward the front of the server) and lift it up.

3. Loosen the screw that secures the front indicator module (FIM) assembly to the server chassis [2].

**FIGURE:** Removing the Front Indicator Module



4. Carefully slide the FIM assembly toward the rear of the server enough to lift it over the Phillips screw and out of the server [2].

5. Disconnect the FIM cable from the FIM assembly and set the assembly aside [3].

6. Continue to “Install the Front Indicator Module” on page 127.

#### Related Information

- “Install the Front Indicator Module” on page 127

## ▼ Install the Front Indicator Module

1. **Attach an antistatic wrist strap to your wrist, and then to a metal area on the chassis.**  
See [“Take Antistatic Measures”](#) on page 42
2. **Unpack the replacement FIM and place it on an antistatic mat.**
3. **Connect the FIM cable to the replacement FIM assembly [3].**  
See [FIGURE: Removing the Front Indicator Module](#) on page 126.
4. **Carefully lower the FIM assembly into the chassis, position it over the Phillips screw in the server chassis, and slide it forward so all the LEDs, USB connectors, and Power On button fit into place on the server front panel [2].**
5. **Tighten the Phillips screw to secure the FIM assembly to the server chassis [2].**
6. **Place the storage drive cage cover over the server storage drive cage and install the six Phillips screws to secure the cover to the server.**  
There are three Phillips screws on each side of the storage drive cage.
7. **Ensure that server fan door is closed.**
8. **Return the server to operation.**
  - a. **Return the server to the normal rack position.**  
See [“Return the Server to the Normal Rack Position”](#) on page 148.
  - b. **Reconnect the data cables to the server and reconnect the power cords to the server power supplies.**  
See [“Reconnect Data Cables and Power Cords”](#) on page 149.
  - c. **Power on the server.**  
See [“Power On the Server”](#) on page 150.  
Verify that the Power/OK status indicator is steady on.

### **Related Information**

- [“Remove the Front Indicator Module”](#) on page 125

---

## Servicing the Motherboard (FRU)

Follow these procedures to remove and install the motherboard.



---

**Caution** – The motherboard should be serviced only by an Oracle qualified service technician.

---



---

**Caution** – Ensure that all power is removed from the server before removing or installing the motherboard. You must disconnect the power cables before performing these procedures.

---



---

**Caution** – These procedures require that you handle components that are sensitive to electrostatic discharge. This sensitivity can cause the components to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Take Antistatic Measures” on page 42](#).

---

- [“Remove the Motherboard” on page 128](#)
- [“Install the Motherboard” on page 135](#)

#### **Related Information**

- [“Remove the Server From the Rack” on page 41](#)
- [“Take Antistatic Measures” on page 42](#)
- [“Remove the Server Top Cover” on page 43](#)

## ▼ Remove the Motherboard



---

**Caution** – The motherboard should be serviced only by an Oracle qualified service technician.

---



---

**Caution** – Use the Oracle ILOM backup utility prior to removing the motherboard. This utility backs up the Oracle ILOM configuration of the service processor. For more information, see the Oracle ILOM 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.

---

### **1. Prepare the server for service.**

- a. Power off the server and disconnect the power cords from the power supplies.**

See [“Powering Down the Server” on page 33](#).

**b. Extend the server to the maintenance position.**

See [“Extend the Server to the Maintenance Position”](#) on page 39.

**c. Attach an antistatic wrist strap to your wrist, and then to a metal area on the chassis.**

See [“Take Antistatic Measures”](#) on page 42.

**d. Remove the server top cover.**

See [“Remove the Server Top Cover”](#) on page 43.

**2. Remove the following reusable components:**



---

**Caution** – During the motherboard removal procedure, it is important to label the power supplies with the slot numbers from which they were removed (PS0, PS1). This is required because the power supplies must be reinstalled into the same slots from which they were removed; otherwise, the server FRU top-level indicator (TLI) data might be lost. When a server requires service, the FRU TLI is used by Oracle to verify that the warranty on the server has not expired. For more information on the server FRU TLI, see [“FRU TLI Auto-Update”](#) on page 30.

---

**a. Fan modules**

For instructions, see [“Remove a Fan Module”](#) on page 51.


**b. Power supplies**

For instructions, see [“Remove a Power Supply”](#) on page 57.

**c. PCIe risers and attached PCIe cards**

For instructions, see [“Servicing PCIe Risers \(CRU\)”](#) on page 74.

**3. Disconnect the disk backplane power cable from the motherboard [1].**



4. Disconnect the disk backplane LED cable from the motherboard [2].
5. Disconnect the front indicator module (FIM) cable from the motherboard [3].
6. If the server has a DVD drive, do the following:
  - a. Disconnect the DVD drive cable from the motherboard [4].
  - b. Carefully lift the DVD drive cable out of the cable trough.

7. Disconnect the SAS cables from the internal HBA, and then carefully lift the SAS cables that you disconnected from the internal HBA out of the cable trough.
8. Remove the server mid-wall [5].
  - a. Using a No. 2 Phillips screwdriver, loosen the four green captive screws that secure the mid-wall to the server chassis.
  - b. Lift the mid-wall up slightly and pull in toward the front of the server to disengage it from the raised mushroom-shaped standoffs that are located on the server chassis sidewall (one on each end of the mid-wall).
  - c. Place the mid-wall, DVD cable, and SAS cables toward the front of the server and out of the way of the motherboard.
9. Remove the motherboard from the server chassis [6].
  - a. Grasp the middle of the air duct in the front and back and slide the motherboard toward the front of the server and lift it slightly to disengage it from the six mushroom-shaped standoffs that are located on the server chassis under the motherboard [6].
  - b. Lift the motherboard out of the server chassis and place it on an antistatic mat, and next to the replacement motherboard [6].
10. Remove the internal USB flash drives from the motherboard and install them on the replacement motherboard.

For instructions, see [“Servicing the Internal USB Flash Drives \(CRU\)”](#) on page 94.
11. Remove the DDR3 DIMMs from the motherboard and install them on the replacement motherboard.

For instructions, see [“Servicing the DIMMs \(CRU\)”](#) on page 62.

---


**Note** – Install the DDR3 DIMMs only in the sockets (connectors) that correspond to the sockets from which they were removed. Performing a one-to-one replacement of the DIMMs significantly reduces the possibility that the DIMMs will be installed in the wrong sockets. If you do not reinstall the DIMMs in the same sockets, server performance might suffer and some DIMMs might not be used by the server.

---

12. Remove the processors from the faulty motherboard.

For instructions, see [“Remove a Processor”](#) on page 106.
13. Remove the processor socket covers from the replacement motherboard and install the processors.

- a. Disengage the processor ILM assembly hinge lever on the right side of the processor socket (viewing the server from the front) by pushing down on the lever and moving it to the side away from the processor, and then rotating the lever upward [Frame 1].



- b. Disengage the processor ILM assembly load lever on the left side of the processor socket (viewing the server from the front) by pushing down on the lever and moving it to the side away from the processor, and then rotating the lever upward [1].
- c. To lift the processor ILM assembly load plate off of the processor socket, rotate the ILM assembly hinge lever on the right side of the processor toward the closed position (the load plate is lifted up as the hinge lever is lowered) and carefully swing the load plate to the fully open position [2].
- d. Grasp the top and underside of the processor socket cover with one hand (place your thumb against the underside of the cover), place your other thumb against the underside of the cover, and carefully push the cover out of the processor ILM assembly load plate [3].



---

**Caution** – Be careful not to allow the processor socket cover to fall into the processor socket as this could result in damage to the socket.

---

- e. **Install a processor into the socket from which you removed the processor socket cover.**

For instructions for installing a processor, see “Install a Processor” on page 112.

- f. **Repeat Step a through Step e above to remove the second processor socket cover from the replacement motherboard and install the second processor.**

**14. Install the processor socket covers on the faulty motherboard.**



---

**Caution** – The processor socket covers must be installed on the faulty motherboard; otherwise, damage might result to the processor sockets during handling and shipping.

---




---

**Caution** – Be careful not to allow the processor socket cover to fall into the processor socket as this could result in damage to the socket.

---

- a. **Open one of the processor ILM assemblies on the faulty motherboard [Frames 1 and 2].**



- b. Hold the processor ILM assembly load plate open with one hand and position the processor socket cover over the top of the load plate so that 1) the arrow on the processor socket cover is aligned with the arrow on the load plate and 2) the fasteners on one side of the cover (the fasteners are located on the underside of the cover) are inside the load plate (it does not matter which side), and use your thumb to press the other side of the processor socket cover into the load plate. [3].

You will hear a clicking sound when the processor socket cover snaps into place.

- c. Close the processor ILM assembly load plate [4 and 5].
- d. Repeat [Step a](#) through [Step c](#) above to install the second processor socket cover on the faulty motherboard.

#### Related Information

- [“Install the Motherboard”](#) on page 135

## ▼ Install the Motherboard




---

**Caution** – The motherboard should be installed only by an Oracle qualified service technician.

---

1. Attach an antistatic wrist strap to your wrist, and then to a metal area on the chassis.  
See [“Take Antistatic Measures”](#) on page 42.
2. Install the motherboard into the server chassis [1].
  - a. To install the motherboard into the server, grasp the middle of the air duct in the front and back and tilt the front of the motherboard up slightly and push it into the opening in the rear of the server chassis [1].
  - b. Lower the motherboard into the server chassis and slide it to the rear until it engages the six mushroom-shaped standoffs located on the server chassis under the motherboard [1].



c. Ensure that the indicators, controls, and connectors on the rear of the motherboard fit correctly into the rear of the server chassis.

3. Install the server mid-wall [2].

a. Ensure that the cables (SAS and DVD cable, if applicable) are running through the opening in the center of the mid-wall.

b. Position the mid-wall with the cables in front of the motherboard so that it engages the mushroom-shaped standoffs that are located on the server chassis sidewall (one for each side of the mid-wall).

- c. Place the FIM cable and the disk backplane power cable alongside the mid-wall next to their respective motherboard connectors.
  - d. Ensure that FIM cable and the disk backplane power cable are not pinched by the mid-wall and that they run beside the mid-wall and not under it; otherwise, the cables might be damaged.
  - e. To secure the mid-wall to the server chassis, tighten the four green captive screws.
4. Carefully place the SAS cable(s) that you disconnected from the internal HBA into the cable trough provided by the air duct on the motherboard.
  5. If the server has a DVD drive, carefully place the DVD drive cable into the cable trough provided by the air duct on the motherboard.
  6. If the server has a DVD drive, reconnect the DVD drive cable to the motherboard [3].
  7. Reconnect the front indicator module (FIM) cable to the motherboard [4].
  8. Reconnect the disk backplane LED cable to the motherboard [5].
  9. Reconnect the disk backplane power cable to the motherboard [6].
10. Reinstall the following reusable components:
- a. **PCIe risers and attached PCIe cards**  
For instructions, see [“Servicing PCIe Risers \(CRU\)”](#) on page 74.
  - b. **Power supplies**



---

**Caution** – When reinstalling power supplies, it is important to reinstall them into the slots from which they were removed during the motherboard removal procedure; otherwise, the server FRU top-level indicator (TLI) data might be lost. When a server requires service, the FRU TLI is used by Oracle to verify that the warranty on the server has not expired. For more information on the server FRU TLI, see [“FRU TLI Auto-Update”](#) on page 30.

---

For instructions, see [“Install a Power Supply”](#) on page 59.

**c. Fan modules**

For instructions, see [“Install a Fan Module”](#) on page 54.

**11. Return the server to operation.**

**a. Install the server top cover.**

See [“Install the Server Top Cover”](#) on page 145.

b. **Close the server fan door.**

c. **Return the server to the normal rack position.**

See “Return the Server to the Normal Rack Position” on page 148.

d. **Reconnect the data cables to the server and reconnect the power cords to the server power supplies.**

See “Reconnect Data Cables and Power Cords” on page 149.

e. **Power on the server.**

See “Power On the Server” on page 150.

Verify that the Power/OK status indicator is steady on.

---

**Note – IMPORTANT:** After replacing the motherboard, you might need to manually program the product serial number (PSN) into the new motherboard. This is necessary because the motherboard is a secondary member of a select group of components that maintain the PSN for service entitlement. If you have replaced more than one of the members of this select group during any given service procedure, a secondary group member might need to be programmed with the PSN. To propagate the FRU top-level indicator (TLI) data to the new motherboard, you must reset the Oracle ILOM service processor (SP). For instructions on resetting the SP, see the Oracle Integrated Lights Out Manager (ILOM) 3.1 Configuration and Maintenance Guide at <http://www.oracle.com/goto/ILOM/docs>

---

### Related Information

- “Remove the Motherboard” on page 128

---

## Servicing the SAS Cables (FRUs)



---

**Caution –** The system supplies power to the cables even when the server is powered off. To avoid personal injury or damage to the server, you must disconnect power cords before servicing the cables.

---

To remove and install cables, follow the procedures in these sections:

- “Remove Storage Drive SAS Cables” on page 139
- “Install Storage Drive SAS Cables” on page 141

## Related Information

- “Extend the Server to the Maintenance Position” on page 39
- “Take Antistatic Measures” on page 42
- “Remove the Server Top Cover” on page 43

## ▼ Remove Storage Drive SAS Cables


1. **Prepare the server for service.**
  - a. **Power off the server and disconnect the power cords from the power supplies.**  
See “Powering Down the Server” on page 33.
  - b. **Extend the server to the maintenance position.**  
See “Extend the Server to the Maintenance Position” on page 39.
  - c. **Attach an antistatic wrist strap to your wrist, and then to a metal area on the chassis.**  
See “Take Antistatic Measures” on page 42.
  - d. **Remove the server top cover.**  
See “Remove the Server Top Cover” on page 43.
2. **Remove all of the server fan modules.**  
See “Remove a Fan Module” on page 51.
3. **Remove the PCIe riser from PCIe slots 3 and 4.**  
See “Remove a PCIe Riser From PCIe Slots 3 and 4” on page 80.
4. **If the server has two disk backplanes, do the following; otherwise, proceed to the next step.**
  - a. **To disconnect the SAS cable from top disk backplane, press the latch, push in toward the connector, and then pull out to remove the cable [1].**

---

**Note** – Servers with four storage drives or fewer have only one disk backplane. Servers with more than four storage drives have two disk backplanes.

---

- b. **Remove the top disk backplane.**  
See “Remove the Disk Backplane” on page 119.
- c. **To disconnect the SAS cable from bottom disk backplane, press and hold the cable latch, push in toward the connector, and then pull out the cable [1].**




5. If the server has only one disk backplane, to disconnect the cable from disk backplane, press and hold the cable latch, push in toward the connector, and then pull out the SAS cable [1].
6. Disconnect the SAS cable(s) from the internal host bus adapter (HBA) [2].  
To disconnect the SAS cable(s) from the internal HBA card, press and hold the cable latches and then pull out the cables.
7. Carefully remove the SAS cables from the trough in the air duct [3].
8. Carefully pull the internal SAS cables through the mid-wall and remove them from the chassis [3].

### Related Information

- [“Install Storage Drive SAS Cables”](#) on page 141

## ▼ Install Storage Drive SAS Cables

1. Properly orient the ends of the SAS cables to connect to the disk backplane and the HBA, respectively.
2. Carefully push the SAS cables through the mid-wall and place them into the cable trough in the middle of the air duct [1].



3. Install the HDDs 0-3 cable.
  - a. Install the HDDs 0-3 cable connector into the bottom disk backplane [2].
  - b. Plug the HDDs 0-3 cable connector into the connector on the left side of the HBA card (the connector that is farthest from the power supplies) [3].
4. If the server has more than four storage drives, do the following:
  - a. Install the top disk backplane.  
See [“Install the Disk Backplane”](#) on page 122.



# Returning the Server to Operation

---

After replacing components inside of the server, perform the procedures in the following sections.

Description	Links
Learn about filler panels.	<a href="#">“Removing and Installing Server Filler Panels” on page 143</a>
Install the server top cover.	<a href="#">“Install the Server Top Cover” on page 145</a>
Remove antistatic measures.	<a href="#">“Remove Antistatic Measures” on page 146</a>
Install the server chassis into the rack.	<a href="#">“Reinstall the Server Chassis Into the Rack” on page 146</a>
Return the server to the normal rack position.	<a href="#">“Return the Server to the Normal Rack Position” on page 148</a>
Reconnecting data cables and power cords.	<a href="#">“Reconnect Data Cables and Power Cords” on page 149</a>
Power on the server.	<a href="#">“Power On the Server” on page 150</a>

---

## Removing and Installing Server Filler Panels

Each server might be shipped with module-replacement filler panels for storage drives and PCIe cards. These filler panels are installed at the factory and must remain in the server until you replace them with a purchased option.

Before you can install an optional server component into the server, you must remove the filler panel from the location into which you intend to install the component. When you remove a storage drive or a PCIe card from the server, you must install either a replacement component or a filler panel.

See the following procedure for instructions for removing and installing the server filler panels:

- [“Remove and Install Filler Panels” on page 144](#)

### Related Information

- [“Servicing CRUs That Do Not Require Server Power-Off” on page 45](#)
- [“Servicing CRUs That Require Server Power-Off” on page 61](#)

## ▼ Remove and Install Filler Panels

- See the procedures in the following table to remove and install filler panels for storage drives and PCIe cards.

Filler Panel Type	Removal Procedure	Installation Procedure
Storage Drive	<ol style="list-style-type: none"><li>1. Locate the storage drive filler panel to be removed from the server.</li><li>2. To unlatch the storage drive filler panel, press the release lever button, and then pull the lever out into a fully opened position.</li><li>3. To remove the filler panel from the slot, hold the opened release lever, and gently slide the filler panel toward you.</li></ol>	<ol style="list-style-type: none"><li>1. Locate the vacant storage drive module slot in the server, and then ensure that the release lever on the filler panel is fully opened. Slide the filler panel into the vacant slot by pressing the middle of the filler panel faceplate with your thumb or finger.</li><li>2. The release lever will close as it makes contact with the chassis. Do not slide the filler panel in all the way. Leave the filler panel out approximately 0.25 to 0.50 inch (6 to 12 mm) from the opening.</li><li>3. Using your thumb or finger, press on the middle of the filler panel faceplate until the release lever engages with the chassis.</li><li>4. Close the release lever until it clicks into place and is flush with the front of the server</li></ol>

Filler Panel Type	Removal Procedure	Installation Procedure
PCI Slot	<ol style="list-style-type: none"> <li>1. Remove the server top cover.</li> <li>2. Remove the PCI slot filler panel from the location into which you intend to install the PCIe card. <b>Note:</b> In single-processor systems, PCIe slot 1 is nonfunctional; therefore, there is no need to remove the filler panel for slot 1.</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove the server top cover.</li> <li>2. Press the PCI filler panel into the vacant PCI slot. <b>Note:</b> In single-processor systems, PCIe slot 1 is nonfunctional; therefore, the server ships with this filler panel installed.</li> </ol>

## ▼ Install the Server Top Cover

### 1. Open the server fan door.

See [“Open the Server Fan Door”](#) on page 43.

### 2. Place the top cover on the chassis [1].

Place the cover down so that it hangs over the rear of the server by about 13 mm (0.5 inches) and the side latches align with the slots in the sides of the chassis.

---

**Note** – There are three latching tabs on the sides of the cover, two on the right side and one on the left side (viewing the server from the front). There is also a latch on the underside of the cover in the front left corner near the green release button.

---

### 3. Check both sides of the chassis to ensure that the four corners of the top cover are fully down and flush with the chassis.

If the cover corners are not flush with the chassis, slide the cover towards the rear of the chassis until you can position the cover correctly.




---


**Caution** – If the top cover is not correctly positioned before you attempt to slide the cover toward the front of the chassis, the internal latch that is located on the underside of the cover might be damaged.

---

### 4. Gently slide the cover toward the front of the chassis until it locks into place (with an audible click) [2].

As you slide the cover toward the front of the server, watch the green release button. You will hear an audible click when the green release button pops up, indicating that the cover is locked.

**FIGURE:** Installing the Top Cover



5. Close the server fan door.

6. Remove the antistatic precautions.

See “Remove Antistatic Measures” on page 146.

#### Related Information

- “Remove the Server Top Cover” on page 43
- “Remove Antistatic Measures” on page 146

---

## ▼ Remove Antistatic Measures

1. Remove any antistatic straps or conductors from the server chassis.
2. Remove the antistatic wrist strap from yourself.

---

## ▼ Reinstall the Server Chassis Into the Rack

If you removed the server chassis from the rack, perform these steps to reinstall it.



---

**Caution** – Deploy any rack anti-tilt mechanisms before installing the server into the rack.

---



---


**Caution** – The server weighs approximately 18.0 kg (40.0 lbs). Two people are required to carry the chassis and install it into the rack.

---

1. Push the slide-rails into the slide-rail assemblies in the rack as far as possible.
2. Raise the server so that the rear ends of the mounting brackets are aligned with the slide-rail assemblies that are mounted in the rack.
3. Insert the mounting brackets into the slide-rails, and then push the server into the rack until the mounting brackets encounter the slide-rail stops, approximately 30 cm (12 inches).

The server is now in the extended maintenance position.

**FIGURE:** Returning the Server to the Rack



**Figure Legend**

- 
- |   |  |
|---|--|
| 1 | Inserting mounting brackets into slide-rails |
| 2 | Slide-rail release tab (green)               |
| 3 | Slide-rail lock                              |
- 

**Related Information**

- [“Remove the Server From the Rack”](#) on page 41
- [“Remove Antistatic Measures”](#) on page 146
- [“Reconnect Data Cables and Power Cords”](#) on page 149

## ▼ Return the Server to the Normal Rack Position

If the server is in the extended maintenance position, use this procedure to return the server to the normal rack position.


1. Push the server back into the rack, as described in the following steps.
  - a. Simultaneously pull and hold the two green release tabs (one on each side of the server) toward the front of the server (see the following figure) while you push the server into the rack.  
As you push the server into the rack, verify that the cable management arm (CMA) retracts without binding.

---


**Note** – To pull a green release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the server.

---

**FIGURE:** Location of the Release Tabs on the Slide-Rails







3. If necessary, reinstall the cables into the CMA and secure them with Velcro straps or cable straps, depending on which version of the CMA you are using.
4. If you pulled the server out of the rack to make it easier to connect the cables, push the server into the rack until the slide-rail locks (on the front of the server) engage the slide-rail assemblies.

You will hear an audible click when the server is in the normal rack position.

#### Related Information

- [“Disconnect Cables From the Server”](#) on page 39
- [“Reinstall the Server Chassis Into the Rack”](#) on page 146
- [“Power On the Server”](#) on page 150

---

## ▼ Power On the Server

As soon as the power cords are connected, standby power is applied and the green Power/OK status indicator on the server front panel blinks. Depending on the configuration of the firmware, the system might boot. If not, complete this step:

- **Power on the server by performing one of the following:**
  - Press the Power button on the server front panel.
  - Log in to the Oracle ILOM web interface, click Host Management > Power Control and select Power On from the Select Action list.
  - Log in to the Oracle ILOM command-line interface (CLI), and type the following command at the Oracle ILOM CLI prompt.

```
-> start /System
```

When the server is powered on and the power-on self-test (POST) code checkpoint tests have completed, the green Power/OK status indicator on the front panel lights and remains lit.

### **Related Information**

- [“Powering Down the Server” on page 33](#)
- [“Reconnect Data Cables and Power Cords” on page 149](#)



# Identifying the Server Ports

This section describes the pinouts of the server connectors.

Description	Links
Learn about the Gigabit Ethernet ports.	<a href="#">“Gigabit Ethernet Ports” on page 153</a>
Learn about the network management port.	<a href="#">“Network Management Port” on page 154</a>
Learn about the serial management port.	<a href="#">“Serial Management Port” on page 155</a>
Learn about the video connector.	<a href="#">“Video Connector” on page 157</a>
Learn about USB ports.	<a href="#">“USB Ports” on page 158</a>

## Gigabit Ethernet Ports


The server has four auto-negotiating 100/1000/10,000BASE-T gigabit Ethernet (GbE) system domain ports. All four Ethernet ports use a standard RJ-45 connector.

The transfer rates are shown in the following table:

**TABLE:** Ethernet Port Transfer Rates

Connection Type	IEEE Terminology	Transfer Rate
Fast Ethernet	100BASE-TX	100 Mbps
Gigabit Ethernet	1000BASE-T	1,000 Mbps
10 Gigabit Ethernet	10GBASE-T	10,000 Mbps

The following figure and table describe the 10-GbE port pin signals.



**Note** – Ethernet ports NET 2 and NET 3 are nonfunctional in single-processor systems.

**TABLE:** 10-GbE Port Signals

Pin	Signal Description	Pin	Signal Description
1	Transmit/Receive Data 0 +	5	Transmit/Receive Data 2 –
2	Transmit/Receive Data 0 –	6	Transmit/Receive Data 1 –
3	Transmit/Receive Data 1 +	7	Transmit/Receive Data 3 +
4	Transmit/Receive Data 2 +	8	Transmit/Receive Data 3 –

### Related Information

- “Server Back Panel View” on page 5
- “Disconnect Cables From the Server” on page 39
- “Reconnect Data Cables and Power Cords” on page 149

## Network Management Port

The server has one 10/100BASE-T Ethernet management domain interface, labeled NET MGT. For information on configuring this port for managing the server with Oracle ILOM, refer to the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.



**TABLE:** Network Management Port Signals

Pin	Signal Description	Pin	Signal Description
1	Transmit Data +	5	Common Mode Termination
2	Transmit Data -	6	Receive Data -
3	Receive Data +	7	Common Mode Termination
4	Common Mode Termination	8	Common Mode Termination

### Related Information

- [“Server Back Panel View” on page 5](#)
- [“Disconnect Cables From the Server” on page 39](#)
- [“Reconnect Data Cables and Power Cords” on page 149](#)

---

## Serial Management Port

The serial management connector (labeled SER MGT) is an RJ-45 connector that can be accessed from the rear panel. This port is the default connection to the server. Use this port *only* for server management.

**TABLE:** Default Serial Connections for Serial Port

Parameter	Setting
Connector	SER MGT
Rate	9600 baud
Parity	None
Stop bits	1
Data bits	8

The following figure and table describe the SER MGT port pin signals.



**TABLE:** Serial Management Port Signals

Pin	Signal Description	Pin	Signal Description
1	Request to Send	5	Ground
2	Data Terminal Ready	6	Receive Data
3	Transmit Data	7	Data Set Ready
4	Ground	8	Clear to Send

If you need to connect to the SER MGT port using a cable with either a DB-9 or a DB-25 connector, follow the pin descriptions in the tables to create a crossover adapter appropriate for your serial connection.

**TABLE:** RJ-45 to DB-9 Adapter Crossover Wiring Reference

Serial Port (RJ-45 Connector)		DB-9 Adapter	
Pin	Signal Description	Pin	Signal Description
1	RTS	8	CTS
2	DTR	6	DSR
3	TXD	2	RXD
4	Signal Ground	5	Signal Ground
5	Signal Ground	5	Signal Ground
6	RXD	3	TXD
7	DSR	4	DTR
8	CTS	7	RTS

**TABLE:** RJ-45 to DB-25 Adapter Crossover Wiring Reference

Serial Port (RJ-45 Connector)		DB-25 Adapter	
Pin	Signal Description	Pin	Signal Description
1	RTS	5	CTS
2	DTR	6	DSR
3	TXD	3	RXD
4	Signal Ground	7	Signal Ground
5	Signal Ground	7	Signal Ground
6	RXD	2	TXD
7	DSR	20	DTR
8	CTS	4	RTS


### Related Information

- [“Server Back Panel View” on page 5](#)
- [“Disconnect Cables From the Server” on page 39](#)
- [“Reconnect Data Cables and Power Cords” on page 149](#)

---

## Video Connector

The video connector is a DB-15 connector that can be accessed from the back panel.



**TABLE:** Video Connector Signals

Pin	Signal Description	Pin	Signal Description
1	Red Video	9	[KEY]
2	Green Video	10	Sync Ground
3	Blue Video	11	Monitor ID - Bit 1
4	Monitor ID - Bit 2	12	Monitor ID - Bit 0
5	Ground	13	Horizontal Sync
6	Red Ground	14	Vertical Sync
7	Green Ground	15	N/C (Reserved)
8	Blue Ground		


### Related Information

- [“Server Back Panel View”](#) on page 5
- [“Disconnect Cables From the Server”](#) on page 39
- [“Reconnect Data Cables and Power Cords”](#) on page 149

---

## USB Ports

The server has six USB ports for attaching supported USB 2.0-compliant devices. There are two USB ports on the server front panel, two on the rear panel, and two on the motherboard.



**TABLE:** USB Port Signals

<b>Pin</b>	<b>Signal Description</b>
1	+5 V
2	DAT-
3	DAT+
4	Ground

### **Related Information**

- [“Server Back Panel View” on page 5](#)
- [“Disconnect Cables From the Server” on page 39](#)
- [“Reconnect Data Cables and Power Cords” on page 149](#)



# Setting Up BIOS Configuration Parameters

---

This section provides an overview of BIOS configuration management, Legacy BIOS, UEFI BIOS, and the BIOS Setup utility.

Description	Links
Learn about the tools available to manage the BIOS configuration.	<a href="#">“Managing the BIOS Configuration” on page 161</a>
Learn how to access the BIOS Setup Utility.	<a href="#">“Accessing the BIOS Setup Utility” on page 162</a>
Learn about Legacy BIOS and UEFI BIOS.	<a href="#">“Using Legacy or UEFI BIOS” on page 167</a>
Learn how BIOS allocates Option ROM and I/O resources.	<a href="#">“Using BIOS for Resource Allocation” on page 170</a>
Learn how to perform common BIOS setup procedures.	<a href="#">“Common BIOS Setup Utility Tasks” on page 172</a>

## Related Information

- [“BIOS Setup Utility Menu Options” on page 197](#)

---

## Managing the BIOS Configuration

The BIOS configuration parameters on an Oracle x86 server are manageable from the BIOS Setup Utility and Oracle ILOM. You can also download the BIOS firmware using Oracle System Assistant. For information about using these tools to manage the BIOS configuration, see:

- **Oracle System Assistant** – *Oracle X4 Series Servers Administration Guide* at <http://www.oracle.com/goto/x86AdminDiag/docs>.

- **Oracle ILOM** – “Maintaining x86 BIOS Configuration Parameters” in the *Oracle ILOM 3.1 Configuration and Maintenance Guide*
- **BIOS Setup Utility** – “Common BIOS Setup Utility Tasks” on page 172

### Related Information

- Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at: <http://www.oracle.com/goto/ILOM/docs>

---

## Accessing the BIOS Setup Utility

The BIOS Setup Utility provides six main menus that you can use to view product information, and to configure, enable, and disable, or manage system components.

This section provides the following information:

- “BIOS Setup Utility Menus” on page 162
- “BIOS Key Mappings” on page 163
- “Access BIOS Setup Utility Menus” on page 164
- “Navigate BIOS Setup Utility Menus” on page 165

## BIOS Setup Utility Menus

The following table provides descriptions for the top-level BIOS Setup Utility menus.

**TABLE:** BIOS Setup Utility Menus Summary

Menu	Description
Main	General product information, including memory, time/date, security settings, system serial number, and CPU and DIMM information.
Advanced	Configuration information for the CPU, trusted computing, USB, and other information. Set the IP address for the server SP.
Boot	Enable or disable Oracle System Assistant support, set the boot mode to Legacy BIOS or UEFI BIOS, and configure the boot device priority.

**TABLE:** BIOS Setup Utility Menus Summary (*Continued*)

Menu	Description
IO	Manage configuration settings for I/O devices, such as I/O virtualization settings, and enable and disable Option ROMs.
UEFI Driver Control	Manage PCIe drivers for all configurable devices. Menu is only available when operating in UEFI BIOS Boot Mode.
Save & Exit	Save changes and exit, discard changes and exit, discard changes, or restore the default BIOS settings.

See “[BIOS Setup Utility Menu Options](#)” on page 197 for examples of each of these screens.

### Related Information

- “[BIOS Setup Utility Menu Options](#)” on page 197
- “[Navigate BIOS Setup Utility Menus](#)” on page 165

## BIOS Key Mappings

When viewing the BIOS output from a terminal using the serial console redirection feature, some terminals do not support function keys. BIOS supports the mapping of function keys to Control key sequences when serial redirection is enabled. The following table provides a description of the function key to Control key sequence mappings.

**TABLE:** Function Key to Control Key Sequence Mapping

Function Key	Control Key Sequence	BIOS POST Function	BIOS Setup Function
F1	Ctrl+Q	Not applicable	Activate the Setup Utility Help menu.
F2	Ctrl+E	Enter BIOS Setup Utility while the system is performing the power-on self-test (POST).	Not applicable
F7	Ctrl+D	Not applicable	Discard changes. (Not applicable to UEFI Driver Control menu)
F8	Ctrl+P	Activate the BIOS Boot Menu.	Not applicable

**TABLE:** Function Key to Control Key Sequence Mapping (Continued)

Function Key	Control Key Sequence	BIOS POST Function	BIOS Setup Function
F9	Ctrl+O	Launch Oracle System Assistant. BIOS boots to Oracle System Assistant, bypassing the current Boot Options Priority list for this one-time boot method.	Activate Load Optimal Values pop-up menu. (Not applicable to UEFI Driver Control menu)
F10	Ctrl+S	Not applicable	Activate Save and Exit pop-up menu. (Not applicable to UEFI Driver Control menu)
F12	Ctrl+N	Activate Network boot.	Not applicable

### Related Information

- [“Access BIOS Setup Utility Menus” on page 164](#)
- [“Navigate BIOS Setup Utility Menus” on page 165](#)

## ▼ Access BIOS Setup Utility Menus

You can access the BIOS Setup Utility screens from the following interfaces:

- Use a USB keyboard and VGA monitor connected directly to the server. (A mouse is not required to access the BIOS Setup Utility.)
- Use a terminal (or terminal emulator connected to a computer) through the serial port on the back panel of the server.
- Connect to the server using the Oracle ILOM Remote Console application.

### 1. Reset or power on the server.


For example, to reset the server:

- **From the local server**, press the Power button on the front panel of the server to power off the server, and then press the Power button again to power on the server.
- **From the Oracle ILOM web interface**, click Host Management > Power Control and select Reset from the Select Action list.
- **From the Oracle ILOM CLI on the server SP**, type **reset /System**

The power-on self-test (POST) sequence begins.

2. To enter the BIOS Setup Utility, press the F2 key (Ctrl+E from a serial connection) when prompted and while the BIOS is running the power-on self-tests (POST).

The BIOS Setup Utility Main Menu screen appears.



### Related Information

- “BIOS Setup Utility Menus” on page 162
- “BIOS Key Mappings” on page 163
- “BIOS Setup Utility Menu Options” on page 197

## ▼ Navigate BIOS Setup Utility Menus

To navigate the menus or options listed on a menu, use the arrow keys. The currently selected option or sub-menu is highlighted. For further instructions on how to navigate and change settings in the BIOS Setup Utility, refer to the online information provided on the menu.

### 1. Access the BIOS Setup Utility.

See “Access BIOS Setup Utility Menus” on page 164.

**2. Use the left and right arrow keys to select the different primary menu options.**

As you select each menu option, the top-level screen for that menu option appears.

**3. To navigate the options presented on a top-level screen, use the up and down arrow keys.**

Only options that can be modified are highlighted when you press the up and down arrow keys.

- If an option can be modified, as you select the option, user instructions for modifying the option appear in the right column of the screen.
- If an option is a link to a sub-screen, a description of the sub-menu content appears in the right column.

**4. Modify an option by pressing the + or - keys (plus or minus keys) or by pressing Enter and selecting the desired option from the pop-up menus.**

**5. Press the Esc key to return from a sub-menu screen to the previous menu screen.**

Pressing Esc from a top-level menu is equivalent to selecting the Discard Changes and Exit option from the Save & Exit Menu.

**6. Modify parameters as needed.**

**7. Press F10 to save your changes and exit the BIOS Setup Utility.**

Alternatively, you can select the Save & Exit Menu, and then select the Save Changes and Reset to save your changes and exit the BIOS Setup Utility.

---

**Note** – After modifying any BIOS settings and selecting Save Changes and Reset from the Save & Exit Menu, the subsequent reboot might take longer than a typical reboot where no settings were modified. The additional delay is required to ensure that changes to the BIOS settings are synchronized with Oracle ILOM.

---

**Related Information**

- [“BIOS Setup Utility Menus” on page 162](#)
- [“BIOS Key Mappings” on page 163](#)
- [“BIOS Setup Utility Menu Options” on page 197](#)

---

# Using Legacy or UEFI BIOS

The BIOS firmware controls the system from power-on until an operating system is booted. The BIOS is based on the Unified Extensible Firmware Interface (UEFI) specification. However, the BIOS supports booting from both Legacy BIOS and UEFI BIOS, depending on which operating system you are using.

This section includes the following information:

- “Selecting Legacy BIOS or UEFI BIOS Boot Mode” on page 167
- “Switching Between Legacy BIOS and UEFI BIOS” on page 168
- “UEFI BIOS Boot Mode Advantages” on page 169
- “Configuration Utilities for Add-In Cards” on page 169

## Selecting Legacy BIOS or UEFI BIOS Boot Mode

BIOS supports two boot modes: Legacy BIOS and UEFI BIOS. You can set the UEFI BIOS Boot Mode using the Boot Menu in the BIOS Setup Utility. UEFI BIOS Boot Mode selection depends on the operating system type and configuration that is installed in the system. Some devices and operating systems do not yet support UEFI BIOS and can only boot in Legacy BIOS Boot Mode. Depending on your situation, you might have to specify which boot mode of BIOS you want to use, Legacy BIOS Boot Mode or UEFI BIOS Boot Mode.

Choose Legacy BIOS Boot Mode to allow host bus adapters (HBAs) to use Option ROMs. Choose UEFI BIOS Boot Mode to use UEFI drivers.

When using operating systems that support booting only from Legacy BIOS, the Legacy BIOS Boot Mode must be used. When using operating systems that support booting from Legacy BIOS or UEFI BIOS, either mode can be used. However, once a mode is chosen and an operating system is installed, the operating system can only be booted using the same mode that was used for the installation.

The following operating systems do not support UEFI BIOS:

- Oracle Solaris 10
- Oracle Linux 5.x
- Red Hat Enterprise Linux 5.x
- Oracle VM 3.2

For updates to this list, refer to the *Sun Server X4-2 Product Notes* at:

<http://www.oracle.com/goto/x4-2/docs>

Only devices that support the selected mode are listed on the BIOS Boot screen. If you select UEFI BIOS Boot Mode, only boot candidates that support UEFI BIOS are listed in the Boot Options Priority list. If you select Legacy BIOS Boot Mode, only boot candidates that support Legacy BIOS are listed in the Boot Options Priority list.

### Related Information

- [“Switching Between Legacy BIOS and UEFI BIOS” on page 168](#)
- [“UEFI BIOS Boot Mode Advantages” on page 169](#)
- [“Configuration Utilities for Add-In Cards” on page 169](#)

## Switching Between Legacy BIOS and UEFI BIOS

When switching between Legacy BIOS Boot Mode and UEFI BIOS Boot Mode (either direction), BIOS settings that affect the Boot Options Priority list settings will be changed. If the boot mode is changed, the boot candidates from the previous boot mode disappear. The boot candidates for the newly changed boot mode appear after you save your changes and reset the host and in the next boot to the BIOS Setup Utility.

---

**Note** – When switching between Legacy BIOS Boot Mode and UEFI BIOS Boot mode, Boot Options Priority list settings will not be preserved. Typically, once a boot mode is selected, there is no need to switch boot modes. However, there is one notable exception: the Pc-Check utility must be run in Legacy BIOS Boot Mode. If boot settings are customized while in UEFI BIOS Boot Mode, and you need to run diagnostics, you should use the BIOS Backup and Restore feature to capture the customized settings prior to switching the boot mode to Legacy BIOS Boot Mode to run diagnostics. When you return to UEFI BIOS Boot Mode, you can use the Oracle ILOM Backup and Restore feature to reinstate your saved settings.

---

Because the settings for a given boot mode do not persist after a transition between modes, you should use the BIOS Backup and Restore feature to capture and preserve the BIOS configuration if you intend to switch back to the previous boot mode and want to retain your previous BIOS settings. For information about the BIOS Backup and Restore feature, refer to the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.

### Related Information

- [“Selecting Legacy BIOS or UEFI BIOS Boot Mode” on page 167](#)
- [“UEFI BIOS Boot Mode Advantages” on page 169](#)
- [“Configuration Utilities for Add-In Cards” on page 169](#)

# UEFI BIOS Boot Mode Advantages

When the option is available to choose between a Legacy BIOS Boot Mode or a UEFI BIOS Boot Mode operating system installation, the advantages to choosing a UEFI BIOS Boot Mode installation include the following:

- Avoids Legacy Option ROM address constraints. For more information, see [“Legacy Option ROM Allocation” on page 170](#).
- Supports operating system boot partitions greater than 2 terabytes (2 TB) in size. For more information about limitations for supported operating systems, refer to the *Sun Server X4-2 Product Notes* at:  
<http://www.oracle.com/goto/X4-2/docs>
- Integrates PCIe device configuration utilities within the BIOS Setup Utility menus. For more information, see [“BIOS Setup Utility Menu Options” on page 197](#).
- Displays bootable operating system images in the boot list as labeled entities, for example, you will see a Windows boot manager label as opposed to raw device labels.

## Related Information

- [“Selecting Legacy BIOS or UEFI BIOS Boot Mode” on page 167](#)
- [“Select the Boot Device” on page 175](#)

# Configuration Utilities for Add-In Cards

The method for interacting with configuration utilities for add-in cards and (system resident) I/O adapters differs depending on whether Legacy BIOS Boot Mode or UEFI BIOS Boot Mode is used.

In Legacy BIOS Boot Mode, I/O adapter utilities are invoked during BIOS POST progression using hot keys identified by the adapter Option ROM during POST. When the hot key is pressed, the adapter specific configuration utility interface is presented. Often the interface will have a vendor-specific design.

In UEFI BIOS Boot Mode, the configuration screens for the add-in cards will appear as menu items in the BIOS UEFI Driver Control Menu as part of the standard BIOS Setup Utility screens. For example, if the Oracle Sun Storage 6Gb SAS PCIe RAID host bus adapter (HBA) is installed in the server, the configuration utility for the HBA appears as a menu selection on the BIOS UEFI Driver Control Menu.

## Related Information

- [“Selecting Legacy BIOS or UEFI BIOS Boot Mode” on page 167](#)

---

# Using BIOS for Resource Allocation

This section explains how the BIOS allocates Option ROM and I/O resources.

- [“Legacy Option ROM Allocation” on page 170](#)
- [“I/O Resource Allocation” on page 171](#)

## Legacy Option ROM Allocation

In Legacy BIOS Boot Mode, there are PC architecture constraints on Legacy Option ROM allocation. These constraints do not apply to UEFI Option ROMs, which are often referred to as UEFI drivers.

Choose Legacy BIOS Boot Mode to allow host bus adapters (HBAs) to use Option ROMs. Choose UEFI BIOS Boot Mode to use UEFI drivers.

The system BIOS allocates 128 KB of address space for Legacy Option ROMs. This address space is shared between on-board devices and PCIe add-in cards. This fixed address space limitation is imposed by the PC architecture and not by the BIOS itself. It is possible to exhaust the available address space when installing PCIe add-in cards. When the address space is exhausted, Oracle ILOM displays an `Option ROM Space Exhausted` message, which means that one or more devices cannot load Option ROMs.

For example, if you install a SAS PCIe card, you might encounter a message similar to the following in the Oracle ILOM event log:

```
Option ROM Space Exhausted - Device XXX Disabled
```

By default, all on-board Legacy Options ROMs are enabled in the BIOS. However, you can disable most of these Option ROMs, unless they are required to support booting from the associated device or to provide some other boot-time function. For example, it is not necessary to load the Option ROM for the on-board network ports unless you want to boot from one or more network ports (even then, you can disable the Options ROMs for the remaining ports).

To minimize server boot time and reduce the likelihood of exhausting the available Option ROM address space, disable the Option ROMs for all devices that you do not intend to boot from. Enable Option ROMs only for those devices from which you intend to boot. If Option ROMs are enabled for more than one boot device, you might encounter an Option ROM space exhausted condition.

If you encounter the Option ROM space exhausted condition even after disabling all devices from which you do not intend to boot, then disable additional Option ROMs. Under some circumstances it might be necessary to disable Option ROMs for all devices except for the primary boot device.

### Related Information

- [“Access BIOS Setup Utility Menus” on page 164](#)
- [“Configure Option ROM Settings” on page 192](#)

## I/O Resource Allocation

The system provides 64 KB of I/O address space. With the increasing number of PCIe devices supported on the system, there is a possibility that there are not enough I/O resources for all the devices. Setup options are available to enable or disable the I/O resource allocation for each PCIe slot. The default for this option is enabled. When enabled, I/O resources are allocated to the device as normal. When disabled, I/O resources are not allocated to the device.

If there are one or more Sun Quad Port Gigabit Ethernet PCIe Low Profile Adapter cards installed in the server, then the BIOS might detect a condition where legacy I/O address space resources are exhausted. The following is a common form of error that might be logged:

```
6491 Tue Dec 7 14:19:57 2012 IPMI Log minor
```

```
ID = a5a9 : 12/07/2012 : 14:19:57 : System Firmware Error :  
sensor number
```

```
= 0x00 : PCI resource exhaustion : Bus 147 Device 0 Func 0
```

```
6490 Tue Dec 7 14:19:57 2012 IPMI Log minor
```

```
ID = a5a8 : 12/07/2012 : 14:19:57 : System Firmware Error :  
sensor number
```

```
= 0x00 : PCI resource exhaustion : Bus 147 Device 0 Func 1
```

To eliminate the PCI resource exhaustion condition, you should disable I/O resource allocation for any slot in which the Sun Quad Port Gigabit Ethernet PCIe Low Profile Adapter card is installed unless you intend to use that card as a bootable device. If you intend to use that card as a bootable device and you are encountering a PCI resource exhaustion event for that specific device, then it is necessary to disable I/O

allocation for some of the other card slots in the system. In general, it is safe, but not typically required, to disable I/O resource allocation for any cards not intended to be used as bootable devices, similar to the disabling of Option ROMs.

### Related Information

- [“Access BIOS Setup Utility Menus” on page 164](#)
- [“Configure I/O Resource Allocation” on page 193](#)

---

## Common BIOS Setup Utility Tasks

This section presents the procedures for some of the BIOS setup tasks that you will typically perform when setting up and managing the server.

- [“Verify BIOS Factory Default Settings” on page 172](#)
- [“Select Legacy BIOS or UEFI BIOS Boot Mode” on page 173](#)
- [“Select the Boot Device” on page 175](#)
- [“Configure iSCSI Virtual Drives” on page 176](#)
- [“Enable or Disable Oracle System Assistant” on page 184](#)
- [“Configure TPM Support” on page 186](#)
- [“Configure SP Network Settings” on page 189](#)
- [“Configure Option ROM Settings” on page 192](#)
- [“Configure I/O Resource Allocation” on page 193](#)
- [“Exit BIOS Setup Utility” on page 194](#)

### ▼ Verify BIOS Factory Default Settings

In the BIOS Setup Utility, you return the BIOS settings to the optimal factory default values, as well as view and edit settings as needed. Any changes that you make in the BIOS Setup Utility (using the F2 key) persist until the next time you change the settings.

Before you begin, ensure that the following requirements are met:

- A hard disk drive or solid state drive is properly installed in the server.
- A console connection is established to the server.

#### 1. Reset or power on the server.

- **From the local server**, press the Power button on the front panel of the server to power off the server, and then press the Power button again to power on the server.
  - **From the Oracle ILOM web interface**, click Host Management > Power Control and select Reset from the Select Action list.
  - **From the Oracle ILOM CLI on the server SP**, type `reset /System`  
The server resets.
2. **When prompted, press the F2 key to access the BIOS Setup Utility.**
  3. **To ensure that the factory defaults are set, do the following:**
    - a. **Press the F9 key to automatically load the optimal factory default settings.**

A message appears prompting you to continue this operation by selecting OK or to cancel the operation by selecting Cancel.
    - b. **In the message, highlight OK, and then press Enter.**

The BIOS Setup Utility screen appears with the cursor highlighting the first value on the screen.
  4. **Press F10 to save the changes and exit the BIOS Setup Utility.**

Alternatively, you can save the changes and exit the BIOS Setup Utility by navigating to the Save & Exit Menu and selecting Save Changes and Reset.

#### **Related Information**

- [“Access BIOS Setup Utility Menus” on page 164](#)
- [“BIOS Setup Utility Menus” on page 162](#)
- [“BIOS Key Mappings” on page 163](#)

## ▼ **Select Legacy BIOS or UEFI BIOS Boot Mode**

The BIOS firmware supports both Legacy BIOS Boot Mode and UEFI BIOS Boot Mode. The default setting is Legacy BIOS Boot Mode. Because some operating systems (OS) support both Legacy BIOS and UEFI BIOS, and some operating systems support only Legacy BIOS, you have the following options:

- If the OS being installed supports only Legacy BIOS, you must ensure that the BIOS is set to Legacy BIOS Boot Mode before you do the OS installation.
- If the OS being installed supports both Legacy BIOS and UEFI BIOS, you can set the BIOS to either Legacy BIOS Boot Mode or UEFI BIOS Boot Mode before you do the OS installation.

The following operating systems do not support UEFI BIOS:

- Oracle Solaris 10

- Oracle Linux 5.x
- Red Hat Enterprise Linux 5.x
- Oracle VM 3.2

**1. Access the BIOS Setup Utility menus.**


See “Access BIOS Setup Utility Menus” on page 164.

**2. From the BIOS Main Menu screen, select Boot.**

The Boot Menu screen appears.

**3. From the Boot Menu screen, use the up and down arrow keys to select UEFI/Legacy BIOS Boot Mode, and then press Enter.**

The UEFI/BIOS dialog box appears.




---

**Note** – You cannot configure the boot device priority after switching the boot mode. A system reboot is required to properly populate the Boot Options Priority list with devices that support the chosen boot mode.

---

**4. Use the up and down arrow keys to select the appropriate boot mode, and then press Enter.**

**5. Press F10 to save the changes and exit the BIOS Setup Utility.**

## Related Information

- [“BIOS Setup Utility Menus” on page 162](#)
- [“BIOS Key Mappings” on page 163](#)

## ▼ Select the Boot Device

The Boot Options Priority list contents depend on which BIOS boot mode is selected. When UEFI BIOS Boot Mode is selected, only UEFI BIOS boot candidates will be initialized and displayed in the Boot Options Priority list. When Legacy BIOS is selected, only Legacy BIOS boot candidates are initialized and displayed.

In addition to using the F2 key to view or edit the system BIOS settings, you can use the F8 key during the BIOS startup to specify a temporary boot device. This selected boot device is in effect only for the current system boot. The permanent boot device specified using the F2 key will be in effect after booting from the temporary boot device.

### 1. Reset or power on the server.

- **From the local server**, press the Power button on the front panel of the server to power off the server, and then press the Power button again to power on the server.
- **From the Oracle ILOM web interface**, click Host Management > Power Control and select Reset from the Select Action list.
- **From the Oracle ILOM CLI on the server SP**, type `reset /System`  
The server resets.

### 2. Press the F8 key (or Ctrl+P from a serial connection) when prompted while the BIOS is running the power-on self-test (POST).

The Please Select Boot Device dialog box appears.

### 3. In the dialog box, select the boot device option according to the operating system and BIOS mode you elected to use, and then press Enter.

Use the up and down arrow keys to select the boot device. Based on the boot mode you selected (UEFI BIOS Boot Mode or Legacy BIOS Boot Mode), the Please Select Boot Device dialog box displays only the applicable devices. For example, when the UEFI BIOS Boot Mode is elected, only UEFI BIOS boot devices are displayed in the dialog.

### 4. Press F10 to save the changes and exit the BIOS Setup Utility.

## Related Information

- [“BIOS Setup Utility Menus” on page 162](#)
- [“BIOS Key Mappings” on page 163](#)

## ▼ Configure iSCSI Virtual Drives

iSCSI virtual drives are used primarily to run supported operating systems that reside on an external server that function as the Sun Server X4-2 host operating system.

iSCSI virtual drives must be configured in the iSCSI BIOS Setup Utility screens. You must set the iSCSI parameters on the selected port.

Before you begin:

- You should be familiar with iSCSI theory of operation for the selected OS.
- Refer to the OS documentation to verify that iSCSI targets can be mounted on a client.
- You will need access to an external iSCSI server running on any supported OS.
- The Sun Server X4-2 must be in UEFI BIOS Boot Mode, not Legacy BIOS Boot Mode.

See [“Select Legacy BIOS or UEFI BIOS Boot Mode”](#) on page 173.

- You must provide the following information from the iSCSI target server. The following items are entered into the iSCSI BIOS Setup Utility screens:

Item Number	Name	Example
1	Target name	iqn.198812.com.oracle:x4-2-target <b>Note</b> - iSCSI requires an iqn format for this item.
2	iSCSI initiator name	iqn.198812.com.oracle:002222de444e <b>Note</b> - iSCSI requires an iqn format for this item.
3	Virtual device	Virtual Disk 0
4	Logical Unit Number	LUN 0
<i>Additional Information:</i>		
5	IP address of iSCSI server	111.111.1.11 (IPv4)
6	Port number	3210

### 1. Access the BIOS Setup Utility menus.

See [“Access BIOS Setup Utility Menus”](#) on page 164.


### 2. In the BIOS Setup Utility menus, navigate to the UEFI Driver Control Menu.

Options displayed include iSCSI booting and all controllable devices.

---


**Note** – The selection for iSCSI will always be an option in UEFI BIOS Boot mode; however, other menu options might change depending on which cards are installed in the system.

---




**3. Select iSCSI, and then to press Enter.**

The iSCSI Initiator Name screen appears.



**4. Select iSCSI Initiator Name, and then press Enter.**

The iSCSI Initiator Name dialog box appears.



5. Type the desired iSCSI Qualified Name (IQN) into the iSCSI Initiator Name dialog box, and then press Enter to save the changes.

The IQN identifies:

The string "iqn"

A date code that specifies the year and month in which the organization registered the domain or subdomain name used as the naming authority string

The organizational naming authority string, which consists of a valid, reversed domain or subdomain name

Optionally, a ":" (colon) followed by a string that the assigning organization can choose, which must make each assigned iSCSI name unique

The iSCSI Initiator Name must conform to the IQN naming scheme (see *RFC 3271 – Internet Small Computer Systems Interface (iSCSI) Naming and Discovery*). For example: `iqn.1988-2.com.oracle:000000000000`


The iSCSI Initiator Name appears in the UEFI Driver Control screen.



7. Select the NIC port MAC address that corresponds to your chosen iSCSI boot target, and then press Enter.

For example: Port 00-21-28-E7-71-06.

The Port Configuration screen appears. iSCSI is disabled by default.



8. Select iSCSI Mode, and then press the + or - key (plus or minus key) to toggle iSCSI Mode to Enabled to enable the iSCSI port for iSCSI boot.
9. Determine whether you want to set DHCP to enabled or disabled. DHCP is disabled by default.
  - If you keep DHCP disabled, continue to Step 10.
  - If you set DHCP to enabled, continue to Step 11.
10. If you elect to keep DHCP disabled, manually enter the following settings, and then press Enter to save your changes.
  - a. Select Target Name, and then type the iqn target name. For example: **iqn.1988-12.oracle.com:X4-2-target**
  - b. Select Target IP Address, and then type the target IP address of the iSCSI server in dotted-decimal notation. For example: **111.111.1.11**

c. Select `Target Port`, and then type the target port of the iSCSI server.

For example: **3260** (default target port setting)

---

**Note** – When iSCSI is enabled on a network port, PXE is disabled for the port.

---

d. Select `Boot LUN`, and then type the hexadecimal representation of the logical unit number (LUN).

For example: **0**

e. Continue to [Step 12](#)

11. To set DHCP to enabled, do the following, and then press `Enter` to save your changes.


a. Select `Enable DHCP setting`, and then press the `+ or - key (plus or minus key)` to change the setting to `Enabled`.

You do not need to enter the settings for the iSCSI Initiator and the related fields are hidden.

b. Select `Get target info via DHCP`, and toggle the setting to `Enabled`.

The target information is retrieved from the DHCP service and the related fields are hidden

The following screen shows `Enable DHCP` and `Get target info via DHCP` set to `Enabled`.




**12. Select a Challenge-Handshake Authentication Protocol (CHAP) Type to enable password security.**

- None – If None is selected, the default setting, CHAP is disabled and not required.
- One Way (also known as unidirectional) – If One Way is selected, the CHAP Name and CHAP Secret are required.
  - CHAP Name – User configurable. Typically the name of the Initiator, but can be any name. Must also be set at the target to authenticate the Initiator.
  - CHAP Secret – User configurable password. Must be set on the target and the Initiator.
- Mutual – If Mutual (also known as bidirectional) is selected, CHAP Name, CHAP Secret, Reverse CHAP Name, and Reverse CHAP Secret are required.
  - Reverse CHAP Name – Set a CHAP name for the target as a parameter of the target.
  - Reverse CHAP Secret – Set a password for the target.

---

**Note** – The target must be configured to acknowledge a CHAP and for the parameters to be used.

---



13. Verify that your settings match the iSCSI target server information.
14. Press F10 to save the changes and exit the BIOS Setup utilities.  
See [“Exit BIOS Setup Utility”](#) on page 194.
15. Restart the server.
16. Press the F8 key (or Ctrl+P from a serial console) when prompted while the BIOS is running the power-on-self-test (POST) code checkpoint tests.  
The Please Select Boot device dialog box appears.
17. Verify that the iSCSI target appears in the boot list.

#### Related Information

- [“Access BIOS Setup Utility Menus”](#) on page 164
- [“Exit BIOS Setup Utility”](#) on page 194

## ▼ Enable or Disable Oracle System Assistant


If you have disabled Oracle System Assistant, you can use the BIOS Setup Utility Boot Menu to put the USB device in an online state, so that Oracle System Assistant becomes available to the operating system.

**1. Access the BIOS Setup Utility.**

See “Access BIOS Setup Utility Menus” on page 164.


**2. In the BIOS Setup Utility menus, navigate to the Boot Menu.**

The Boot Menu screen appears.



**3. Select OSA Configuration.**

The OSA Configuration screen appears. The setting for OSA Internal Support is either Enabled or Disabled.



4. To change the setting, use the + or - key (plus or minus), and then press Enter to select either Enabled or Disabled.
5. Press F10 to save the changes and exit the BIOS Setup Utility.

#### Related Information

- [“BIOS Main Menu Selections” on page 198](#)

## ▼ Configure TPM Support

If you intend to use the Trusted Platform Module (TPM) feature set, you must configure the server to support this feature.

---


**Note** – TPM enables you to administer the TPM security hardware in your server. For additional information about implementing this feature, refer to the Trusted Platform Module Management documentation provided by your operating system vendor.

---


#### 1. Access the BIOS Setup Utility menus.

See [“Access BIOS Setup Utility Menus” on page 164](#).


2. In the BIOS Setup Utility menus, navigate to the Advanced Menu.  
The Advanced Settings Menu screen appears.
3. In the Advanced Menu screen, select Trusted Computing.  
The TPM Configuration screen appears.



4. If the TPM State is listed as Disabled, select TPM Support and press Enter.  
A TPM Support dialog box appears.



5. In the dialog box, set TPM Support to Enable, and then press Enter. The updated TPM Configuration screen appears.



6. Press F10 to save the changes and exit the BIOS Setup Utility.

#### Related Information

- “BIOS Setup Utility Menus” on page 162
- “Exit BIOS Setup Utility” on page 194
- Microsoft’s Windows Trusted Platform Module Management documentation

## ▼ Configure SP Network Settings

Choose one of the following methods to specify service processor (SP) network settings:


- **BIOS** – Assign the IP address for the server SP from the BIOS Setup Utility on the Advanced Menu.
- **Oracle ILOM** – For instructions on setting the IP address for the server SP using Oracle ILOM, refer to the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.
- **Oracle System Assistant** – For instructions on using Oracle System Assistant to configure SP network settings, see the *Oracle X4 Series Servers Administration Guide* at <http://www.oracle.com/goto/x86AdminDiag/docs>.

**1. Access the BIOS Setup Utility menus.**

See “Access BIOS Setup Utility Menus” on page 164.

**2. In the BIOS Setup Utility menus, navigate to the Advanced Menu.**


The Advanced Menu screen appears.



**3. In the Advanced Menu, select BMC Network, and then press Enter.**


The BMC Network Configuration screen appears.

The BMC is the Baseboard Management Controller.



**4. Select Refresh, and then press Enter to display the current BMC network settings.**

The BMC Network Configuration screen appears.



5. Select **Commit** to update the BMC network settings with the latest values.
6. Press **F10** to save the changes and exit the BIOS Setup Utility.

### Related Information

- [“BIOS Setup Utility Menus”](#) on page 162
- [“Exit BIOS Setup Utility”](#) on page 194


## ▼ Configure Option ROM Settings

1. Access the BIOS Setup Utility menus.

See [“Access BIOS Setup Utility Menus”](#) on page 164.


2. In the BIOS Setup Utility menus, navigate to the IO Menu.

The IO Menu screen appears.



3. Select the internal device or add-in card slot for which you want to enable or disable Option ROM.

The Option ROM screen for that device or add-in card slot appears.



**4. Do one of the following:**

- Select Enabled to enable the Option ROM setting for NET 0 or NET 1.
- Select Disabled to disable the Option ROM setting for NET 0 or NET 1.

**5. Press the F10 key to save the changes and exit the BIOS Setup Utility.**

**Related Information**

- “Legacy Option ROM Allocation” on page 170
- “Access BIOS Setup Utility Menus” on page 164
- “BIOS Setup Utility Menus” on page 162
- “Exit BIOS Setup Utility” on page 194

## ▼ Configure I/O Resource Allocation

**1. Access the BIOS Setup Utility menus.**

See “Access BIOS Setup Utility Menus” on page 164.

**2. In the BIOS Setup Utility menus, navigate to the IO Menu.**

The IO Menu screen appears.

**3. Select the add-in card you want to configure.**

**4. Do one of the following:**

- Select **Enabled** to enable I/O resource allocation for the add-in card.
- Select **Disabled** to disable I/O resource allocation for the add-in card.

**5. Press F10 to save the changes and exit the BIOS Setup Utility.**

**Related Information**

- “I/O Resource Allocation” on page 171
- “Access BIOS Setup Utility Menus” on page 164
- “BIOS Setup Utility Menus” on page 162
- “Exit BIOS Setup Utility” on page 194

## ▼ Exit BIOS Setup Utility

1. Use the left and right arrow keys to navigate to the top-level **Save & Exit Menu**.
2. Use the up and down arrow keys to select the desired action.
3. Press **Enter** to select the option.

A confirmation dialog box appears.



4. In the confirmation dialog box, select **Yes** to proceed and exit the BIOS Setup Utility, or select **No** to stop the exit process.

---

**Note** – After modifying any BIOS settings and selecting **Save Changes** and **Reset** from the **Save & Exit Menu**, the subsequent reboot might take longer than a typical reboot where no settings were modified. The additional delay is required to ensure that changes to the BIOS settings are synchronized with Oracle ILOM.

---

#### **Related Information**

- [“Access BIOS Setup Utility Menus” on page 164](#)
- [“BIOS Setup Utility Menus” on page 162](#)



# BIOS Setup Utility Menu Options

---

This section includes searchable text-based representations and screenshots of the main menus in the BIOS Setup Utility for the Sun Server X4-2. Following the text and screenshot for each menu is a table of the options available from that menu.

The following sections are discussed.

Description	Links
Review the BIOS Main Menu selections.	<a href="#">“BIOS Main Menu Selections” on page 198</a>
Review the BIOS Advanced Menu selections.	<a href="#">“BIOS Advanced Menu Selections” on page 203</a>
Review the BIOS IO Menu selections.	<a href="#">“BIOS IO Menu Selections” on page 213</a>
Review the Boot Menu selections.	<a href="#">“BIOS Boot Menu Selections” on page 217</a>
Review the BIOS UEFI Driver Control Menu selections.	<a href="#">“UEFI Driver Control Menu Selections” on page 221</a>
Review the BIOS Save & Exit Menu selections.	<a href="#">“BIOS Save &amp; Exit Menu Selections” on page 225</a>


## Related Information

- *Oracle X4 Series Servers Administration Guide* at:  
<http://www.oracle.com/goto/x86AdminDiag/docs>
- [“Setting Up BIOS Configuration Parameters” on page 161](#)

# BIOS Main Menu Selections

This section includes a searchable text-based representation and a screenshot of the BIOS Main Menu. The options that are available from the Main Menu are described in the table that follows. Options in the table that are marked as “(R/O)” are read-only information and cannot be changed.

```
Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.
Main Advanced IO Boot UEFI Driver Control Save & Exit
/-----+-----\
| Project Version          25.01.05.00          |Set the Date. Use Tab
| System Date              [Sat 07/16/2013]     |to switch between Data
| System Time              [19:58:46]          |elements.
|-----+-----|
| Active Logical Cores     40                   |
| QPI Link Speed           8.0 GT/s             |
| Total Memory             16 GB (DDR3)         |
| Current Memory Speed     1333 MHz            |
| USB Devices:             |-----|
|   1 Drive, 1 Keyboard, 1 Mouse, 3 Hubs       |><: Select Screen
|                                              |^v: Select Item
|
| BMC Firmware Status      Healthy              |Enter: Select
| BMC Firmware Revision    3.1.2.0 r78939      |+/-: Change Opt.
|
|> Product Information     |F1: General Help
|> CPU Information         |(Ctrl+Q from serial
|> DIMM Information        |keyboard)
|> Security Setting        |Q: Scroll Help Pane Up
|                          |A: Scroll Help Pane Down|
|                          |ESC: Exit
|-----+-----|
Version 2.15.1229. Copyright (C) 2012 American Megatrends, Inc.
```



**TABLE:** BIOS Main Menu Options

Setup Options	Options	Defaults	Description
<b>Project Version (R/O)</b>			BIOS version is displayed. This string is a unique identifier used to reference a specific BIOS release. Format is XXYYZZPP, which indicates: <ul style="list-style-type: none"> <li>• XX - Unique project/platform code.</li> <li>• YY - BIOS major release.</li> <li>• ZZ - BIOS minor release.</li> <li>• PP - Build number.</li> </ul> Example: 18.01.04.01
<b>System Date</b>			Current date is displayed. You can change the date setting. Example: [Thu 10/20/2011]
<b>System Time</b>			Current time is displayed. You can change the time setting. Example: [13:38:27]
<b>Active Logical Cores</b>		40	

**TABLE:** BIOS Main Menu Options (*Continued*)

Setup Options	Options	Defaults	Description
<b>QPI Link Speed (R/O)</b>	SLOW/ 6.4 GT/s/ 7.2 GT/s/ 8.0 GT/s		Intel Quick Path Interconnect (QPI) operational speed is displayed.
<b>Total Memory (R/O)</b>			Memory in gigabytes is displayed. Example: 16-GB (DDR3)
<b>Current Memory Speed (R/O)</b>			Memory speed is displayed. Example: 1333 MHz
<b>USB Devices (R/O)</b>			Detected USB devices are displayed. Example: 1 keyboard, 1 mouse, 3 hubs
<b>BMC Status (R/O)</b>			
<b>BMC Firmware Revision (R/O)</b>			The service processor firmware version is displayed. Example: 3.1.2.0 r78939
<b>PRODUCT INFORMATION (R/O)</b>			Product information is displayed.
Product Name			Product name is displayed. Example: Sun Server X4-2
Product Serial Number			Product serial number is displayed. Example: 1134FML00V
Board Serial Number			Board serial number is displayed. Example: 0328MSL-1132U900
<b>CPU INFORMATION (R/O)</b>			Attributes of a single processor (CPU) are defined. A separate information structure is provided for each processor supported in the system. Most of the values are dependent on the processor.
<b>Socket 0 CPU Information</b>			If CPU socket 0 is populated, the following options are listed. Otherwise, displays "Not Present."
Intel CPU @ 2.70 GHz			Processor ID brand is displayed.

**TABLE:** BIOS Main Menu Options (*Continued*)

Setup Options	Options	Defaults	Description
CPU Signature			Processor (CPU) information is displayed. Example: 206d5
Microcode Patch			Software update (microcode patch) information is displayed. Example: 512
Max CPU Speed			Maximum non-turbo speed of the processor is displayed. Example: 2700 MHz
Min CPU Speed			Minimum speed of the processor is displayed. Example: 1200 MHz
Processor Cores			Number of available processor cores is displayed. Example: 8
Intel HT Technology			Indicates whether Intel Hyper Threading is supported.
Intel VT-x Technology			Indicates whether Intel Virtualization Technology is supported.
L1 Data Cache			Example: 32 KB x 8
L1 Code Cache			Example: 32 KB x 8
L2 Cache			Example: 256 KB x 8
L3 Cache			Example: 20480 KB
<b>Socket 1 CPU Information</b>			If CPU socket 1 is populated, the same options as Socket 0 CPU Information are displayed. Otherwise, displays "Not Present."
<b>DIMM INFORMATION (R/O)</b>			Memory module (DIMM) presence and size information are displayed.
<b>CPU Socket 0 DIMM Information</b>			If DIMM is present, memory size in gigabytes is displayed. Otherwise, displays "Not Present."


**TABLE:** BIOS Main Menu Options (*Continued*)

Setup Options	Options	Defaults	Description
D0...D7			Memory size in gigabytes is displayed. Example: Socket 0 DIMMs D0 – 4 GB D1 – 4 GB D2 – 4 GB D3 – 4 GB D4 – 2 GB D5 – 2 GB D6 – Not present D7 – Not present
<b>CPU Socket 1 DIMM Information</b>			If DIMM is present, memory size in gigabytes is displayed. Otherwise, displays "Not Present."
D0...D7			See previous DIMM information example.
<b>SECURITY SETTING</b>			Configure the security setting.
Administrator Password			Set the Administrator password.

### Related Information

- ["BIOS Advanced Menu Selections" on page 203](#)
- ["BIOS IO Menu Selections" on page 213](#)
- ["BIOS Boot Menu Selections" on page 217](#)
- ["UEFI Driver Control Menu Selections" on page 221](#)
- ["BIOS Save & Exit Menu Selections" on page 225](#)





**TABLE:** BIOS Advanced Menu Options

Setup Options	Options	Defaults	Description
<b>PROCESSORS</b>			Enable or disable processor (CPU) features.
Hyper-threading	Disabled/Enabled	Enabled	When enabled, two threads are available per enabled core. When disabled, only one thread per enabled core is available.
Execute Disable Bit	Disabled/Enabled	Enabled	When enabled, execute disable bit can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS (Oracle Solaris, Oracle VM, Windows Server, Red Hat Enterprise Linux, SUSE Linux Enterprise Server, and VMware ESXi).
Hardware Prefetcher	Disabled/Enabled	Enabled	Enable the mid-level cache (L2) streamer prefetcher.
Adjacent Cache Line Prefetcher	Disabled/Enabled	Enabled	Enable the mid-level cache (L2) prefetching of adjacent cache lines.

**TABLE:** BIOS Advanced Menu Options (*Continued*)

<b>Setup Options</b>	<b>Options</b>	<b>Defaults</b>	<b>Description</b>
DCU Streamer Prefetcher	Disabled/Enabled	Enabled	Enable prefetching of next L1 data line based on multiple loads in same cache line.
DCP IP Prefetcher	Disabled/Enabled	Enabled	Enable prefetching of next L1 line based on sequential load history.
Intel Virtualization Technology	Disabled/Enabled	Enabled	When enabled, a Virtual Machine Manager (VMM) can utilize the additional hardware capabilities provided by Intel Virtualization Technology.
<b>CPU Power Management Configuration</b>			Displays processor (CPU) information. BIOS provides C-states, P-states, and T-states support in order for the OS to manage the power utilization of the system. Power management is also controlled by the service processor based on system policies.
Power Technology	Disabled/Enabled/ Efficient/Custom	Efficient	Enable the power management features. The following options are not displayed if Power Technology is set to Disabled.
Intel SpeedStep	Disabled/Enabled	Enabled	Displays only if Power Technology is set to Custom. Enable or disable Intel SpeedStep. The Intel technology used to support P-state transitions is referred to as Intel SpeedStep.
Turbo Mode	Disabled/Enabled	Enabled	Displays only if Power Technology is set to Custom, Intel SpeedStep is set to enabled, and Turbo Mode is supported in the CPU. Enable or disable Turbo Mode.
CPU C3 Report	Disabled/Enabled	Disabled	Displays only if Power Technology is set to Custom and power state (C3) is supported in the CPU. Enable or disable CPU C3 (ACPI C2) report to operating system.

**TABLE:** BIOS Advanced Menu Options (Continued)

Setup Options	Options	Defaults	Description
CPU C6 Report	Disabled/Enabled	Enabled	Displays only if Power Technology is set to Custom and power state (C6) is supported in the CPU. Enable or disable CPU C6 (ACPI C3) report to operating system.
CPU C7 Report	Disabled/Enabled	Enabled	Displays only if Power Technology is set to Custom and power state (C7) is supported in the CPU. Enable or disable CPU C7 (ACPI C3) report to operating system.
Package C-States	Disabled/Enabled	Enabled	Displays only if Power Technology is set to Custom. The power state control is referred to as C-State. Enable or disable the Package C-State limit.
Energy Performance	Performance/ Balanced Performance/ Balanced Energy/ Energy Efficient	Balanced Performance	Optimize between performance and power savings. Windows 2008 and later operating systems override this value according to its power plan.
<b>USB PORTS</b>			Set USB port configuration parameters.
EHCI Hand-off	Disabled/Enabled	Disabled	Enable or disable Enhanced Host Controller Interface (EHCI) hand-off support.
Port 60/64 Emulation	Disabled/Enabled	Enabled	Enable I/O port 60h/64h emulation support. Enable this setting for the complete USB keyboard legacy support for non-USB aware operating systems.
All USB Devices	Disabled/Enabled	Enabled	Enable or disable all USB devices.
Rear Port 0	Disabled/Enabled	Enabled	Enable or disable USB Port 0.
Rear Port 1	Disabled/Enabled	Enabled	Enable or disable USB Port 1.
Front Port 0	Disabled/Enabled	Enabled	Enable or disable USB Port 2.
Front Port 1	Disabled/Enabled	Enabled	Enable or disable USB Port 3.
Internal Port 0	Disabled/Enabled	Enabled	Enable or disable USB Port 4.

**TABLE:** BIOS Advanced Menu Options (*Continued*)

Setup Options	Options	Defaults	Description
Internal Port 1	Disabled/Enabled	Enabled	Enable or disable USB Port 5.
<b>SERIAL PORT CONSOLE REDIRECTION</b>			Provides the capability to redirect console output/input to the serial port. Graphic output is not redirected. BIOS serial console redirection lets you monitor BIOS POST messages and navigate the BIOS Setup Utility menus and Option ROMs from a terminal connected to the server using a serial connection.
External Serial Port	System/BMC	System	Control whether the external serial port connects to the Baseboard Management Controller (BMC) or directly to the system. Set to BMC for serial link management.
EMS Console Redirection	Disabled/Enabled	Disabled	Enable or disable console redirection for Windows Emergency Management Service (EMS) administration.
Console Redirection	Disabled/Enabled	Enabled	Enable or disable console redirection.
Terminal Type	VT100/ VT100+/ VT-UTF8/ ANSI	VT100+	Select the emulation for the terminal: <ul style="list-style-type: none"> <li>• VT100: ASCII character set.</li> <li>• VT100+: Extends VT100 to support color, function keys, etc.</li> <li>• VT-UTF8: Uses UTF8 encoding to map Unicode characters onto one or more bytes.</li> <li>• ANSI: Extended ASCII character set.</li> </ul>
Bits per Second	9600/ 10200/ 57600/ 115200	9600	Select the serial port transmission speed. The speed must be matched on the connecting serial device. Long or noisy lines require lower speeds.
Data Bits	07/ 08/ 11	8	Select the data bits.

**TABLE:** BIOS Advanced Menu Options (Continued)

Setup Options	Options	Defaults	Description
Parity	None/ Even/ Odd/ Mark/ Space/	None	<p>A parity bit can be sent with the data bits to detect some transmission errors.</p> <ul style="list-style-type: none"> <li>• None: No parity bits are sent.</li> <li>• Even: Parity bit is 0 if the number of 1s in the data bits is even.</li> <li>• Odd: Parity bit is 0 if the number of 1s in the data bits is odd.</li> <li>• Mark: Parity bit is always 1.</li> <li>• Space: Parity bit is always 0.</li> </ul> <p>Mark and Space parity do not allow for error detection. They can be used as an additional data bit.</p>
Stop Bits	01/02	1	<p>Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning of a serial data packet.) The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.</p>
Flow Control	None/ Hardware RTS/ CTS	None	<p>Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a “stop” signal can be sent to stop the data flow. Once the buffers are empty, a “start” signal can be sent to restart the flow. Hardware flow control uses two wires to send start and stop RTS (request to send) and CTS (clear to send) signals.</p>
<b>TRUSTED COMPUTING</b>			<p>If you intend to use the Trusted Platform Module (TPM) feature set, you must configure the server to support TPM. The TPM feature is used by the OS for proof that the BIOS code has not been tampered with.</p>

**TABLE:** BIOS Advanced Menu Options (*Continued*)

Setup Options	Options	Defaults	Description
TPM Support	Disabled/Enabled	Enabled	Enable or disable TPM support. Only UEFI BIOS implements this setup option. If disabled, the OS will not show TPM. Reset of the platform is required.
TPM State	Disabled/Enabled	Disabled	Displays whether TPM Support is enabled.
Current TPM Status Information (R/O)			If TPM Support is disabled, Current TPM Status displays "TPM SUPPORT OFF." If TPM Support is enabled, Current TPM Status displays: <ul style="list-style-type: none"> <li>• TPM Enabled Status:</li> <li>• TPM Active Status:</li> <li>• TPM Owner Status:</li> </ul>
<b>NETWORK STACK</b>			Configure network stack settings.
Network Stack	Disabled/Enabled	Enabled	Enable or disable the UEFI network stack.
Ipv4 PXE Support	Disabled/Enabled	Enabled	Enable or disable IPv4 PXE Boot support. If disable, the IPv4 Boot Option will not be created.
Ipv6 PXE Support	Disabled/Enabled	Disabled	Enable or disable IPv6 PXE Boot support. If disable, the IPv6 Boot Option will not be created.
<b>BMC NETWORK</b>			Configure Baseboard Management Controller (BMC) network parameters.
BMC Network: Current Active Management Port (R/O)			Active management port settings are displayed.
Refresh			Refresh current BMC network information with the latest information from the service processor.
Active Management Port	NETMGT/ NET0/ NET1/ NET2/ NET3		Change the management port that is currently active.

**TABLE:** BIOS Advanced Menu Options (Continued)

Setup Options	Options	Defaults	Description
Commit			Commit the current BMC network information.
IPv4 Configuration (R/O)			Current configuration of the IPv4 settings is displayed.
Channel Number (R/O)		1	Current channel number is displayed.
IPv4 Assignment (R/O)	Static/Dynamic	Static	View whether the service processor is assigned a static IPv4 address or assigned a dynamic IPv4 address using Dynamic Host Control Protocol (DHCP).
Current IPv4 Address in BMC (R/O)			Current IPv4 address of the service processor is displayed. Example: 172.31.255.255
Current IPv4 MAC Address in BMC (R/O)			Current IPv4 MAC address for the service processor is displayed. Example: 00:12:46:BE:0A:02
Current IPv4 Subnet Mask in BMC (R/O)			Current IPv4 subnet mask address for the service processor is displayed. Example: 255.255.255.0
Refresh			Select Refresh to update to the current settings.
IPv4 Address			If IPv4 Assignment is set to Static, set the IPv4 address for the service processor. Example: 172.31.255.255
IPv4 Subnet Mask			If the IPv4 Assignment is set to Static, set the IPv4 subnet mask. Example: 255.255.255.0
IPv4 Default Gateway			If the IPv4 Assignment is set to Static, set the IPv4 default gateway Example: 172.31.255.255
Commit			Commit the IPv4 configuration settings.

**TABLE:** BIOS Advanced Menu Options (*Continued*)

Setup Options	Options	Defaults	Description
IPv6 Configuration (R/O)	Static/Dynamic	Dynamic	Current configuration of the IPv6 settings is displayed. IPv6 addresses are written with hexadecimal digits and colon separators. For example: 2001:0db0:000:82a1:0000:0000:1234:abcd. IPv6 addresses are composed of two parts: a 64-bit subnet prefix and a 64-bit host interface ID. To shorten the IPv6 address, you can (1) omit all leading zeros, and (2) replace one consecutive group of zeros with a double colon (::). For example: 2001:db0:0:82a1::1234:abcd
Channel Number (R/O)		1	Current channel number is displayed.
Current IPv6 State (R/O)			Current IPv6 state is displayed.
Current IPv6 Auto Configuration (R/O)			Current IPv6 autoconfiguration parameters are displayed.
Link Local IPv6 Address (R/O)			Current link local IPv6 address is displayed. Example: fe80::214:4fff:feca:5f7e/64
Static IPv6 Address (R/O)			Current static IPv6 address is displayed. Example: 2001:0db0:000:82a1:0000:0000:1234:abcd
IPv6 Gateway (R/O)			Current IPv6 gateway address is displayed. Example: fe80::211:5dff:febe:5000/128
Dynamic IPv6 Address 1- <i>n</i> (R/O)			Current dynamic IPv6 addresses are displayed. Example: fec0:a:8:b7:214:4fff:feca:5f7e/64
Refresh			Select Refresh to update to the current settings.

**TABLE:** BIOS Advanced Menu Options (Continued)

Setup Options	Options	Defaults	Description
IPv6 State (R/O)	Disabled/Enabled		View whether the IPv6 state is enabled or disabled.
Auto IPv6 Configuration	Disabled/ Stateless/ Dhcpv6_stateless/ Dhcpv6_stateful	Disabled	<p>Autoconfiguration options are:</p> <ul style="list-style-type: none"> <li>• Disabled: When autoconfiguration is disabled, only the Link Local address is set. None of the autoconfiguration options to configure an IPv6 address are run.</li> <li>• Stateless: When enabled, the IPv6 Stateless autoconfiguration is run to learn the IPv6 addresses for the device.</li> <li>• Dhcpv6_stateless: When enabled, the Dhcpv6_stateless autoconfiguration is run to learn the DNS and domain information for the device.</li> <li>• Dhcpv6_stateful: When enabled, the Dhcpv6_stateful autoconfiguration is run to learn the IP addresses and DNS information for the device.</li> </ul>
Static IPv6 Address			<p>Set the static IPv6 address.</p> <p>Example: 2001:0db0:000.82a1:0000:0000:1234:abcd</p>
Commit			Commit the IPv6 configuration settings.

### Related Information

- [“BIOS Main Menu Selections” on page 198](#)
- [“BIOS IO Menu Selections” on page 213](#)
- [“BIOS Boot Menu Selections” on page 217](#)
- [“UEFI Driver Control Menu Selections” on page 221](#)
- [“BIOS Save & Exit Menu Selections” on page 225](#)

---

# BIOS IO Menu Selections


This section includes a searchable text-based representation and a screenshot of the BIOS IO Menu. The options that are available from the IO Menu are described in the table that follows.

```
Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.
Main  Advanced  IO  Boot  UEFI Driver Control  Save & Exit
/-----+-----\
|> PCI Subsystem Settings          |PCI, PCI-X and PCI
|> IO Virtualization              |Express Settings.
|> IOAT                            |
|
|   Internal Devices
|> NET0/1
|> NET2/3
|
|   Add-In Cards
|> Slot 1
|> Slot 2
|> Slot 3
|> Slot Internal
|>
|>
|
|-----+-----\
|><: Select Screen
|^v: Select Item
|Enter: Select
|+/-: Change Opt.
|F1: General Help
|F7: Discard Changes
|F9: Optimized Defaults
|F10: Save & Exit
|ESC: Exit
|
|-----+-----/
Version 2.15.1229. Copyright (C) 2012 American Megatrends, Inc.
```

---

**Note** – PCIe slot 1 and Ethernet ports NET2 and NET3 are nonfunctional in single-processor systems.

---



**TABLE:** BIOS IO Menu Options

Setup Options	Options	Defaults	Description
<b>PCI SUBSYSTEM SETTINGS</b>			Configure PCI, PCI-X, and PCI Express settings.
PCI 64 Bit Resources Allocation	Disabled/Enabled	Enabled	Enable or disable 64-bit capable devices to be decoded in above 4G address space. This setting is available only if the system supports 64-bit decoding.
<b>IO VIRTUALIZATION</b>			Configure single root I/O virtualization settings.
VT-d	Disabled/Enabled	Enabled	Enable or disable Intel Virtualization Technology for directed I/O (VT-d). If enabled, ensures improved isolation of I/O resources for greater reliability, security, and availability.

**TABLE:** BIOS IO Menu Options (Continued)

Setup Options	Options	Defaults	Description
SR-IOV	Disabled/Enabled	Disabled	Single Root I/O Virtualization (SR-IOV) is used to configure devices into multiple virtual devices that can be used on virtual OS installations. If supported by the hardware and set to enabled, all devices within the system that are SR-IOV capable are configured to support SR-IOV and I/O resources are allocated to the device as normal. If set to disabled, I/O resources are not allocated to the device.
ARI	Disabled/Enabled	Disabled	If Alternate Routing ID (ARI) is supported by the hardware and set to enabled, devices are permitted to locate virtual functions (VFs) in function numbers 8 to 255 of the captured bus number, instead of normal function numbers 0 to 7.
<b>I/OAT</b>			Configure settings for the Intel I/O Acceleration Technology (I/OAT).
Intel I/OAT	Disabled/Enabled	Enabled	Enable or disable Intel I/OAT.
DCA Support	Disabled/Enabled	Enabled	Enable or disable direct cache access (DCA) support.
<b>INTERNAL DEVICES</b>			Configure settings for the embedded network controller.
<b>NET0/1 OpROM Enable</b>	Disabled/Enabled	Enabled	Enable or disable Option ROM. If set to enabled, Option ROM for the card executes as normal. If set to disabled, Option ROM for the card is not copied into memory and the execution of the Option ROM is inhibited.

**TABLE:** BIOS IO Menu Options *(Continued)*

Setup Options	Options	Defaults	Description
<b>NET2 and NET3 OpROM Enable</b> <b>Note</b> - Ethernet ports NET2 and NET3 are nonfunctional in single-processor systems.	Disabled/Enabled	Enabled	Enable or disable Option ROM. If set to enabled, Option ROM for the card executes as normal. If set to disabled, Option ROM for the card is not copied into memory and the execution of the Option ROM is inhibited.
<b>ADD-IN CARDS</b>			Enable or disable the add-in cards.
<b>Slot 1</b> <b>Note</b> - PCIe slot 1 is nonfunctional in single-processor systems.			
IO Enable	Disabled/Enabled	Enabled	Enable or disable I/O for the add-in card.
OpROM Enable	Disable/Enabled	Enabled	Enable or disable Option ROM for add-in card.
<b>Slot 2</b>			
IO Enable	Disabled/Enabled	Enabled	Enable or disable I/O for the add-in card.
OpROM Enable	Disable/Enabled	Enabled	Enable or disable Option ROM for add-in card.
<b>Slot 3</b>			
IO Enable	Disabled/Enabled	Enabled	Enable or disable I/O for the add-in card.
OpROM Enable	Disable/Enabled	Enabled	Enable or disable Option ROM for add-in card.
<b>Slot Internal</b>	Disabled/enabled	Enabled	
IO Enable	Disabled/Enabled	Enabled	Enable or disable the I/O for the internal host bus adapter (HBA) card.
OpROM Enable	Disable/Enabled	Enabled	Enable or disable Option ROM for the internal host bus adapter (HBA) card.

### Related Information

- [“BIOS Main Menu Selections” on page 198](#)
- [“BIOS Advanced Menu Selections” on page 203](#)

- “BIOS Boot Menu Selections” on page 217
- “UEFI Driver Control Menu Selections” on page 221
- “BIOS Save & Exit Menu Selections” on page 225

## BIOS Boot Menu Selections

This section includes a searchable text-based representation and a screenshot of the BIOS Boot Menu. The options that are available from the Boot Menu are described in the table that follows.

```

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.
Main Advanced IO Boot UEFI Driver Control Save & Exit
/-----+-----\
| UEFI/BIOS Boot Mode          [Legacy BIOS]          |UEFI: Only UEFI Boot
|                               |                       |options are initialized
| Retry Boot List              [Disabled]             |and present to user.
| Network Boot Retry           [Enabled]              |Legacy BIOS: Only
| > OSA Configuration          |                       |legacy boot options are
|                               |                       |initialized and present
| Boot Option Priority          |                       |to user.
| [PXE:NET0:IBA XE Slot 4000 v2193] |               |
| [PXE:NET1:IBA XE Slot 4001 v2193] |               |
| [PXE:NET2:IBA XE Slot 8800 v2193] |               |
| [PXE:NET3:IBA XE Slot 8801 v2193] |               |
|                               |-----+-----|
|                               |><: Select Screen
|                               |^v: Select Item
|                               |Enter: Select
|                               |+/-: Change Opt.
|                               |F1: General Help
|                               |F7: Discard Changes
|                               |F9: Optimized Defaults
|                               |F10: Save & Exit
|                               |ESC: Exit
|                               |
|-----+-----\
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

```

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Main Advanced ID <b>Boot</b> UEFI Driver Control Save & Exit		
UEFI/BIOS Boot Mode	[Legacy BIOS]	UEFI: Only UEFI Boot options are initialized and present to user. Legacy BIOS: Only legacy boot options are initialized and present to user.
Retry Boot List	[Disabled]	
Network Boot Retry	[Enabled]	++: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F7: Discard Changes F9: Optimized Defaults F10: Save & Exit ESC: Exit
▶ OSA Configuration		
Boot Option Priority		
[PXE:NET0:IBA XE Slot 4000 v2193]		
[PXE:NET1:IBA XE Slot 4001 v2193]		
[PXE:NET2:IBA XE Slot 8800 v2193]		
[PXE:NET3:IBA XE Slot 8801 v2193]		
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		
		AB

**TABLE:** BIOS Boot Menu Options

Setup Options	Options	Defaults	Description
UEFI/BIOS Boot Mode	Legacy BIOS/UEFI	Legacy BIOS	Select either Legacy BIOS or UEFI BIOS as the boot mode. <ul style="list-style-type: none"><li>• Enable UEFI: Only UEFI BIOS boot options are initialized and presented to user.</li><li>• Enable Legacy BIOS: Only Legacy BIOS boot options are initialized and presented to user.</li></ul>
Retry Boot List	Disabled/Enabled	Enabled	If enabled, BIOS automatically retries to boot from the top of the Boot Options Priority list when all devices have been attempted and failed.
Network Boot Retry	Disabled/Enabled	Enabled	If enabled, BIOS automatically retries the PXE list present in the system when all PXE attempts have failed. If set to disabled, the system halts and displays the error message "Network Boot Failed" when all PXE boots failed. If set to Boot List, fail over to the main Boot Options Priority list.


**TABLE:** BIOS Boot Menu Options (*Continued*)

Setup Options	Options	Defaults	Description
<b>OSA Configuration</b>			Configure whether the operating system recognizes Oracle System Assistant at boot.
OSA Internal Support	Disabled/Enabled	Enabled	Enable or disable the internal USB port for Oracle System Assistant boot. If enabled, the Oracle System Assistant media is recognized by the system. If disabled, the Oracle System Assistant media will not be recognized by the system.
<b>Boot Option Priority</b>			Set the system boot order. Example: [PXE:NET0:IBA XESlot 2000 v2193] [PXE:NET0:IBA XESlot 2001 v2193] [PXE:NET0:IBA XESlot 8800 v2193] [PXE:NET0:IBA XESlot 8801 v2193] [Disabled]

### Related Information

- [“BIOS Main Menu Selections”](#) on page 198
- [“BIOS Advanced Menu Selections”](#) on page 203
- [“BIOS IO Menu Selections”](#) on page 213
- [“UEFI Driver Control Menu Selections”](#) on page 221
- [“BIOS Save & Exit Menu Selections”](#) on page 225





**TABLE:** BIOS UEFI Driver Control Menu Options

Setup Options	Options	Default	Description
iSCSI Configuration	NA	NA	Select to configure the iSCSI initiator name parameters. Only available in UEFI BIOS mode.
iSCSI Initiator Name	NA (must be specified)	None	The worldwide unique name of the iSCSI Initiator. Only IQN format is accepted.
Add an Attempt	When this option is selected, a sub-menu with following options is presented.		
	• iSCSI Attempt Name	None	The human name that you assigned to this attempt.
	• iSCSI Mode	Disabled	Set to Enabled for multipath I/O (MPIO). MPIO can boost the performance of an application by load balancing traffic across multiple ports.

**TABLE:** BIOS UEFI Driver Control Menu Options (*Continued*)

Setup Options	Options	Default	Description
Add an Attempt (Continued)	• Internet Protocol	IP4	Can be set to IP4, IP6, or Autoconfigure. The initiator IP address is assigned by the system to IP6. In Autoconfigure mode, the iSCSI driver attempts to connect to the iSCSI target using the IPv4 stack. If this fails, then the iSCSI driver attempt to connect using the IPv6 stack.
	• Connection Retry Count	0	The count range is 0 to 16. If set to 0, there are no retries.
	• Connection Establishing Timeout	1,000	The timeout value in milliseconds. The timeout range is 100 milliseconds to 20 seconds.
	• OUI-format ISID (R/O)	This valued derived from MAC address	OUI-format ISID represented in six bytes.
	• Configure ISID	The last three bytes of the OUI-format ISID	The default value is derived from the MAC address. Only this portion of the ISID is configurable.
	• Enable DHCP	Enabled	Enabled or disable.
	• Initiator IP Address	None	Use to set the initiator IP address.
	• Initiator Subnet Mask	None	Use to set initiator subnet mask address.
	• Gateway	None	Use to set initiator gateway address.
	• Target Name		Worldwide unique name of the target. Only IQN format is accepted.
	• Target IP address	None	Use to set target IP address
	• Target Port	3260	Use to change target port number.
• Boot LUN	0	Use to set the hexadecimal representation of the boot logical unit number (LUN).	


**TABLE:** BIOS UEFI Driver Control Menu Options (Continued)

Setup Options	Options	Default	Description
Add an Attempt (Continued)	• Authentication Type	CHAP	Defines the Challenge-Handshake Authentication Protocol (CHAP)
	• CHAP Type	One Way	Use to set CHAP type to either One Way or Mutual.
	• CHAP Name	None	Use to set CHAP name.
	• CHAP Secret	None	Use to set the CHAP secret. The secret length range is 12 to 16 bytes.
Delete Attempts	NA	None	Use to delete one or more attempts.
Change Attempt Order	NA	None	Use to change the order of attempts.
<b>Controller Management</b>			Select to manage controller properties, to create or clear controller configurations, and to save or clear controller events.
View Controller Properties (R/O)			Select to view controller properties.
Change Controller Properties			Select to change controller properties.
Create Configuration			Use to specify RAID level and select physical disks.
Save Controller Events			Select to specify the file system, the directory and the file name to used to save controller events.
<b>Physical Disk Management</b>			Select to view properties and perform operations on physical disks.
View Physical Disk Properties (R/O)			Select to view physical disk properties
Select Physical Disk Operations			Select to manage physical disk operations
<b>Port Configuration Menu</b>			Select to set and display port configuration information.
NIC Configuration (R/O)			Select to view the network device port setting.
Blink LEDs	0 - 15	0	LEDs will blink for a specified duration (up to 15 seconds)
<b>Port Configuration Information (R/O)</b>			Displays the port settings for the network device.

### Related Information

- [“BIOS Main Menu Selections” on page 198](#)





**TABLE:** BIOS Save & Exit Menu Options

Setup Options	Description
Save Changes and Reset	Save changes and then reset the system.
Discard Changes and Exit	Exit the BIOS Setup Utility without saving any changes.
Discard Changes	Discard changes made to the setup options so far.
Restore Defaults	Restore and load all default setup options for BIOS.

### Related Information

- “BIOS Main Menu Selections” on page 198
- “BIOS Advanced Menu Selections” on page 203
- “BIOS IO Menu Selections” on page 213
- “BIOS Boot Menu Selections” on page 217
- “UEFI Driver Control Menu Selections” on page 221

# Monitoring Components and Identifying SNMP Messages

---

This section includes information about monitoring components and identifying SNMP messages for the Sun Server X4-2.

The following sections are discussed.

Description	Links
Review how Oracle ILOM monitors component health and faults.	<a href="#">“Monitoring Component Health and Faults Using Oracle ILOM” on page 227</a>
Review information about system components and nomenclature.	<a href="#">“Monitoring System Components” on page 228</a>
Review SNMP traps generated by the server.	<a href="#">“Identifying SNMP Trap Messages” on page 239</a>

## Related Information

- Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at: <http://www.oracle.com/goto/ILOM/docs>

---

## Monitoring Component Health and Faults Using Oracle ILOM

The Oracle ILOM 3.1 interfaces provide easy-to-view information about the health status of system components. From the Oracle ILOM web interface or the `/System` target in the Oracle ILOM command-line interface, you can collect system-specific information about the server, determine the health state of discrete components, and view any open problems on the server. Oracle ILOM automatically detects system hardware faults and environmental conditions on the server. If a problem occurs on the server, Oracle ILOM will automatically do the following:

- Illuminate the Service Required status indicator (LED) on the server front and back panels.
- Identify the faulted component in the Open Problems table.
- Record system information about the faulted component or condition in the event log.

For further information about administering open problems that are detected and reported by Oracle ILOM, refer to “Administering Open Problems” in the *Oracle Integrated Lights Out Manager (ILOM) 3.1 User’s Guide*.

### Related Information

- Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at: <http://www.oracle.com/goto/ILOM/docs>

---

## Monitoring System Components

The tables in this section identify the system components and describe the naming conventions applied to the components of the Sun Server X4-2.

Each section corresponds to an IPMI entity ID and lists sensors, indicators, and field-replaceable units (FRUs) related to that entity. The tables contain the following fields:

- **Component Name** – Shows the user-visible component name used in management interfaces to refer to a specific sensor, indicator, or FRU. The IPMI name is a shortened form of the component name, and is indicated by the **boldface** portion of the component name.
- **IPMI Type** – Indicates the type of sensor, indicator, or FRU represented.
- **Description** – Describes of this particular component name reference.
- **Values** – Defines the states of the sensor, indicator, or FRU entity, and any specific units or values that are expected, if applicable.

---

**Note** – Some component names are hidden in the Oracle ILOM user interfaces. These names are marked as hidden in the following tables. Further, as of Oracle ILOM 3.1, the Oracle ILOM 3.0 legacy targets `/SYS` and `/STORAGE` have been replaced by `/System`. Even though these legacy targets might be hidden, you can still use them to issue commands. For information on legacy targets, see the ILOM 3.1 Documentation Library at <http://www.oracle.com/goto/ILOM/docs>.

---

This section includes information for the following server components:

- “System Chassis Components” on page 229
- “Cooling Unit Components” on page 231
- “Disk Backplane Components” on page 232
- “Memory Device Components” on page 232
- “Power Unit Components” on page 233
- “Processor Components” on page 235
- “System Board Components” on page 235
- “System Firmware Components” on page 237
- “Hard Disk Drive Components” on page 238

## System Chassis Components

The following table lists the system chassis components.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS	FRU	General host FRU	
/SYS/UUID	FRU	Unique system ID	Derived from host MAC address. Use for PXE boot and licensing.
/SYS/ACPI	State sensor	Precondition for sensors that need to know if the host is on	<i>(hidden)</i> 01h-ACPI_ON_WORKING 20h-ACPI_SOFT_OFF
/SYS/PWRBS	Discrete sensor	Power budget status	01h-DEASSERTED 02h-ASSERTED
/SYS/VPS	Threshold sensor	Virtual power sensor	Watts
/SYS/VPS_CPUS	Threshold sensor	Virtual power sensor (CPUs)	Watts
/SYS/VPS_MEMORY	Threshold sensor	Virtual power sensor (Memory)	Watts
/SYS/VPS_FANS	Threshold sensor	Virtual power sensor (Fans)	Watts
/SYS/INTSW	Discrete sensor	Chassis intrusion switch	01h-DEASSERTED 02h-ASSERTED

<b>Component Name (Oracle ILOM CLI Targets)</b>	<b>IPMI Type</b>	<b>Description</b>	<b>Values (if applicable)</b>
/SYS/T_AMB	Threshold sensor	System ambient temperature	Degrees C
/SYS/TEMP_FAULT	Indicator	Temperature Fault LED	Color: Amber Location: Mainboard Off: Normal On: Chassis overtemp fault
/SYS/OK	Indicator	OK LED	Color: Green Location: Front panel Off: Power is off. Fast blink: SP is booting. Slow blink: Host is in BIOS. On: Host is booting OS.
/SYS/SERVICE	Indicator	Service Required LED	Color: Amber Location: Front panel Off: Server is normal. On: Server requires service.
/SYS/LOCATE	Indicator	Locator LED	Color: White Location: Front and rear panels Off: Normal Fast blink: Locate function is activated; self-extinguishes after 30 minutes.
/SYS/HOST_ERR	Discrete sensor	Writable digital, OEM reserved sensor type, per IPMI	0x02: asserts SYS/SERVICE 0x01: deasserts SYS/SERVICE
/SYS/PS_FAULT	Indicator Rear	Power Supply Fault LED	Color: Amber Location: Mainboard Off: Normal On: General power supply fault
/SYS/FAN_FAULT	Indicator	Top Fan Fault LED	Color: Amber Location: Mainboard Off: Normal On: General fan fault

## Related Information

- “Cooling Unit Components” on page 231
- “Disk Backplane Components” on page 232
- “Memory Device Components” on page 232
- “Power Unit Components” on page 233
- “Processor Components” on page 235
- “System Board Components” on page 235
- “System Firmware Components” on page 237
- “Hard Disk Drive Components” on page 238

## Cooling Unit Components

The system has 1.57-inch (40-mm) fan modules with two fans in each module. The following table lists the system cooling unit components.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/MB/FM[0-3]	FRU	Fan module FRU	
/SYS/MB/FM[0-3]/PRSNT	Discrete sensor	Fan module is present.	01h-ENTITY_PRESENT, 02h-ENTITY_ABSENT
/SYS/MB/FM[0-3]/F[0-1]/TACH	Threshold sensor	Fan module fan speed	RPM
/SYS/MB/FM[0-3]/SERVICE	Indicator	Fan Service Required LED	Color: Amber Location: Mainboard Off: Normal On: Fan module was diagnosed as faulty.
/SYS/MB/FM[0-3]/OK	Indicator	Fan Module OK LED	Color: Green Location: Mainboard On: Normal Off: Fan module is offline.

## Related Information

- “System Chassis Components” on page 229
- “Disk Backplane Components” on page 232
- “Memory Device Components” on page 232

- “Power Unit Components” on page 233
- “Processor Components” on page 235
- “System Board Components” on page 235
- “System Firmware Components” on page 237
- “Hard Disk Drive Components” on page 238

## Disk Backplane Components

The following table lists the disk backplane (DBP) components.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description
/SYS/DBP[0-2]	FRU	Disk backplane FRUs for a multiple DBP configuration
/SYS/DBP	FRU	Disk backplane FRU for a single DBP configuration

### Related Information

- “System Chassis Components” on page 229
- “Cooling Unit Components” on page 231
- “Memory Device Components” on page 232
- “Power Unit Components” on page 233
- “Processor Components” on page 235
- “System Board Components” on page 235
- “System Firmware Components” on page 237
- “Hard Disk Drive Components” on page 238

## Memory Device Components

The following table lists the memory device components.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/MB/P[0-1]/D[0-7]	FRU	Host CPU DIMM FRU	

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/MB/P[0-1]/D[0-7]/PRSNT	Discrete sensor	Host CPU DIMM is present.	01h-ENTITY_PRESENT, 02h-ENTITY_ABSENT
/SYS/MB/P[0-1]/D[0-7]/SERVICE	Indicator	Host CPU DIMM Service LED	Color: Amber Location: Mainboard Off: Normal On: DIMM is diagnosed as faulty.

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“Processor Components” on page 235](#)
- [“System Board Components” on page 235](#)
- [“System Firmware Components” on page 237](#)
- [“Hard Disk Drive Components” on page 238](#)

## Power Unit Components

The following table lists the power unit components.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/PS[0-1]	FRU	Power supply FRU	
/SYS/PS[0-1]/PRSNT	Discrete sensor	Power supply is present.	01h-ENTITY_PRESENT, 02h-ENTITY_ABSENT

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/PS[0-1]/STA TE	Discrete sensor	Multistate, power supply sensor type, per IPMI	Presence detected Failure detected Predictive failure Power supply input lost Power supply input lost or out-of-range Power supply input out-of-range Configuration error
/SYS/PS[0-1]/P_I N	Power sensor	Input power draw	Watts
/SYS/PS[0-1]/P_O UT	Power sensor	Output power	Watts
/SYS/PS[0-1]/V_I N	Voltage sensor	Input voltage	Volts
/SYS/PS[0-1]/V_1 2V	Voltage sensor	12V rail voltage	Volts
/SYS/PS[0-1]/V_3 V3	Voltage sensor	3.3V rail voltage	Volts
/SYS/PS[0-1]/T_O UT	Temperature sensor	Ambient temperature	Degrees C

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Processor Components” on page 235](#)
- [“System Board Components” on page 235](#)
- [“System Firmware Components” on page 237](#)
- [“Hard Disk Drive Components” on page 238](#)

# Processor Components

The following table lists the processor (CPU) components.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/MB/P[0-1]	FRU	Host CPU FRU	
/SYS/MB/P[0-1]/PRSNT	Discrete sensor	Host CPU is present.	01h-ENTITY_PRESENT, 02h-ENTITY_ABSENT
/SYS/MB/P[0-1]/SERVICE	Indicator	Host CPU Service LED	Color: Amber Location: Mainboard Off: Normal On: Processor was diagnosed as faulty.
/SYS/MB/P[0-1]/V_DIMM	Static sensor	CPU's DIMM bank operating voltage	LVDIMM = 1.3V non-LVDIMM = 1.5V

## Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“System Board Components” on page 235](#)
- [“System Firmware Components” on page 237](#)
- [“Hard Disk Drive Components” on page 238](#)

# System Board Components

The following table lists the system board components.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/MB	FRU	General host system board FRU	
/SYS/MB/NET[0-3]	FRU	Host Ethernet FRU	

<b>Component Name (Oracle ILOM CLI Targets)</b>	<b>IPMI Type</b>	<b>Description</b>	<b>Values (if applicable)</b>
/SYS/MB/PCIE[1-6]/PRSENT	Discrete sensor	Option card inserted into PCIe slot	01h-ENTITY_PRESENT, 02h-ENTITY_PRESENT
/SYS/MB/T_OUT_ZONE[0-2]	Threshold sensor	Cooling zone exhaust temperature	Degrees C
/SYS/MB/T_IN_ZONE[0-2]	Threshold sensor	Cooling zone inlet temperature	Degrees C
/SYS/MB/T_CORE_NET01, /SYS/MB/T_CORE_NET23	Threshold sensor	Gigabit Ethernet controller die temperature	Degrees C
/SYS/MB/T_IN_PS[0,1]	Threshold sensor	PSU inlet temperature	Degrees C
/SYS/MB/SASEXP	FRU	SAS expander FRU	
/SYS/MB/SASEXP/PRSENT	Discrete sensor	SAS expander board presence	01h-ENTITY_PRESENT, 02h-ENTITY_PRESENT
/SYS/MB/SASEXP/T_CORRE	Threshold sensor	SAS expander board temperature	Degrees C
/SYS/MB/RIO	FRU	Rear I/O board	
/SYS/MB/RIO/PRSENT	Discrete sensor	Rear I/O board presence	01h-ENTITY_PRESENT, 02h-ENTITY_PRESENT
/SYS/MB/CONNBD	FRU	Connector board on QPI bridge	
/SYS/MB/CONNBD/PRSENT	Discrete sensor	Connector board presence	01h-ENTITY_PRESENT, 02h-ENTITY_PRESENT
/SYS/SP	FRU	Service processor FRU	
/SYS/SP/OK	Indicator	SP OK LED	Color: Green Location: Front panel On: SP is operating.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/SP/SERVICE	Indicator	SP Service Required LED	Color: Amber Location: Front panel Off: SP is working properly. On: SP requires service.
/SYS/SP/NET[0-1]	FRU	SP Ethernet FRU	

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“Processor Components” on page 235](#)
- [“System Firmware Components” on page 237](#)
- [“Hard Disk Drive Components” on page 238](#)

## System Firmware Components

The following table lists the system firmware components.

Component Name (Oracle ILOM CLI Target)	IPMI Type	Description
/SYS/MB/BIOS	FRU	BIOS FRU

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“Processor Components” on page 235](#)

- “System Board Components” on page 235
- “Hard Disk Drive Components” on page 238

## Hard Disk Drive Components

The following table lists the hard disk drive (HDD) components.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/MB/RHDD[0-1]	FRU	Rear hard disk drive FRU	From host
/SYS/MB/RHDD[0-1]/PRSNT	Discrete sensor	Rear hard disk drive presence	01h-ENTITY_PRESENT, 02h-ENTITY_ABSENT
/SYS/MB/RHDD[0-1]/SERVICE	Indicator	Rear hard disk drive Service Required LED	Color: Amber Location: Rear HDD On: Hard disk drive was diagnosed as faulty.
/SYS/MB/RHDD[0-1]/OK2RM	Indicator	Rear hard disk drive OK to Remove LED	Color: Blue Location: Rear HDD Off: Normal On: Ready to remove
/SYS/MB/RHDD[0-1]/STATE	Discrete sensor	Writable multistate, slot/connect or sensor type, per IPMI	FAULT: Asserts SERVICE IDENTIFY: Blinks OK2RM OK2RM: Asserts OK2RM
/SYS/DBP[0-2]/HDD[0-x]	FRU	Hard disk drive FRU	From host
/SYS/DBP[0-2]/HDD[0-y]/PRSNT	Discrete sensor	Hard disk drive presence	01h-ENTITY_PRESENT, 02h-ENTITY_ABSENT
/SYS/DBP[0-2]/HDD[0-y]/SERVICE	Indicator	Hard disk drive Service Action LED	Color: Amber Location: HDD Off: Normal On: Hard disk drive was diagnosed as faulty.

Component Name (Oracle ILOM CLI Targets)	IPMI Type	Description	Values (if applicable)
/SYS/DBP[0-2]/HDD[0-y]/OK2RM	Indicator	Hard disk drive OK to Remove LED	Color: Blue Location: HDD Off: Normal On: Ready to remove
/SYS/DBP[0-2]/HDD[0-y]/STATE	Discrete sensor	Writable multistate, slot/connect or sensor type, per IPMI	FAULT: Asserts SERVICE IDENTIFY: Blinks OK2RM OK2RM: Asserts OK2RM

### Related Information

- “System Chassis Components” on page 229
- “Cooling Unit Components” on page 231
- “Disk Backplane Components” on page 232
- “Memory Device Components” on page 232
- “Power Unit Components” on page 233
- “Processor Components” on page 235
- “System Board Components” on page 235
- “System Firmware Components” on page 237

## Identifying SNMP Trap Messages

It is possible to configure Oracle ILOM to generate Simple Network Management Protocol (SNMP) traps when hardware problems occur. For information about how to configure SNMP alert rule destinations to start receiving these traps, refer to the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library at:

<http://www.oracle.com/goto/ILOM/docs>

The tables in these sections list the set of SNMP traps that are generated from Oracle ILOM:

- “Generic Host Events” on page 240
- “Environmental Events” on page 240
- “Hard Disk Drive Events” on page 242

- “Power Events” on page 243
- “Fan Events” on page 246
- “Memory Events” on page 248
- “Entity Presence Events” on page 253
- “Physical Presence Events” on page 254

## Generic Host Events

The following table lists generic host events.

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> Assert <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/HOST_ERR
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> Deassert <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/HOST_ERR

### Related Information

- “System Chassis Components” on page 229
- “Cooling Unit Components” on page 231
- “Disk Backplane Components” on page 232
- “Memory Device Components” on page 232
- “Power Unit Components” on page 233
- “Processor Components” on page 235
- “System Board Components” on page 235
- “Hard Disk Drive Components” on page 238

## Environmental Events

Messages and Descriptions	Sensor Name
<p><b>SNMP Message:</b> sunHwTrapTempFatalThresholdExceeded</p> <p><b>Oracle ILOM Message:</b> Lower fatal threshold exceeded</p> <p><b>Severity and Description:</b> Critical; A temperature sensor has reported that its value has gone above an upper fatal threshold setting or below a lower fatal threshold setting.</p> <p>The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/PS0/T_OUT</p> <p>/SYS/PS1/T_OUT</p> <p>/SYS/MB/T_IN_ZONE0</p> <p>/SYS/MB/T_OUT_ZONE0</p> <p>/SYS/MB/T_IN_ZONE1</p> <p>/SYS/MB/T_OUT_ZONE1</p> <p>/SYS/MB/T_IN_ZONE2</p> <p>/SYS/MB/T_OUT_ZONE2</p>
<p><b>SNMP Message:</b> sunHwTrapTempFatalThresholdDeasserted</p> <p><b>Oracle ILOM Message:</b> Lower fatal threshold no longer exceeded</p> <p><b>Severity and Description:</b> Informational; A temperature sensor has reported that its value has gone below an upper fatal threshold setting or above a lower fatal threshold setting.</p> <p>The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/PS0/T_OUT</p> <p>/SYS/PS1/T_OUT</p> <p>/SYS/MB/T_IN_ZONE0</p> <p>/SYS/MB/T_OUT_ZONE0</p> <p>/SYS/MB/T_IN_ZONE1</p> <p>/SYS/MB/T_OUT_ZONE1</p> <p>/SYS/MB/T_IN_ZONE2</p> <p>/SYS/MB/T_OUT_ZONE2</p>
<p><b>SNMP Message:</b> sunHwTrapTempFatalThresholdExceeded</p> <p><b>Oracle ILOM Message:</b> Upper fatal threshold exceeded</p> <p><b>Severity and Description:</b> Critical; A temperature sensor has reported that its value has gone above an upper fatal threshold setting or below a lower fatal threshold setting.</p> <p>The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/PS0/T_OUT</p> <p>/SYS/PS1/T_OUT</p> <p>/SYS/MB/T_IN_ZONE0</p> <p>/SYS/MB/T_OUT_ZONE0</p> <p>/SYS/MB/T_IN_ZONE1</p> <p>/SYS/MB/T_OUT_ZONE1</p> <p>/SYS/MB/T_IN_ZONE2</p> <p>/SYS/MB/T_OUT_ZONE2</p>
<p><b>SNMP Message:</b> sunHwTrapTempFatalThresholdDeasserted</p> <p><b>Oracle ILOM Message:</b> Upper fatal threshold no longer exceeded</p> <p><b>Severity and Description:</b> Informational; A temperature sensor has reported that its value has gone below an upper fatal threshold setting or above a lower fatal threshold setting.</p> <p>The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/PS0/T_OUT</p> <p>/SYS/PS1/T_OUT</p> <p>/SYS/MB/T_IN_ZONE0</p> <p>/SYS/MB/T_OUT_ZONE0</p> <p>/SYS/MB/T_IN_ZONE1</p> <p>/SYS/MB/T_OUT_ZONE1</p> <p>/SYS/MB/T_IN_ZONE2</p> <p>/SYS/MB/T_OUT_ZONE2</p>
<p><b>SNMP Message:</b> sunHwTrapTempFatalThresholdExceeded</p> <p><b>Oracle ILOM Message:</b> Lower fatal threshold exceeded</p> <p><b>Severity and Description:</b> Critical; A temperature sensor has reported that its value has gone above an upper fatal threshold setting or below a lower fatal threshold setting.</p> <p>The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/T_AMB</p> <p>/SYS/MB/T_CORE_NET01</p> <p>/SYS/MB/T_CORE_NET23</p> <p>/SYS/MB/T_IN_PS0</p> <p>/SYS/MB/T_IN_PS1</p>

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapTempFatalThresholdDeasserted	/SYS/T_AMB
<b>Oracle ILOM Message:</b> Lower fatal threshold no longer exceeded	/SYS/MB/T_CORE_NET01
<b>Severity and Description:</b> Informational; A temperature sensor has reported that its value has gone below an upper fatal threshold setting or above a lower fatal threshold setting.	/SYS/MB/T_CORE_NET23
The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.	/SYS/MB/T_IN_PS0
	/SYS/MB/T_IN_PS1
<b>SNMP Message:</b> sunHwTrapTempFatalThresholdExceeded	/SYS/MB/T_CORE_NET01
<b>Oracle ILOM Message:</b> Upper fatal threshold exceeded	/SYS/MB/T_CORE_NET23
<b>Severity and Description:</b> Critical; A temperature sensor has reported that its value has gone above an upper fatal threshold setting or below a lower fatal threshold setting.	/SYS/MB/T_IN_PS0
The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.	/SYS/MB/T_IN_PS1
<b>SNMP Message:</b> sunHwTrapTempFatalThresholdDeasserted	/SYS/MB/T_CORE_NET01
<b>Oracle ILOM Message:</b> Upper fatal threshold no longer exceeded	/SYS/MB/T_CORE_NET23
<b>Severity and Description:</b> Informational; A temperature sensor has reported that its value has gone below an upper fatal threshold setting or above a lower fatal threshold setting.	/SYS/MB/T_IN_PS0
The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.	/SYS/MB/T_IN_PS1

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“Processor Components” on page 235](#)
- [“System Board Components” on page 235](#)
- [“Hard Disk Drive Components” on page 238](#)

## Hard Disk Drive Events

The following table lists hard disk drive events.

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapSlotOrConnectorError	/SYS/DBP/HDD0/STATE
<b>Oracle ILOM Message:</b> Assert	/SYS/DBP/HDD1/STATE
<b>Severity and Description:</b> Major; A sensor associated with a slot or connector has detected an error.	/SYS/DBP/HDD2/STATE
	/SYS/DBP/HDD3/STATE
	/SYS/DBP/HDD4/STATE
	/SYS/DBP/HDD5/STATE
	/SYS/DBP/HDD6/STATE
	/SYS/DBP/HDD7/STATE
	<b>SNMP Message:</b> sunHwTrapSlotOrConnectorOk
<b>Oracle ILOM Message:</b> Dessert	/SYS/DBP/HDD1/STATE
<b>Severity and Description:</b> Informational; A sensor associated with a slot or connector has returned to its normal state.	/SYS/DBP/HDD2/STATE
	/SYS/DBP/HDD3/STATE
	/SYS/DBP/HDD4/STATE
	/SYS/DBP/HDD5/STATE
	/SYS/DBP/HDD6/STATE
	/SYS/DBP/HDD7/STATE

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“Processor Components” on page 235](#)
- [“System Board Components” on page 235](#)
- [“Hard Disk Drive Components” on page 238](#)

## Power Events

The following table lists power events.

Messages and Descriptions	Sensor Name
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/POLL
Oracle ILOM Message: Assert	/SYS/PS1/POLL
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyOk	/SYS/PS0/POLL
Oracle ILOM Message: Deassert	/SYS/PS1/POLL
<b>Severity and Description:</b> Informational; A power supply sensor has returned to its normal state.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_PRESENCE ASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_PRESENCE DEASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_FAILURE ASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_FAILURE DEASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_PREDICTIVE_FAILURE ASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_PREDICTIVE_FAILURE DEASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_INPUT_LOST ASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_INPUT_LOST DEASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	
SNMP Message: sunHwTrapPowerSupplyError	/SYS/PS0/STATE
Oracle ILOM Message: PS_INPUT_ERROR ASSERT	/SYS/PS1/STATE
<b>Severity and Description:</b> Major; A power supply sensor has detected an error.	

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapPowerSupplyError <b>Oracle ILOM Message:</b> PS_INPUT_ERROR DEASSERT <b>Severity and Description:</b> Major; A power supply sensor has detected an error.	/SYS/PS0/STATE
<b>SNMP Message:</b> sunHwTrapPowerSupplyError <b>Oracle ILOM Message:</b> PS_INPUT_RANGE_ERROR ASSERT <b>Severity and Description:</b> Major; A power supply sensor has detected an error.	/SYS/PS1/STATE
<b>SNMP Message:</b> sunHwTrapPowerSupplyError <b>Oracle ILOM Message:</b> PS_INPUT_RANGE_ERROR DEASSERT <b>Severity and Description:</b> Major; A power supply sensor has detected an error.	/SYS/PS0/STATE
<b>SNMP Message:</b> sunHwTrapPowerSupplyError <b>Oracle ILOM Message:</b> PS_CONFIG_ERROR ASSERT <b>Severity and Description:</b> Major; A power supply sensor has detected an error.	/SYS/PS1/STATE
<b>SNMP Message:</b> sunHwTrapPowerSupplyError <b>Oracle ILOM Message:</b> PS_CONFIG_ERROR DEASSERT <b>Severity and Description:</b> Major; A power supply sensor has detected an error.	/SYS/PS0/STATE
<b>SNMP Message:</b> sunHwTrapSensorNonCritThresholdExceeded <b>Oracle ILOM Message:</b> Upper noncritical threshold exceeded <b>Severity and Description:</b> Minor; A sensor has reported that its value has gone above an upper non-critical threshold setting or below a lower non-critical threshold setting. This generic 'sensor' trap is generated when the SNMP agent does not recognize the component type. The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.	/SYS/VPS
<b>SNMP Message:</b> sunHwTrapSensorThresholdOk <b>Oracle ILOM Message:</b> Upper noncritical threshold no longer exceeded <b>Severity and Description:</b> Informational; A sensor has reported that its value is in the normal operating range. The generic 'sensor' trap is generated when the SNMP agent does not recognize the component type.	/SYS/VPS
<b>SNMP Message:</b> sunHwTrapPowerSupplyError <b>Oracle ILOM Message:</b> Assert <b>Severity and Description:</b> Major; A power supply sensor has detected an error.	/SYS/PWRBS
<b>SNMP Message:</b> sunHwTrapPowerSupplyOk <b>Oracle ILOM Message:</b> Deassert <b>Severity and Description:</b> Informational; A power supply sensor has returned to its normal state.	/SYS/PWRBS
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ACPI_ON_WORKING ASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/ACPI

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ACPI_ON_WORKING DEASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/ACPI
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ACPI_SOFT_OFF ASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/ACPI
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ACPI_SOFT_OFF DEASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/ACPI

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“Processor Components” on page 235](#)
- [“System Board Components” on page 235](#)
- [“Hard Disk Drive Components” on page 238](#)

## Fan Events

The following table lists fan events.

Messages and Descriptions	Sensor Name
<p><b>SNMP Message:</b> sunHwTrapFanSpeedCritThresholdExceeded</p> <p><b>Oracle ILOM Message:</b> Lower critical threshold exceeded</p> <p><b>Severity and Description:</b> Major; A fan speed sensor has reported that its value has gone above an upper critical threshold setting or below a lower critical threshold setting. The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/MB/FM0/F0/TACH</p> <p>/SYS/MB/FM0/F1/TACH</p> <p>/SYS/MB/FM1/F0/TACH</p> <p>/SYS/MB/FM1/F1/TACH</p> <p>/SYS/MB/FM2/F0/TACH</p> <p>/SYS/MB/FM2/F1/TACH</p> <p>/SYS/MB/FM3/F0/TACH</p> <p>/SYS/MB/FM3/F1/TACH</p>
<p><b>SNMP Message:</b> sunHwTrapFanSpeedCritThresholdDeasserted</p> <p><b>Oracle ILOM Message:</b> Lower critical threshold no longer exceeded</p> <p><b>Severity and Description:</b> Informational; A fan speed sensor has reported that its value has gone below an upper critical threshold setting or above a lower critical threshold setting. The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/MB/FM0/F0/TACH</p> <p>/SYS/MB/FM0/F1/TACH</p> <p>/SYS/MB/FM1/F0/TACH</p> <p>/SYS/MB/FM1/F1/TACH</p> <p>/SYS/MB/FM2/F0/TACH</p> <p>/SYS/MB/FM2/F1/TACH</p> <p>/SYS/MB/FM3/F0/TACH</p> <p>/SYS/MB/FM3/F1/TACH</p>
<p><b>SNMP Message:</b> sunHwTrapFanSpeedFatalThresholdExceeded</p> <p><b>Oracle ILOM Message:</b> Lower fatal threshold exceeded</p> <p><b>Severity and Description:</b> Critical; A fan speed sensor has reported that its value has gone above an upper fatal threshold setting or below a lower fatal threshold setting. The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/MB/FM0/F0/TACH</p> <p>/SYS/MB/FM0/F1/TACH</p> <p>/SYS/MB/FM1/F0/TACH</p> <p>/SYS/MB/FM1/F1/TACH</p> <p>/SYS/MB/FM2/F0/TACH</p> <p>/SYS/MB/FM2/F1/TACH</p> <p>/SYS/MB/FM3/F0/TACH</p> <p>/SYS/MB/FM3/F1/TACH</p>
<p><b>SNMP Message:</b> sunHwTrapFanSpeedFatalThresholdDeasserted</p> <p><b>Oracle ILOM Message:</b> Lower fatal threshold no longer exceeded</p> <p><b>Severity and Description:</b> Informational; A fan speed sensor has reported that its value has gone below an upper fatal threshold setting or above a lower fatal threshold setting. The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower threshold.</p>	<p>/SYS/MB/FM0/F0/TACH</p> <p>/SYS/MB/FM0/F1/TACH</p> <p>/SYS/MB/FM1/F0/TACH</p> <p>/SYS/MB/FM1/F1/TACH</p> <p>/SYS/MB/FM2/F0/TACH</p> <p>/SYS/MB/FM2/F1/TACH</p> <p>/SYS/MB/FM3/F0/TACH</p> <p>/SYS/MB/FM3/F1/TACH</p>

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)

- “Memory Device Components” on page 232
- “Power Unit Components” on page 233
- “Processor Components” on page 235
- “System Board Components” on page 235
- “Hard Disk Drive Components” on page 238

## Memory Events

The following table lists memory events.

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapSensorNonCritThresholdExceeded <b>Oracle ILOM Message:</b> Upper noncritical threshold exceeded <b>Severity and Description:</b> Minor; A sensor has reported that its value has gone above an upper non-critical threshold setting or below a lower non-critical threshold setting. This generic ‘sensor’ trap is generated when the SNMP agent does not recognize the component type. The sunHwTrapThresholdType object indicates whether the threshold was an upper or lower.	/SYS/VPS_CPUS /SYS/VPS_MEMORY
<b>SNMP Message:</b> sunHwTrapSensorThresholdOk <b>Oracle ILOM Message:</b> Upper noncritical threshold no longer exceeded <b>Severity and Description:</b> Informational; A sensor has reported that its value is in the normal operating range. This generic ‘sensor’ trap is generated when the SNMP agent does not recognize the component type.	/SYS/VPS_CPUS /SYS/VPS_MEMORY
<b>SNMP Message:</b> sunHwTrapComponentFault <b>Oracle ILOM Message:</b> event fault.cpu.intel.quickpath.link_slow <b>Severity and Description:</b> Major; A component is suspected of causing a fault. This generic ‘component’ trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB
<b>SNMP Message:</b> sunHwTrapComponentFaultCleared <b>Oracle ILOM Message:</b> event fault.cpu.intel.quickpath.link_slow <b>Severity and Description:</b> Informational; A component fault has been cleared. This generic ‘component’ trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB
<b>SNMP Message:</b> sunHwTrapComponentFault <b>Oracle ILOM Message:</b> event fault.cpu.intel.quickpath.unknown-errcode <b>Severity and Description:</b> Major; A component is suspected of causing a fault. This generic ‘component’ trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB

Messages and Descriptions	Sensor Name
<p><b>SNMP Message:</b> sunHwTrapComponentFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.cpu.intel.quickpath.unknown-errcode</p> <p><b>Severity and Description:</b> Informational; A component fault has been cleared. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFault</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimmememtest-failed</p> <p><b>Severity and Description:</b> Major; A component is suspected of causing a fault. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimmememtest-failed</p> <p><b>Severity and Description:</b> Informational; A component fault has been cleared. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFault</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimmememtest-failed</p> <p><b>Severity and Description:</b> Major; A component is suspected of causing a fault. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimmememtest-failed</p> <p><b>Severity and Description:</b> Informational; A component fault has been cleared. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFault</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimmememtest-failed</p> <p><b>Severity and Description:</b> Major; A component is suspected of causing a fault. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimmememtest-failed</p> <p><b>Severity and Description:</b> Informational; A component fault has been cleared. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFault</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimmememtest-failed</p> <p><b>Severity and Description:</b> Major; A component is suspected of causing a fault. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB

Messages and Descriptions	Sensor Name
<p><b>SNMP Message:</b> sunHwTrapComponentFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.-ddr3u-unsupported</p> <p><b>Severity and Description:</b> Informational; A component fault has been cleared. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFault</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.mrc.unknown-errcode</p> <p><b>Severity and Description:</b> Major; A component is suspected of causing a fault. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapComponentFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.mrc.unknown-errcode</p> <p><b>Severity and Description:</b> Informational; A component fault has been cleared. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.</p>	/SYS/MB
<p><b>SNMP Message:</b> sunHwTrapMemoryFault</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.udimm-unsupported</p> <p><b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.</p>	/SYS/MB/P/D
<p><b>SNMP Message:</b> sunHwTrapMemoryFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.udimm-unsupported</p> <p><b>Severity and Description:</b> Informational; A memory component fault has been cleared.</p>	/SYS/MB/P/D
<p><b>SNMP Message:</b> sunHwTrapMemoryFault</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.sodimm-unsupported</p> <p><b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.</p>	/SYS/MB/P/D
<p><b>SNMP Message:</b> sunHwTrapMemoryFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.sodimm-unsupported</p> <p><b>Severity and Description:</b> Informational; A memory component fault has been cleared.</p>	/SYS/MB/P/D
<p><b>SNMP Message:</b> sunHwTrapMemoryFault</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.4gb-fused</p> <p><b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.</p>	/SYS/MB/P/D
<p><b>SNMP Message:</b> sunHwTrapMemoryFaultCleared</p> <p><b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.4gb-fused</p> <p><b>Severity and Description:</b> Informational; A memory component fault has been cleared.</p>	/SYS/MB/P/D

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.8gb-fused <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.8gb-fused <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.incompatible <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.incompatible <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.incompatible-maxranks <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.incompatible-maxranks <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.incompatible-quadrack <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.incompatible-quadrack <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.numranks-unsupported <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.numranks-unsupported <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.speed-slow <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.speed-slow <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.disable-quadrank <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.disable-quadrank <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.population-invalid <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.population-invalid <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.out-of-order <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.out-of-order <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFault <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.category-unknown <b>Severity and Description:</b> Major; A memory component is suspected of causing a fault.	/SYS/MB/P/D
<b>SNMP Message:</b> sunHwTrapMemoryFaultCleared <b>Oracle ILOM Message:</b> event fault.memory.intel.dimm.category-unknown <b>Severity and Description:</b> Informational; A memory component fault has been cleared.	/SYS/MB/P/D

## Related Information

- “System Chassis Components” on page 229
- “Cooling Unit Components” on page 231
- “Disk Backplane Components” on page 232
- “Memory Device Components” on page 232
- “Power Unit Components” on page 233
- “Processor Components” on page 235
- “System Board Components” on page 235
- “Hard Disk Drive Components” on page 238

## Entity Presence Events

The following table lists entity presence events.

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ENTITY_PRESENT ASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB/P0/PRSNT /SYS/MB/P1/PRSNT
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ENTITY_PRESENT DEASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB/P0/PRSNT /SYS/MB/P1/PRSNT
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ENTITY_ABSENT ASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB/P0/PRSNT /SYS/MB/P1/PRSNT

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ENTITY_ABSENT DEASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB/P0/PRSNT /SYS/MB/P1/PRSNT
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ENTITY_DISABLED ASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB/P0/PRSNT /SYS/MB/P1/PRSNT
<b>SNMP Message:</b> sunHwTrapComponentError <b>Oracle ILOM Message:</b> ENTITY_DISABLED DEASSERT <b>Severity and Description:</b> Major; A sensor has detected an error. This generic 'component' trap is generated when the SNMP agent does not recognize the component type.	/SYS/MB/P0/PRSNT /SYS/MB/P1/PRSNT

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“Processor Components” on page 235](#)
- [“System Board Components” on page 235](#)
- [“Hard Disk Drive Components” on page 238](#)

## Physical Presence Events

The following table lists physical presence events.

Messages and Descriptions	Sensor Name
<b>SNMP Message:</b> sunHwTrapSecurityIntrusion <b>Oracle ILOM Message:</b> Assert <b>Severity and Description:</b> Major; An intrusion sensor has detected that someone may have physically tampered with the system.	/SYS/INTSW /SYS/SP/SP_NEEDS_REBOOT
<b>SNMP Message:</b> sunHwTrapSecurityIntrusion <b>Oracle ILOM Message:</b> Deassert <b>Severity and Description:</b> Major; An intrusion sensor has detected that someone may have physically tampered with the system.	/SYS/INTSW /SYS/SP/SP_NEEDS_REBOOT

### Related Information

- [“System Chassis Components” on page 229](#)
- [“Cooling Unit Components” on page 231](#)
- [“Disk Backplane Components” on page 232](#)
- [“Memory Device Components” on page 232](#)
- [“Power Unit Components” on page 233](#)
- [“Processor Components” on page 235](#)
- [“System Board Components” on page 235](#)
- [“Hard Disk Drive Components” on page 238](#)



# Index

---

## A

- add-in cards
  - configuration utilities in Legacy BIOS Boot Mode, 169
  - configuration utilities in UEFI BIOS Boot Mode, 169
- Advanced BIOS screen, 203
- antistatic
  - mat, 32
  - measures
    - removing, 146
    - taking, 42
  - wrist strap, 31

## B

- battery
  - description, 17
  - installing, 98
  - removing, 97
- BIOS boot mode, switching between Legacy BIOS and UEFI BIOS modes, 168
- BIOS factory defaults, verifying, 172
- BIOS Setup Utility
  - accessing, 164
  - Advanced screen, 203
  - boot mode, 167
  - Boot screen, 217
  - exiting from, 194
  - function keys, 163
  - IO screen, 213
  - Legacy BIOS Boot Mode, 167
  - Main screen, 198
  - menus, accessing, 164
  - navigating menu options, 165
  - Save & Exit screen, 225
  - service processor network settings, 189
  - setup screens summary, 162

- shortcut key sequences, 163
- TPM support, 186
- UEFI BIOS Boot Mode, 167
- UEFI Driver Control screen, 221
- UEFI-compliant, description, 167

- board components, 229
- Boot BIOS screen
  - options available, 217
- boot device, selecting, 175
- boot mode
  - preserving settings when switching modes, 168
  - selecting, 173

## C

- cables
  - data and power
    - connecting, 149
    - disconnecting, 39
- chassis components, 229
- components and nomenclature, 229
- cooling unit components, 231

## D

- default boot mode, 173
- diagnostics, 22
  - Oracle ILOM firmware, 22
  - Oracle VTS software, 23
  - Pc-Check, 22, 23
- DIMMs
  - description, 17
  - fault LEDs
    - inconsistencies with BIOS, 70
  - faulty
    - identifying, 71
  - installing, 73
  - physical layout, 64
  - population example for optimal performance, 65

- population rules, 67
- rank classification labels, 69
- removing, 71
- disk backplane
  - configurations, 118
  - description, 18
  - installing, 122
  - removing, 119
- disk backplane components, 232
- disk components, 238
- disk drives
  - See* storage drive
- DVD drive
  - installing, 93
  - removing, 91

## E

- electrostatic discharge
  - See* ESD
- ESD
  - prevention, 42
  - safety precautions, 31
- Ethernet ports
  - pinouts, 154
- exploded view of server, 15
- external inspection, 26

## F

- fan modules
  - description, 18
  - installing, 54
  - removing, 51
- Fault Remind Button
  - location, 70
  - using, 70
- FIM
  - description, 18
  - servicing, 125
  - with 2.5-inch storage drives
    - installing, 127
    - removing, 125
- firmware components, 229
- FRU
  - locations, 99
- function keys within BIOS Setup Utility, 163

## G

- gathering information for service visit, 24
- general troubleshooting guidelines, 24
- Gigabit Ethernet ports, 153
  - pinouts, 154
- guidelines for troubleshooting, 24

## H

- hard disk drive components, 238
- hard drives
  - See* storage drive
- hot-plugging storage drives, 46

## I

- illustrated parts breakdown, 15
- inspecting server
  - external, 26
  - internal, 26
- installing, 133
  - disk backplane, 122
  - fan modules, 54
  - PCIe risers, 78, 82
  - power supply, 59
  - processor(s), 112
  - server into rack, 146
  - storage drive, 49
  - top cover, 145
- Integrated Lights Out Manager
  - See* Oracle ILOM
- Internal HBA card
  - removing, 89
- internal inspection, 26
- internal USB flash drive
  - installing, 95
  - removing, 95
- IO allocation
  - address space, 171
  - enabling and disabling resources, 193
  - minimizing resource exhaustion, 171
- IO BIOS screen, 213
- IP address, setting, 189
- IPMI type, 228

## L

- latch release button
  - storage drive, 49

- LEDs
  - power supply, 55, 57
  - troubleshooting, 26
  - visual notification, 22
- Legacy BIOS boot mode
  - selecting, 167
  - switching between BIOS boot modes, 168
- locator LED button, 8, 27

## M

- Main BIOS screen, 198
- memory device components, 232
- menus, BIOS Setup Utility, 164
- motherboard
  - description, 18
  - installing, 135
  - removing, 128
  - servicing, 127

## N

- NET MGT port
  - pinout, 11, 154
- network management port
  - See NET MGT
- network settings, service processor, 189

## O

- Option ROMs
  - enabling and disabling, 176, 192
  - legacy BIOS allocation, 170
  - minimizing resource exhaustion, 170
- Oracle ILOM
  - diagnostics, 22
  - firmware, 22
  - POST, 22
- Oracle Solaris OS predictive self-healing, 23
- Oracle VTS software, 23

## P

- Pc-Check diagnostics, 22
- PCIe cards
  - description, 18
  - removing from slot 1 and 2, 86
  - removing from slot 3, 87
  - servicing, 84
  - slot characteristics, 85

- PCIe risers
  - description, 18
  - installing in slots 1 and 2, 78
  - installing in slots 3 and 4, 82
  - location and differences, 75
  - removing from slot 1 and 2, 77
  - removing from slot 3 and 4, 80
- PCIe slot numbering, 85
- pinouts
  - Ethernet ports, 154
  - Gigabit Ethernet ports, 154
  - RJ-45 to DB-25 crossover wiring, 157
  - RJ-45 to DB-9 crossover wiring, 156
  - SER MGT, 156
  - USB port, 159
  - video connector, 157
- ports
  - Ethernet, 153
  - Gigabit Ethernet, 153
  - NET MGT, 11, 154
  - network management, 11, 154
  - SER MGT, 155
  - serial management, 155
  - USB, 158
  - video, 157
- POST code checkpoint tests, 8, 151
- power
  - standby mode, 37, 38
  - standby power mode, 39
- power down server
  - gracefully, 34
  - with power button, 36
- power on, server, 164
- power problems, troubleshooting, 26
- power supply
  - description, 18
  - installing, 59
  - LEDs, 55, 57
  - removing, 57
  - servicing, 55
  - status indicators, 11
- power unit components, 233
- Power/OK indicator, 8
- powering off the system, 33
- predictive self-healing, 23
- processor components, 235
- processor socket cover, 131, 133

- processor(s)
  - identifying faulty, 107
  - installing, 112
  - physical layout, 64
  - release lever
    - disengaging, 109
  - removal/replacement tool, 113
  - removing, 106

- PSU
  - See* power supply

## R

- rackmount
  - stabilizing the rack, 40
- removing, 131
  - antistatic measures, 146
  - disk backplane, 119
  - fan modules, 51
  - motherboard, 128
  - power supply, 57
  - processor(s), 106
  - server from rack, 41
  - storage drive, 47

## S

- safety
  - ESD precautions, 31
  - precautions, 29
  - symbols, 30
- Save & Exit BIOS screen, 225
- screens, BIOS Setup Utility, 162, 164
- SER MGT
  - pinouts, 156
  - RJ-45 to DB-25 crossover pinouts, 157
  - RJ-45 to DB-9 crossover pinouts, 156
- serial management port
  - See* SER MGT
- server
  - inspecting internal components, 26
  - installing into rack, 146
  - removing from rack, 41
- server, power on, 164
- service
  - gathering information, 24
  - preparing server, 33
  - returning server to operation, 143
- service processor

- network settings, configuring, 189
- service visit information, gathering, 24
- shortcut key sequences in BIOS Setup Utility, 163
- shutting down the system
  - gracefully, 33
  - gracefully using Oracle ILOM CLI, 34
  - gracefully using Oracle ILOM web interface, 35
  - gracefully using the Power button, 36
  - immediately, 33
  - immediately using Oracle ILOM CLI, 37
  - immediately using Oracle ILOM web interface, 38
  - immediately using the Power button, 36, 37, 38

- Simple Network Management Protocol (SNMP)

- Traps
  - generated by system, 239

- standby power, 37, 38, 39

- status indicators
  - power supply, 11
  - storage drive, 10

- stop command, 34

- storage drive
  - description, 17
  - hot-plugging, 46
  - identification, 48
  - installing, 49
  - latch release button, 49
  - locations, 48
  - removing, 47
  - status indicators, 10

- storage drive SAS cables
  - installing, 141
  - removing, 139

- system board components, 235
- system chassis components, 229
- system components and nomenclature, 228
- system firmware components, 237

## T

- tools required, 32
- top cover
  - installing, 145
  - removing, 43
- troubleshooting
  - external components, 26
  - gathering information, 24
  - guidelines, 24

- inspecting server, 25
- LEDs, 26
- locator LED button, 27
- power problems, 26
- task list, 21

- Trusted Platform Module (TPM), configuring
  - support for, 186

## **U**

- UEFI boot mode
  - advantages of using, 169
  - selecting, 167
- UEFI Driver Control BIOS screen, 221
- UEFI driver control, enabling and disabling, 176
- UEFI-compliant BIOS, description, 167
- USB port
  - pinouts, 159

## **V**

- video port
  - pinouts, 157

## **W**

- weight of server, 41

