

Oracle® Communications

EAGLE Maintenance Guide



Release 47.0

F41415-02

August 2023



Oracle Communications EAGLE Maintenance Guide, Release 47.0

F41415-02

Copyright © 1993, 2023, Oracle and/or its affiliates.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software, software documentation, data (as defined in the Federal Acquisition Regulation), or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, then the following notice is applicable:

U.S. GOVERNMENT END USERS: Oracle programs (including any operating system, integrated software, any programs embedded, installed, or activated on delivered hardware, and modifications of such programs) and Oracle computer documentation or other Oracle data delivered to or accessed by U.S. Government end users are "commercial computer software," "commercial computer software documentation," or "limited rights data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, reproduction, duplication, release, display, disclosure, modification, preparation of derivative works, and/or adaptation of i) Oracle programs (including any operating system, integrated software, any programs embedded, installed, or activated on delivered hardware, and modifications of such programs), ii) Oracle computer documentation and/or iii) other Oracle data, is subject to the rights and limitations specified in the license contained in the applicable contract. The terms governing the U.S. Government's use of Oracle cloud services are defined by the applicable contract for such services. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle®, Java, and MySQL are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Inside are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Epyc, and the AMD logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services unless otherwise set forth in an applicable agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

Contents

1 Introduction

1.1	Overview	1-1
1.2	Scope and Audience	1-1
1.3	References	1-2
1.4	Hardware Repair and Return	1-2
1.4.1	Repair and Return Shipping Instructions	1-3
1.5	Maintenance Strategy	1-4
1.6	System Maintenance Log	1-5

2 Preventive Maintenance

2.1	Introduction	2-1
2.2	Maintaining the Fuse and Alarm Panel	2-1
2.2.1	1U FAP P/N 870-2804-01	2-2
2.2.1.1	FAP Components	2-2
2.2.1.2	Alarms	2-3
2.2.1.3	Diode Testing and the Shorting Board	2-4
2.2.2	3U FAP	2-7
2.2.2.1	FAP Components	2-7
2.2.2.2	Alarms	2-11
2.2.2.3	Diode Testing and the Diode Jumper	2-11
2.3	Removable Drives	2-15
2.3.1	Removable USB Drive	2-15
2.3.2	Fixed SATA Drive	2-18
2.4	Daily Procedures	2-41
2.4.1	Backing Up the Database Daily	2-41
2.4.2	System Reports Analysis	2-43
2.4.3	Reports Description	2-43
2.4.4	File Transfer for LNP and INP Measurements	2-44
2.5	Weekly Procedures	2-45
2.5.1	Database Archive (Weekly)	2-45
2.5.2	Printer Inspection	2-46
2.5.3	Remote Access Verification	2-47

2.6	Monthly Procedures	2-47
2.6.1	Database Archive (Monthly)	2-47
2.6.2	FAP Load Balance Verification (PN 870-0243-XX only)	2-48
2.6.3	Change the Fan Tray Filter	2-53
2.6.4	Changing the Air Supply Filter	2-53
2.6.5	Cleaning Printer	2-54
2.6.6	Fuse Spares Inventory	2-55
2.6.7	Wrist Strap Test	2-55
2.7	Quarterly Procedures	2-56
2.7.1	Database Archive (Quarterly)	2-56
2.7.2	Preventing Dust Buildups	2-57
2.7.3	Rectifier Voltage Inspection/Recording	2-58
2.8	Semi-Annual Procedures	2-58

3 Corrective Maintenance

3.1	Introduction	3-1
3.2	System Alarm Levels	3-2
3.3	Trouble Detection	3-2
3.4	Output Messages	3-9
3.5	Alarm Clearing Procedures	3-11
3.6	Retrieve Trouble Report	3-11
3.7	Hourly Status Message Reports	3-12
3.8	Maintenance System Event Logs	3-16
3.9	Obituaries	3-18
3.10	Terminal Not Responding	3-19
3.11	Printer Not Working	3-20
3.12	Modem Not Working	3-22
3.13	Link Maintenance	3-22
3.13.1	Link Maintenance Enhancements	3-28
3.14	Power Down of In-Service System	3-36
3.15	Power Up of the System	3-39

A Card Removal/Replacement Procedures

A.1	Introduction	A-1
A.2	EAGLE Replacement Parts List	A-1
A.3	E5-MASP Card Replacement	A-1
A.4	E5-MDAL Card Replacement	A-14
A.5	HIPR2 Card Replacement	A-17
A.6	Determine Card Changeout Time	A-20

A.7	E5-ATM-B Card Replacement	A-21
A.8	SS7 and IP7 Card Replacement	A-24
A.9	E5-ENET-B Module	A-28
A.9.1	IP SIGTRAN on E5-ENET-B	A-30
A.9.2	EROUTE on E5-ENET-B	A-35
A.10	Database Services Module (DSM)	A-40
A.11	E5-SM8G-B Card Replacement	A-43
A.12	E5-ENET-B Card Replacement	A-46
A.13	Replacing Cards with SLIC Hardware	A-50
A.14	Database Communications Module (DCM)	A-51
A.15	Measurement Collection and Polling Module (E5-MCPM)	A-53
A.16	Replacing a Card in the EAGLE	A-54
A.17	Replacing Cards in the Holdover Clock	A-56
A.17.1	Non-Failed Clock Input (CI) Card Replacement	A-57
A.17.2	ST3 Card Replacement	A-58
A.17.3	MIS Card Replacement	A-60
A.17.4	TOCA Card Replacement	A-61
A.18	Fan Assembly P/N 890-0001-xx	A-64
A.18.1	Replace the Fan Unit	A-65
A.18.2	Replace Fan Controller Card	A-65
A.18.3	Replace Fan Assembly	A-66
A.18.3.1	Procedure - Power Down the Fan Assembly	A-66
A.18.3.2	Procedure - Remove Fan Cables and Fan Assembly	A-67
A.18.3.3	Procedure - Install the Fan Assembly	A-68
A.18.3.4	Procedure - Power Up the Fan Assembly	A-70

B Holdover Clock Troubleshooting Procedures

B.1	Introduction	B-1
B.2	Interpreting System Alarms, Lamps And Trouble Isolation	B-1

C Part Numbers

C.1	Overview	C-1
C.2	Cables, Adapters	C-2
C.3	Customer Supplied Ethernet Cable Requirements	C-6
C.4	Components	C-6
C.5	Frames, Backplanes, FAPs, and Fans	C-8
C.6	Labels	C-9
C.7	Miscellaneous Parts	C-10

My Oracle Support (MOS)

[My Oracle Support \(MOS\)](#) is your initial point of contact for any of the following requirements:

- **Product Support:**

The generic product related information and resolution of product related queries.

- **Critical Situations**

A critical situation is defined as a problem with the installed equipment that severely affects service, traffic, or maintenance capabilities, and requires immediate corrective action. Critical situations affect service and/or system operation resulting in one or several of these situations:

- A total system failure that results in loss of all transaction processing capability
- Significant reduction in system capacity or traffic handling capability
- Loss of the system's ability to perform automatic system reconfiguration
- Inability to restart a processor or the system
- Corruption of system databases that requires service affecting corrective actions
- Loss of access for maintenance or recovery operations
- Loss of the system ability to provide any required critical or major trouble notification

Any other problem severely affecting service, capacity/traffic, billing, and maintenance capabilities may be defined as critical by prior discussion and agreement with Oracle.

- **Training Need**

Oracle University offers training for service providers and enterprises.

My Oracle Support (<https://support.oracle.com>) is your initial point of contact for all product support and training needs. A representative at Customer Access Support can assist you with My Oracle Support registration.

Call the Customer Access Support main number at 1-800-223-1711 (toll-free in the US), or call the Oracle Support hotline for your local country from the list at <http://www.oracle.com/us/support/contact/index.html>. When calling, make the selections in the sequence shown below on the Support telephone menu:

- For Technical issues such as creating a new Service Request (SR), select **1**.
- For Non-technical issues such as registration or assistance with My Oracle Support, select **2**.
- For Hardware, Networking and Solaris Operating System Support, select **3**.

You are connected to a live agent who can assist you with My Oracle Support registration and opening a support ticket.

My Oracle Support is available 24 hours a day, 7 days a week, 365 days a year.

Acronyms

The following table provides information about the acronyms and the terminology used in the document:

Table Acronyms

Acronym	Description
AS	Associate State
BOC	Bit Oriented Code
CDL	Command Driven Loopback
CI	Clock Input
CSV	Comma Separated Value
DCM	Database Communications Module
DPC	Destination Point Codes
DSM	Database Services Module
DUT	Device Under test
DVM	Digital Volt/Ohm Meter
EDCM	Enhanced Database Communications Module
EMDC	Element Measurement & Data Collection
EPAP	EAGLE Provisioning Application Processor
ESD	Electrostatic Discharge
FAP	Fuse and Alarm Panel
FD CRNT	Fixed Disk Current Partition
FTA	File Transfer Area
GPL	Generic Program Loads
IMP	Interprocessor Message Transport
IPMX	Interprocessor Message Transport Power and Multiplexer
LBF	Load Balance Factor
LFS	Link Fault Sectionalization
LIM	Link Interface Module
LSMSSS	Local Services Management System Subsystem
MAS	Maintenance and Administration Subsystem
MASP	Maintenance Administration Subsystem Processor
MCA	Matrix Controller Automatic
MCPM	Measurement Collection and Polling Module
MIS	Maintenance Interface System
MPS	Multi-Purpose Server
MRN	Message Reference Number
NDCSS	Network Data Collection Subsystem
PST	Primary State
RMA	Return of Material Authorization
RMC	Remote Maintenance Center
SCMMA	State Change due to Manual Action

Table (Cont.) Acronyms

Acronym	Description
SCP	Signaling Control Point
SLC	Signaling Link Code
SLIC	Service and Link Interface Card
SST	Secondary State
STP	Signal Transfer Point
TFP	Transfer Prohibited
TFR	Transfer Restricted
TOCA	Timing Output Composite Automatic
UAM	Unsolicited Alarm Messages
UIM	Unsolicited Information Messages

What's New in This Guide

This section introduces the documentation updates for Release 47.0 in Oracle Communications EAGLE Maintenance Guide.

Release 47.0 -F41415-02, August 2023

- Added a note about the list of cards supported by EAGLE release 47.0 in the [Introduction](#) section.

1

Introduction

This chapter describes the content and structure of the user's guide, indicates how to obtain help, details where to find related documentation, and provides other general information.

1.1 Overview

Maintenance Guide provides preventive and corrective maintenance procedures used in maintaining the Oracle Communications EAGLE and the **Multi-Purpose Server (MPS)** systems.

NOT_SUPPORTED:

Be sure to wear a wrist strap connected to the wrist strap grounding point of the **EAGLE** before performing any installation procedures on the EAGLE.

The manual is organized as follows:

- [Introduction](#) provides general information about the organization of this manual, a description of the EAGLE maintenance strategy, and a list of acronyms and abbreviations.
- [Preventive Maintenance](#) provides recommended scheduled routines for the EAGLE.
- [Corrective Maintenance](#) provides procedures to use in response to all system alarms by the EAGLE.

In addition, these appendices of this manual provide useful reference material for maintenance, diagnostic, and troubleshooting activities.

- [Card Removal/Replacement Procedures](#)
- [Holdover Clock Troubleshooting Procedures](#)
- [Part Numbers](#)

1.2 Scope and Audience

This manual is intended for maintenance personnel who must maintain the EAGLE. The technician should be familiar with **SS7** protocols. The manual provides preventive and corrective procedures that will aid maintenance personnel in maintaining the EAGLE.

Preventive maintenance procedures are routines to be carried out on a scheduled basis to help prevent system failures. These routines are industry-standard recommendations and may be adopted to fit any company maintenance plan.

The corrective maintenance procedures are those used in response to a system alarm or output message. These procedures are EAGLE-specific and aid in the detection, isolation, and repair of faults.

1.3 References

For more information on Maintenance Guide, refer to the following documents:

- *Application B Card Hardware and Installation Guide*
- *Commands User's Guide*
- *Installation Guide*

1.4 Hardware Repair and Return

Any system components being returned for repair or replacement must be processed through the Oracle Return Material Authorization (RMA) procedures. A hardware repair is defined as an item returned to Oracle due to a failure, with the returned item being repaired and returned to the customer. It is essential that serial numbers are recorded correctly. RMAs cannot be created without a valid serial number. All repair and quality information is tracked by serial number. [Table 1-1](#) lists the basic RMA types. [Table 1-2](#) lists the RMA return reasons.

Table 1-1 Basic RMA Types

Replacement Type	Description	Turnaround
Priority Advance Replacement	Customer requests the URGENT replacement of a damaged product	Same Day Shipment
Advance Replacement	Customer request the replacement of a damaged product	Shipment Within 3 Business Days
Repair / Return	Customer will return a damaged product for repair	Shipment Within 5 Days After Receipt
Expendable	A damaged part, such as a cable, is replaced, but the Customer does not return the damaged product	Depends on Urgency - Shipment Within 3 Business Days

Table 1-2 RMA Reasons for Return

Reason for Return	Description
Damaged by Environment	Product damaged by environmental phenomena such as water damage or earthquake.
Damaged in Shipment	Damaged between shipment from Oracle and receipt at the Customer's installation site.
DOA – Dead on Arrival	Product is not functional when it is first installed at the Customer's location.
Lab Return	Products returned from lab sites.
Product Capture	Defect to be captured by Quality or Engineering (not Product Recall).

Table 1-2 (Cont.) RMA Reasons for Return

Reason for Return	Description
Product Deficiency	Anything wrong with the part that doesn't fall into another category.
Product Recall	Products recalled by divisions for the repair of a defect or replacement of defective products.
Return – No Product Deficiency	Anything returned without the product being defective.

1.4.1 Repair and Return Shipping Instructions

All returned equipment, assemblies, or subassemblies must be shipped to the Oracle Repair and Return Facility specified by the [My Oracle Support \(MOS\)](#). The item being returned must be shipped in the original carton or in an equivalent container assuring proper static handling procedures and with the freight charges prepaid.

The assigned RMA number must be clearly printed on the “RMA#.” line of the shipping label on the outside of the shipping package. If the RMA number is not placed on the label, the return could be delayed.

Procedure - RMA

1. Obtain and confirm the following information before contacting the [My Oracle Support \(MOS\)](#):
 - Your name:
 - Company name:
 - Call-back number:
 - Email address:
 - Which product you are calling about?
 - Site location:
 - CLEI number
 - System serial number (NT, CE, LM, DS, etc.):
 - Complete software release (e.g., 28.0.1-41.53.0):
 - Upgrade forms
 - WI005153
 - WI005154
 - WI005218
 - WI005219
 - WI005220
 - Oracle card type: (e.g., E5-APP-B, E5-ENET, etc.):
 - Oracle card part number (870-#####-##):
 - Associated serial number (102#####):

- Reason for return or replacement (isolated from system):
- Full name of person the replacement card is being shipped to:
- Shipping address:

 **Note:**

If possible, include associated alarms (UAMs) and a copy of the associated output (capture file).

2. Contact the [My Oracle Support \(MOS\)](#) and request a Return of Material Authorization (RMA).
3. If the item is a like-for-like advance replacement, the [My Oracle Support \(MOS\)](#) arranges for shipment of the replacement item to the customer.
 - a. Wait for the replacement component to arrive.
 - b. Package the defective component in the box of materials you received with your replacement. Use proper static handling procedures.
 - c. Label the outside and inside of the box with your RMA number clearly visible. Place the packing slip from the received replacements on the inside of your box.
 - d. Ship the defective component to the return address listed on the packing slip.
4. If the item is a repair/return, the [My Oracle Support \(MOS\)](#) arranges for shipment of the replacement item to the customer.
 - a. Package the defective component in a suitable package for shipping. Use proper static handling procedures.
 - b. Label the outside and inside of the box with your RMA number clearly visible. Include a packing slip with all the information from [1](#) along with the RMA number.
 - c. Ship the defective component to the following address:

ORACLE
Attn: RMA Department
5200 Paramount Parkway
Morrisville, NC 27560
RMA#: <assigned by Oracle>
 - d. Wait for the repaired component to arrive.

1.5 Maintenance Strategy

The EAGLE is equipped with an automated surveillance system, which allows many failures to be detected and repaired autonomously. When trouble is detected, and its cause determined, the system software attempts to isolate the trouble and recover itself through reinitialization. Because of the use of distributed processing throughout the system, the reinitialization can be localized with little or no impact on the rest of the system or network.

If the system software is unable to correct the problem, an output message is generated and maintenance personnel are provided with equipment location, nature of the trouble, and alarm severity.

There are three levels of recovery in the EAGLE:

- Application self recovery
- System maintenance software intervention
- Maintenance personnel intervention.

Application Self Recovery

This is the most desirable method of recovery, as it is nearly transparent to the network, and does not require any system resources. Examples of applications capable of self recovery:

- **Link** failure
- **Link** set failure
- **Route** failure
- Interprocessor message transport (IMT) bus failure.

Failure of a link relies on **SS7** maintenance to correct the trouble. This usually entails placing the link out of service (**OS**), re-aligning the link, then placing the link back in service.

Route failures also rely on **SS7** maintenance. Transfer restricted (**TFR**) and transfer prohibited (**TFP**) are commonly used to reroute messages around a node.

System Maintenance Software Intervention

The system maintenance software operates at two levels, maintenance and administration subsystem (**MAS**) and application subsystem (**SS7**, **GLS**, **DTA**). All troubles detected at the application level are reported to the maintenance and administration subsystem (**MAS**), which is responsible for generating system alarms and output messages.

Maintenance Personnel Intervention

Maintenance personnel intervention is required when hardware fails, or when software is unable to recover. There are few occurrences of maintenance that would require maintenance personnel intervention. Examples include:

- Blown fuses
- Loss of power

 **Note:**

Maintenance personnel intervention is required to restore the power. Once power is restored, the EAGLE recovers automatically.

- **Card** failure

1.6 System Maintenance Log

The purpose of the System Maintenance Log is to provide both maintenance personnel and [My Oracle Support \(MOS\)](#) with a complete trouble history for a specific site. This history aids

in spotting trouble trends, which, if left unrecorded, would be impossible to detect. Record all maintenance regardless of nature.

On the following page is an example of a system maintenance log. Use this page to generate copies for your site. Oracle recommends this log be completed after every preventive and corrective maintenance procedure.

This is a troubleshooting aid, and should be filled out completely. Printouts or any other supportive material should be referenced whenever possible. [My Oracle Support \(MOS\)](#) may ask for some of this information at a later time, if a particular trend begins to develop.

The trouble code field in the log is for recording EAGLE trouble messages. All maintenance (regardless of nature) should be recorded on this log for reference when troubleshooting.

Table 1-3 System Maintenance Log

System Maintenance Log

2

Preventive Maintenance

2.1 Introduction

The procedures on the following pages are routine maintenance procedures to be performed on a scheduled basis. These procedures are recommendations that if followed will aid in maintaining system performance and data integrity.

These routines aid in detecting trouble trends and intermittent troubles. As with any maintenance activity, personnel should be encouraged to maintain a log of all routines performed. This aids the maintenance technician as well as [My Oracle Support \(MOS\)](#) in determining the source of system troubles and ways to prevent certain troubles from occurring again.

Instructions for performing required maintenance routines are provided. In the event another document may be required for a specific task, that document is referenced.


2.2 Maintaining the Fuse and Alarm Panel

The Fuse and **Alarm Panel (FAP)** serves as a central location for identifying a variety of potential problem conditions. However, you may have to occasionally perform corrective maintenance on the **FAP**, itself.

The **FAP** consist of five major functions:

- Input connections
- Diodes
- Fuse Arrays
- **Alarm** circuitry
- Output connections

Figure 2-1 FAP High-Level Block Diagram



To assist your **FAP** maintenance efforts, this section provides information about the **FAP** unit:

- The **FAP** components
- **FAP** alarms
- Diode testing and the diode jumper

For more detailed information on the **FAP** and its components, refer to the **FAP Technical Reference (820-2888-01)**.

2.2.1 1U FAP P/N 870-2804-01

The 1U FAP (P/N 870-2804-01) is a low-profile unit that provides protected distribution of -48VDC power to the shelves in the frame. Allowing for the full population of a frame and for the failure of one primary supply, new installations of Control and Extension frames require two 60A feeds.

2.2.1.1 FAP Components

The **FAP** is composed of three field replaceable units, of which two can be hot-swapped.

Table 2-1 FAP Component Replacement

Component	Replacement Requirements	Part Number
Diode Board	Field replaceable	870-2806-01
Shorting Board	Field replaceable	870-2805-01
1U FAP	Field replaceable (with service interruption)	870-2804-01 (includes Diode and Shorting Boards)

Diode Board

The diode board in the FAP contains power diodes and circuitry which allow one bus to pick up the entire load when there is a loss of input power on the other bus.

Shorting Board

The Shorting board allows the removal of the diode board without taking down the system. This permits periodic maintenance of the diodes without having to power down or remove the unit from the shelf. In the bypass position, both A and B power is connected to the fuse blocks so the diode board can be safely removed. The Shorting board has an LED which is off when the board is in normal operational mode and is green when in the bypass mode of operation.

2.2.1.2 Alarms

The **FAP** provides visual alarms, by means of a lit **LED**, for a variety of status alarms.

Table 2-2 FAP Alarm Conditions

Alarm	Alarm Condition	Remote Indications
Critical LED	<ul style="list-style-type: none"> EAGLE command through E5-TDM E5-MDAL not present and E5-MDAL_P jumper off 	Dependent on EAGLE software
Major LED	EAGLE command through E5-TDM	Dependent on EAGLE software
Minor LED	EAGLE command through E5-TDM	Dependent on EAGLE software
Fuse LED	<ul style="list-style-type: none"> Distribution fuse blown Alarm circuit board removed (no LED indication) Jumper on the jumper circuit board is on Power feed failure 	Fuse alarm to EAGLE through E5-TDM
PWR A LED	Power feed A is off, but power is available to B.	Fuse alarm to EAGLE through E5-TDM
PWR B LED	Power feed B is off, but power is available to A.	Fuse alarm to EAGLE through E5-TDM
Shorting Board LED	Shorting board in maintenance mode.	Fuse alarm to EAGLE through E5-TDM

A fuse alarm identifies the following problems or conditions within the **FAP**:

- blown fuse(s)

- power loss for side A or B
- alarm card removed
- maintenance mode

Use the following indicators to determine the nature of the problem:

Table 2-3 Additional Alarm Indicators

Indicator	Alarm Condition
Fuse alarm and fuse flag down	Blown fuse
Fuse alarm and PWR A LED	Input power loss on A
Fuse alarm and PWR B LED	Input power loss on B
Fuse alarm red and Shorting Board LED is green	Shorting Board in maintenance mode (bypassing diodes)
Fuse alarm red and Shorting Board LED is off	Shorting Board in normal mode, blown fuse

2.2.1.3 Diode Testing and the Shorting Board

The Diode Board must be tested periodically. To test the Diode Board without powering down the entire EAGLE, perform the following procedures.


2.2.1.3.1 Maintenance Mode

This section describes how to place the Shorting Board into maintenance (bypass) mode. Maintenance mode allows the removal of the Diode Board without taking down the system.

Procedure — Shorting Board Maintenance Mode


1. Check to verify the Shorting Board LED is not on, indicating the FAP is in normal mode.
2. Locate two screws securing the Shorting Board in its slot (see [Figure 2-2](#)). Note the orientation of the Shorting Board LED. Turn the screws at each corner of the board to the left until they disengage.

Figure 2-2 Shorting Board Faceplate, Normal Mode



3. Pull the board straight out of the FAP until the board is clear of the frame.
4. Turn the Shorting Board over and reinsert the board into its slot. Note the orientation of the Shorting Board LED (see [Figure 2-3](#)).

Figure 2-3 Shorting Board Faceplate, Maintenance Mode



The Shorting Board LED turns green and the fuse alarm LEDs turn red.

5. Ensure the board is seated properly and tighten the two screws to secure the board.
6. The Shorting Board is now in the maintenance (bypass) mode of operation.

2.2.1.3.2 Diode Board


This section describes how to remove and test the Diode Board.

Procedure — Remove the Diode Board

Use this procedure to remove the Diode Board for diode testing.

1. Check to verify the Shorting Board LED is on, indicating the FAP is in maintenance (bypass) mode.
2. Locate two screws securing the Diode Board in its slot. Turn the screws to the left until they disengage.

Figure 2-4 Diode Board Faceplate




3. Pull the board straight out of the FAP until the board is clear of the frame.

Procedure - Diode Testing

Use this procedure to test the power diodes on the Diode Board. A Digital Volt/Ohm Meter (DVM) with a Diode Setting is required. All testing is performed at the edge connector (J1) on the board.

Figure 2-5 Diode Board Edge Connector J1



1. Set the DVM to test diodes.
2. Connect the DVM positive (+) lead and negative (-) lead to the pins indicated for each power diode.

Table 2-4 Power Diode Test Points

Diode	J1 Pin Positive (+) Lead	J1 Pin Negative (-) Lead
CR1 #1	3	16
CR1 #2	6	16
CR2 #1	14	1
CR2 #2	11	1
CR3 #1	4	16
CR3 #2	5	16
CR4 #1	13	1
CR4 #2	12	1

The DVM should indicate a short circuit ($>0.1V$, $<0.2V$). Record the measurement.

3. Reverse the leads.
The DVM should indicate an open circuit (OL). Record the measurement.
4. If any measurements are in error, the diode board must be replaced.
5. If the measurements are within acceptable parameters, reinstall the Diode Board.


2.2.1.3.3 Normal Mode

Use this procedure to place the Shorting board into normal mode. This mode of operation allows one bus to pick up the entire load when there is a loss of input power on the other bus.

Procedure — Shorting Board Normal Mode


1. Check to verify the Shorting Board LED is green, indicating the FAP is in maintenance mode.
2. Locate two screws securing the Shorting Board in its slot. Note the orientation of the Shorting Board LED (Figure 2-6). Turn the screws at each corner of the board to the left until they disengage.

Figure 2-6 Shorting Board Faceplate, Maintenance Mode



3. Pull the board straight out of the FAP until the board is clear of the frame.
4. Turn the Shorting Board over and reinsert the board into its slot. Note the orientation of the Shorting Board LED (see Figure 2-7).

Figure 2-7 Shorting Board Faceplate, Normal Mode



 **Note:**

The Shorting Board LED is off and the fuse alarm LEDs turn green.

5. Ensure the board is seated properly and tighten the two screws to secure the board.
6. The Shorting Board is now in the normal mode of operation.

2.2.2 3U FAP

The 3U FAP is a normal-profile unit that provides protected distribution of –48VDC power to the shelves in the frame. Allowing for the full population of a frame and for the failure of one primary supply, new installations of Control and Extension frames require two 60A feeds. The 3U FAP may be one of the following:


- 870-1606-01 (all revisions)
- 870-1616-02 with a revision G or lower
- 870-2320-01 with a revision B or lower

2.2.2.1 FAP Components

The **FAP** consists of nine printed circuit boards, each identified by an acronym on its label (see [Figure 2-8](#)):


- Backplane (**FAP_BP**): Located inside the **FAP** unit, parallel to the back side of the **FAP** box.
- **Alarm** board (**FAP_AB**): Located on the center-right of the front panel, set vertically inside the **FAP** unit, perpendicular to the front panel.
- Diode boards (**FAP_DB**): Two boards located on the front panel, flanking the **Alarm** and Jumper boards on the left and right, and perpendicular to the front panel. Set vertically inside the **FAP** unit.
- Extender boards (**FAB-EB**): Two boards located inside the **FAP** unit, parallel to the bottom of the **FAP** box, on the far right and left of the unit.
- Fuse holder boards (**FAP_FB**): Two boards located inside and parallel to the front panel, on the far right and left of the **FAP** unit.
- Jumper board (**FAP_JB**): Located on the center-left of the front panel, set vertically in the unit, perpendicular to the front panel.

Figure 2-8 Location of FAP Components



Each of the **FAP** components has associated functions.

Figure 2-9 FAP Component Functions



The **FAP** is composed of nine circuit boards. Eight of these circuit boards are field replaceable, and can be hot-swapped.

Table 2-5 FAP Component Replacement

Component	Replacement Requirements	Part Number
FAP Backplane (FAP_BP)	Must be replaced through factory	850-0515-xx
FAPAlarm Board (FAP_AB)	Field replaceable	850-0518-xx (card) 870-1609-xx (assembly)

Table 2-5 (Cont.) FAP Component Replacement

Component	Replacement Requirements	Part Number
FAP Diode Boards (FAP_DB_A and FAP_DB_B)	Field replaceable (one at a time)	850-0517-xx (card) 870-1608-xx (assembly)
FAP Extender Boards (FAP_EB)	Field replaceable (one at a time with service interruption)	850-0519-xx
FAP Fuse Holder Boards (FAP_FB)	Field replaceable (one at a time with service interruption)	850-0516-xx
FAP Jumper Board (FAP_JB)	Field replaceable	850-0523-xx (card) 870-1641-xx (assembly)

The following sections describe each type of circuit board:

Backplane Board (**FAP_BP**)

The backplane circuit board provides all of the external connections for the **FAP**. It consists primarily of circuit routing and connectors, but also has one pull-down resistor, which provides a default alarm signal for the Fuse **Alarm** in the event the alarm board is removed from the **FAP**.

Alarm Board (**FAP_AB**)

The alarm circuit board provides indicators and relays for the **EAGLE** status and fuse alarms. This board includes a jumper (**JMP50**) for future use. This jumper is installed for all existing configurations.

Diode Boards (**FAP_DB**)

The diode circuit boards provide power diodes and power input test points. Four diode footprints are included: two for Assembly A and two for Assembly B. Only one of the four positions is intended to be populated; the second footprint is provided for future part rating changes or additional heat-dissipation capabilities.

Extender Boards (**FAP_EB**)

The extender board provides connection between the backpanel board and the fuse holder boards.

Fuse Holder Boards (**FAP_FB**)

The fuse holder boards provide 20 fuses with a common alarm.

Jumper Board (**FAP_JB**)

The jumper board provides the capability to by-pass the diode boards with a fuse. Use this board only for maintenance operations.

2.2.2.2 Alarms

The **FAP** provides visual alarms, by means of a lit **LED**, for a variety of status alarms (see [Table 2-6](#)).

Table 2-6 FAP Alarm Conditions

Alarm	Alarm Condition	Remote Indications
Critical LED	<ul style="list-style-type: none"> EAGLE command through E5-MCAP E5-MDAL not present and E5-MDAL_P jumper off 	Dependent on EAGLE software
Major LED	EAGLE command through E5-MCAP	Dependent on EAGLE software
Minor LED	EAGLE command through E5-MCAP	Dependent on EAGLE software
Fuse LED	<ul style="list-style-type: none"> Distribution fuse blown Alarm circuit board removed (no LED indication) Jumper on the jumper circuit board is on Power feed failure 	Fuse alarm to EAGLE through E5-MCAP
PWR A LED	Power feed A is off, but power is available to B.	Fuse alarm to EAGLE through E5-MCAP
PWR B LED	Power feed B is off, but power is available to A.	Fuse alarm to EAGLE through E5-MCAP
OP/MAINTLED	Jumper on the jumper circuit board is on.	Fuse alarm to EAGLE through E5-MCAP

A fuse alarm identifies the following problems or conditions within the **FAP**:

- blown fuse(s)
- power loss for side A or B
- alarm card removed
- maintenance mode

Use the following indicators to determine the nature of the problem:

Table 2-7 Additional Alarm Indicators

Indicator	Alarm Condition
Fuse alarm and fuse flag down	Blown fuse
Fuse alarm and PWR A LED	Input power loss on A
Fuse alarm and PWR B LED	Input power loss on B
Fuse alarm and OP/MAINT LED is red	Diode jumper is installed (by-passing diodes)

2.2.2.3 Diode Testing and the Diode Jumper

The diode board must be tested periodically. To test a diode circuit board without powering down the entire **EAGLE**, perform the procedure listed in [Table 2-8](#) for the corresponding **FAP** part number.

Table 2-8 FAP Part Numbers and Corresponding Procedures

Part Number	FAP Procedure
870-1606-01 (all revisions)	Procedure 1
870-1616-02 revision G or lower	Procedure 1
870-1606-02 revision H or higher	Procedure 2
870-2320-01 revision B or lower	Procedure 1
870-2320-01 revision C or higher (or 870-2320-03)	Procedure 2

Procedure 1

This procedure to test a diode circuit board without powering down the entire **EAGLE** applies to the following **FAPs**:

- 870-1606-01 (all revisions)
 - 870-1616-02 with a revision G or lower
 - 870-2320-01 with a revision B or lower
1. Check to verify the **OP/MAINT LED** is green, indicating the **FAP** is not in maintenance mode.
 2. Unscrew the two thumbscrews securing the **FAP** jumper board and remove the board.
 3. On the jumper circuit board, move the jumper (the **DB-26** male connector) from P71 to P72. Tighten the thumbscrews connecting the jumper to its mate, to ensure a good connection. This repositioning overrides the diodes, establishing a direct connection between input and fuse panels.

 **warning:**

If fuses are blown, **DO NOT** continue with this procedure. Instead, contact [My Oracle Support \(MOS\)](#) at the appropriate number.

4. Make sure the glass fuses are installed and verify they are “good” by using the multimeter to check for continuity across each of the glass fuses.
5. Verify that two glass fuses are behind the P72 connector. If these fuses are not present, install them before continuing.
6. Slide the jumper board back into the **FAP** and verify both of the following alarms display:
 - the **OP/MAINT LED** lights red on the **FAP**
 - an EAGLE fuse alarm displays on the terminal

You may now remove either or both diode circuit boards without affecting EAGLE service.

 **Note:**

Using the jumper override negates the backpower protection usually provided by the diode board.

7. Locate diode board A and unscrew the two thumbscrews securing the board. Remove the board from the **FAP**.
8. Locate the diode to be tested. It has three pins and is attached to the large heat sink. The diode is labeled **CR43**.
9. Set your digital multimeter to measure resistance.
10. Measure the resistance between the center pin of the diode and either of the outside pins. Record this measurement.
11. Measure the resistance between these same pins again, but switch the multimeter leads, so the positive lead is now on the opposite pin. Record this measurement.
12. Compare the two measurements. If the diode is functioning properly, one reading should be less than 10K ohms and the other should be much greater.

If both readings are above or below 10K ohms, the diode may have failed. Replace the failed board with a spare diode board.
13. Repeat steps 9 through 11, measuring the resistance between the *other* outside pin and the center pin.

This completes the test for diode board A.
14. Repeat steps 6 through 12, using diode board B. This completes the test for diode board B.
15. Reinsert the two functional diode boards. Tighten the thumbscrews on each board to secure it to the **FAP**.
16. Unscrew the two thumbscrews securing the **FAP** jumper board and remove the board.
17. On the jumper circuit board, move the jumper (the **DB-26** male connector) back from P72 to its original position on P71. Tighten the thumbscrews connecting the jumper to its mate, to ensure a good connection. This repositioning returns the diodes to their original, non-maintenance position.
18. Slide the jumper board back into the **FAP**. Verify the **OP/MAINT LED** lights green. The fuse alarm **LED** returns to green.

The diode board testing procedure is completed.

Procedure 2

This procedure to test a diode circuit board without powering down the entire **EAGLE** applies to the following **FAPs**:

- 870-1606-02 with revision H or higher
 - 870-2320-01 with revision C or higher (or 870-2320-03)
1. Check to verify the **OP/MAINTLED** is green, indicating the **FAP** is not in maintenance mode.
 2. Unscrew the two thumbscrews securing the **FAP** jumper board and remove the board.
 3. On the jumper circuit board, unclip the 12 pin connector jumper from P71 and re-attach it to P72.

Insert it until the plastic retaining clips "snap". Note that the jumper has a retaining strap so it won't get dropped or lost. This repositioning overrides the diodes, establishing a direct connection between input and fuse panels.

 **warning:**

If fuses are blown, **DO NOT** continue with this procedure. Instead, contact [My Oracle Support \(MOS\)](#) at the appropriate number.

4. Slide the jumper board back into the **FAP** and verify both of the following alarms display:
 - the **OP/MAINTLED** lights red on the **FAP**
 - an EAGLE fuse alarm displays on the terminal
You may now remove either or both diode circuit boards without affecting EAGLE service.
5. Locate diode board A and unscrew the two thumbscrews securing the board.
Remove the board from the **FAP**.
6. Locate the diode to be tested.
There are two power diodes, each with three pins. They are labeled **CR43** and **CR44** for diode board A.
7. Set your digital multimeter to diode check mode..
8. Measure the voltage drop between the center pin of the **CR43** diode and either of the outside pins with the ground probe on the center lead.
Record this measurement.
9. Measure the voltage drop between these same pins again, but switch the multimeter leads, so the positive lead is now on the opposite pin.
Record this measurement.
10. Compare the two measurements.
If the diode is functioning properly, the first reading should be between 0.2 and 0.1 volts and the other should be read as an open circuit. Otherwise, replace² the failed board with a spare diode board.
11. Repeat 9 through 10, measuring the voltage between the *other* outside pin and the center pin of **CR43**.
12. Repeat 6 through 10, using diode board B.
This completes the test for diode board B.
13. Reinsert the two functional diode boards.
Tighten the thumbscrews on each board to secure it to the **FAP**.
14. Unscrew the two thumbscrews securing the **FAP** jumper board and remove the board.
15. On the jumper circuit board, unclip the 12 pin connector jumper back from P72 to its original position on P71.
Insert it until the plastic retaining clips "snap." This repositioning returns the diodes to their original, non-maintenance position.

16. Slide the jumper board back into the **FAP**.

Verify the **OP/MAINTLED** lights green. The fuse alarm **LED** returns to green. The diode board testing procedure is completed.

2.3 Removable Drives

This section provides information about the removable drives associated with the EAGLE Maintenance Administration Subsystem Processor (MASP).

A removable drive is used for two purposes:

- To hold an off-line, backup copy of the administered data and system **GPLs**
- To hold a copy of the measurement tables

To use a removable drive to hold the system data, it must be formatted for system data. To use a removable drive to hold measurements data, it must be formatted for measurements data. The EAGLE provides the user the ability to format a removable drive for either of these purposes. A removable drive can be formatted on the EAGLE by using the `format-disk` command. For more information on the `format-disk` command refer to *Commands User's Guide*.

Removable drives described in this section include:

- [Removable USB Drive](#)
- [Fixed SATA Drive](#)

The USB storage media in the flush-mounted USB port of the MSP card is also used for backups. The `dest=usb` parameter is used to run the same.

2.3.1 Removable USB Drive

Purpose:

This section is referenced in this manual by many procedures requiring the use of the removable USB thumb disk in the E5-MASP card. The procedures found in this section are recommended procedures for handling the removable USB drive in the E5-MASP card.

Requirements:


None

Procedure - Remove USB Drive

1. Verify that the removable USB drive is locked in position and in use.

The removable drive latch (SW1) is in the LOCKED position and the Removable Media Status **LED** on the E5-MASP is Off. Refer to [Figure 2-10](#).

Figure 2-10 Removable USB Drive LOCKED




2. Move SW1 from the LOCKED to the unlocked position and wait for the LED to indicate a steady blue state. See [Figure 2-11](#).

When SW1 is transitioned from locked to unlocked, the LED will flash blue to indicate the drive is unlocked and in process of shutting down.

Caution:

Removal of the drive prior to the LED indicating steady blue could result in drive corruption.

Figure 2-11 Removable USB Drive UNLOCKED



3. When the LED indicates a steady blue state, the removable USB drive can be safely removed. The **LED** is off when the USB drive is fully ejected from the drive media.
The USB drive can now be removed from the drive media.
4. Lift the access door up, swing it past the detent position so that the door remains open on its own.
5. Grasp the pull tab of the slide and pull the slide out slowly until it stops (it travels about a half inch).

▲ Caution:

The full travel of the slide is less than an inch, do not try to pull the assembly to expose the full length of the thumb drive as this is beyond the slide's designed travel.

6. The USB drive is disengaged and can be taken from the inject eject assembly.
7. Insert a USB drive into the inject-eject assembly.
8. Grasp the pull tab of the slide and push the slide in slowly until you feel the USB drive is seated in its slot (it travels about a half inch).
9. Close the access door.
10. Move SW1 from the unlocked to the LOCKED position.
When SW1 is transitioned from unlocked to locked, the LED will flash blue to indicate the drive is locked and in process of coming online.
11. When the LED turns Off, the removable USB drive is ready for use.

2.3.2 Fixed SATA Drive

Purpose:

This section is referenced in this user's guide by many procedures requiring the use of the fixed SATA drive in the E5-MASP card. The procedures found in this section are recommended procedures for handling the fixed drive in the E5-MASP card.

Requirements

- The new SATA Drives to be installed should be at the current system release.
- Before beginning this procedure, make sure there is a copy of the current release GPLs on a removable USB drive on-hand.
- System backups should be performed prior to the start of this procedure. Refer to [Daily Procedures](#).
- You must be logged in to the EAGLE prior to performing this procedure.

Procedure - Remove Fixed SATA Drive

1. Enter the following command to verify that the Measurement feature bit is on.

```
rtrv-feat
```

The following is an example of a possible output. The **MEASPLAT** field shows whether the Measurement feature is on or off. In this example, Measurement feature is **ON**.

```
eagle3 02-01-05 00:51:32 EST EAGLE5 41.2.0-62.69.65
rtrv-feat
Command entered at terminal #7.
;

eagle3 02-01-05 00:51:32 EST EAGLE5 41.2.0-62.69.65
EAGLE FEATURE LIST

GTT      = on      GWS      = on      NRT      = off
X25G     = off     LAN      = on      CRMD     = off
SEAS     = off     LFS      = off     MTPRS    = off
FAN      = on      DSTN5000 = off     WNP      = off
CNCF     = off     TLNP     = off     SCCPCNV  = off
TCAPCNV  = off     IPISUP   = off     X252000  = off
PLNP     = off     NCR      = off     ITUMTPRS = on
SLSOCB   = off     EGTT     = on      VGTT     = on
MPC      = on      ITUDUPPC = on      MEASPLAT = on
TSCSYNC  = off     E5IS     = off
```

If feature bit is turned **OFF**, go to **5**.

2. Enter the following command to retrieve the measurements setup.

```
rtrv-meas-sched
```

The following is an example of a possible output. The **COLLECT** field shows whether measurement collection is on or off. In this example, measurement collection is **ON**.

```

npeeagle4 02-02-04 21:13:49 EST  EAGLE5 41.2.0-62.69.65
rtrv-meas-sched
Command entered at terminal #1.
;

npeeagle4 02-02-04 21:13:49 EST  EAGLE5 41.2.0-62.69.65
COLLECT          = ON
GTWYLSFLTR      = (both)
-----
SYSTOT-STP      = (off)
SYSTOT-TT       = (off)
COMP-LNKSET     = (off)
COMP-LINK       = (off)
GTWY-STP        = (off)
GTWY-LNKSET     = (off)
MTC-D-STP       = (on)
MTC-D-LINK      = (on)
MTC-D-LNKSET    = (on)
;

```

If measurement collection is **OFF**, go to [5](#).

- Issue the following command to turn **OFF** measurement collection.

```
chg-meas:collect=off
```

The following is an example of a possible output.

```

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP  XX.x.x-YY.y.y
chg-meas:collect=off
Command entered at terminal #10.
;

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP  XX.x.x-YY.y.y
CHG-MEAS: MASP A - COMPLTD
;

```

- Enter the following command to verify measurements collection is **OFF**.

```
rtrv-meas-sched
```

The following is an example of a possible output. The **COLLECT** field shows whether measurement collection is on or off. In this example, measurement collection is **OFF**.

```

npeeagle4 02-02-04 21:13:49 EST  EAGLE5 41.2.0-62.69.65
rtrv-meas-sched
Command entered at terminal #1.
;

npeeagle4 02-02-04 21:13:49 EST  EAGLE5 41.2.0-62.69.65
COLLECT          = OFF
GTWYLSFLTR      = (both)
-----
SYSTOT-STP      = (off)
SYSTOT-TT       = (off)

```

```

COMP-LNKSET      = (off)
COMP-LINK        = (off)
GTWY-STP        = (off)
GTWY-LNKSET      = (off)
MTCD-STP        = (on)
MTCD-LINK        = (on)
MTCD-LNKSET      = (on)

```

;

5. Enter the following command to display the card status:

```
rept-stat-card:appl=oam
```

The following is an example of a possible output.

Command Accepted - Processing

```

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
rept-stat-card:appl=oam
Command entered at terminal #14.

```

;

```

tekelecstp 10-04-19 16:47:51 EDT EAGLE5 41.1.0-62.64.1
CARD  VERSION      TYPE      GPL      PST
SST   AST
1113  132-064-000  E5MCAP   OAMHC    IS-NR
Standby -----
1115  132-064-000  E5MCAP   OAMHC    IS-NR
Active -----

```

Command Completed.

;

6. Enter the following command to display the card status:

```
this rept-stat-card
```

The following is an example of a possible output.

```

e5oam 08-12-01 15:38:32 EST EAGLE 46.0.0
CARD  VERSION      TYPE      GPL      PST
SST   AST
1108  -----      MCPM     MCP      OOS-MT-DSBLD
Manual -----
1109  030-009-000  HIPR2    HIPR2    IS-NR
Active -----
1110  030-009-000  HIPR2    HIPR2    IS-NR
Active -----
1111  030-010-000  IPSM     IPS      IS-NR
Active -----
1113  030-010-008  E5MCAP   OAMHC    IS-NR
Standby -----
1114  -----      E5TDM    IS-NR
Active -----
1115  030-010-008  E5MCAP   OAMHC    IS-NR

```

```

Active      -----
   1116     -----   E5TDM                      IS-NR          Active
-----
   1117     -----   E5MDAL                     OOS-MT         Isolated
-----

Command Completed.

```

In this sample output, 1113/1114 are standby and 1115/1116 are active.

Verify the E5-MASP card containing the fixed SATA drive to be replaced is in the **Standby** position before continuing.

- If it is **Standby**, go to 10.
 - If it is not **Standby**, go to 7.
7. Enter the following command to force the **Active** E5-MASP card to become **Standby**
- ```
init-card:loc=xxxx
```
- where xxxx is the card location (1113 or 1115).

 **Note:**

User will need to login after executing this command.

8. Enter the following command to re-login:

```
login:uid=eagle
```

9. Enter the password to complete login:

```
Enter Password : xxxxx
```

 **Note:**

This document does not provide the passwords required in the procedures. Passwords should be acquired from the customer.

The following is an example of a possible output.

```

Command Accepted - Processing

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
Command entered at terminal #13.
;
tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
NOTICE: This is a private computer system.
Unauthorized access or use may lead to prosecution.
0 LOGIN failures since last successful LOGIN
Last successful LOGIN was on port 13 on 09-03-04 @ 14:18:21
;

```

10. Inhibit the **Standby** card location from service by entering the following command:

inh-card:loc=xxxx  
wherexxxx is the **Standby** card location.

The following is an example of a possible output.

Command Accepted - Processing

```
eagle3 02-01-18 18:00:06 EST EAGLE 41.2.0-62.69.65
inh-card:loc=1113
Command entered at terminal #1.
```

;

```
eagle3 02-01-18 18:00:06 EST EAGLE 41.2.0-62.69.65
Card has been inhibited.
```

;


```
eagle3 02-01-18 18:00:06 EST EAGLE 41.2.0-62.69.65
Command Completed.
```

;

11. Verify that the SATA drive is locked in position and in use. Refer to [Figure 2-12](#).

The SATA drive latch (SW2) is in the LOCKED position and the SATA Media Status LED on the E5-MASP is Off.

Figure 2-12 SATA Drive Locked



12. Move SW2 from the LOCKED to the unlocked position and wait for the LED to indicate a steady blue state. See [Figure 2-13](#).

When SW2 is transitioned from locked to unlocked, the LED will flash blue to indicate the drive is unlocked and in process of shutting down.


**▲ Caution:**

Removal of the drive prior to the LED indicating steady red could result in drive corruption.

**▲ Caution:**

If locking switch is transitioned from locked to unlocked and the E5-MASP is in service, removal of the drive module will result in a card obit. All drive LEDs will blink red.

**Figure 2-13 SATA Drive UNLOCKED**



13. When the LED indicates a steady blue state, the SATA drive can be safely removed. The LED is off when the drive is fully ejected from the drive.

The drive can now be removed from the slot.

14. Loosen the SATA drive mounting screws.
15. Grasp the screws and pull the drive out slowly until it is free from the card.
16. Slide a SATA drive into the drive slot on the card.



17. Gently push the drive in slowly until it is properly seated.
18. Tighten the mounting screws.
19. Move SW2 from the unlocked to the LOCKED position.

When SW2 is transitioned from unlocked to locked, the LED will flash blue to indicate the drive is locked and in process of coming online.

20. When the LED turns Off, the SATA drive is ready for use.
21. Enter the following command to verify the card is in Standby and OOS-MT-DSBLD.

```
rept-stat-card:loc=xxxx:mode=full
where xxxx is the card location (1113 or 1115).
```

The following is an example of a possible output.

Command Accepted - Processing

```
eagle3 02-01-01 00:35:50 EST EAGLE5 41.2.0-62.69.65
rept-stat-card:loc=1115:mode=full
Command entered at terminal #1.
;

eagle3 02-01-01 00:35:50 EST EAGLE5 41.2.0-62.69.65
CARD VERSION TYPE GPL PST SST AST
1115 ----- E5MCAP OAMHC OOS-MT-DSBLD Manual

ALARM STATUS = ** 0514 Standby MASP is inhibited
BLMCAP GPL version = 132-068-000
IMT BUS A = -----
IMT BUS B = -----
CLOCK A = -----
CLOCK B = -----
CLOCK I = -----
MBD BIP STATUS = Valid
MOTHER BOARD ID = E5-MCAP
DBD STATUS = Valid
DBD TYPE = 1G ENET
DBD MEMORY SIZE = 4096M
HW VERIFICATION CODE = -----
CURRENT TEMPERATURE = 29C (85F)
PEAK TEMPERATURE: = 29C (85F) [02-01-01 00:23]
TROUBLE TEXT VER. = -----

Command Completed.
;
```

22. Issue the command to retrieve GPL versions.

```
rept-stat-gpl:loc=<stby E5-MASP>
where <stby E5-MASP> is the card location (1113 or 1115).
```

The following is an example of a possible output.

Command Accepted - Processing

```
eagle3 02-01-01 00:36:25 EST EAGLE5 41.2.0-62.69.65
```

```

rept-stat-gpl:loc=1115
Command entered at terminal #1.
;

eagle3 02-01-01 00:36:25 EST EAGLE5 41.2.0-62.69.65
GPL Auditing ON

 GPL CARD RUNNING APPROVED TRIAL
OAMHC 1115 ----- 132-069-061
132-069-061 *
 BLMCAP 132-068-000 132-068-000
132-068-000

 Command Completed.
;

```

Verify that the OAMHC and BLMCAP GPLs match on the Running, Approved and Trial columns.

 **Note:**

If GPL are in alarm contact [My Oracle Support \(MOS\)](#) and have system USB drives available for corrections

23. Enter the following command to put the card that was inhibited in back into service.

```

alw-card:loc=xxxx
wherexxxx is the card location used in 6.

```

Following is an example of a possible output.

```

Command Accepted - Processing

eagle3 02-01-18 18:02:20 EST EAGLE5 41.2.0-62.69.65
alw-card:loc=1113
Command entered at terminal #1.
;

eagle3 02-01-18 18:02:20 EST EAGLE5 41.2.0-62.69.65
Card has been allowed.
;

eagle3 02-01-18 18:02:20 EST EAGLE5 41.2.0-62.69.65
Command Completed.
;

```

 **Note:**

Allow the card to run for 5 minutes before continuing.

24. Enter the following command to verify the database is not consistent (different level as the other cards in the system).

```
rept-stat-db:display=version
```

The following is an example of a possible output.

Command Accepted - Processing

```
eagle3 02-01-10 21:52:58 EST EAGLE5 41.2.0-62.69.65
rept-stat-db:display=version
Command entered at terminal #1.
```

;

```
eagle3 02-01-10 21:52:59 EST EAGLE5 41.2.0-62.69.65
DATABASE STATUS: >> OK <<
 E5TDM 1114 (ACTV) E5TDM 1116 (STDBY)
 C LEVEL TIME LAST BACKUP C LEVEL TIME LAST
BACKUP

 FD BKUP Y 79 02-01-05 18:06:16 EST Y 1 02-01-05
00:06:16 EST
 FD CRNT Y 79 Y 1
 MCAP 1113 MCAP 1115
 - -----
 RD BKUP - - - - - -
 USB BKP - - - - - -

 CARD/APPL LOC C T LEVEL TIME LAST UPDATE VERSION STATUS

 OAMHC-RMV 1113 - - - - - - -
 OAMHC-USB 1113 - - - - - - -
 E5TDM-CRNT 1114 Y N 79 02-01-04 23:46:18 132-013-000
NORMAL
 E5TDM-BKUP 1114 Y - 79 02-01-04 23:46:18 132-013-000
NORMAL
 OAMHC-RMV 1115 - - - - - - -
 E5TDM-CRNT 1116 Y N 1 02-01-04 00:06:16 132-013-000
NORMAL
 E5TDM-BKUP 1116 Y - 1 02-01-04 00:06:16 132-013-000
NORMAL
```

EPAP A (NOACCS)

```
 C BIRTHDATE LEVEL EXCEPTION
 - -----
 PDB - - - -
 RTDB - - - -
 RTDB-EAGLE - - - -
```

EPAP B (NOACCS)

```
 C BIRTHDATE LEVEL EXCEPTION
 - -----
 PDB - - - -
 RTDB - - - -
```

RTDB-EAGLE - - - - -

;

Compare the VERSION STATUS of the E5-MASP cards. The DB Level in the new drive is expected to be different.

If the database VERSION on the new disk is not the same as the active disk, stop the procedure and contact [My Oracle Support \(MOS\)](#).

25. Enter the following command to show the version numbers of the GPLs stored on each fixed disk (E5-MASP).

```
rtrv-gpl
```

The following is an example of a possible output.

```
tekelecstp 18-01-18 21:23:11 EST EAGLE 46.5.1.5.0-73.10.0
rtrv-gpl
Command entered at terminal #18.
```

;

Command Accepted - Processing

```
tekelecstp 18-01-18 21:23:11 EST EAGLE 46.5.1.5.0-73.10.0
GPL Auditing ON
```

| GPL          | CARD | RELEASE     | APPROVED    | TRIAL       |
|--------------|------|-------------|-------------|-------------|
| REMOVE TRIAL |      |             |             |             |
| OAMHC        | 1114 | 143-010-000 | 143-010-000 | ALM         |
| OAMHC        | 1116 | 143-010-000 | 143-010-000 | ALM         |
| OAMHC        | 1115 |             |             |             |
| OAMHC69      | 1114 | 143-010-000 | 143-010-000 | ALM         |
| OAMHC69      | 1116 | 143-010-000 | 143-010-000 | ALM         |
| OAMHC69      | 1115 |             |             |             |
| IPSG32       | 1114 | 143-010-000 | 143-010-000 | 143-010-000 |
| IPSG32       | 1116 | 143-010-000 | 143-010-000 | 143-010-000 |
| IPSG32       | 1115 |             |             |             |
| BLMCAP       | 1114 | 143-010-000 | 143-010-000 | 143-010-000 |
| BLMCAP       | 1116 | 143-010-000 | 143-010-000 | 143-010-000 |
| BLMCAP       | 1115 |             |             |             |
| HIPR2        | 1114 | 143-010-000 | 143-010-000 | 143-010-000 |
| HIPR2        | 1116 | 143-010-000 | 143-010-000 | 143-010-000 |

|         |      |             |             |       |             |
|---------|------|-------------|-------------|-------|-------------|
| HIPR2   | 1115 | -----       | -----       | ----- | -----       |
| SFAPP   | 1114 | 143-010-000 | 143-010-000 | ALM   | 143-010-000 |
| SFAPP   | 1116 | 143-010-000 | 143-010-000 | ALM   | 143-010-000 |
| SFAPP   | 1115 | -----       | -----       | ----- | -----       |
| SS7HC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SS7HC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SS7HC   | 1115 | -----       | -----       | ----- | -----       |
| SCCPHC  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SCCPHC  | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SCCPHC  | 1115 | -----       | -----       | ----- | -----       |
| ERTHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ERTHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ERTHC   | 1115 | -----       | -----       | ----- | -----       |
| IPSHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSHC   | 1115 | -----       | -----       | ----- | -----       |
| ATMHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ATMHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ATMHC   | 1115 | -----       | -----       | ----- | -----       |
| IPSG    | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSG    | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSG    | 1115 | -----       | -----       | ----- | -----       |
| PKTGHC  | 1114 | 143-010-000 | 143-010-000 |       | -----       |
| PKTGHC  | 1116 | 143-010-000 | 143-010-000 |       | -----       |
| PKTGHC  | 1115 | -----       | -----       | ----- | -----       |
| BLIXP   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLIXP   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLIXP   | 1115 | -----       | -----       | ----- | -----       |
| MCPHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| MCPHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| MCPHC   | 1115 | -----       | -----       | ----- | -----       |
| SIPHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SIPHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SIPHC   | 1115 | -----       | -----       | ----- | -----       |
| DEIRHC  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| DEIRHC  | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| DEIRHC  | 1115 | -----       | -----       | ----- | -----       |
| ENUMHC  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ENUMHC  | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ENUMHC  | 1115 | -----       | -----       | ----- | -----       |
| PKTG64  | 1114 | 143-010-000 | 143-010-000 |       | -----       |
| PKTG64  | 1116 | 143-010-000 | 143-010-000 |       | -----       |
| PKTG64  | 1115 | -----       | -----       | ----- | -----       |
| BLDC64  | 1114 | 143-010-000 | -----       |       | 143-010-000 |
| BLDC64  | 1116 | 143-010-000 | 000-000-000 | ALM   | 143-010-000 |
| BLDC64  | 1115 | -----       | -----       | ----- | -----       |
| SCCP64  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SCCP64  | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SCCP64  | 1115 | -----       | -----       | ----- | -----       |
| BLSLC32 | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLSLC32 | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLSLC32 | 1115 | -----       | -----       | ----- | -----       |
| BLSLC64 | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLSLC64 | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLSLC64 | 1115 | -----       | -----       | ----- | -----       |

```

SIP64 1114 143-010-000 143-010-000 143-010-000

SIP64 1116 143-010-000 143-010-000 143-010-000

SIP64 1115 ----- ----- -----

DEIR64 1114 143-010-000 143-010-000 143-010-000

DEIR64 1116 143-010-000 143-010-000 143-010-000

DEIR64 1115 ----- ----- -----

ENUM64 1114 143-010-000 143-010-000 143-010-000

ENUM64 1116 143-010-000 143-010-000 143-010-000

ENUM64 1115 ----- ----- -----

BLDC32 1114 143-010-000 ----- 143-010-000

BLDC32 1116 143-010-000 ----- 143-010-000

BLDC32 1115 ----- ----- -----

MCPHC69 1114 143-010-000 143-010-000 143-010-000

MCPHC69 1116 143-010-000 143-010-000 143-010-000

MCPHC69 1115 ----- ----- -----

IPSHC69 1114 143-010-000 143-010-000 143-010-000

IPSHC69 1116 143-010-000 143-010-000 143-010-000

IPSHC69 1115 ----- ----- -----

BLSL932 1114 143-010-000 143-010-000 143-010-000

BLSL932 1116 143-010-000 143-010-000 143-010-000

BLSL932 1115 ----- ----- -----

```

```

;
Command Executed

```

If the new SATA drive shows alarmed GPLs, contact [My Oracle Support \(MOS\)](#).

26. Enter the following command to repair the standby's **E5-MASP** database:

```
chg-db:action=repair
```

The `action=repair` copies the current and backup databases from the active to the standby fixed disk.

The following is an example of a possible output.

```

RLGHNCXA03W 03-08-27 03:46:49 EST EAGLE 34.0.0
chg-db:action=repair
Command entered at terminal #10.
;
RLGHNCXA03W 03-08-27 03:46:50 EST EAGLE 34.0.0
REPAIR: MASP A - Repair starts on standby MASP.
;

```

 **Note:**

Observe that the command execution time may require approximately 20 to 45 minutes.

```

RLGHNCXA03W 03-08-27 04:15:22 EST EAGLE 34.0.0
REPAIR: MASP A - Repair from fixed disk complete.
;

```

Wait for the 'repair complete' message to display and for the **E5-MASP** to return to in-service status.

**27.** Issue the report status command for the standby E5-MASP.

```
rept-stat-card:loc=xxxx:mode=full
```

Where **xxxx** is the **STBY E5-MASP** slot from **6**.

The following is an example of a possible output.

```

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
rept-stat-card:loc=xxxx
Command entered at terminal #10.
;
tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
CARD VERSION TYPE GPL PST SST AST
xxxx XXX-XXX-XXX E5MCAP OAMHC IS-NR Standby

ALARM STATUS = No Alarms.
BLMCAP GPL version = XXX-XXX-XXX
IMT BUS A = Conn
IMT BUS B = Conn
CLOCK A = Active
CLOCK B = Idle
CLOCK I = Idle
MBD BIP STATUS = Valid
MOTHER BOARD ID = E5-MCAP
DBD STATUS = Valid
DBD TYPE = 1G ENET
DBD MEMORY SIZE = 4096M
HW VERIFICATION CODE = ----
CURRENT TEMPERATURE = 44C (112F)

```

```
PEAK TEMPERATURE: = 46C (115F) [09-03-31 08:18]
TROUBLE TEXT VER. = ----
```

Command Completed.

;

Verify that the standby goes to IS-NR.

28. Enter the following command to verify that the database counts of both MASPs.

```
rept-stat-db:display=all
```

The following is an example of the possible output for a good database.

```
eagle3 02-01-11 16:11:25 EST EAGLE5 41.2.0-62.69.65
rept-stat-db:display=version
Command entered at terminal #1.
;

eagle3 02-01-11 16:11:26 EST EAGLE5 41.2.0-62.69.65
DATABASE STATUS: >> OK <<
 E5TDM 1114 (ACTV) E5TDM 1116 (STDBY)
 C LEVEL TIME LAST BACKUP C LEVEL TIME
LAST BACKUP

 FD BKUP Y 79 02-01-05 18:06:16 EST Y 79 02-01-05
18:06:16 EST
 FD CRNT Y 79 Y 79
 MCAP 1113 MCAP 1115
 - -----
 RD BKUP Y 79 02-01-05 11:15:16 EST - -
-
 USB BKP - - - - - -
-

 CARD/APPL LOC C T LEVEL TIME LAST UPDATE VERSION
STATUS

 OAMHC-RMV 1113 - - - - - -
 OAMHC-USB 1113 - - - - - -
 E5TDM-CRNT 1114 Y N 79 02-01-04 23:46:18
132-013-000 NORMAL
 E5TDM-BKUP 1114 Y - 79 02-01-04 23:46:18
132-013-000 NORMAL
 OAMHC-RMV 1115 - - - - - -
 E5TDM-CRNT 1116 Y N 79 02-01-04 23:46:18
132-013-000 NORMAL
 E5TDM-BKUP 1116 Y - 79 02-01-04 23:46:18
132-013-000 NORMAL

 EPAP A (NOACCS)
 C BIRTHDATE LEVEL EXCEPTION
 - -----

```



```

PDB - - - -
RTDB - - - -
RTDB-EAGLE - - - -

 EPAP B (NOACCS)
 C BIRTHDATE LEVEL EXCEPTION
 - ----- - -
PDB - - - -
RTDB - - - -
RTDB-EAGLE - - - -

```

```
;
```

29. Repeat 5 - 28 on all remaining SATA Drives identified for replacement.

30. If 3 was executed, issue the command to turn the measurements collection on.

```
chg-meas:collect=on
```

Execute this command only if measurement feature bit is turned on from 1.

The following is an example of a possible output.

```

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
chg-meas:collect=on
Command entered at terminal #10.

```

```
;
```

```

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
CHG-MEAS: MASP A - COMPLTD

```

```
;
```

31. Enter command to copy measurements

```
copy-meas
```

To execute this command, measurement collection must be turned off. If measurement collection is on, enter the `chg-meas:collect=off` command to turn off measurement collection.

The removable drive:

- must be inserted
- must be initialized

The following is an example of a possible output.

```

eagle3 02-01-11 19:09:16 EST EAGLE5 41.2.0-62.69.65
copy-meas
Command entered at terminal #1.

```

```
;
```

```

COPY MEASUREMENTS: MASP A - COPY STARTS ON ACTIVE MASP
COPY MEASUREMENTS: MASP A - COPY TO REMOVABLE USB DRIVE COMPLETE

```

```
;
```

32. Issue the command to retrieve measurement setup.

```
rtrv-meas-sched
```

The following is an example of a possible output. The **COLLECT** field shows whether measurement collection is on or off.

```

npeeagle4 02-02-04 01:13:49 EST EAGLE5 41.2.0-62.69.65
rtrv-meas-sched
Command entered at terminal #1.
;

npeeagle4 02-02-04 01:13:49 EST EAGLE5 41.2.0-62.69.65
COLLECT = on
GTWYLSFLTR = (both)

SYSTOT-STP = (off)
SYSTOT-TT = (off)
COMP-LNKSET = (off)
COMP-LINK = (off)
GTWY-STP = (off)
GTWY-LNKSET = (off)
MTCN-STP = (on)
MTCN-LINK = (on)
MTCN-LNKSET = (on)
;

```

If COLLECT=ON, continue to next step, otherwise repeat 30.

 **Note:**

If 30 is repeated and measurements do not turn on contact [My Oracle Support \(MOS\)](#).

**33.** Issue the report card status command.

```
rept-stat-card:appl=oam
```

The following is an example of a possible output.

```

Command Accepted - Processing

eagle3 02-01-01 00:29:24 EST EAGLE5 41.2.0-62.69.65
rept-stat-card:appl=oam
Command entered at terminal #1.
;

eagle3 02-01-01 00:29:24 EST EAGLE5 41.2.0-62.69.65
CARD VERSION TYPE GPL PST
SST AST
1113 132-069-061 E5MCAP OAMHC IS-NR
Active -----
1115 132-069-061 E5MCAP OAMHC IS-NR
Standby -----

Command Completed.
;

```

**34. Issue the command to display database status.**

```
rept-stat-db:display=all
```

The following is an example of a possible output.

```
eagle3 02-01-11 16:11:25 EST EAGLE5 41.2.0-62.69.65
rept-stat-db:display=version
Command entered at terminal #1.
;

eagle3 02-01-11 16:11:26 EST EAGLE5 41.2.0-62.69.65
DATABASE STATUS: >> OK <<
 E5TDM 1114 (ACTV) E5TDM 1116 (STDBY)
 C LEVEL TIME LAST BACKUP C LEVEL TIME LAST
BACKUP

 FD BKUP Y 79 02-01-05 18:06:16 EST Y 79 02-01-05 18:06:16 EST
 FD CRNT Y 79 Y 79
 MCAP 1113 MCAP 1115
 - -----
 RD BKUP Y 79 02-01-05 11:15:16 EST - - - -
 USB BKP - - - - - - - -

 CARD/APPL LOC C T LEVEL TIME LAST UPDATE VERSION STATUS

 OAMHC-RMV 1113 - - - - - - -
 OAMHC-USB 1113 - - - - - - -
 E5TDM-CRNT 1114 Y N 79 02-01-04 23:46:18 132-013-000
NORMAL
 E5TDM-BKUP 1114 Y - 79 02-01-04 23:46:18 132-013-000
NORMAL
 OAMHC-RMV 1115 - - - - - - -
 E5TDM-CRNT 1116 Y N 79 02-01-04 23:46:18 132-013-000
NORMAL
 E5TDM-BKUP 1116 Y - 79 02-01-04 23:46:18 132-013-000
NORMAL

 EPAP A (NOACCS)
 C BIRTHDATE LEVEL EXCEPTION
 - -----
 PDB - - - -
 RTDB - - - -
 RTDB-EAGLE - - - -

 EPAP B (NOACCS)
 C BIRTHDATE LEVEL EXCEPTION
 - -----
 PDB - - - -
 RTDB - - - -
 RTDB-EAGLE - - - -

;

```

Look in the columns labeled 'C' and 'LEVEL' output by this command.

- Verify entries in column 'C' show 'Y' which indicates coherence.
- Verify both 'FD CRNT' Levels are equal.

**35. Report replacement drive location.**

```
rept-stat-card:mode=full:loc=XXXX
```

Where XXXX location of replaced drive.

The following is an example of a possible output.

```
Command Accepted - Processing
```

```
eagle3 02-01-18 18:10:28 EST EAGLE5 41.2.0-62.69.65
rept-stat-card:mode=full:loc=1113
Command entered at terminal #1.
```

```
;
```

```
eagle3 02-01-18 18:10:28 EST EAGLE5 41.2.0-62.69.65
CARD VERSION TYPE GPL PST
SST AST
1113 132-069-061 E5MCAP OAMHC IS-NR
Standby -----
ALARM STATUS = No Alarms.
BLMCAP GPL version = 132-068-000
IMT BUS A = Conn
IMT BUS B = Conn
CLOCK A = Active
CLOCK B = Idle
CLOCK I = Idle
MBD BIP STATUS = Valid
MOTHER BOARD ID = E5-MCAP
DBD STATUS = Valid
DBD TYPE = 1G ENET
DBD MEMORY SIZE = 4096M
HW VERIFICATION CODE = ----
CURRENT TEMPERATURE = 30C (86F)
PEAK TEMPERATURE: = 30C (86F) [02-01-18 17:58]
TROUBLE TEXT VER. = ----
```

```
Command Completed.
```

```
;
```

**36. Issue the command to OAM database.**

```
rept-stat-card:appl=oam
```

The following is an example of a possible output.

```
Command Accepted - Processing
```

```
tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
rept-stat-card:appl=oam
Command entered at terminal #14.
```

```
;
```

```
tekelecstp 10-04-19 16:47:51 EDT EAGLE5 41.1.0-62.64.1
```

```

CARD VERSION TYPE GPL PST SST AST
1113 132-064-000 E5MCAP OAMHC IS-NR Standby

1115 132-064-000 E5MCAP OAMHC IS-NR Active

```

```

Command Completed.
;

```

### 37. Issue the command to display Clock status.

```
rept-stat-clk
```

The following is an example of a possible output.

```
Command Accepted - Processing
```

```

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
rept-stat-clk
Command entered at terminal #1.
;

```

```

tekelecstp YY-MM-DD hh:mm:ss TTTT PPP XX.x.x-YY.y.y
COMPOSITE PST SST AST
 SYSTEM CLOCK IS-NR Idle -----
ALARM STATUS = No Alarms.
 Primary Comp Clk 1114 (CLK A) IS-NR Active
 Primary Comp Clk 1116 (CLK B) IS-NR Active
 Secondary Comp Clk 1114 (CLK A) IS-NR Idle
 Secondary Comp Clk 1116 (CLK B) IS-NR Idle

```

```

Clock Using Bad
CLK A 3 0
CLK B 0 0
CLK I 0 --

```

```

HIGH SPEED PST SST AST
 SYSTEM CLOCK IS-NR Idle -----
ALARM STATUS = No Alarms.
 Primary HS Clk 1114 (HS CLK A) OOS-MT Fault
 Primary HS Clk 1116 (HS CLK B) OOS-MT Fault
 Secondary HS Clk 1114 (HS CLK A) OOS-MT Fault
 Secondary HS Clk 1116 (HS CLK B) OOS-MT Fault

```

```

HS CLK TYPE 1114 = RS422
HS CLK LINELEN 1114 = -----
HS CLK TYPE 1116 = RS422
HS CLK LINELEN 1116 = -----

```

```

Clock Using Bad
HS CLK A 0 0
HS CLK B 0 0
HS CLK I 0 --

```

```
Command Completed.
;
```

Verify that there are no Clock alarms.

- If there are no clock alarms then proceed to next step.
- If clock alarms are present note the alarms and contact [My Oracle Support \(MOS\)](#).

 **Note:**

E5-MASP may require card initialization if clock errors are being reported.

 **Note:**

Card initialization is not required if customer is not using CLOCK.

**38.** If required, prepare E5-MASP for Clock Acceptance

 **Note:**

Both E5-MASP must be installed.

**39.** Issue the following command to check clock status.

```
rept-stat-clk
```

The following is an example of a possible output.

```
regnsk0613w 10-05-06 11:13:10 CST EAGLE 41.1.2-62.69.1
rept-stat-clk
Command entered at terminal #21.
;

Command Accepted - Processing
regnsk0613w 10-05-06 11:13:10 CST EAGLE 41.1.2-62.69.1
COMPOSITE PST SST AST
SYSTEM CLOCK IS-NR Idle

ALARM STATUS = No Alarms.
Primary Comp Clk 1114 (CLK A) OOS-MT
Fault
Primary Comp Clk 1116 (CLK B) OOS-MT
Fault
Secondary Comp Clk 1114 (CLK A) OOS-MT
Fault
Secondary Comp Clk 1116 (CLK B) OOS-MT
Fault

Clock Using Bad
```

```

CLK A 10 0
CLK B 3 0
CLK I 0 --

HIGH SPEED PST SST AST
SYSTEM CLOCK IS-NR Idle -----
ALARM STATUS = No Alarms.
Primary HS Clk 1114 (HS CLK A) IS-NR Active
Primary HS Clk 1116 (HS CLK B) IS-NR Active
Secondary HS Clk 1114 (HS CLK A) OOS-MT Fault
Secondary HS Clk 1116 (HS CLK B) IS-NR Idle

HS CLK TYPE 1114 = T1 FRAMED
HS CLK LINELEN 1114 = LONGHAUL
HS CLK TYPE 1116 = T1 FRAMED
HS CLK LINELEN 1116 = LONGHAUL

Clock Using Bad
HS CLK A 0 0
HS CLK B 0 0
HS CLK I 0 --

Command Completed.
;

```

In this example, the secondary clock is in some condition other than Idle or Active.

**40.** Issue the command to check clock options.

```
rtrv-clkopts
```

The following is an example of a possible output.

```

Command Accepted - Processing
regnsk0613w 10-05-06 11:13:19 CST EAGLE 41.1.2-62.69.1
CLK OPTIONS

PRIMARY

HSCLKSRC t1framed
HSCLKLL longhaul

SECONDARY

HSCLKSRC rs422
HSCLKLL longhaul

;
Command Executed

```

**41.** Issue the command to change clock options for the secondary.

```
chg-clkopts:clock=secondary:hsclksrc=t1framed:force=yes
```

 **Note:**

Issue this command only if alarms were recorded in 37.

The following is an example of a possible output.

```
Command Accepted - Processing
 regnsk0613w 10-05-06 11:14:14 CST EAGLE 41.1.2-62.69.1
 CHG-CLKOPTS: MASP B - COMPLTD
;
```

**42.** Issue the command to change clock options primary.

```
chg-clkopts:clock=primary:hsclksrc=tlframed:force=yes
```

 **Note:**

Issue this command only if alarms were recorded in 37.

The following is an example of a possible output.

```
Command Accepted - Processing
 regnsk0613w 10-05-06 11:14:14 CST EAGLE 41.1.2-62.69.1
 CHG-CLKOPTS: MASP B - COMPLTD
;
```

**43.** Issue the following command to check clock status.

```
rept-stat-clk
```

The following is an example of a possible output.

```
Command Executed
> rept-stat-clk

 regnsk0613w 10-05-06 11:14:27 CST EAGLE 41.1.2-62.69.1
 rept-stat-clk
 Command entered at terminal #21.
;
```

```
Command Accepted - Processing
 regnsk0613w 10-05-06 11:14:28 CST EAGLE 41.1.2-62.69.1
 COMPOSITE PST SST AST
 SYSTEM CLOCK IS-NR Idle

 ALARM STATUS = No Alarms.
 Primary Comp Clk 1114 (CLK A) OOS-MT
Fault
 Primary Comp Clk 1116 (CLK B) OOS-MT
Fault
 Secondary Comp Clk 1114 (CLK A) OOS-MT
Fault
 Secondary Comp Clk 1116 (CLK B) OOS-MT
```



```

Fault

Clock Using Bad
CLK A 10 0
CLK B 3 0
CLK I 0 --

HIGH SPEED PST SST AST
SYSTEM CLOCK IS-NR Idle -----
ALARM STATUS = No Alarms.
Primary HS Clk 1114 (HS CLK A) IS-NR Active
Primary HS Clk 1116 (HS CLK B) IS-NR Active
Secondary HS Clk 1114 (HS CLK A) IS-NR Idle
Secondary HS Clk 1116 (HS CLK B) IS-NR Idle

HS CLK TYPE 1114 = T1 FRAMED
HS CLK LINELEN 1114 = LONGHAUL
HS CLK TYPE 1116 = T1 FRAMED
HS CLK LINELEN 1116 = LONGHAUL

Clock Using Bad
HS CLK A 0 0
HS CLK B 0 0
HS CLK I 0 --

Command Completed.
;

```

44. Procedure complete.

## 2.4 Daily Procedures

The procedures found in this section are recommended procedures for daily routine preventive maintenance. Some procedures may refer to other chapters within this document.

### 2.4.1 Backing Up the Database Daily

**Purpose:**

This procedure is used to make a backup of the database on the fixed disk and provide a current copy of the system data to be stored on-site. This procedure can then be used in the event a fixed disk is damaged. This procedure should not be confused with the other database archival procedures. Should the backup removable USB drive created with this procedure become unreadable, the other procedures in this chapter will ensure that a good copy of the database is still available.

**Requirements:**

- The databases in the current partitions of both **MASPs (FDCRNT)** must be coherent.
- At least one removable USB drive formatted for system data is needed for this routine. Each removable USB drive should be labeled as "Daily Backup." Each day, select the removable USB drive with this label and perform the backup procedure.

**Interval:**

Daily

**Procedure - Backing Up the Database**

1. Enter the following command to check the operational status of the database:

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

2. Enter the following command to create a backup of the database on the fixed disk:

```
chg-db:action=backup
```

This command should take no longer than 30 minutes to execute. It could take longer depending on other system activity that is in progress when this command is entered. During command execution, these messages appear (the active **MASP** is displayed first):

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk
complete.
BACKUP (FIXED) : MASP B - Backup starts on standby MASP.
BACKUP (FIXED) : MASP B - Backup on standby MASP to fixed disk
complete.
```

3. Insert the removable USB drive labeled "Daily Backup" into the removable USB media slot. You can also use the USB storage media in the flush-mounted USB port of the MASP card for backups.

Reference: [Removable Drives](#)

4. Enter the following command to create a backup of the database on the removable USB drive:

```
chg-db:action=backup:dest=remove
```

During command execution, these messages should appear.

```
BACKUP (REMOVABLE) : MASP A - Backup starts on active MASP.
BACKUP (REMOVABLE) : MASP A - Backup to removable USB drive
complete.
```

For the USB storage media in the flush-mounted USB port of the MASP card for backups, use the following command:

```
chg-db:action=backup:dest=usb
```

5. Verify that the databases on the removable USB drive (**RDBKUP**) and the current partition of the active **MASP (FDCRNT)** are coherent by entering the following command:  

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

6. Remove the removable USB drive from the removable USB media slot.

Reference: [Removable Drives](#)

7. Make an entry in the site maintenance log that a backup was performed.

Place the removable USB drive in a safe place, easily accessible in the event of a catastrophic failure.

## 2.4.2 System Reports Analysis

**Purpose:**

The purpose of this routine is to inspect the printer outputs for possible trouble messages and routinely check the status of the **STP** through traffic measurements. By inspecting printouts and measurements on a daily basis, system trends can be detected and resolved.

**Requirements:**

Printer must be configured to receive traffic reports. Measurements collection must be activated before reports containing current data can be printed. Enter the following command to activate measurements collection, if necessary: `chg-meas:collect=on`

Refer to *Commands User's Guide* for more information. If measurements are already allowed, an error message indicates this.

## 2.4.3 Reports Description

**Purpose:**

This includes a system terminal and printer output system related messages as well as network protocol messages. Any abnormal activity (this is network dependent) should be highlighted and saved for later retrieval. Refer to [Corrective Maintenance](#) for a description of system related messages and procedures for recovery.

**Requirements:**

None

**Interval:**

Daily

**Variables:**

hh = The end half-hour interval (0 - 2330) for requested interval

**Procedure - Print Report**

1. Enter the following command to print a measurements report for the **STP** entity  
`type:rept-meas:type=systot:enttype=stp`
2. Enter the following command to print a measurements report for the link entity type (this command requires either the loc and port parameters or the lsn parameter): `rept-meas:type=comp:enttype=link`
3. Review the **STP** report and compare with the link report.

If excessive errors exist on any one particular link, enter the following command to print a report for the time period the errors occurred:

```
rept-meas:enttype=link:period=specific:hh
```

Refer to *Commands User's Guide* for more information on using the `rept-meas` command.

4. From this report, determine what events may have occurred during the 30 minute measurements collection period.

## 2.4.4 File Transfer for LNP and INP Measurements

**Purpose:**

The purpose of this procedure is to output **LNP/INP** measurements to the file transfer area (**FTA**) so the measurements can be collected.

**Requirements:**

A computer with a **VT320** or **KSR** connection to the EAGLE. A communication program that both emulates **VT** terminals and supports Kermit file transfer. Previous **LNP/INP** measurement files must have been successfully transferred and deleted (**dlt-fta**) before the start of this procedure. A spreadsheet program that can import Comma Separated Value (**CSV**) text files. A **PC** running ProComm© for Windows and Microsoft Excel© can also be used.

**Interval:**

Daily and/or weekly.

**Procedure - File Transfer**

1. From the EAGLE**VT320** or **KSR** terminal, enter the following command to display the contents of the **FTA:disp-fta-dir:loc=xxxx**  
  
Where **xxxx** = the active **E5-TDM** (1114 or 1116).
2. From the EAGLE**VT320** or **KSR** terminal, enter the following command to delete any existing files from the **FTA:dlt-fta:loc=xxxx:all=yes**  
  
Where **xxxx** = the active **E5-TDM** (1114 or 1116)
3. In this example, from the EAGLE**VT320** or **KSR** terminal, enter the following command to send **LNP** daily measurements to the **FTA:rept-meas:enttype=lnp:type=mtcd**
4. Enter the following command to acquire a list of the files transferred to the **FTA** in step 4:**disp-fta-dir:loc=xxxx**  
  
Where **xxxx** = the active **E5-TDM** (1114 or 1116).
5. Enter the following command to activate the file transfer:**act-file-trns:loc=xxxx**  
  
Where**xxxx**= the active **E5-TDM** (1114 or 1116).
6. Transfer the desired files (with .csv suffixes) to the **PC** by using the get command from within the communications program configured to run Kermit in **ASCII** mode.  
  
An example of the Kermit commands to extract the previous day's records are as follows:> get mon\_lnp.csv > get tues\_ssp.csv > get thu\_lrn.csv > get sat\_npa.csv > finish
7. Run a spreadsheet program and open each of the files collected to view the **LNP/INP** measurement data.
8. Once all the files are successfully transferred and confirmed, enter the following command to remove the files from the **FTA:dlt-fta:loc=xxxx:all=yes**  
  
Where **xxxx** = the active **E5-TDM** (1114 or 1116)

## 2.5 Weekly Procedures

The procedures found in this section are recommended for weekly routine preventive maintenance. Some procedures may refer to other chapters within this document.

### 2.5.1 Database Archive (Weekly)

**Purpose:**

The purpose of this procedure is to create a copy of the database on a weekly basis over a period of four weeks to be stored in an archive. The copies can then be used in the event a removable USB drive is damaged, and a new copy is required. This routine will generate four copies of the database, all taken at weekly intervals.

Each tape in this cycle should be designated as Week 1, Week 2, Week 3, or Week 4. When all four removable USB drives have been used, repeat the process starting with the Week 1 USB drive.

**Requirements:**

Four removable USB drives formatted for system data are required for this routine. The removable USB drive should be labeled "Week 1" through "Week 4." Once each week, select the removable USB drive with the appropriate label and perform the backup procedure. Each week, select the removable USB drive with the next sequential number and perform this procedure.

**Interval:**

Weekly

**Procedure - Archive Database (Weekly)**

1. Enter the following command to check the operational status of the database:

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

2. Insert the removable USB drive labeled "Week x" into the removable USB drive media slot. You can also use the USB storage media in the flush-mounted USB port of the MASP card for backups.

Reference: [Removable Drives](#).

3. Enter the following command to create a backup of the database on the removable USB drive:

```
chg-db:action=backup:dest=remove
```

During command execution, these messages should appear.

```
BACKUP (REMOVABLE) : MASP A - Backup starts on active MASP.
BACKUP (REMOVABLE) : MASP A - Backup to removable USB drive complete.
```

For the USB storage media in the flush-mounted USB port of the MASP card for backups, use the following command:

```
chg-db:action=backup:dest=usb
```

4. Verify that the databases on the removable USB drive backup partition (**RD BKUP**) and the current partition of the active maintenance and administration subprocessor system (**MASP**) fixed disk current partition (**FD CRNT**) are coherent by entering the following command:

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

5. Remove the removable USB drive from the removable USB drive media slot.

Reference: [Removable Drives](#)

6. Make an entry in the site maintenance log that a backup was performed for the appropriate week (Week 1, Week 2, Week 3, or Week 4).

Place the removable USB drive in a safe place, easily accessible in the event of a catastrophic failure.

## 2.5.2 Printer Inspection

### Purpose:

This procedure verifies the printer is operational and the ribbon does not need replacement. Should the printer cease operation, system reports and trouble reports would not be printed at the system printer. Use the following procedure to verify the operation of the printer.

### Requirements:

A printer connected through an **RS232** to a serial port on the EAGLE control shelf backplane. Refer to the printer user manual (provided by the printer manufacturer) for detailed specifics on maintaining the printer.

### Interval:

Weekly

### Variables:

x = **TDM** serial port number (1-16)

### Procedure -Printer Inspection

1. Verify the carriage assembly is free of any debris.  
Remove the top of the printer if necessary.
2. Check that the power indicator is illuminated (on).  
If not, verify the power cord is plugged in.
3. Check the online indicator.  
If off, press the select button. Verify the indicator is illuminated.
4. Verify the presence of on-line indicators using the printer *Users Manual*.
5. Enter the following command to send output to the printer: `act-echo:trm=x`.
6. Type the following command at a terminal to verify the printer is operating: `rept-stat-trm`  
  
If the printer does not print any messages, check the printer cable and verify it is connected to a system terminal. If not, reconnect the printer cable (refer to the *Installation Guide* for cable pinouts).
7. Look at the printout.

If the ink is faded and difficult to read, replace the ribbon. Refer to the *Users Manual* provided by the manufacturer for ribbon replacement procedures.

## 2.5.3 Remote Access Verification

**Purpose:**

The purpose of this routine is to verify proper operation of the modem used for remote access of the EAGLE system.

**Requirements:**

Remote terminal and modem.

**Interval**

Weekly

**Procedure - Remote Access Verification**

1. From a remote **PC** or terminal, dial the telephone number of the modem connected to the Eagle.
2. When connected, verify you are able to log in to the EAGLE system and enter commands.
3. Once you have verified the operation of the modem, logoff from the EAGLE and terminate your connection.

## 2.6 Monthly Procedures

The procedures found in this section are recommended procedures for monthly routine preventive maintenance. Some procedures may refer to other chapters within this document.

### 2.6.1 Database Archive (Monthly)

**Purpose:**

The purpose of this procedure is to create a copy of the database on a monthly basis over a period of four months to be stored in an archive. The copies can then be used in the event a removable USB drive is damaged, and a new copy is required. This routine will generate four copies of the database, all taken at monthly intervals.

Each tape in this cycle should be designated as Month 1, Month 2, Month 3, or Month 4. When all four removable USB drives have been used, repeat the process starting with the Month 1 USB drive.

**Requirements:**

Four removable USB drives formatted for system data are required for this routine. The removable USB drive should be labeled "Month 1" through "Month 4." Once each month, select the removable USB drive with the appropriate label and perform the backup procedure. Each month, select the removable USB drive with the next sequential number and perform this procedure.

**Interval**

Monthly

**Procedure - Database Archive (Monthly)**

1. Enter the following command to check the operational status of the database:

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

2. Insert the removable USB drive labeled "Month x" into the removable USB drive media slot. You can also use the USB storage media in the flush-mounted USB port of the MASP card for backups.

Reference: [Removable Drives](#)

3. Enter the following command to create a backup of the database on the removable USB drive:

```
chg-db:action=backup:dest=remove
```

```
BACKUP (REMOVABLE) : MASP A - Backup starts on active MASP.
BACKUP (REMOVABLE) : MASP A - Backup to removable USB drive
complete.
```

For the USB storage media in the flush-mounted USB port of the MASP card for backups, use the following command:

```
chg-db:action=backup:dest=usb
```

4. Verify that the databases on the removable USB drive (**RDBKUP**) and the current partition of the active **MASP (FDCRNT)** are coherent by entering the following command:

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

5. Remove the removable USB drive from the removable USB drive media.

Reference: [Removable Drives](#)

6. Make an entry in the site maintenance log that a backup was performed for the appropriate month (Month 1, Month 2, Month 3, or Month 4).

Place the removable USB drive in a safe place, easily accessible in the event of a catastrophic failure.

## 2.6.2 FAP Load Balance Verification (PN 870-0243-XX only)

### Purpose:

This procedure is used to verify the Load Balance Factor (**LBF**) for the A and B power supplied to each Fuse and **Alarm Panel (FAP)** in the EAGLE. This procedure applies **ONLY** to installed **FAPs** with P/N 870-0243-XX.

The **LBF** is an empirically derived number that provides an indication if a Oracle **STP** System Frame has an open power distribution diode. The difference in amperage between the "A" versus "B" battery leads should be within a "typical" range. Values outside of this range should be an indication of a potential problem and requires further investigation.

### Requirements:

Oracle recommends that the verification be performed using a Clamping Type Multimeter (Clamp Amp Meter). If the Clamp Meter has different settings or functions than the ones described in this procedure, consult the instruction manual for this



meter and determine substitute settings or functions. Results of this verification should be recorded on the form provided with this procedure and filed with the **STP** System maintenance records.

 **Caution:**

This procedure must be performed with the utmost Caution. All safety precautions associated with in service equipment and power must be strictly followed. Any equipment that is below the shelf that is being worked on must be protected from falling tools or debris. All jewelry, rings, watches must be removed before this procedure is started. Read this procedure completely before proceeding.

**Interval:**

Monthly

**Procedure - FAP Load Balance**

1. Login to system via a dedicated terminal or connect a **PC** to an EAGLE terminal port.  
Open a capture log via ProComm Plus or other **PC** communications program.
2. Enter the following command to determine the status of all the cards in the system.  

```
rept-stat-card
```

If necessary, refer to *Commands User's Guide* to interpret the output. Save the results to compare with the outputs at the conclusion of this procedure.
3. Enter the following command to verify the status of the signaling links.  

```
rept-stat-slk
```

If necessary, refer to *Commands User's Guide* to interpret the output. Save the results to compare with the outputs at the conclusion of this procedure.
4. Enter the following command to get a report of all the device trouble notifications that are currently logged in the **OAMRAM** storage area.  

```
rept-stat-trbl
```

If necessary, refer to *Commands User's Guide* to interpret the output. Save the results to compare with the outputs at the conclusion of this procedure.
5. Enter the following command to check the status of the IMT.  

```
rept-stat-imt
```

If necessary, refer to *Commands User's Guide* to interpret the output. Save the results to compare with the outputs at the conclusion of this procedure.
6. Enter the following command to check the status of the **SCCP** subsystem.  

```
rept-stat-sccp
```

If necessary, refer to *Commands User's Guide* to interpret the output. Save the results to compare with the outputs at the conclusion of this procedure.
7. Enter the following command to check the operational status of the database.  

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output. Save the results to compare with the outputs at the conclusion of this procedure. Verify that **FDCRNT** and **FDBKUP** for **E5-TDM 1114** and **E5-TDM 1116** match. If they do not match, perform [Daily Procedures](#) before continuing.

 **warning:**

Do not proceed to the next step if the backup fails.

8. Set the Clamp Amp Meter to measure **DC** amps.

Set the dial to the **DC** 400A setting and zero out/adjust the meter by turning the **0 ADJ** control. The meter must read 00.0.

 **Note:**

On the inside of the Clamp Amp Meter there should be an arrow. The arrow must always be pointing towards the frame when clamped around the cable. If the meter cannot be directly observed, the **DATAHOLD** function can be utilized, if the meter is so equipped, and the reading will hold. The jaws of the meter must be around the cable for the **DATAHOLD** function to operate.

Values of less than 1.0 Amp on **BOTH** the "A" and "B" sides are not applicable. Ignore plus (+) or minus (-) in the meter reading.

9. Measure the current on the **A** side of the EAGLE Frame **FAP** selected for verification.

Clamp the meter around the **-48VDC A** battery cable on the **FAP**. Record the reading on the [Oracle](#).

10. Depress the **DATAHOLD** function again, if this option was utilized in 9 Verify the Clamp Amp Meter reading is 00.0.

The meter must read 00.0 before proceeding with 11.

11. Measure the current on the **B** side of the EAGLE Frame **FAP** selected in 9.

Clamp the meter around the **-48VDC B** battery cable on the **FAP**. Record the reading on the [Oracle](#).

12. Calculate the Load Balance Factor (**LBF**) and record on the [Oracle](#).


- a. Compute the difference between **A** and **B** sides (A-B) or (**B-A**).
- b. The difference is divided by the lower of the two (2) measured values (**A** or **B**) and expressed as a percentage.

This percentage is the **LBF**.


- c. Enter the **LBF** in the appropriate space on the Test Record form.

Refer to [Figure 2-14](#) and [Figure 2-15](#) for examples of this formula. Data indicates that the acceptable range can be between 0% and 125%. The 125% point is a **Flag** that indicates further investigation is warranted. It indicates the potential for at least one open diode.

**Figure 2-14 Open Diode Example**



**Figure 2-15 Steady State Example**



13. [My Oracle Support \(MOS\)](#), for values above the 125% threshold.
14. Depress the **DATAHOLD** function again, if this option was utilized in 9 .  
Verify the Clamp Amp Meter reading is 00.0. The meter must read 00.0 before proceeding with 15.
15. Repeat Steps 8 through 14 for all EAGLEFAPs.
16. Enter the following command to determine the status of all the cards in the system.  
`rept-stat-card`

Compare the output with the results from 2. The outputs should be the same as initially recorded.

17. Enter the following command to verify the status of the signaling links.

```
rept-stat-slk
```

Compare the output with the results from 3. The outputs should be the same as initially recorded.

18. Enter the following command to get a report of all the device trouble notifications that are currently logged in the **OAMRAM** storage area.

```
rept-stat-trbl
```

Compare the output with the results from 4. The outputs should be the same as initially recorded.

19. Enter the following command to check the status of the IMT.

```
rept-stat-imt
```

Compare the output with the results from 5. The outputs should be the same as initially recorded.

20. Enter the following command to check the status of the **SCCP** subsystem:

```
rept-stat-sccp
```

Compare the output with the results from 6. The outputs should be the same as initially recorded.

21. Enter the following command to check the operational status of the database.

```
rept-stat-db
```

Compare the output with the results from 7. The outputs should be the same as initially recorded.

**Table 2-9 Oracle Method of Procedure Test Record**

| ORACLE Method of Procedure Test Record |           |           |                  |                           |                 |
|----------------------------------------|-----------|-----------|------------------|---------------------------|-----------------|
| Frame                                  | A Battery | B Battery | A-B Delta (Amps) | Load Balance Factor (LBF) | Technician/Date |
| CF 00                                  |           |           |                  |                           |                 |
| EF 00                                  |           |           |                  |                           |                 |
| EF 01                                  |           |           |                  |                           |                 |
| EF 02                                  |           |           |                  |                           |                 |
| EF 03                                  |           |           |                  |                           |                 |
| EF 04                                  |           |           |                  |                           |                 |
| MISC                                   |           |           |                  |                           |                 |

 **Note:**

Complete this test record for all **FAP** tests. Retain this record in the Oracle EAGLE **STP** System maintenance files.

## 2.6.3 Change the Fan Tray Filter

**Purpose:**

The purpose of this routine is to make sure a clean and adequate supply of air is available to cool the **HC MIM** cards.

**Requirements:**

A replacement fan tray filter.


**Interval:**

Monthly

**Procedure - Change Fan Tray Filter**

1. Locate the filter tab on the fan assembly.

**Figure 2-16 Fan Assembly**



2. Pull the filter tab to remove the fan tray filter.
3. Insert the replacement filter into the fan filter slot.  
Align the filter over the replaceable fans.

## 2.6.4 Changing the Air Supply Filter

**Purpose:**

The purpose of this routine is to prevent dirt and dust from building up around the fan units, hindering them from cooling the shelf effectively.

**Requirements:**

A replacement air filter (P/N 551-0011-01).

**Interval**

Every 45 days.

**Procedure - Change Air Supply Filter**


1. Turn the fan power switch to the **OFF** position.

The **ActiveLED** under the fans becomes unlit and the fan **Alarm LED** turns red. The EAGLE generates a **UAM** indicating a fan failure.

2. Unscrew the two thumbscrews securing the grill and remove it.

The air filter is now accessible.

**Figure 2-17 Fan Filter Replacement**



3. Remove and discard the old air filter.

4. Position the new air filter so that it covers the opening to the fan assembly.

Check the bottom edge of the filter to make sure the airflow indicator arrows are pointing away from you and towards the fan assembly.

5. To replace the grill, position it on the fan assembly and screw in the two thumbscrews to secure the grill in place.

6. Turn the fan power switch to the **ON** position.

The two **LEDs** for the fan assembly turn green and the EAGLE generates a **UIM** to indicate the fan alarm is cleared.

## 2.6.5 Cleaning Printer

**Purpose:**

The purpose of this routine is to prevent the system printer from building up dirt and dust around the print heads and carriage assemblies, preventing it from operating.

**Requirements:**

Printer cleaning kit, or cleaning solvent. Cotton swabs and damp cloth.

**Interval**

Monthly

**Procedure - Clean Printer**

- Follow the manufacturer's procedures for cleaning the print head and carriage assembly.

## 2.6.6 Fuse Spares Inventory

**Purpose:**

This routine verifies ample spare fuses are available. Fuses are used in the fuse and alarm panel (**FAP**).

**Requirements**

None

**Interval**

Monthly

**Procedure - Fuse Inventory**

Two types of fuses are used in the EAGLE:

1. Industry standard **GMT** fuse 1 amp
2. Industry standard **GMT** fuse 3 amp

Spare fuses are stored in a fuse tray located on the side of each frame. Check that both types of **GMT** fuses are in this tray. Oracle recommends no fewer than five of each fuse type be readily accessible. If the EAGLE is not located at the end of a bay, check your facility's spare fuse storage. **GMT** fuses are industry standard fuses and are provided by Oracle during installation of the system. Additional inventory of these fuses should be purchased through Oracle.

## 2.6.7 Wrist Strap Test

**Purpose:**

The purpose of this routine is to verify the integrity of the anti-static wrist strap and ground cord used when handling cards from the EAGLE.

**Requirements:**

Ohmmeter, wrist strap (equipped with the EAGLE).

**Interval:**

Monthly

**Procedure - Wrist Strap Test**

1. Detach the grounding cord from the wrist strap.

**NOT\_SUPPORTED:**

If the resistance measured is less than 800 Kohms, you may be electrocuted if the equipment short circuits while you are wearing the wrist strap. If the resistance measured is greater than 1200 Kohms, you may damage your equipment.

2. Using an ohmmeter, measure the resistance between the two ends of the ground cord.
3. If you measure a resistance between 800 Kohms and 1200 Kohms, the ground cord is safe to continue using.
4. If you measure a resistance that is not between 800 Kohms and 1200 Kohms, discard the ground cord and wrist strap.

They are no longer safe to use.

## 2.7 Quarterly Procedures

The procedures found in this section are recommended procedures for quarterly routine preventive maintenance. Some procedures may refer to other chapters within this document.

### 2.7.1 Database Archive (Quarterly)

**Purpose:**

The purpose of this routine is to create an archive copy of the EAGLE database. This archive copy should be stored off-site and saved for emergency recovery when all other procedures have failed. This routine will reuse the same removable USB drive each quarter.

**Requirements**

This procedure requires a removable USB drive formatted for system data.

**Interval**

Quarterly

**Procedure \_Database Archive (Quarterly)**

1. Enter the following command to check the operational status of the database:

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

2. Insert the removable USB drive labeled "Archive" into the removable USB drive media slot. You can also use the USB storage media in the flush-mounted USB port of the MASP card for backups.

Reference: [Removable Drives](#)

3. Enter the following command to create a backup of the database on the removable USB drive:



```
chg-db:action=backup:dest=remove
```

```
BACKUP (REMOVABLE) : MASP A - Backup starts on active MASP.
BACKUP (REMOVABLE) : MASP A - Backup to removable USB drive complete.
```

For the USB storage media in the flush-mounted USB port of the MASP card for backups, use the following command:

```
chg-db:action=backup:dest=usb
```

4. Verify that the databases on the removable USB drive (**RDBKUP**) and the current partition of the active **MASP (FDCRNT)** are coherent by entering the following command:

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

5. Remove the removable USB drive from the removable USB drive media slot.

Reference: [Removable Drives](#)

6. Make an entry in the site maintenance log that a backup was performed on the "Archive" removable USB drive.

Place the removable USB drive in a safe place off-premise. This copy is for emergency recovery in the event all other methods of database recovery failed.

## 2.7.2 Preventing Dust Buildups

### Purpose:

The purpose of this routine is to prevent dust build-up in and around the cabinet. Collection of dust within the EAGLE can allow electrostatic charges to build around circuit cards, possibly damaging cards installed in the system.

### Requirements:

Damp cloth

### Interval:

Quarterly

### Procedure - Prevent Dust Buildup

1. Open the cabinet doors on the front of the cabinet(s).

 **Note:**

Do not use compressed air. Do not remove the plexiglass panels from the rear of the frame. This procedure is to be used for removing dust from the front of the system and from around the card cages only.

Using a damp cloth, wipe the dust from the doors and from the front of the card cages.

2. Using the same cloth, wipe the dust from the air intakes and around the exterior of the system frames.

## 2.7.3 Rectifier Voltage Inspection/Recording

**Purpose:**

The purpose of this routine is to verify that the rectifier is providing adequate voltages and has not become a marginal supply. By identifying power supply problems early, the possibility of failure can be circumvented.

**Requirements:**

Volt meter capable of measuring **DC** voltages in the range of -20VDC to -60VDC.

**Interval**

Quarterly

**Procedure - Rectifier Voltage Inspection**

1. Locate the power source for the EAGLE.
2. Using a **VOM**, measure the -48VDC supply.
3. Verify voltages are between -46VDC and -52VDC.

(If voltages are higher or lower, refer to the manufacturers maintenance procedures for appropriate action).

## 2.8 Semi-Annual Procedures

The procedure found in this section is recommended for semi-annual (every 6 months) routine preventive maintenance. Some procedures may refer to other chapters within this document.

**Spare Inventory Rotation**

**Purpose:**

The purpose of this routine is to verify the integrity of spare cards. By rotating spares on a regular basis, their operation can be verified before they are needed as replacements.

**Requirements**

None

**Interval**

Semi-annually (every 6 months)

**Procedure - Semi-annual Procedures**

1. Identify the spare cards in your inventory.

 **warning:**

This procedure may interrupt service. Verify the type of card and service it provides, and only use this routine during the maintenance window.

2. Locate the card in service that matches the configuration of your spare card.
3. Verify the part numbers and revision numbers of the cards are compatible.

4. Refer to [Card Removal/Replacement Procedures](#) for the proper procedure for each card type.
5. Place the card from your spares inventory into the now empty slot.  
Perform any administrative commands described in [Card Removal/Replacement Procedures](#).
6. Make an entry in the site maintenance log and place the card removed from the system into your spares inventory.

# 3

## Corrective Maintenance

### 3.1 Introduction

The EAGLE trouble detection is distributed throughout the system. Each processor continually monitors its internal subsystems and certain external subsystems. Whenever a trouble condition changes state, the processor analyzes the change and stores the analysis for reporting to the active **E5-MASP**. The trouble detection software does not affect the service quality of the system.

Each **E5-MASP** is made up of two cards, the **E5-MCAP** card and the **E5-TDM** (terminal disk module).

The E5-MCAP card is equipped with 4 GB of physical application processor memory. The primary data interface to the E5-MCAP is RS-232 interfaces (i.e.: terminals) through the E5-TDM.

The E5-MCAP card contains one **latched USB port** for use with removable flash media (“thumb drive”), and one flush-mounted USB port for use with a plug-in flash drive. The removable media drive is used to install and back up customer data. The flush-mounted USB port is used for upgrade and could be used for disaster recovery. The removable flash media is used as a replacement for the legacy Magneto-Optic (MO) Drive. The E5-MCAP card is a replacement for the obsoleted legacy GPSM-II card used for the **MCAP** function.

#### Note:

The E5-MCAP card can not be used for the other functions for which the GPSM-II class (e.g.: MCP, IPS, DCM) card is used.

The **E5-TDM** card contains four major subsystems: the Terminal Processor Subsystem, the System Clock/Control Subsystem, the SATA Subsystem, and a Power Subsystem. These subsystems provide the EAGLE with 16 user-accessible terminals, distributes Composite Clocks and High Speed Source clocks throughout the EAGLE, distributes Shelf ID to the EAGLE, and disk storage for an E5-MCAP card. The E5-TDM card provides an interface to the E5-MDAL card for system alarms.

The E5-TDM card contains one fixed solid-state SATA drive that is removable and used to store primary and backup system databases, measurements, and Generic Program Loads (GPLs).

To determine which **MASP** is active either enter the `rept-stat-db` command, or enter the `rept-stat-card` command, or examine the **LEDs** on both **E5-TDM** cards. If the **LED** on the **E5-TDM** card is green, the associated **E5-MASP** is active. (If the **LED** on the **E5-TDM** card toggles between green and amber, the associated **E5-MASP** is standby.)

The output of the `rept-stat-db` command shows which **E5-MASP** is active with the indicator (**ACTV**) following the **E5-TDM** card location. The indicator (**STDBY**) following the **E5-TDM** card location shows which **E5-MASP** is standby.

The output of the `rept-stat-card` command shows which **E5-MASP** is active with the entry **ACTIVE** in the **SST** field for the **E5-MCAP** card. The entry **STANDBY** in the **SST** field for the **E5-MCAP** card shows which **E5-MASP** is standby.

The database commands, such as `rept-stat-db`, refer to the **E5-TDM** because the **E5-TDM** contains the fixed disk drive and the removable USB media for the **E5-MASP**.

## 3.2 System Alarm Levels

There are three levels of alarms in the EAGLE system. They are:

### Critical

A critical alarm is an indication of a severe service affecting problem that can be related to traffic, billing, and maintenance capabilities and requires immediate maintenance attention, regardless of time of day.

### Major

A major alarm is an indication of a problem that seriously affects system operation, maintenance and administration, etc. and requires immediate attention. The urgency is less than in critical situations because of a lesser immediate or impending effect on system performance, customers, and operating company operations and revenue.

### Minor

A minor alarm is an indication of a problem that does not have a serious impact on service, and does not require immediate maintenance attention.



#### Note:

Some UAMs are considered informational if they satisfy the following conditions in the SNMP V2 traps generated by EAGLE E5OAM:

1. The Alarm Level is stated as "No alarm condition" in this user's guide.
2. The alarm is not intended to clear any higher severity UAM as per the corresponding UAM Balancing Matrix.

These UAMs are informational only and neither contribute to the total number of alarms in the system nor change the alarm state of the device on EAGLE.

## 3.3 Trouble Detection

The first step in analyzing a system trouble is to know when a trouble exists. The EAGLE handles this task through:

- Audible alarms
- Visual alarms
- Event/error messages

### Audible Alarms

The EAGLE has three types of audible alarms: critical, major and minor. Audible alarms are generated by the E5-maintenance disk and alarm card (**E5-MDAL**), and

can be heard through the electronic sonalert device installed on the card. Each alarm has its own distinct cadence as described in the following:

- Critical - Two tones 0.5 seconds apart, separated by 1.5 seconds of silence.
- Major - Single tone, separated by 1.5 seconds of silence.
- Minor - Single tone of 5 seconds or continuous tone for power plant alarm.

### Visual Alarms

The EAGLE has several types of visual alarms. They are:

- **AlarmLEDs** on the Fuse and **Alarm Panel (FAP)**
- Alarms displayed on the system terminal
- **LEDs** on application cards
- End cabinet alarm indicators

Maintenance personnel usually see the alarm **LEDs** on the fuse and alarm panel (**FAP**) and the alarms displayed on the system terminal screen to alert them that a system problem exists. The **LEDs** on a card help maintenance personnel diagnose where a problem exists.

### MDAL LEDs

Following are the five alarm **LEDs** on the face of the obsolete **MDAL** card. Although the card is obsolete, the functionality remains uniform. See [Figure 3-1](#):


- Critical
- Major
- Minor
- **MASP-A**
- **MASP-B**

When the system detects an alarm, the appropriate alarm level and location (**MASP-A** or **MASP-B**) **LEDs** illuminate. See [Figure 3-1](#).

#### Note:

Verify the state of the **MDAL** card by observing the **LEDs** on the face of the **MDAL** card. The fuse and alarm panel do not reflect any alarms caused by the **MDAL** card.

Figure 3-1 MDAL Alarm LEDs



### Alarm LEDs on the Fuse and Alarm Panel (FAP)


There are six alarm **LEDs** on the **FAP** that indicate:

- Power alarm **LEDs** (A and B)
- A critical alarm
- A major alarm
- A minor alarm
- A fuse alarm

The **FAP** provides protected distribution of power to the system. Protection is provided by the fuses placed in the **GMT** fuse holders used in the panel. The **FAP** contains a fuse fail alarm circuit that operates when one or more of the panel's fuses fail. An **LED** changes from green to red when a fuse has failed. The **LED** remains red until the fuse has been replaced.

The fuse and alarm panel uses **GMT** fuses for individual circuit protection (see [Figure 3-2](#)). The EAGLE uses 3A and 1A fuses, depending on the application. When a fuse fails due to an overload condition, a small colored flag on the fuse shows the position of the fuse that has failed. The flag is gray on 1A fuses, blue on 3A fuses, black/white on 7.5A fuses, and red on 10A fuses.

**Figure 3-2 GMT Fuse**



The panel contains two separate circuits, A and B. Current flows from the input terminals to the fuse bus. When a fuse is installed in a fuse holder, the circuit is completed to the output connector. The Fuse Fail **Alarm LED** on the front panel indicates the condition of the panel. Green is indicated if power is applied to the panel and there are no failed fuses. The green **LED** changes to red when a fuse fails. An unlit **LED** indicates a failed **LED** or no power to the fuse and alarm panel.

The fuse and alarm panel is also equipped with frame alarm **LEDs** that display the critical, major, and minor alarms generated by the EAGLE system.

The fuse and alarm panels have the A and B buses connected through diodes to allow one bus to pick up the entire load when the other bus loses power.

[Table 3-1](#), [Table 3-2](#) and [Table 3-3](#) describe the front panel configuration of the fuse and alarm panels.

**Table 3-1 Fuse and Alarm Panel Front Items (870-2804-01)**


| Fuse Panel Item | Description                                                                                                                                                           |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fuse Positions  | 2 groups of 20 <b>GMT</b> fuses                                                                                                                                       |
| PWR ALM         | LED indicator for A or B diode board input power <ul style="list-style-type: none"> <li>Green - input power applied</li> <li>Red - no input power to board</li> </ul> |
| FUSE ALM        | LED indicator for fuse fail alarm <ul style="list-style-type: none"> <li>Green - normal</li> <li>Red - blown fuse</li> </ul>                                          |
| CR              | <b>LED</b> indicator for frame critical alarm                                                                                                                         |
| MAJ             | <b>LED</b> indicator for frame major alarm                                                                                                                            |
| MIN             | <b>LED</b> indicator for frame minor alarm                                                                                                                            |



**Table 3-1 (Cont.) Fuse and Alarm Panel Front Items (870-2804-01)**

| Fuse Panel Item | Description                                                                                                                         |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------|
| Shorting Board  | LED indicator for mode of operation <ul style="list-style-type: none"> <li>• Off - normal</li> <li>• Green - maintenance</li> </ul> |


**Figure 3-3 Fuse and Alarm Panel Front Layout (870-2804-01)**



**Table 3-2 Fuse and Alarm Panel Front Items (870-0243-xx)**


| Fuse Panel Item | Description                                                           |
|-----------------|-----------------------------------------------------------------------|
| Fuse Positions  | 2 groups of 20 GMT fuses                                              |
| Card Holder     | slide-card holder with 2 designation cards for 20 fuse positions each |
| Fuse Alarm      | LED indicator for fuse fail alarm                                     |
| Critical Alarm  | LED indicator for critical alarm                                      |
| Major Alarm     | LED indicator for major alarm                                         |
| Minor Alarm     | LED indicator for minor alarm                                         |
| Power Alarm     | LED indicator for lose of power on either A bus or B bus              |

**Figure 3-4 Fuse and Alarm Panel Front Layout (870-0243-xx)**



**Table 3-3 Fuse and Alarm Panel Front Items (870-1606-xx/870-2320-xx)**

| Fuse Panel Item  | Description                                                                                                             |
|------------------|-------------------------------------------------------------------------------------------------------------------------|
| Fuse Positions   | Two groups of 20 <b>GMT</b> fuses                                                                                       |
| <b>PWR ALARM</b> | <b>LED</b> indicator for A or B diode board input power<br>Green - input power applied<br>Red - no input power to board |
| <b>OP/MAINT</b>  | <b>LED</b> indicator for mode of operation<br>Green - normal<br>Red - maintenance                                       |
| <b>FUSE</b>      | <b>LED</b> indicator for fuse fail alarm<br>Green - normal<br>Red - blown fuse                                          |
| <b>CRITICAL</b>  | <b>LED</b> indicator for frame critical alarm                                                                           |
| <b>MAJOR</b>     | <b>LED</b> indicator for frame major alarm                                                                              |
| <b>MINOR</b>     | <b>LED</b> indicator for frame minor alarm                                                                              |

**Figure 3-5 Fuse and Alarm Panel Front Layout (870-1606-xx/870-2320-xx)**

### Alarms appearing on a terminal screen

Three types of alarms may be displayed on a system terminal screen:

- **CRIT** - Indicates a critical alarm
- **MAJR** - Indicates a major alarm
- **MINR** - Indicates a minor alarm

These appear as three highlighted boxes in the top left corner of a terminal. If an alarm condition exists, it is displayed in one of the highlighted boxes. There is a fourth box next to the three alarm boxes that is not used. To obtain information about the alarm, use the `rept-stat-alm` command at the system terminal, followed by a carriage return.

This command provides all current alarm status. Refer to *Commands User's Guide* for more information about the `rept-stat-alm` command.

### Alarms on Application Cards

Each application card has **LEDs** that indicate the condition of the card. **Alarm** conditions appear on the card if the card has a fault. Refer to *Installation Guide* for the location and description of the card **LEDs**.

### End Cabinet Alarm Indicators

There are three alarm **LEDs** on the end cabinet:

- A critical alarm **LED**
- A major alarm **LED**
- A minor alarm **LED**

When an alarm condition is present, one or more of these **LEDs** illuminate in the signifying the overall system alarm level. Refer to *Installation Guide* for alarm indicators.

### Event/Error Messages

Unsolicited messages are used in the EAGLE for trouble notification and to communicate the status of the system to Operations Services (**OS**). The EAGLE outputs two types of unsolicited messages.

- Unsolicited **Alarm** Messages (**UAMs**) are used to denote a persistent problem with device or object that needs the attention of a craftsman. Some examples are a link failure, a subsystem being out of service, or a card not receiving a system clock.
- Unsolicited Informational Messages (**UIMs**) are indications of transient events that have occurred. **UIM** examples include messages that an **MSU** contains invalid data or failed a gateway screening function.

The location of a card with a fault is displayed with the event/error message. The location is displayed as a card number. **Card** numbers are used to locate the card in the EAGLE system. Refer to *Installation Guide* for card locations.

Following is an example of an event/error message displaying the card location:

```
RLGHNCXA21W 00-02-07 12:01:43 EST EAGLE 35.0.0
** 0014.0008 ** CARD 1113 OAM Active MASP has become isolated
```

The card location always follows the word "**CARD**" in the message. In this example, the card number is **1113**.

### IMT Bus States

The states of the IMT bus are combined from the primary state (**PST**) and secondary state (**SST**) for each IMT bus. See *Commands User's Guide* for information about PST and SST states and definitions.

The `rept-stat-imt` command is used to report the status of the IMT bus. An example of the output follows:

```

RLGHNCXA03W 00-09-27 16:50:24 EST EAGLE 31.5.0
IMT PST SST AST
A IS-NR Active -----
ALARM STATUS = No alarms
IMT PST SST AST
B IS-ANR Fault -----
ALARM STATUS = ** 0108 Major IMT Failure Detected
Command Completed.

```

### IMT System Alarm Level Determination

The state of the IMT subsystem is determined from the state of each IMT bus. If both buses are **IS-NR** active, the IMT subsystem is **IS-NR** active. If only one IMT bus is manually disabled (**IS-ANR** manual), the IMT subsystem is **IS-ANR** manual. Otherwise, the IMT subsystem state is **IS-ANR** fault.

The alarm level of an IMT bus in the **IS-ANR** fault state is determined by how many bad card connections it has. The number of bad connections required for a major alarm or a minor alarm are as follows:

- 0 failures = no alarm
- 1-2 failures = minor alarm
- 3 or more = major alarm

The alarm levels on the individual buses combine to give the overall alarm level for the IMT subsystem. [Table 3-4](#) shows the rules that are used to determine the overall alarm level of the system of IMT buses.

**Table 3-4 IMT Bus Alarm Levels**

| Bus A Alarm Level | Bus B Alarm Level | Overall Alarm Level |
|-------------------|-------------------|---------------------|
| Normal            | Normal            | Normal              |
| Normal            | Minor             | Normal              |
| Minor             | Normal            | Normal              |
| Normal            | Major             | Minor               |
| Major             | Normal            | Minor               |
| Minor             | Minor             | Major               |
| Minor             | Major             | Major               |
| Major             | Minor             | Major               |
| Major             | Major             | Critical            |


## 3.4 Output Messages

The EAGLE generates output messages in response to command input or fault conditions in the EAGLE or in the network. The format for these messages is generally uniform. Some messages include additional data.

Network messages provide the text description of the event, and on the lines below the text line, any additional information.

The following example shows the general format of an output message.

**Figure 3-6 Output Message Format**



The fields in an output message (shown in the figure above) are described next:

- **Host CLLI code** - a maximum of one alpha character and ten alphanumeric characters. The **CLLI** code uniquely identifies the system in terms of its physical location. The **CLLI** code must be unique among all elements in the system.  
The **CLLI** code consists of the following:
  - City = 4 characters
  - State = 2 characters
  - Building = 2 characters
  - Equipment type = 3 characters
- **Date** - The date the message was generated, in the format *year-month-day*.
- **Time** - The time the message was generated with time zone, in the format *hour: minutes: second time zone*.
- **System Release Number** - contains a system identifier and the version ID number. The system identifier, can be `EAGLE` or `EAGLE5` depending on the product key enabled on the system. The version ID number has the software release specific GPL set that is expected to be installed on the system as approved loads. The format of the version ID number is in the form of **maj.min.maint**, defined as follows:
  - **maj** - the major release ID
  - **min** - the minor release ID
  - **maint** - the maintenance release ID
- **Alarm Level** - a one or two character indicator of the alarm level, defined as follows:
  - **\*C** = Critical **Alarm**
  - **\*\*** = Major **Alarm**
  - **\*** = Minor **Alarm**
  - *blank* = No **Alarm**
- **Message Sequence Number** - This number is an index for all output messages. The number increments sequentially for every message. The output messages originating from the card in location 1113 has a range from 0001 through 4999. The range for location 1115 is 5000 through 9999.

- **Message Reference Number** - Messages that are associated with a specific action are numbered for reference. These messages are defined in this chapter, along with a corrective action.
- **Affected Device** - The device that caused the message to be generated. This generally describes the card type.

Network messages with additional data display the additional lines below the text string and message reference number (**MRN**). See individual messages for examples of output.

All network messages are non-alarm and are used to notify the user of network events. There may or may not be a procedure associated with these messages.

## 3.5 Alarm Clearing Procedures

After an audible has sounded, it can be silenced by entering the following command:

```
rls-alm:lvl=xxxx
```

where *xxxx* can be:

- *minr* - Silences a minor alarm
- *majr* - Silences a major alarm
- *crit* - Silences a critical alarm.

All alarm types can be silenced with the following command:

```
rls-alm
```

The `rls-alm` command does not clear visual alarms on the terminals or alarm indicators on the fuse and alarm panel (**FAP**) or frame panels.

Once an audible alarm is silenced, any new alarm conditions cause the alarm to sound again.

Silencing a specific alarm when a lower level alarm is also present results in the next highest audible alarm level being activated. For example, the system has both critical and major alarms present. When the critical alarm is silenced, the audible major alarm begins to sound.

## 3.6 Retrieve Trouble Report

Application maintenance software is responsible for monitoring trouble on a card. There are three types of troubles or faults:

- Abnormal situation is being reported by software.
- An **SS7** message has a problem (an invalid **DPC**, for example)
- A hardware fault is being reported.

Trouble reports are used by [My Oracle Support \(MOS\)](#) to help analyze problems with the EAGLE system. To help [My Oracle Support \(MOS\)](#), retain any printouts of the trouble report. The output of the `rtrv-trbl` command should be reviewed with a member of [My Oracle Support \(MOS\)](#). To display the current trouble reports, enter the following command at the system terminal:

```
rtrv-trbl:loc=1115:num=1:mode=c
```

The **mode=c** parameter provides a continuous output of the trouble reports as they occur. The **loc=** parameter specifies the active **E5-MCAP**. The **num** parameter indicates how many trouble reports you want to display.

A typical trouble report looks similar to this:

```
tekelecstp 00-05-15 19:04:05 EST EAGLE 35.0.0
 Card 1115 Module tc_utl.c Line 1617 Class 1103 Severity 1
 00 02 f6 00 01 23 06 22 05 00
 Report Date 00-05-15 Time19:04:05
```

The trouble reports include:

- **Card** number
- Module name
- Line number
- Class
- Severity

## 3.7 Hourly Status Message Reports

The system provides hourly reports that include a list of all alarms and any devices that are manually deactivated or inhibited. The report contains the alarms that exist at the time the report is generated. Any alarms that have occurred, and have been cleared in the last hour, are not reported. The hourly status message report is automatically generated at the beginning of each hour (08:00, 09:00, and so forth). The system sends the report to all system terminals that can receive unsolicited program update messages.

The information shown in the hourly status report can also be displayed by entering one or more of the following commands.

### Note:

Systems supporting an **ITU** network are not configured with the **LNP** or **SEAS** features.

- `rept-stat-alm`: Displays the summary of all alarm counts.
- `rept-stat-card`: When used with the **stat** parameter, displays all cards with the state specified by the **stat** parameter. Refer to *Commands User's Guide* for additional information on the use of parameters with this command.
- `rept-stat-cdt`: Displays the customer defined troubles.
- `rept-stat-clk`: Displays the status of the clocks.
- `rept-stat-cluster`: Displays the summary status and statistical information for all configured cluster point codes.
- `rept-stat-db`: When used with the `display=except` parameter, displays the status of the system database by displaying the database level of the cards whose


database level does not match the active fixed disk current partition. Refer to *Commands User's Guide* for additional information on the use of parameters with this command.

- `rept-stat-dlk`: When used with the **:stat** parameter, displays the status of the **TCP/IP** data links. Refer to *Commands User's Guide* for additional information on the use of parameters with this command.
- `rept-stat-dstn`: When used with the **stat** parameter, displays the destination point codes with the state specified by the `stat` parameter. Refer to *Commands User's Guide* for additional information on the use of parameters with this command.
- `rept-stat-dstn`: When used with the **mode=full** parameter, displays the subsystem status. Refer to *Commands User's Guide* for additional information on the use of parameters with this command.
- `rept-stat-mps`: Displays in a single report, the overall status of the **EPAP** (EAGLE Provisioning Application Processor) subsystem.
- `rept-stat-gpl`: Displays the version of the **GPL** currently being used by an application and which versions of the **GPL** are the trial and approved versions of that **GPL**.
- `rept-stat-imt`: Displays the primary, secondary, and associated maintenance states of the IMT buses.
- `rept-stat-lnp`: Displays the status and statistics related to **LNP**.
- `rept-stat-ls`: When used with the **stat** parameter, displays the linksets that have the state specified by the `stat` parameter. Refer to *Commands User's Guide* for additional information on the use of parameters with this command.
- `rept-stat-sccp`: Displays the status of the **TSMs** running the **SCCP** application.
- `rept-stat-seas`: Displays the status of the **SEAS** subsystem.
- `rept-stat-slk`: When used with the **stat** parameter, displays the signaling links that have the state specified by the `stat` parameter. Refer to *Commands User's Guide* for additional information on the use of parameters with this command.
- `rept-stat-sys`: Displays the status of these items: alarms, IMT buses, **SS7** signaling links, linksets, destination point codes (**DPCs**), the maintenance and administration subsystem (**MAS**), clocks, **TSMs** loaded with the **SCCP** or **GLS** application, security subsystem, and the **SEAS** subsystem.
- `rept-stat-trbl`: Displays a report of all the device trouble notifications that are currently logged in the **OAMRAM** storage area. The severity of each alarm is also identified in the report.
- `rept-stat-trm`: Displays the status of the terminal serial ports.
- `rept-stat-xlist`: Displays the statistics related to the storage of exception list (x-list) entries.

If the message reference number (**MRN**) field has a null value (no field entry), the device has been manually removed from service (through `inh-card`, `canc-slk`, and so forth). There is no alarm for the device and the condition type is **SCMMA** (state change due to manual action). The date and time in the report refer to the date and time of the alarm or when the device was removed from service. The format of the output is in [Figure 3-7](#).



**Figure 3-7 Format of Hourly Status Message Output**



The following is a list of the device types and subsystems (with the **ID** of the affected device or subsystem) that the hourly status message report displays reports for. For example, if the device type being reported on is **CARD**, then card locations are displayed. Only those device types and subsystems that have disabled devices or alarm conditions are displayed in the hourly status message report. If there is more than one device type or subsystem to display, they are displayed in the following order.

1. **CARD** - the card location
2. **IMT** - the IMT bus A or IMT bus B
3. **BITS** - the **BITS** clock
4. **TRM** - the terminal port
5. **SLK** - the linkset name and the signaling link code (**SLC**)
6. **DLK** - the data links
7. **LS** - the linkset name
8. **DPC** - the destination point code
9. **CDT** - the customer defined trouble number
10. **FUSEPNL** - the frame **ID** of the system
11. **SYSTEM** - system
12. **ALM** - alarms
13. **SYSCLK** - system clock
14. **SYSIMT** - system IMT
15. **SCCPSS** - **SCCP** subsystem
16. **GLSSS** - **GLS** subsystem
17. **GPL\_SS** - the name of the **GPL**
18. **XLISTSS** - **XLIST** subsystem
19. **SEASSS** - **SEAS** subsystem
20. **SECULOG** - Security log
21. **LNPSS** - **LNP** subsystem

22. **LSMS Q.3 Association** - Local Services Management System **Association**
23. **LSMSSS** - Local Services Management System subsystem
24. **HS System CLK** - High-Speed system clock
25. **EMDC Links** - Element Measurement & Data Collection Application Links
26. **NDCSS** - Network Data Collection subsystem
27. **NDC Q.3 Association** - Network Data Collection Q.3 association
28. **GSMSS** - **GSM** subsystem
29. **MPS (ELAP/EPAP) - Multi-Purpose Server**
30. **DSM Links - Database Services Module**
31. **INPSS** - **INP** subsystem
32. **SECURITYSS** - Security subsystem

Within each device type or subsystem being reported, the subsets of the report are displayed in the following order.

1. Disabled Devices
2. Minor Alarms
3. Major Alarms
4. Critical Alarms

The *cond type* field supports five values for this release:

- **SCMMA**: The device has been disabled due to manual maintenance action. This condition applies regardless of a previous alarm state.
- **MTCEINT-0**: The reported device is off normal (**ANR**), but there is no alarm associated with this device. An alarmed condition for another device typically affects the state of this device. For example, out-of-service (**OOS**) links affect the condition of the linksets.
- **MAN**: The reported device is off-normal (**OOS-MT**), but there is no alarm associated with this device. The off-normal condition was caused by manual intervention (by entering the ent-dstn command, for example).
- **NULL**: No specific cond type is supported. There is sufficient information to ascertain the device condition from the report. You should use a rept-stat command for further information.
- **INAUDB**: The user has manually inhibited alarms for this device. The time when the device was inhibited is recorded and displayed during the hourly report.

Following is an example of the report:

```

RLGHNCXA21W 00-07-16 12:20:12 EDT EAGLE 35.0.0
1240.0000 REPT COND CARD
\CARD 1101:0013,,SA,00-07-16,10:03:29,,,,**"
\CARD 1107:,SCMMA,,00-07-16,10:03:29,,,,"
\CARD 1113:0143,,NSA,00-07-16,10:03:29,,,*"

RLGHNCXA21W 00-07-16 12:20:12 EDT EAGLE 35.0.0
1241.0000 REPT COND SLK
\SLK 1s1201-0,,NSA,00-07-16,10:03:29,,,,*"
\SLK 1s1201-1,,NSA,00-07-16,10:03:30,,,,*"

```

```

"SLK ls1202-0,,NSA,00-07-16,10:03:31,,,,*"
"SLK ls1202-1,,NSA,00-07-16,10:03:32,,,,*"

RLGHNCXA21W 00-07-16 12:20:12 EDT EAGLE 35.0.0
1242.0000 REPT COND LS
"LS ls1201:,MTCEINT-0,,00-07-16,10:03:29,,,,,"
"LS ls1202:0318,,NSA,00-07-16,10:03:29,,,,*"
"LS ls1203:0318,,00-07-16,10:03:29,,,,*"
"LS lsx23 :0318,,NSA,00-07-16,10:03:33,,,,*"

RLGHNCXA21W 00-07-16 12:20:12 EDT EAGLE 35.0.0
1243.0000 REPT COND DPC
"DPC 001-001-001:0313,,SA,00-07-16,10:03:29,,,,*C"
"DPC 002-002-002:0313,,SA,00-07-16,10:03:30,,,,*C"
"DPC 003-003-003:0313,,SA,00-07-16,10:03:31,,,,*C"
"DPC 001-005-* :0313,,SA,00-07-16,10:03:32,,,,*C"
"DPC 006-006-006:,MAN,,00-07-16,10:03:32,,,,,"

RLGHNCXA21W 00-07-16 12:20:12 EDT EAGLE 35.0.0
1244.0000 REPT COND TRM
"TRM 2:..SCMMA,00-07-16,10:03:29,,,,,"
"TRM 3:0048,,NSA,00-07-16,10:03:29,,,,*"

```

## 3.8 Maintenance System Event Logs

The `rtrv-log` command is used to retrieve records from the active or standby event logs generated by the maintenance system. This command selects these records based on a span of time or a specific log file index. There are numerous ways to sort and filter the output. Refer to *Commands User's Guide* for details on using the `rtrv-log` command. A sample output follows:

```

rtrv-log:sdate=030715:stime=220000:num=50:snum=106:enum=350
ncralstp00001 10-03-16 10:15:29 EST EAGLE 42.0.0
Card 1113; SYS REL= 31.3.0; STP CLLI= ncralstp00001; Timezone= EST

****03-07-16 00:23:55****
3161.0200 SLK 1103,B RCVRY-LKF: link
available
****03-07-16 01:43:51****
3163.0317 LSET A123456789 RCVRY-LKSTO: linkset
allowed
****03-07-16 03:00:23****
3165.0108 ** IMT BUS A Major IMT fault detected
****03-07-16 03:37:59****
3166.0292 *C GLS SYSTEM GLS is not available
****03-07-16 07:22:06****
3167.0313 *C DPC 021-005-000 DPC is prohibited
****03-07-16 09:33:17****
3168.0348 * SEAS SYSTEM SEAS is at minimum service
****03-07-16 09:34:01****
3169.0112 * IMT SYSTEM Major Failures detected on both
****03-07-16 09:35:07****
3170.0160 * CLOCK SYSTEM 1116-S clock failed

```

```

****03-07-16 09:36:34****
3171.0160 * CARD 1116 OAM 1116-S clock failed
****03-07-16 09:38:12****
3173.0308 *C SYSTEM Node isolated due to SLK failure
****03-07-16 09:39:56****
3174.0331 *C SCCP SYSTEM SCCP is not
available
****03-07-16 09:45:29****
3180.0321 * XLIST X-LIST occupancy threshold Exceeded
****03-07-16 09:48:48****
3181.0175 * SECURITY 1114 LOGBUFROVL-SECULOG - upload required
;

UAM Report terminated - end of log reached.
END OF LOG REPORT.
;

```

The `rtrv-trbltx` command is used to retrieve alarm and **UIM** message information including **MRN** (message reference number), level (for Alarms), Output Group and text.

The default `rtrv-trbltx` report displays all Alarms (in numerical order), and then all **UIMs**. Using the optional parameters, the capability exists to display a range of Alarms or **UIMs**, search for Alarms, **UIMs** or both message types matching a specific Output Group or sort all entries by Output Group. Refer to *Commands User's Guide* for details on using the `rtrv-log` command. A sample output follows:

```

rtrv-trbltx:OUTGRP=all
ncralstp00001 03-07-16 10:15:29 EST Rel XX.X.X

Card 1113; SYS REL= XX.X.X; STP CLLI= ncralstp00001; Timezone= EST
Alarm Report
 MRN LEVEL OUTPUT GROUP TEXT

 Output Group - SYS
 0001 MAJR SYS Card has reset
 0002 MINR SYS Card is not running approved GPL
 :
 0912 NONE SYS Dynamic database is now consistent
 :
 Output Group - LINK
 :
 0479 NONE LINK Link not Monitored
UIM Report
 MRN OUTPUT GROUP TEXT

 Output Group - SYS
 1000 SYS MTP rcvd UPU - user part is not
SCCP
 1001 SYS MTP rcvd Transfer Controlled (TFC)
 :
 1499 SYS Invalid MRN detected

```

```

:
Output Group - LINK
 13nn LINK Example text
END OF RTRV-TRBLTX REPORT.
;

```

## 3.9 Obituaries

An obituary is a set of data that describes the status of the system just before a processor restarted due to a fault in hardware or software. The data includes a register and stack dump of the processor, card location, reporting module number, software code location, and class of the fault detected. In most situations, obituary reports are generated automatically when a card is reset. Obituary reports can also be retrieved manually using the `rtrv-obit` command. Refer to *Commands User's Guide* for information on using the `rtrv-obit` command. Obituaries should immediately be reported to the [My Oracle Support \(MOS\)](#).

To help [My Oracle Support \(MOS\)](#), retain any printouts of the obituary. [My Oracle Support \(MOS\)](#) can use the report to analyze the problem. A typical obituary looks like the following:

```

rtrv-obit:loc=1115:num=2

rlghncxa03w
13-04-19
12:09:15 EST EAGLE5 45.0.0-64.62.0

STH: Received a BOOT APPL-Obituary reply for restart
 Card 1115 Module crc_mgr.c Line 482 Class 01d3
 Register Dump :
 EFL=00000246 CS =0008 EIP=0064d4d8 SS =0010
 EAX=00000000 ECX=00000000 EDX=00c8fc70
EBX=0b86570c
 ESP=030f5fa0 EBP=030f5fb0 ESI=0000000a
EDI=00000000
 DS =0010 ES =0010 FS =0010 GS =0010

 Stack Dump :
 [SP+1E]=eeee [SP+16]=0b80 [SP+0E]=0b86 [SP+06]=0000
 [SP+1C]=eeee [SP+14]=42ed [SP+0C]=570c [SP+04]=0246
 [SP+1A]=0000 [SP+12]=030f [SP+0A]=0000 [SP+02]=0000
 [SP+18]=000a [SP+10]=5fd0 [SP+08]=0000 [SP+00]=0008

 User Data Dump :
 07 ff 00 00 80 ca 11 04 00 00 03 00 00 00 00
00
 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00
 00 00 00 80 ca 10 04 00
Report Date:13-04-12 Time:09:16:30

```

```

-
;
rlghncxa03w 13-04-19 12:09:16 EST EAGLE5 45.0.0-64.62.0

STH: Received a BOOT APPL-Obituary reply for restart
Card 1213 Module radb_mgr.c Line 652 Class 01d7
Register Dump :
 EFL=00000246 CS =0008 EIP=0061bea8 SS =0010
 EAX=06c25c83 ECX=000005e8 EDX=00000000 EBX=06c25c38
 ESP=0251fed0 EBP=0251fee0 ESI=0be2a582 EDI=00000200
 DS =0010 ES =0010 FS =0010 GS =0010

Stack Dump :
[SP+1E]=0000 [SP+16]=0b97 [SP+0E]=06c2 [SP+06]=0b97
[SP+1C]=00d4 [SP+14]=a454 [SP+0C]=5c38 [SP+04]=c429
[SP+1A]=06c2 [SP+12]=0251 [SP+0A]=0250 [SP+02]=0251
[SP+18]=5c38 [SP+10]=ff10 [SP+08]=0f14 [SP+00]=fee0

User Data Dump :
8f 82 fb ed 01 01 5a 01 5a 0b 00 86 00 00 00 99 Z.Z.....
54 8c 1a 87 00 00 00 f0 54 8c 1a 77 00 08 00 00 T.....T..w....
00 00 00 00 00 00 00 00 00
Report Date:13-04-12 Time:10:40:36

;

```

## 3.10 Terminal Not Responding

When a terminal is not responding, perform the following procedure:

1. Verify the terminal is connected to the **MMI** port on the back of the control shelf.
2. Verify the terminal is set up for 7-E-1.
3. From a working terminal, enter the following command to determine the port connected to the faulty terminal:

```
rtrv-trm
```

Note the port number. From the output message, verify the settings are correct. If no working terminal is available, contact the [My Oracle Support \(MOS\)](#).

4. Enter the following command to inhibit the terminal failing to respond:

```
inh-trm:trm=x
```

where *x* is the terminal that is not responding.

5. Enter the following command to re-activate the terminal failing to respond:

```
alw-trm:trm=x
```

where *x* is the terminal that is not responding. If the terminal fails to respond, go to 6.

6. Enter the following command to ensure that the other terminal devices are functioning:

```
rept-stat-trm
```

Following is an example of the output:

```
RLGHNCXA03W 00-02-07 09:50:17 EST EAGLE 35.0.0
```

| TRM | PST          | SST    | AST   |
|-----|--------------|--------|-------|
| 1   | IS-NR        | Active | ----- |
| 2   | IS-NR        | Active | ----- |
| 3   | IS-NR        | Active | ----- |
| 4   | OOS-MT-DSBLD | MANUAL | ----- |
| 5   | IS-NR        | Active | ----- |
| 6   | IS-NR        | Active | ----- |
| 7   | IS-NR        | Active | ----- |
| 8   | IS-NR        | Active | ----- |
| 9   | IS-NR        | Active | ----- |
| 10  | IS-NR        | Active | ----- |
| 11  | IS-NR        | Active | ----- |
| 12  | IS-NR        | Active | ----- |
| 13  | OOS-MT-DSBLD | MANUAL | ----- |
| 14  | OOS-MT-DSBLD | MANUAL | ----- |
| 15  | OOS-MT-DSBLD | MANUAL | ----- |
| 16  | OOS-MT-DSBLD | MANUAL | ----- |

Command Completed.

7. Verify the problem is not with the terminal by swapping terminals with a known good terminal.

Make sure the physical connections are firmly seated. If the terminal works, replace the original terminal.

8. If a single terminal is not functioning and you have verified that the terminal is good, the connections are good, and the settings are correct, then from another terminal inhibit the terminal port with the following command:

```
rmv-trm:trm=x
```

where *x* is the terminal port number (1 through 16).

9. Enable the terminal port with the following command:

```
rst-trm:trm=x
```

where *x* is the terminal port number (1 through 16). If this action corrects the problem, you are done with this procedure.

10. If the terminal still does not respond, contact the [My Oracle Support \(MOS\)](#).

## 3.11 Printer Not Working

Perform the following procedure if the printer is not working.

1. Enter the following command to determine the port connected to the faulty printer:

```
rtrv-trm
```

Note the port number. From the output message, verify the settings are correct.

2. Verify the printer is connected, and the power is on.

Run a printer test to verify the printer is operational (refer to the printer manual for printer tests). If there is no problem with the printer, continue with [3](#). If there is a problem with the printer, go to [4](#).

3. Enter the following command to ensure that the other terminal devices are functioning on the **E5-TDM** in the active **E5-MASP**:

```
rept-stat-trm
```

Following is an example of the output:

```

RLGHNCXA03W 00-02-07 09:50:17 EST EAGLE 35.0.0
TRM PST SST AST
1 IS-NR Active -----
2 IS-NR Active -----
3 IS-NR Active -----
4 OOS-MT-DSBLD MANUAL -----
5 IS-NR Active -----
6 IS-NR Active -----
7 IS-NR Active -----
8 IS-NR Active -----
9 IS-NR Active -----
10 IS-NR Active -----
11 IS-NR Active -----
12 IS-NR Active -----
13 OOS-MT-DSBLD MANUAL -----
14 OOS-MT-DSBLD MANUAL -----
15 OOS-MT-DSBLD MANUAL -----
16 OOS-MT-DSBLD MANUAL -----
Command Completed.

```

4. Verify the problem is not with the printer by swapping printers with a known good printer.

Make sure the physical connections are firmly seated. If the printer works, replace the original.

5. If a single port is not functioning and it has been verified the printer is good, the connections are good, and the settings are correct, inhibit the printer port with the following command:

```
rmv-trm:trm=x
```

where *x* is the printer port number (1 through 16).

6. Enable the printer port with the following command:

```
rst-trm:trm=x
```

where *x* is the terminal port number (1 through 16). If this action corrects the problem, you are done with this procedure.

7. If none of the ports are active, trying resetting and then reseating the **E5-TDM** card.
8. If the problem persists, replace the **E5-TDM** card.  
See [Card Removal/Replacement Procedures](#).
9. If the terminal still does not respond, contact the [My Oracle Support \(MOS\)](#).

10. If only the printer port is inactive, inhibit the printer with the following command:

```
rmv-trm:trm=x
```

where *x* is the printer number (1 through 16).

11. Enable the printer with the following command:

```
rst-trm:trm=x
```

If this action corrects the problem, you are done with this procedure. If the problem persists, reseal the **E5-TDM** card.

12. If reseating the **E5-TDM** card does not correct the problem, replace the **E5-TDM** card.



See [Card Removal/Replacement Procedures](#).

13. If the printer still does not respond, contact the [My Oracle Support \(MOS\)](#).

## 3.12 Modem Not Working

Using Procomm Plus and a modem connected to a serial port on the system, the system can be accessed the remotely. If there are problems connecting to the modem, perform the following procedure:

1. Check the physical connection.  
The connector to the modem should be an **RS-232** connection and firmly seated in both the serial port of the system and the modem.
2. Verify the flow control is set to **software**.
3. Start Procomm Plus and check the modem settings.

The following are possible modem settings for the recommended modem, the Motorola **UDS**. (Other types of modems may have different settings):

- **AT&F0** - Load factory profile and defaults
- **AT&C1** - Make **DCD** true
- **ATE0** - Disable command echo. If you use this command, you do not see the commands that you enter. Be careful to enter the commands correctly.
- **ATQ1** - Stop the results codes to the terminal
- **AT&W0** - Store profile in memory location 0
- **AT&Y** - Select stored profile 0 on power up

## 3.13 Link Maintenance

**Link** maintenance covers the proper functionality of a signaling link, from an EAGLE **MTP** card to a remote **NE**.

### Link Fault Sectionalization

The link fault sectionalization (**LFS**) feature allows maintenance personnel to perform **DSOA** link fault sectionalization tests, a series of far end loopback tests, from the system and identify faulty segments of an **SS7** transmission path up to and including the remote network element.

The point on the signaling link at which each loopback test ends is the far end loopback point. A far end loopback point is achieved when the remote link element sends the received data back to the transmitter, allowing the transmitter to verify the received data. The remote link elements are shown in [Table 3-5](#).

**Table 3-5 Remote Link Element types**

| Element    | Description         | Valid for the Latching Link Fault Sectionalization Test? | Valid for the Non-latching Link Fault Sectionalization Test? |
|------------|---------------------|----------------------------------------------------------|--------------------------------------------------------------|
| <b>DSO</b> | <b>DSO</b> Dataport | yes                                                      | no                                                           |

**Table 3-5 (Cont.) Remote Link Element types**

| Element    | Description                      | Valid for the Latching Link Fault Sectionalization Test? | Valid for the Non-latching Link Fault Sectionalization Test? |
|------------|----------------------------------|----------------------------------------------------------|--------------------------------------------------------------|
| <b>OCU</b> | <b>OCU</b> Dataport              | yes*                                                     | yes                                                          |
| <b>CSU</b> | <b>CSU</b> Dataport              | yes*                                                     | yes                                                          |
| <b>DSU</b> | <b>DSU</b> Dataport              | yes*                                                     | yes                                                          |
| <b>NEI</b> | <b>Network Element</b> Interface | yes                                                      | no                                                           |

\* The **OCU**, **CSU** and **DSU** must be strapped or optioned to support latching link fault sectionalization loopback.

The loopback point is moved along the signaling link path until the point is in the far end network element. Therefore, each loopback point along the link requires the initiation of one link fault sectionalization test on the **SS7LIM**.

The link fault sectionalization test types for loopback tests are shown in [Table 3-6](#).

**Table 3-6 Link Fault Sectionalization Test Types**

| Link Fault Sectionalization Test Types                        | Description                                                                                                     |
|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
| Latching link fault sectionalization test ( <b>LLT-auto</b> ) | A loopback point is established using signaling commands and remains until it is removed by signaling commands. |
| Latching link fault sectionalization test ( <b>LLT-man</b> )  | A loopback point is established by manual means and remains until it is removed by manual means.                |
| Non-latching link fault sectionalization test ( <b>NLT</b> )  | A loopback command is interleaved with the test data.                                                           |

The **SS7LIM** must be powered up and in service with the signaling link deactivated (**OOS-MT-DSBLD**) before starting the link fault sectionalization tests. No signaling traffic is on the signaling link by the **SS7LIM** while the link is performing a link fault sectionalization test.

The system supports a maximum of 32 remote link elements for each **SS7** link.

The system allows a maximum of 1024 **SS7** simultaneous **LFS** tests.

### Hardware Configuration

The link fault sectionalization feature requires a **LIM** hardware configured as shown in [Table 3-8](#). The test data is guaranteed to be a continuous data stream, and the commands provide the ability to put any element in the link into latched loopback.

The test data is provided is shown in [Table 3-7](#). The data stream sent is verified against the data stream received and a bit error count is updated. If the bit error count is 255 or greater in one second period, the value of the bit error count remains at 255, does not overflow and the test is terminated.

**Table 3-7 Link Fault Sectionalization Test Patterns**

| Test Pattern       | Data           | Description                                                                                                                                     |
|--------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| B2047              | N/A            | 2047-bit Bert pattern sent until it is terminated by software.                                                                                  |
| B2047 Non Latching | N/A            | 2047-bit Bert pattern sent interleaved with loopback command until it is terminated by software.                                                |
| B511               | N/A            | 511-bit Bert pattern sent until it is terminated by software.                                                                                   |
| B511 Non latching  | N/A            | 511-bit Bert pattern sent interleaved with loopback command until it is terminated by software.                                                 |
| <b>OCTET</b>       | default = h'32 | A continuous series of the specified octet data is sent until it is terminated by software. (Latching only)                                     |
| <b>ALTERNATE</b>   | default = h'FF | A count of 100 octets of the specified data followed by 100 octets of 0 is sent alternating until it is terminated by software. (Latching only) |

**LFS** tests initiated by the **EAGLE** are used to test the functionality of a signaling link (**SLK**) from an **EAGLEMTP** card through multiple channel banks to a remote **Network Element**. The number of simultaneous tests that can be run on a specific card are shown in parenthesis ( ) in [Table 3-8](#). The maximum number of simultaneous tests for a card is determined by hardware type. [Table 3-8](#) shows the relationship between hardware type and **LFS** support. A key for the values follows:

- **NV** indicates **APPL** is not valid for the given hardware.
- **No** indicates **LFS** testing is not supported for this combination of hardware, provisioned type, and provisioned application.
- **Yes** indicates **LFS** testing is supported (max tests per card is shown in parenthesis)

**Table 3-8 Hardware/Card/APPL LFS Support**

|                 |               | Provisioned Application |           |
|-----------------|---------------|-------------------------|-----------|
| <b>MPL</b>      |               | Yes (1)                 | <b>NV</b> |
| <b>MPL-T</b>    |               | Yes (8)                 | <b>NV</b> |
| <b>E1/T1MIM</b> | <b>LIMT1</b>  | Yes (8)                 | Yes (8)   |
|                 | <b>LIMCH*</b> | Yes (8)                 | Yes (8)   |
| <b>HC MIM</b>   | <b>LIMT1</b>  | Yes (64)                | Yes (64)  |

\*If associated parent card is **LIMT1**

## Test Indicators

Two indicators are used by the `rept-stat-slk` and `rept-stat-ls` commands to show whether the signaling link has a far end loopback condition and if a link fault sectionalization test is in progress.

When the signaling link is in a far end loopback condition:

- The primary state (**PST**) is **OOS-MT-DSBLD**.
- The secondary state (**SST**) is **LPBK** .
- The associate state (**AST**) is **FE** .

When a link fault sectionalization test is in progress:

- The primary state (**PST**) is **OOS-MT-DSBLD**.
- The secondary state (**SST**) is **LPBK** .
- The associate state (**AST**) is **LFS** .

When both the signaling link is in a far end loopback condition and a link fault sectionalization test is in progress:

- The primary state (**PST**) is **OOS-MT-DSBLD**.
- The secondary state (**SST**) is **LPBK** .
- The associate state (**AST**) is **FE-LFS**.

## Test Report

Test results are displayed to the terminal when the link fault sectionalization tests have completed. The following is an example of a link fault sectionalization test report.

```

RLGHNCXA03W 96-04-16 16:02:05 EST EAGLE 35.0.0
LOC = 1205 Port = B LSN = ----- Start time = 11:10:34
PATTERN = ALTERNATE DATA= FF MAXERR = 10 TIME = 00:02:00
TEST STATUS = ERROR, bit error exceeded threshold.
LBP CLLI RLE REP LFST BIT_ERROR ERRORED_SEC DURATION
2 rlghncxa05w DSO 0 LLT 0 0 00:02:00
3 ----- OCU 0 NLT 8 2 00:02:00
5 ----- NEI 0 LLT 15 1 00:01:20

```

## LFS Test Details

- *EAGLE Initiated LFS Loopback Test Details*  
**Loopback Test Type:** EAGLE initiated Level 1 **DS0LFS** test  
**Link State:** Link is down.  
**Equipment tested:** Level 1 element(s) in a signaling path.  
**Purpose:** Test the error rates of a signaling path.  
**Description:** Sends loopback code to establish loopback and then performs **BERT** test for a specified period of time.  
**Typical use:** To validate signaling path has acceptable error rate.  
**Testing Limits:** 1024 concurrent link tests per system.

- *Remote Initiated LFS Loopback Test Details*  
**Loopback Test Type:** Remote Loopback **FAREND** initiated **DS0LFS** test.  
**Link State:** Link can be up or down.  
**Equipment tested:** Near end H/W up to level 2 (**LXVR**) and far end H/W level 1 interface.  
**Purpose:** Auto-loopback a **BERT** test to the far end.  
**Description:** When receiving a loopback code, deactivate the link and go into loopback.  
**Typical use:** Used to remotely test the far end with standard **DS0BERT** tests.  
**Testing Limits:** No limit on number of cards.

### Link Fault Test Commands

The link fault sectionalization feature uses the following commands:

- `ent-lbp` — add link fault sectionalization test data to the database.
- `chg-lbp` — change existing link fault sectionalization test data in the database.
- `dlt-lbp` — remove link fault sectionalization test data from the database.
- `rtrv-lbp` — display link fault sectionalization test data in the database.
- `act-lbp` — start a link fault sectionalization test.
- `dact-lbp` — stop a link fault sectionalization test.
- `rept-stat-lfs` — generates a report of all links that are under test.

The link fault sectionalization data is configured in the database using the parameters shown in [Table 3-9](#).

**Table 3-9 Link Fault Sectionalization Data Entry Parameters**

| Link Fault Sectionalization Data Entry Parameters | Description                                                                                                                                                     |
|---------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Card Location                                     | <b>SS7LIM</b> card location                                                                                                                                     |
| Port Number                                       | Port a or b, and a1, a2, a3, b1, b2, b3 on the <b>MPL</b>                                                                                                       |
| Loopback Point Number                             | Identifies the remote link element for setting the loopback point. Value is from 1 to 32.                                                                       |
| <b>CLLI</b>                                       | Description of the remote link element                                                                                                                          |
| <b>Remote Link Element Type</b>                   | The remote element type from <a href="#">Table 3-5</a> .                                                                                                        |
| Repetition Count                                  | A repetition of the same element type in the link path. This is needed for configuring the link element as a latched loopback point. The value is from 0 to 31. |
| <b>Link Fault Sectionalization Test Type</b>      | <b>Link</b> fault sectionalization test type from <a href="#">Table 3-6</a> ( <b>LFS</b> -man not supported for the database)                                   |

Use the `act-lbp` command to start one or a sequence of link fault sectionalization tests. The data stream sent is verified against the data stream received and the bit error counts and block error counts are displayed when the test completes.

The link fault sectionalization test parameters are described in [Table 3-7](#). If either the remote link element type, repetition count, or link fault sectionalization test type are specified with the `act-lbp` command, they must all be specified and the loopback point number parameter is ignored. Otherwise the values for remote link element type, repetition count, or link fault sectionalization test type are read from the data entered with the `ent-lbp` command using the loopback point number parameter value. The test data parameter is only valid for test patterns **OCTET** and **ALTERNATE**.

If all **LBP**s are selected for the loopback point number parameter, a sequential test of the **LBP**s, as entered in the database with the `ent-lbp` command for that signaling link, is performed until the entire signaling link has been tested. When performing a test with all **LBP**s, the test is aborted with the first failed test.

The test is stopped either because the amount of time for the test has expired or if the bit error threshold has been exceeded. The time duration parameter specifies the maximum time duration for one link fault sectionalization loopback point test. The default value is one second (00:00:01) and the maximum value that can be entered is 24 hours (24:00:00). The bit error threshold parameter specifies the maximum number of bit errors allowed for one link fault sectionalization loopback point test. The default value is 56 errors and the maximum value that can be entered is 4,838,400 (24 hours x 56 errors per second).

**Table 3-10 Link Fault Sectionalization Test Parameters**

| Parameters                            | Description                                                                                                                                              |
|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Card Location                         | <b>SS7LIM</b> card location                                                                                                                              |
| Port /Link Number                     | Signaling link id a to a63 and b to b63                                                                                                                  |
| Loopback Point Number                 | The remote link element for setting the loopback point. Value is from 1 to 32, or if this parameter is not specified, all <b>LBP</b> s are selected.     |
| Remote Link Element Type              | The remote element type from <a href="#">Table 3-5</a> .                                                                                                 |
| Repetition Count                      | A repetition of the same element type in the link path. The value is from 0 to 31.                                                                       |
| Link Fault Sectionalization Test Type | Link fault sectionalization test type from <a href="#">Table 3-6</a> .                                                                                   |
| Time duration                         | Time for one loopback point in hours, minutes, and seconds (hh:mm:ss). The value is from 00:00:01 to 24:00:00. The default value is 1 second (00:00:01). |
| Error threshold                       | Bit error threshold. The value is from 0 to 4838400. The default value is 56.                                                                            |
| Test pattern                          | The test pattern from <a href="#">Table 3-7</a> . The default value is B2047.                                                                            |
| Test data                             | The octet to be used for test pattern <b>OCTET</b> or <b>ALTERNATE</b> only.                                                                             |

 **Note:**

Links A32-A63 and B32-B63 are only applicable for SLIC cards running the IPSPG application.

The `dact-lbp` command stops the link fault sectionalization test in progress and cancels any pending link fault sectionalization tests for the **SS7** link. The pending tests are the next sequential **LBP**s for the **SS7** signaling link when an entire link test was initiated.

### 3.13.1 Link Maintenance Enhancements

The **Link Maintenance Enhancements** feature covers the following areas:

- Allows the operator to force a card into loopback. Without this enhancement, a card will go in and out of loopback as determined by loopback codes sent by the far end.
- `tst-slk` enhancements for **ATM** customers. The loopback parameters for **ATM** cards in the `tst-slk` command act in a similar fashion as the `act-lbp` command for standard **DS0** loopbacks. Other `tst-slk` enhancements not specifically related to **ATM** are also provided.

#### Command Driven Loopback

Command Driven Loopback (**CDL**) is the ability to locally drive a signaling link into a manual line loopback. The data received on the signaling link is echoed (transmitted) back. Commands are used to provide this capability on an individual signaling link basis. **CDL** allows loopback testing of a signaling link when either far-end initiated loopbacks are prevented or when a constant loopback state is desired. This command driven setting of loopback is similar in functionality to a remote initiated loopback. [Table 3-11](#) shows a breakdown of support for Command Driven Loopback based on the **MTP** card type. [Figure 3-8](#) shows a conceptual view of a signaling links network connections. Local transceiver (**LXVR**) is a `tst-slk` initiated test in which the line transmit is looped back to the line receive internal to the card. **CDL** is "LXVR in reverse", the line receive is looped back to the line transmit.

**Table 3-11 Command Driven Loopback Support**


| MTPCard Type    | Supported | MTPCard Type           | Supported |
|-----------------|-----------|------------------------|-----------|
| MPL (DSO)       | Yes       | <b>T1-ATM</b>          | Yes       |
| E1-ATM          | Yes       | <b>T1MIM (Channel)</b> | Yes       |
| E1MIM (Channel) | Yes       | IPLIM                  | No        |
|                 |           | IPGTWY                 | No        |

#### Test Indicators

If an **MTP** card boots, then all links on this card, by default, are not in **CDL**. A link in **CDL** is persistent across an **OAM switchover**. Signaling links must be inhibited (**OOS-MT-DSBLD**) to perform command driven loopback. Signaling links in **CDL** have the following conditions:

- The primary state (**PST**) is **OOS-MT-DSBLD**.
- The secondary state (**SST**) is **LPBK**.
- The associate state (**AST**) is **CDL**.

Figure 3-8 Signaling Link Network Connections



### Test Signaling Link

The *tst-slk* command is used to flush out intermittent link problems that are not captured with the one shot testing. The *tst-slk* command allows for duration tests up to 24 hours, stopping of an in-progress test, and forcing the execution of a test. The *tst-slk* command is grouped into two categories, message based tests and hardware-based tests.

The **SLTC** and **OAM** tests are message based. These tests involve sending a message to the far end and expecting an appropriate reply. The **LXVR**, **LINE**, and **PAYLOAD** tests are hardware-based. These tests involve setting hardware registers and after an appropriate duration resetting hardware registers. To prevent overloading of a signaling link, message based tests are delayed 1 to 10 seconds between receipt of an appropriate reply and sending of the next test message. Table 3-12 shows a breakdown of support for each *tst-slk* test based on **MTP** card.

Table 3-12 *tst-slk* Support

| MTP Card Type          | tst-slk Test | tst-slk Test | tst-slk Test | tst-slk Test | tst-slk Test |
|------------------------|--------------|--------------|--------------|--------------|--------------|
|                        | SLTC         | LXVR         | OAM          | LINE         | PAYLOAD      |
| <b>OCU</b>             | Yes          | Yes          | No           | No           | No           |
| <b>MPL (DSO)</b>       | Yes          | Yes          | No           | No           | No           |
| <b>E1-ATM</b>          | Yes          | Yes          | Yes          | No           | No           |
| <b>T1-ATM</b>          | Yes          | Yes          | Yes          | Yes          | Yes          |
| <b>T1MIM (Channel)</b> | Yes          | No           | No           | No           | No           |
| <b>E1MIM (Channel)</b> | Yes          | No           | No           | No           | No           |
| <b>IPLIM</b>           | Yes          | No           | No           | No           | No           |
| <b>IPGTWY</b>          | No           | No           | No           | No           | No           |
| <b>E1 HC MIM</b>       | Yes          | No           | No           | No           | No           |
| <b>T1 HC MIM</b>       | Yes          | No           | No           | No           | No           |
| <b>T1 HC MIM</b>       | Yes          | No           | No           | No           | No           |



### Test Signaling Links Test (tst-slk) Indicators

Signaling links performing `tst-slk` commands have a secondary state of **LPBK**, and an associated state corresponding to the type of loopback (**SLTC**, **OAM**, **LXVR**, **PAYLOAD**, **LINE**). The link must be **OOS-MT-DSBLD** for **LXVR**, **PAYLOAD**, and **LINE** tests.

If an **OAM switchover** occurs, while the `tst-slk` command is running, the test is aborted. If an **MTP** card with an active test boots then the test is aborted.

### Test E1 and T1 Ports

The `tst-e1` and `tst-t1` commands initiate loopback testing of the specified **E1** and **T1** ports on the **HC MIM** and **E5-E1T1** cards. There are 8 physical ports on the **HC MIM** or **E5-E1T1** card. This `tst-e1/t1` command is not used for any other **MTP** card type. [Table 3-13](#) shows a breakdown of support for each `tst-e1/t1` test based on **MTP** card.

**Table 3-13** `tst-e1/tst-t1` Support

| MTPCard Type     | tst-e1 Test | tst-t1 Test |
|------------------|-------------|-------------|
| <b>E1 HC MIM</b> | Yes         | Yes         |
| <b>T1 HC MIM</b> | Yes         | Yes         |
| <b>E5-E1T1</b>   | Yes         | Yes         |

### Test E1/T1 Port (tst-e1/t1) Indicators

Signaling links performing `tst-e1/t1` commands have a secondary state of **LPBK**, and an associated state corresponding to the type of loopback. For `tst-e1` the loopback types are: (**LXVR**, **LINE**, and **PAYLOAD**). For `tst-t1`, the loopback types are: (**LXVR**, **LINE**, **FELINE**, **PAYLOAD**, and **FEPAYLOAD**).

If an **OAM switchover** occurs, while the `tst-e1/t1` command is running, the test is aborted. If an **MTP** card with an active test boots then the test is aborted.

### tst-slk and tst-e1/t1 Loopback Test Details

- SLTC Loopback Test Details*  
**Loopback Test Type:** **SLTC** (EAGLE initiated Level 3 **SS7SLT**).  
**Link State:** Link is up.  
**Equipment tested:** Near and far end up to Level 3.  
**Purpose:** Test the entire path to the far end at Level 3.  
**Description:** Valid only for `tst-slk` This will send an **SLTM** out and expects an **SLTA** back.  
**Typical use:** To validate connectivity of a signaling path.  
**Testing Limits:** 1024 concurrent link tests per system.
- OAM Loopback Test Details*  
**Loopback Test Type:** **OAM** (EAGLE initiated Level 1 **ATM** test).  
**Link State:** Link is down.

**Equipment tested:** Near and far end level 1 S/W and H/W including all hardware on the cards.

**Purpose:** Test the entire near and far end level 1 H/W by exchanging **ATM** cells.

**Description:** Valid only for `tst-slk` Sends **OAM** cells out to far end for 60 seconds if no errors, 2 minutes when errors are received.

**Typical use:** Verifies **ATM** cells can be exchanged between 2 signaling points.

**Testing Limits:** 1024 concurrent link tests per system.

- *LINE/FELINE*> *Loopback Test Details*

**Loopback Test Type:** **LINE/FELINE** (EAGLE initiated Level 1-2 **ATM** test)

**Link State:** Link is down.

**Equipment tested:** Near end H/W up to level 2 (**LXVR**) and far end H/W level 1 interface.

**Purpose:** H/W continuity check between near and far end.

**Description:** This detail sequence is valid for `tst-slk:loopback=line` and `tst-t1:loopback=feline`.

`tst-t1:loopback=line` installs the local line loopback (receive to transmit) similar to an `act-cdl:loopback=line`.

The following steps occur:

1. Device under test (**DUT**) sends **T1** bit oriented code (**BOC**) to remote device.
2. Remote device receives **BOC** and programs hardware.
3. **DUT** attempts level 2 alignment.
4. If link aligns (level 2), test passes, else test fails.
5. **DUT** sends **BOC** to remote device to remove loopback.
6. Remote device receives **BOC** and re-programs hardware.

 **Note:**

If the **DUT** boots in the middle of the sequence, the remote device needs to have the link activated/de-activated and it will return to the original programming.

**Typical use:** Used for a link in line timing to check continuity from the near end level 2 H/W to the level 1 interface at the far end.

**Testing Limits:** 1024 concurrent link tests per system.

- *PAYLOAD/FEPLAYLOAD* *Loopback Test Details*

**Loopback Test Type:** **PAYLOADFEPLAYLOAD** (EAGLE initiated Level 1-2 **ATM** test)

**Link State:** Link is down.

**Equipment tested:** Near end H/W up to level 2 (**LXVR**) and far end H/W level 1 interface.

**Purpose:** H/W continuity check between near and far end.

**Description:** This detail sequence is valid for `tst-slk:loopback=payload` and `tst-t1:loopback=fepayload`.

`tst-t1:loopback=payload` installs the local payload loopback (receive to transmit) similar to an `act-cdl:loopback=payload`.

The following steps occur:

1. Device under test (**DUT**) sends **T1** bit oriented code (**BOC**) to remote device.
2. Remote device receives **BOC** and programs hardware.
3. **DUT** attempts level 2 alignment.
4. If link aligns (level 2), test passes, else test fails.
5. **DUT** sends **BOC** to remote device to remove loopback.
6. remote device receives **BOC** and re-programs hardware.

 **Note:**

If the **DUT** boots in the middle of sequence, the remote device needs to have the link activated/de-activated and it will return to the original programming

**Typical use:** Used for a link in source timing to check continuity from the near end level 2 H/W to the level 1 interface at the far end.

**Testing Limits:** 1024 concurrent link tests per system.

- *LXVR Loopback Test Details*

**Loopback Test Type:** **LXVR** (EAGLE initiated Level 1 Internal card loopback)

**Link State:** Link is down.

**Equipment tested:** Local card.

**Purpose:** Test the near end card only.

**Description:** Valid for both `tst-slk` and `tst-t1`. This tests the near end card up through level 2.

**Typical use:** To validate the **Card** on the Eagle as good.

**Testing Limits:** 1024 concurrent link tests per system.

### Link Maintenance Enhancements Commands

The link maintenance enhancements feature utilizes the following commands:

- `act-cdl` — this command initiates a command driven loopback for testing a signaling link.
- `dact-cdl` — this command deactivates a previously initiated Command Driven Loopback if active. If not, it will attempt to clear both near-end and far-end latched loopback points.
- `rept-stat-cdl` — this command generates a report of the signaling links currently in command driven loopback (along with the amount of time the link has been in **CDL**). The following is an example of a possible output.

```
tekelecstp 96-04-16 16:02:05 EST EAGLE 35.0.05
SLK CDL CDL-TIME
```

```

1102,A1 LINE 00:04:01
1201,A PAYLOAD 01:04:11
1203,A LINE 00:22:21
1203,B LINE 20:04:01
1208,A LINE 01:05:22
1211,A PAYLOAD 00:14:01

```

- `tst-slk` — this command provides several methods for testing **SLKs**.
- `rept-stat-tstslk` — this command generates a report of the status of the **MTP** signaling links currently under test. The report includes the type of test and the elapsed time for the test. The following is an example of a possible output.

```

tekelecstp 96-04-16 16:02:05 EST EAGLE 35.0.0
 SLK LOOPBACK MAX-TIME TEST-TIME
 1102,A1 SLTC 01:00:00 00:04:01
 1201,A OAM 02:00:00 01:04:11
 1203,A LXVR 00:50:00 00:22:21
 1203,B LXVR 24:00:00 20:04:01
 1208,A PAYLOAD 01:10:00 01:05:22
 1211,A LINE 21:30:00 00:14:01
;

```

- `tst-e1` — this command initiates the testing of **E1** Ports. The loopback parameter on this command is used to select local transceiver (lxvr), line, and payload loopback tests. This command is rejected if a loopback test is not compatible with the port type. This command is only supported on **HCMIM** and **E5-E1T1** hardware. The following is an example of a possible output.

 **Note:**

Faults are not reported with this test. Refer to the `rept-stat-e1` command and output for port status results.

```

> tst-e1:elport=1:loc=1203:loopback=lxvr

 rlghncxa03w 05-01-07 16:19:08 EST EAGLE5 33.0.0
 Command Accepted: Test Port message is sent.
;
 rlghncxa03w 05-01-07 16:19:08 EST EAGLE5 33.0.0
 Command Completed.
;

> tst-e1:elport=1:loc=1203:action=stop

 rlghncxa03w 05-01-07 16:19:08 EST EAGLE5 33.0.0
 Command Accepted: Stop Port test message is sent.
;

 rlghncxa03w 05-01-07 16:19:08 EST EAGLE5 33.0.0

```

Command Completed.

;

- *tst-t1* — this command initiates the testing of **T1** Ports. The loopback parameter on this command is used to select local transceiver (lxvr), line, far end line (feline), payload, and fare end payload (fepayload) loopback tests. This command is rejected if a loopback test is not compatible with the port type. This command is only supported on **HCMIM** and **E5-E1T1** hardware.

The command for stopping the tests differ for feline and fepayload. In order to stop the loopback tests, for loopback=line, payload, and lxvr, the command syntax used is `tst-t1:loc=<card loc>;tlport=<tlport number>;action=stop`. For the feline and fepayload loopback types, the command syntax used is `tst-t1:loc=<card loc>;tlport=<tlport number>;action=stop;loopback=<feline or fepayload>`. The following is an example of a possible output.

 **Note:**

Faults are not reported with this test. Refer to the `rept-stat-t1` command and output for port status results.

```
> tst-t1:loc=1101:tlport=2:action=start:loopback=payload
```

Command Accepted - Processing

```
e5oam 02-02-08 23:58:38 MST UNKNOWN ???.?-61.11.0
tst-t1:loc=1101:tlport=2:action=start:loopback=payload
Command entered at terminal #6.
```

;

```
e5oam 02-02-08 23:58:38 MST UNKNOWN ???.?-61.11.0
Command Accepted: Test Port message is sent.
```

;

```
e5oam 02-02-08 23:58:38 MST UNKNOWN ???.?-61.11.0
Command Completed.
```

;

```
> tst-t1:loc=1101:tlport=2:action=stop
```

Command Accepted - Processing

```
e5oam 02-02-08 23:59:01 MST UNKNOWN ???.?-61.11.0
tst-t1:loc=1101:tlport=2:action=stop
Command entered at terminal #6.
```

;

```
e5oam 02-02-08 23:59:01 MST UNKNOWN ???.?-61.11.0
Command Accepted: Stop Test Port message is sent.
```

;

```
e5oam 02-02-08 23:59:01 MST UNKNOWN ???.?-61.11.0
Command Completed.
```

```
;
```

- `rept-stat-e1`— this command generates a report of the status of the E1 port and signaling link for cards with provisioned E1 ports. The following is an example of a possible output.

```
rept-stat-e1:loc=1203:e1port=1
rlghncxa03w 05-01-04 07:01:08 EST EAGLE5 33.0.0
LOC E1PORT PST SST AST
1203 1 IS-NR Avail PARENT
ALARM STATUS = No Alarms.
UNAVAIL REASON = --
SLK TS PST SST AST
A 1 IS-NR Avail ---
A1 2 IS-NR Avail ---
Command Completed.
```

```
;
```

- `rept-stat-t1`— this command generates a report of the status of the T1 port and signaling link for cards with provisioned T1 ports. The following is an example of a possible output while `loopback=line` is in progress.

```
> rept-stat-t1:loc=1204:t1port=1
```

```
Command Accepted - Processing
```

```
tekelecstp 04-01-19 07:26:03 EST UNKNOWN ???.?-63.47.1
rept-stat-t1:loc=1204:t1port=1
Command entered at terminal #5.
```

```
;
```

```
tekelecstp 04-01-19 07:26:03 EST UNKNOWN ???.?-63.47.1
LOC T1PORT PST SST AST
1204 1 OOS-MT-DSBLD LPBK LINE
ALARM STATUS = No Alarms.
UNAVAIL REASON = No errors, allow device
SLK TS PST SST AST
A 1 OOS-MT-DSBLD Manual -----
```

```
Command Completed.
```

```
;
```

[Table 3-14](#) lists how the AST field will display depending on the loopback type.

**Table 3-14 Loopback AST Field Display**

| Loopback Type            | AST Field Display |
|--------------------------|-------------------|
| Local transceiver (lxvr) | LXVR              |
| Line (line)              | LINE              |
| Far end line (feline)    | FE LINE           |

**Table 3-14 (Cont.) Loopback AST Field Display**

| Loopback Type               | AST Field Display |
|-----------------------------|-------------------|
| Payload (payload)           | PAYLOAD           |
| Far end payload (fepayload) | FE PAYLD          |

## 3.14 Power Down of In-Service System

### **warning:**

This procedure will isolate the system and put the network in a degraded mode. [My Oracle Support \(MOS\)](#) before any part of this procedure is performed.

### **Note:**

If the EAGLE loses power or both OAM cards are removed at the same time, then OAM may not retain the current date and time once the MASP cards are back in service. The user may need to manually update the system date and time using `set-date` & `set-time` commands.

To minimize the impact on the rest of the network during power up, proper network planning must be performed. This requires having the **MTP Restart Feature** configured on the system. This power down procedure does not require any special configuration on the system. This procedure should be performed in emergency situations or with prior planning assistance from [My Oracle Support \(MOS\)](#). Terminal access to the system is required to deactivate the links. If there is no terminal access to the system, proceed to [19](#).

1. If this is an emergency power down, proceed with [11](#) Otherwise continue with [2](#) .
2. Enter the following command to check the operational status of the database:

```
rept-stat-db
```

If necessary, refer to *Commands User's Guide* to interpret the output.

3. Enter the following command to backup the database on the fixed disk:

```
chg-db:action=backup:dest=fixed
```

This command takes a minimum of 2 minutes to execute. It may take longer depending on other system activity that is in progress when this command is entered.

4. Verify that the databases of both **MASPs** are coherent by entering the following command:

```
rept-stat-db
```

The following is an example of the output from a coherent database.  
> rept-stat-db

```

Command Accepted - Processing
 oflnmoxallw 00-10-08 15:56:40 CDT EAGLE 35.0.0
 rept-stat-db
 Command entered at terminal #4.
;
 oflnmoxallw 00-10-08 15:56:40 CDT EAGLE 35.0.0
 DATABASE STATUS: >> OK <<
 TDM 1114 (STDBY) TDM 1116 (ACTV)
 C LEVEL TIME LAST BACKUP C LEVEL TIME LAST
BACKUP

 - - - - -
 FD BKUP Y 342256 00-10-07 00:40:29 CDT Y 342256 00-10-07
00:40:29 CDT
 FD CRNT N 342374 Y 342375
 E5-MDAL 1117

```

If necessary, refer to *Commands User's Guide* to interpret the output.

5. Insert a pre-formatted (for system data) removable USB drive into the removable USB drive media slot. You can also use the USB storage media in the flush-mounted USB port of the MASP card for backups.

Refer to [Removable Drives](#). Continue with 6.

6. Enter the following command to create a backup of the database on the removable USB drive:

```
chg-db:action=backup:dest=remove
```

For the USB storage media in the flush-mounted USB port of the MASP card for backups, use the following command:

```
chg-db:action=backup:dest=usb
```

7. Verify that the databases on the removable USB drive (**RDBKUP**) and the current partition of the active **MASP (FDCRNT)** are coherent by entering the following command:

```
rept-stat-db
```

The following is an example of the output from a coherent database.

```

> rept-stat-db
Command Accepted - Processing
 oflnmoxallw 00-10-08 15:56:40 CDT EAGLE 35.0.0
 rept-stat-db
 Command entered at terminal #4.
;
 oflnmoxallw 00-10-08 15:56:40 CDT EAGLE 35.0.0
 DATABASE STATUS: >> OK <<
 TDM 1114 (STDBY) TDM 1116 (ACTV)
 C LEVEL TIME LAST BACKUP C LEVEL TIME LAST
BACKUP

 - - - - -
 FD BKUP Y 32256 00-10-07 00:40:29 CDT Y 32256 00-10-07
00:40:29 CDT

```



```
FD CRNT N 32374 Y 32375
 E5-MDAL 1117
 - -----
```

If necessary, refer to the *Commands User's Guide* to interpret the output.

8. Remove the removable USB drive from the removable USB drive media slot.

Refer to [Removable Drives](#).

9. Make an entry in the site maintenance log that a backup was performed.

10. Enter the following command to verify the status of the mate EAGLE:

```
rept-stat-trbl
```

If there is any trouble or abnormal condition, [My Oracle Support \(MOS\)](#).

11. Enter the following command to retrieve the linksets.

```
rtrv-ls
```

12. Enter the following command to retrieve the links.

```
rtrv-slk
```

13. Enter the following command to deactivate all E-links.

Use the outputs from [11](#) and [12](#).

```
dact-slk:loc=xxxx:port=y
```

where xxxx is the card location stenciled on the shelf of the system and y is the port number on the card specified in the loc parameter.

14. Enter the following command to deactivate all A-links.

Use the outputs from [11](#) and [12](#).

```
dact-slk:loc=xxxx:port=y
```

where xxxx is the card location stenciled on the shelf of the system and y is the port number on the card specified in the loc parameter.

15. Enter the following command to deactivate all B-links.

Use the outputs from [11](#) and [12](#).

```
dact-slk:loc=xxxx:port=y
```

where xxxx is the card location stenciled on the shelf of the system and y is the port number on the card specified in the loc parameter.

16. Enter the following command to deactivate all D-links.

Use the outputs from [11](#) and [12](#).

```
.dact-slk:loc=xxxx:port=y
```

where xxxx is the card location stenciled on the shelf of the system and y is the port number on the card specified in the loc parameter.

17. Enter the following command to deactivate all C-links.

Use the outputs from [11](#) and [12](#).

```
dact-slk:loc=xxxx:port=y
```

where xxxx is the card location stenciled on the shelf of the system and y is the port number on the card specified in the loc parameter.

18. Enter the following command to verify all links on the system are OOS-MT.

```
rept-stat-slk
```

Repeat 13 through 17 for any links not having the proper status.

19. Pull the fuses or open the breaker at the customer power distribution frame to turn off power to the system.

## 3.15 Power Up of the System

### warning:

If the reason for the EAGLE Power Off is unknown or if damage to the EAGLE is suspected, do not perform this procedure. contact the [My Oracle Support \(MOS\)](#).

1. Verify that there is no USB drive in the **E5-MDAL** card.  
If there is a USB drive in the **E5-MDAL**, replace the **E5-MDAL** card with a spare **E5-MDAL** card without a USB drive. If the spare **E5-MDAL** card has a USB drive installed, remove the **E5-MDAL** card. This power up will take place without a **E5-MDAL** card installed.
2. At the power distribution frame, insert fuses or close the breaker to restore power to the system.  
All frames with the EAGLE shelves must be powered up. Links that were deactivated during the power down are automatically activated during the power up.
3. Enter the following commands to monitor the system during the power-up:  

```
rept-stat-card
rept-stat-slk
rept-stat-trbl
```

Contact [My Oracle Support \(MOS\)](#) if there is any trouble or abnormal condition during system recovery.
4. Install **E5-MDAL** card and remove removable USB drive, if necessary.

# A

## Card Removal/Replacement Procedures

### A.1 Introduction

This appendix explains how to remove a card from the EAGLE. The procedures include the administrative commands required to take a card out of service and place it back into service.

In the event a numbered event message is encountered, refer to the appropriate procedure in *Unsolicited Alarm and Information Messages Reference*.

Additional information about each command can be found in *Commands User's Guide*.

#### **Caution:**

Always wear a wrist strap or other electrostatic protection when handling EAGLE cards.

#### **Caution:**

Always place removed cards into an electrostatic protection bag before sending to Oracle, or storing in inventory (unless the card is being stored in the optional spare card storage shelf).

#### **Note:**

For the complete list of cards supported by EAGLE Release 47.0, see *Hardware Reference Guide*.

### A.2 EAGLE Replacement Parts List

For a listing of field replaceable parts and cables used in the **EAGLE** and their part numbers, refer to the tables in [Part Numbers](#).

All parts must be replaced through the Return Material Authorization (**RMA**) process. Contact the [My Oracle Support \(MOS\)](#), before replacing any parts.

### A.3 E5-MASP Card Replacement

This procedure is to replace an **E5-MASP** card. Before the E5-MASP is replaced, it must be verified that it is the standby **MASP**.

The E5-MASP (made up of the E5-MCAP and E5-TDM cards) contains the removable USB drive, the fixed disk drive, the terminal processor for the 16 serial I/O ports, and an interface to the maintenance disk and alarm (**E5-MDAL**) card.

1. Before beginning this procedure, make sure there is a copy of the current release **GPLs** on a removable USB drive on-hand.
2. If the active E5-MASP card fails, the EAGLE automatically switches activity to the standby **MASP**.
3. Enter the following command to display the card status:

```
rept-stat-card
```

The following is an example of a possible output.

```

e5oam 08-12-01 15:38:32 EST EAGLE 40.1.0
CARD VERSION TYPE GPL PST
SST AST
 1108 ----- MCPM MCP OOS-MT-DSBLD
Manual -----
 1109 030-009-000 HIPR2 HIPR2 IS-NR
Active -----
 1110 030-009-000 HIPR2 HIPR2 IS-NR
Active -----
 1111 030-010-000 IPSM IPS IS-NR
Active -----
 1113 030-010-008 E5MCAP OAMHC IS-NR Standby -----
 1114 ----- E5TDM IS-NR
Active -----
 1115 030-010-008 E5MCAP OAMHC IS-NR
Active -----
 1116 ----- E5TDM IS-NR
Active -----
 1117 ----- E5MDAL OOS-MT
Isolated -----

```

Command Completed.

In this sample output, 1113/1114 are standby and 1115/1116 are active. Perform 5 only if the card to be replaced is not Standby.

4. From the output of the rept-stat-card command, executed in 3, determine the **MASP** activity.

Record which E5-MCAP is Active and Standby. Record the card locations of both sets of E5-MCAPs and E5-TDMs.

**Table A-1 Card Locations**

| Card           | Location |
|----------------|----------|
| Active E5MCAP  |          |
| Active E5TDM   |          |
| Standby E5MCAP |          |

**Table A-1 (Cont.) Card Locations**

| Card          | Location |
|---------------|----------|
| Standby E5TDM |          |

5. Verify the E5-MASP card to be replaced (failing or non-failing) is *Standby* before continuing.
  - a. If the E5-MASP card is failing it should already be *Standby*. Go to [7](#)
  - b. If the card is not *Standby* and needs replacement, enter the following command to verify the database:
 

```
rept-stat-db:display=all
```

 Verify all the cards in the system have the same database count. If the counts do not match, contact [My Oracle Support \(MOS\)](#).
  - c. Enter the following command to force the active E5-MASP card to become *Standby*:
 

```
init-card:loc=x
```

 where *x* is the card location (1113 or 1115) from [3](#).
6. If [5](#) was performed, execute the `rept-stat-card` command and verify if the card to be replaced is part of the *Standby MASP*.
7. If a failing E5-TDM card is to be replaced, perform a database backup before replacing the failed card.

Insert the removable USB drive with the current release **GPLs** into the Active E5-MASP removable USB port. Using [Daily Procedures](#), create a backup of the database on the Active removable USB drive. Then go to [9](#).

 **warning:**

Do not proceed to [9](#) if the backup fails. Contact [My Oracle Support \(MOS\)](#).

8. If a non-failing E5-TDM card is to be replaced, insert the removable USB drive containing the copy of the current release **GPLs** into the Active E5-MASP.
9. Enter the following command to verify that the security log on the standby **MASP** contains no entries that must be copied to the **FTA** area of the fixed disk:

```
rept-stat-seculog
```

The following is an example of a possible output.

```
RLGHNCXA03W 96-10-04 15:59:06 EDT EAGLE 34.0.0
 -- SINCE LAST UPLOAD -- OLDEST NEWEST LAST
LOC ROLE ENTRIES %FULL OFLO FAIL RECORD RECORD UPLOAD
1114 Active 8312 84 No No 95-08-12 96-01-04 96-12-16
 11:23:56 15:59:06 14:02:22
1116 Standby 693 7 No No 95-09-12 95-09-30 95-09-30
 11:24:12 14:00:06 14:02:13
```

- If the number shown in the **ENTRIES** field for the standby **MASP** (shown with the entry *Standby* in the **ROLE** field) is 0, go to [12](#).

- If the number shown in the **ENTRIES** field for the standby **MASP** is greater than 0, these entries must be copied to the **FTA** area of the fixed disk.

To copy these entries, go to the next step.

10. Copy the security log entries on the standby **MASP** to the **FTA** area on the fixed disk using the following command:

```
copy-secu log:slog=stb:dloc=act
```

The following is a possible output of the message that should appear (the `copy-secu log:slog=stb` command was used).

```
RLGHNCXA03W 96-10-04 15:59:06 EDT EAGLE 34.0.0
Security log on E5TDM 1116 copied to file 961004s.log on E5TDM 1114
```

11. Remove the card from service by entering the following command:

```
rmv-card:loc=xxxx
```

where `xxxx` is the card location.


12. Replace the Standby E5-MASP. Refer to [Figure A-3](#) for description of the E5-MASP LEDs.

- a. On the standby E5-MASP card determined in [6](#), slide the MASP H/S switch (SW3) up to the UNLOCKED position (see [Figure A-1](#)).

**Caution:**

When the Ejector switch goes from locked to unlocked and the E5-APP-B card is in service, the card will halt.

**Figure A-1 E5-MASP Card Inject/Eject Hardware Switch, UNLOCKED**



- b. WAIT for the MASP H/S LED to go from blinking blue to a steady blue.
- c. Grasp the upper and lower card Inject/Eject (I/E) lever release interlock, located just underneath the I/E lever, and press it to meet the I/E lever. This is the mechanical interlock for the card.
- d. While holding the I/E interlock and lever, pull the levers away from the shelf until they are parallel to the floor.
- e. Remove the standby E5-MASP card. Gently pull the card towards you until the card clears the shelf.

 **Note:**

**UAMs** are generated during this step. An audible alarm is generated.

- f. Place the card you have removed in an electrostatic discharge (ESD) protective container, or place the card in the spare card storage shelf.
- g. Be sure that the replacement card has the same Oracle part number and revision number as the card you have just removed.
- h. Open the ejector levers on the replacement card. Insert the spare E5-MASP card. Carefully align the card's edges with the top and bottom card guides. Then push the card along the length of the card guides until the rear connectors on the card engage the mating connectors on the target shelf backplane.

 **Note:**


**UAMs** are generated during this step. An audible alarm is generated. Wait for the E5-MASP card to come up to standby mode.

- i. Push in the top and bottom inject/eject clamps.  
This locks the card in place and ensures a strong connection with the pins on the target shelf backplane.
- j. Slide the MASP H/S switch (SW3) down to the LOCKED position (see [Figure A-2](#)).

 **Note:**

When the Ejector switch goes from UNLOCKED to LOCKED, the E5-APP-B Eject Status LED blinks red as the E5-MASP card goes online.

**Figure A-2 E5-MASP Card Inject/Eject Hardware Switch, LOCKED**



- k. WAIT for the MASP H/S LED to go from blinking blue to off.
13. Insert the removable USB drive containing the appropriate GPLs from 1 into the newly installed E5-MASP. (Refer to [Removable USB Drive](#).)
14. Enter the following command to change the state of the appropriate card to the out of service - maintenance disabled state:

```
inh-card:loc=xxxx:force=yes
```

where xxxx is the card location stenciled on the shelf of the EAGLE. Following is an example of a possible output:

```
RLGHNCXA03W 00-06-05 11:11:28 EDT EAGLE 34.0.0
Card has been inhibited.
```

15. Enter the following command to load and activate the approved **GPL** onto the inhibited card:

```
flash-card:code=appr:loc=xxxx:force=yes
```

where xxxx is the card location used in the previous step. The optional `force=yes` is used to force the command to work on an IS-NR card.

16. Enter the following command to put the card that was inhibited in 14 back into service:

```
alw-card:loc=xxxx
```

where xxxx is the card location used in 14. Following is an example of a possible output:

```
RLGHNCXA03W 00-06-05 11:11:28 EDT EAGLE 34.0.0
Card has been allowed.
```





 **Note:**

The system requires approximately two minutes after [16](#) to acquire duplex mode. As a result, the system will reject the `chg-db:action=repair` until duplex operation fully returns.

The following is an example of a possible output.

```
RLGHNCXA03W 03-08-27 03:46:49 EST EAGLE 34.0.0
chg-db:action=repair
Command entered at terminal #10.
;
RLGHNCXA03W 03-08-27 03:46:50 EST EAGLE 34.0.0
REPAIR: MASP A - Repair starts on standby MASP.
;
```

 **Note:**

Observe that the command execution time may require approximately 20 to 45 minutes.

```
RLGHNCXA03W 03-08-27 04:15:22 EST EAGLE 34.0.0
REPAIR: MASP A - Repair from fixed disk complete.
;
```

Wait for the 'repair complete' message to display and for the to **MASP** return to in-service status. When the 'repair complete' message has displayed, proceed to [20](#)

 **Note:**

Perform this step only if you are coming from [18](#).

20. Enter the following command to show the version numbers of the **GPLs** stored on each fixed disk (**E5-TDM**).

```
rtrv-gpl
```

The following is an example of a possible output.

```
tekelecstp 18-01-18 21:23:11 EST EAGLE 46.5.1.5.0-73.10.0
rtrv-gpl
Command entered at terminal #18.
;

Command Accepted - Processing
tekelecstp 18-01-18 21:23:11 EST EAGLE 46.5.1.5.0-73.10.0
GPL Auditing ON
```

| GPL     | CARD | RELEASE     | APPROVED    | TRIAL | REMOVE      |
|---------|------|-------------|-------------|-------|-------------|
| TRIAL   |      |             |             |       |             |
| OAMHC   | 1114 | 143-010-000 | 143-010-000 | ALM   | -----       |
| OAMHC   | 1116 | 143-010-000 | 143-010-000 | ALM   | -----       |
| OAMHC   | 1115 | -----       | -----       |       | -----       |
| OAMHC69 | 1114 | 143-010-000 | 143-010-000 | ALM   | -----       |
| OAMHC69 | 1116 | 143-010-000 | 143-010-000 | ALM   | -----       |
| OAMHC69 | 1115 | -----       | -----       |       | -----       |
| IPSG32  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSG32  | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSG32  | 1115 | -----       | -----       |       | -----       |
| BLMCAP  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLMCAP  | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLMCAP  | 1115 | -----       | -----       |       | -----       |
| HIPR2   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| HIPR2   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| HIPR2   | 1115 | -----       | -----       |       | -----       |
| SFAPP   | 1114 | 143-010-000 | 143-010-000 | ALM   | 143-010-000 |
| SFAPP   | 1116 | 143-010-000 | 143-010-000 | ALM   | 143-010-000 |
| SFAPP   | 1115 | -----       | -----       |       | -----       |
| SS7HC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SS7HC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SS7HC   | 1115 | -----       | -----       |       | -----       |
| SCCPHC  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SCCPHC  | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SCCPHC  | 1115 | -----       | -----       |       | -----       |
| ERTHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ERTHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ERTHC   | 1115 | -----       | -----       |       | -----       |
| IPSHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSHC   | 1115 | -----       | -----       |       | -----       |
| ATMHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ATMHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| ATMHC   | 1115 | -----       | -----       |       | -----       |
| IPSG    | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSG    | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| IPSG    | 1115 | -----       | -----       |       | -----       |
| PKTGHC  | 1114 | 143-010-000 | 143-010-000 |       | -----       |
| PKTGHC  | 1116 | 143-010-000 | 143-010-000 |       | -----       |
| PKTGHC  | 1115 | -----       | -----       |       | -----       |
| BLIXP   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLIXP   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| BLIXP   | 1115 | -----       | -----       |       | -----       |
| MCPHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| MCPHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| MCPHC   | 1115 | -----       | -----       |       | -----       |
| SIPHC   | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SIPHC   | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| SIPHC   | 1115 | -----       | -----       |       | -----       |
| DEIRHC  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| DEIRHC  | 1116 | 143-010-000 | 143-010-000 |       | 143-010-000 |
| DEIRHC  | 1115 | -----       | -----       |       | -----       |
| ENUMHC  | 1114 | 143-010-000 | 143-010-000 |       | 143-010-000 |

|         |      |             |                 |             |
|---------|------|-------------|-----------------|-------------|
| ENUMHC  | 1116 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| ENUMHC  | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| PKTG64  | 1114 | 143-010-000 | 143-010-000     | -----       |
| -----   |      |             |                 |             |
| PKTG64  | 1116 | 143-010-000 | 143-010-000     | -----       |
| -----   |      |             |                 |             |
| PKTG64  | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| BLDC64  | 1114 | 143-010-000 | -----           | 143-010-000 |
| -----   |      |             |                 |             |
| BLDC64  | 1116 | 143-010-000 | 000-000-000 ALM | 143-010-000 |
| -----   |      |             |                 |             |
| BLDC64  | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| SCCP64  | 1114 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| SCCP64  | 1116 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| SCCP64  | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| BLSLC32 | 1114 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| BLSLC32 | 1116 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| BLSLC32 | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| BLSLC64 | 1114 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| BLSLC64 | 1116 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| BLSLC64 | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| SIP64   | 1114 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| SIP64   | 1116 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| SIP64   | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| DEIR64  | 1114 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| DEIR64  | 1116 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| DEIR64  | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| ENUM64  | 1114 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| ENUM64  | 1116 | 143-010-000 | 143-010-000     | 143-010-000 |
| -----   |      |             |                 |             |
| ENUM64  | 1115 | -----       | -----           | -----       |
| -----   |      |             |                 |             |
| BLDC32  | 1114 | 143-010-000 | -----           | 143-010-000 |
| -----   |      |             |                 |             |
| BLDC32  | 1116 | 143-010-000 | -----           | 143-010-000 |

```

BLDC32 1115 -----
MCPHC69 1114 143-010-000 143-010-000 143-010-000 -----
MCPHC69 1116 143-010-000 143-010-000 143-010-000 -----
MCPHC69 1115 -----
IPSHC69 1114 143-010-000 143-010-000 143-010-000 -----
IPSHC69 1116 143-010-000 143-010-000 143-010-000 -----
IPSHC69 1115 -----
BLSL932 1114 143-010-000 143-010-000 143-010-000 -----
BLSL932 1116 143-010-000 143-010-000 143-010-000 -----
BLSL932 1115 -----

```

```

;
Command Executed

```

21. Examine the output of the previous step.
  - a. If any version is different continue with 22.
  - b. If there are no differences, go to 27.
22. Enter the following command to load the GPLs from the removable USB drive inserted in 13:

```
copy-gpl:sloc=xxxx:dloc=yyyy
```

where xxxx is the card location used in 14 and yyyy is the mated E5-TDM location.

The following is an example of a possible output.

```

rlghncxa03w 09-01-07 00:57:31 EST EAGLE 40.1.0
COPY GPL: MASP B - COPY STARTS ON REMOVABLE DRIVE
;

rlghncxa03w 09-01-07 01:01:27 EST EAGLE 40.1.0
COPY GPL: MASP B - COPY TO STANDBY MASP COMPLETE

```

When the command has completed, go to 27

23. Enter the following command to verify whether measurement collection is on or off:

```
rtrv-meas-sched
```

The following is an example of a possible output. The **COLLECT** field shows whether measurement collection is on or off. In this example, measurement collection is on.

```

RLGHNCXA03W 95-04-03 12:22:55 EST EAGLE 34.0.0
COLLECT = on

SYSTOT-STP = off
SYSTOT-TT = off
COMP-LNKSET = off
COMP-LINK = on
MTCD-STP = on
MTCD-LINK = on

```

- If measurement collection is on, continue with 24.

- If measurement collection is off, proceed to 25.
24. Enter the following command to inhibit all measurements:

```
chg-meas:collect=off
```

 **Caution:**

Measurements must be inhibited or the `copy-disk` command cannot be executed. The `chg-meas:collect=on` command should not be executed while the `copy-disk` command is in progress. When measurements are inhibited, measurement collection is stopped. For the entire period of time when measurements are inhibited, those measurements will be lost. If possible do not inhibit measurements at midnight since doing so can result in the loss of measurements for an entire day.

The following is an example of a possible output of the message that should appear.

```
RLGHNCXA03W 94-02-07 16:12:50 EST EAGLE 34.0.0
CHG-MEAS: MASP A - COMPLTD
```

25. Enter the following `copy-disk` command along with the card location of the standby **E5-TDM** (shown by the indicator **STDBY** in the command output in 17) that the data is being copied to.

```
copy-disk:dloc=xxxx:format=yes
```

Where `xxxx` is the card location of the standby **E5-TDM**.

This command can take from 33 minutes to 1 hour 46 minutes to execute. It can take even longer depending on other system activity in progress when this command is entered.

The following is an example of a possible output of the message that should appear when the command has executed and completed. For this example, the `copy-disk:dloc=1116` command was entered.

```
Copy-disk (fixed): from active (1114) to standby (1116) started.
Extended processing required, please wait.
Copy-disk (fixed): from active (1114) to standby (1116) completed.
Measurements collection may be turned on now if desired.
```

The standby **MASP** is rebooted to load the data when the command completes successfully.

 **Note:**

While this command is executing, commands that affect the database configuration cannot be executed. Any attempt to execute such a command will be rejected.

26. If measurement collection was turned off in 24, enter the following command to turn on the measurements:

```
chg-meas:collect=on
```

The following is an example of a possible output of the message that should appear.

```
RLGHNCXA03W 94-02-07 16:12:50 EST EAGLE 34.0.0
CHG-MEAS: MASP A - COMPLTD
```

27. Enter the following command to verify that the database counts of both **MASPs**.

```
rept-stat-db:display=all
```


The following is an example of the possible output for a good database.

```
rept-stat-db
Command Accepted - Processing
 rlghncxa03w 13-04-19 12:51:29 EST EAGLE5 45.0.0-64.62.0
 rept-stat-db
 Command entered at terminal #4.
;
 rlghncxa03w 13-04-19 12:51:29 EST EAGLE5 45.0.0-64.62.0
 DATABASE STATUS: >> OK <<
 E5TDM 1114 (STDBY) E5TDM 1116 (ACTV)
 C LEVEL TIME LAST BACKUP C LEVEL TIME LAST
BACKUP

 FD BKUP Y 175 13-04-16 16:09:11 MST Y 175 13-04-16
16:09:11 MST
 FD CRNT Y 218 Y 218
 MCAP 1113 MCAP 1115
 - -----
 RD BKUP Y 1 - - Y 1 - -
 USB BKP - - - - - - - -
;

```

Figure A-3 E5-MASP LEDs



E5-MASP LEDs

| LED                       | Status                    | Description                                                                                                                    |
|---------------------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| APPL PROC                 | Off                       | No power                                                                                                                       |
|                           | Red                       | Card is booting                                                                                                                |
|                           | Amber                     | Card is loading                                                                                                                |
|                           | Green                     | Card is running                                                                                                                |
| IMT A                     | Red                       | Not connected to bus                                                                                                           |
|                           | Amber                     | Testing not complete                                                                                                           |
|                           | Green                     | Active and connected to the bus                                                                                                |
| IMT B                     | Red                       | Not connected to bus                                                                                                           |
|                           | Amber                     | Testing not complete                                                                                                           |
|                           | Green                     | Active and connected to the bus                                                                                                |
| ACT A                     | Off                       | Card not functioning                                                                                                           |
|                           | Red                       | No signal detected                                                                                                             |
|                           | Green                     | Signal detected                                                                                                                |
| ACTIVE/<br>STANDBY        | Green                     | This card is the Active MASP                                                                                                   |
|                           | * Blinking<br>Green/Amber | This card is the Standby MASP                                                                                                  |
| SATA MEDIA<br>STATUS      | Off                       | Media is LOCKED and operating                                                                                                  |
|                           | Blinking Blue             | WAIT<br>Media is UNLOCKED and<br>in process of shutting down<br>OR<br>Media is LOCKED and<br>in process of coming online       |
|                           | Steady Blue               | Media is UNLOCKED, turned off,<br>and ready for removal                                                                        |
| REMOVABLE<br>MEDIA STATUS | Off                       | Media is LOCKED and operating                                                                                                  |
|                           | Blinking Blue             | WAIT<br>Media is UNLOCKED and<br>in process of shutting down<br>OR<br>Media is LOCKED and<br>in process of coming online       |
|                           | Steady Blue               | Media is UNLOCKED, turned off,<br>and ready for removal                                                                        |
| MASP H/S                  | Off                       | E5-MASP is LOCKED and operating                                                                                                |
|                           | Blinking Blue             | WAIT -<br>E5-MASP is UNLOCKED and<br>in process of shutting down<br>OR<br>E5-MASP is LOCKED and<br>in process of coming online |
|                           | Steady Blue               | E5-MASP is UNLOCKED, turned off,<br>and ready for removal                                                                      |

\* The LED blinks Green/Amber at a rate of 3 Green to 1 Amber.

## A.4 E5-MDAL Card Replacement

### Description

The E5-MDAL (Figure A-4) provides for external alarm indicators, such as bells, horns and lamp indicators.



- Remove the card from service as described in the section titled, [Replacing a Card in the EAGLE](#).

 **Note:**

Removing the **E5-MDAL** creates a critical alarm at the Remote Maintenance Center (**RMC**) as well as the local office.

Figure A-4 E5-MDAL LEDs



E5-MDAL LEDs

| LED      | Status | Description                               |
|----------|--------|-------------------------------------------|
| CRITICAL | Red    | A critical system alarm has been detected |
|          | Green  | No Alarm                                  |
| MAJOR    | Red    | A major system alarm has been detected    |
|          | Green  | No Alarm                                  |
| MINOR    | Amber  | A minor system alarm has been detected    |
|          | Green  | No Alarm                                  |
| MASP A   | Green  | This is the master MASP                   |
|          | Off    | This is the standby MASP                  |
| MASP B   | Green  | This is the master MASP                   |
|          | Off    | This is the standby MASP                  |

## A.5 HIPR2 Card Replacement

Use this procedure to remove a High-Speed Inter-processor Message Transport Packet Router 2 (HIPR2) card.

Each shelf contains two **HIPR2** cards, one for each IMT bus, that provide continuity of the IMT bus signals even with failed or missing circuit modules. LEDs on the **HIPR2** ([Figure A-5](#)) indicate connectivity to the IMT

1. Enter the following command to verify the status of the IMT buses.

```
rept-stat-imt
```

### warning:

Be sure to inhibit the correct IMT bus. If you inhibit the wrong IMT bus and then remove the **HIPR2**, total nodal isolation will occur. Wait until the IMT has returned to **IS-NR** before replacing the other **HIPR2**.

The following is an example of the possible output.

```
RLGHNCXA03W 98-09-27 16:50:24 EST EAGLE 34.0.0
IMT PST SST AST
 A IS-NR Active -----
ALARM STATUS = No alarms
IMT PST SST AST
 B IS-ANR Fault -----
ALARM STATUS = ** 0108 Major IMT Failure Detected
Command Completed.
```

2. Enter the following command to inhibit the IMT bus associated with the HIPR2 being removed (top HIPR2 accesses bus A, bottom HIPR2 accesses bus B).

```
rmv-imt:bus=x
```

where *x* is the IMT bus to be inhibited.

3. Remove the HIPR2, per the card replacement procedure described in the section titled [Replacing a Card in the EAGLE](#).

Place the new HIPR2 into its place. Be sure the revision numbers are compatible (if in doubt, contact [My Oracle Support \(MOS\)](#)).

4. Enter the following command to restore the IMT bus.

```
alw-imt:bus=x
```

where *x* is the IMT bus inhibited.

### Note:

If **UAM 0002** is output, the newly installed HIPR2 card needs to be flashed.

- Enter the following command to determine if the newly replaced card's memory needs to be flashed:

```
rept-stat-gpl:gpl=xxxxxx
```

where xxxxxx is hipr2.

Following is an example of a HIPR2 output:

```
tekelecstp 09-07-09 16:53:23 EST EAGLE5 41.1
```

Output:

| GPL         | CARD | RUNNING     | APPROVED    | TRIAL |
|-------------|------|-------------|-------------|-------|
| HIPR2       | 1109 | 128-021-000 | 128-021-000 |       |
| 128-021-000 |      |             |             |       |
| HIPR2       | 1110 | 128-021-000 | 128-021-000 |       |
| 128-021-000 |      |             |             |       |

```
Command Completed.
```

```
;
```

 **Note:**

Mismatched GPLs should occur only during upgrades or running a trial GPL.

- Examine the output from 5.
  - If the **GPLs** match, continue with 15.
  - If there is a **GPL** mismatch, continue with 7.
- Enter the following command to verify **GPL Auditing** is **ON**.

```
chg-gpl:audit=on
```

- Enter the following command to load the **GPL** onto the HIPR2 card.

```
init-flash:code=appr:loc=xxxx
```

where xxxx is the card location newly replaced card.

Following is an example of a HIPR2 output using card location 1309:

```
RLGHNCXA03W 00-06-05 11:11:28 EDT EAGLE 34.0.0
FLASH Memory Downloading for card 1309 Started.
```

```
;
```

```
RLGHNCXA03W 00-06-05 11:11:28 EDT EAGLE 34.0.0
HIPR2 Downloading for card 1309 Complete.
```

```
;
```

```
RLGHNCXA03W 00-06-05 11:11:28 EDT EAGLE 34.0.0
Command Completed.
```

- Enter either of the following commands to initialize the HIPR2.

 **Caution:**

These commands boot the HIPR2 processor and bring down the respective IMT bus temporarily (approximately 10 seconds) until the HIPR2 card comes back into service.

Enter either

```
init-mux:bus=[a/b]
```

or

```
init-mux:loc=xxxx
```

where xxxx is the card location used in 8.

 **Note:**

Allow the card to run for 5 minutes before continuing.

- Enter the following command to activate the **GPL** loaded onto the HIPR2 card in 8:

```
act-flash:loc=xxxx
```

where xxxx is the card location used in 8.

Following is an example of the output using card location 1309:

```

RLGHNCXA03W 00-06-05 11:11:28 EDT EAGLE 34.0.0
FLASH Memory Activation for card 1309 Completed.
;
RLGHNCXA03W 00-06-05 11:11:28 EDT EAGLE 34.0.0
Command Completed.
```

- Enter the following command to verify the approved **GPLs** match the running **GPLs**:  
rept-stat-gpl:gpl=hipr2
- If the **GPLs** match, continue with 15.  
If the **GPLs** do not match, continue with 13.
- Enter the following command determine which cards are in alarm condition (indicated by the acronym **ALM** in the `rept-stat-gpl` display):  
rept-stat-gpl
- Note which cards are in an alarm condition and, if in doubt, [My Oracle Support \(MOS\)](#).
- Enter the following command to verify that the HIPR2 card is in service and the IMT bus has been restored.

```
rept-stat-imt
```

```


RLGHNCXA03W 98-09-27 16:50:24 EST EAGLE 34.0.0
IMT PST SST AST
A IS-NR Active -----
```

```

ALARM STATUS = No alarms
IMT PST SST AST
B IS-NR Active -----
ALARM STATUS = No alarms
Command Completed.

```

Figure A-5 HIPR2 LEDs



| HIPR2 State                                  | LED      |       |        |       |
|----------------------------------------------|----------|-------|--------|-------|
|                                              | RATE     | ALIGN | SHELF  | PROC  |
| No power                                     | Off      | Off   | Off    | Off   |
| Power on (cold start)                        | Off      | Off   | Off    | RED   |
| Reset (warm start)                           | Off      | Off   | AMBER  | RED   |
| Programming (cold start)                     | Off      | Off   | Off    | AMBER |
| Programming (warm start)                     | Off      | Off   | AMBER  | AMBER |
| Programming Complete                         | ---      | AMBER | AMBER  | GREEN |
| Shelf Address Capture:                       |          |       |        |       |
| Timer Started                                | ---      | AMBER | AMBER  | GREEN |
| Successful                                   | ---      | GREEN | AMBER  | GREEN |
| Unsuccessful                                 | ---      | RED   | AMBER  | GREEN |
| Code Running                                 | ---      | GREEN | Note 2 | GREEN |
| IMT is operational at:                       |          |       |        |       |
| low-rate (1 Gbps)                            | GREEN    |       |        |       |
| high-rate (2.5 Gbps)                         | GREEN    |       |        |       |
|                                              | Blinking |       |        |       |
| IMT is rate negotiating or in proving period | AMBER    |       |        |       |
| IMT is not operational                       | RED      |       |        |       |

Notes:

- ALIGN and SHELF LEDs are not accessible to software until the FPGA has been programmed. So for the same point in the HIPR bootstrap sequence, the state of these two LEDs can be different depending on whether a warm or cold start is in progress.
- State depends on the address received from OAM and written to Assigned Shelf Address Register and compared to the value previously read from the Assigned Shelf Address Register.
  - RED - Does Not Match
  - GREEN - Matches

## A.6 Determine Card Changeout Time

### Description

This procedure assists the customer in deciding if the card should be changed immediately or during the Maintenance Window.

1. Replace the card immediately if *any* of the following conditions exist:
  - If there is only one link on the card
  - If there is no other in-service link on this card
  - If there is no other in-service link on this card
  - If any destination is prohibited by the current failure.
2. Wait until the maintenance window to replace the card if *all* of the following conditions exist:
  - If the faulty link is not the only in-service link on the card
  - If deactivating the link will prohibit a destination
  - If no destination is prohibited by the current failure.

## A.7 E5-ATM-B Card Replacement

This E5-ATM-B Module provides access to remote SS7, IP and other network elements, such as a Signaling Control Point (SCP). This card is equipped with an industry-standard ATM, or DS0 interface.

1. Enter the following command to determine which links are serviced by this card:

```
rept-stat-card:loc=xxxx
```

Where xxxx is the card location. The following is an example of the possible output.

```
RLGHNCXA03W 98-09-27 16:43:42 EST EAGLE 34.0.0
CARD VERSION TYPE APPL PST SST AST
1201 021-002-000 LIMDS0 CCS7ITU IS-NR Active -----
ALARM STATUS = * 0022 Clock B for card failed.
IMT VERSION = 021-001-000
PROM VERSION = 021-001-000
IMT BUS A = Conn
IMT BUS B = Fault
SLK A PST = IS-NR LS=lsnssp2 CLLI=-----
SLK B PST = IS-NR LS=lsnstpi CLLI=-----
SCCP SERVICE CARD = 1212
Command Completed.
```

2. Refer to procedure to determine when to change the card.

### Note:

The `inh-slk` command will be rejected if inhibiting the link would cause a **DPC** to become unavailable.

3. Enter the following command to inhibit the links on both ports of this card (a and b).

```
inh-slk:loc=xxxx:port=y
```

Where xxxx location of the card from 1 and y is the port.

4. Enter the following command to change the status of the link to out of service - maintenance disabled (`oos-mt-dsblld`).

```
dact-slk:loc=xxxx:port=y
```

Where `xxxx` location used in 3 and `y` are the ports used in 3.

5. Enter the following command to ensure the signaling link status is `oos-mt-dsblld` (out of service - maintenance disabled).

```
rept-stat-slk
```

The following is an example of the possible output.

```
RLGHNCXA03W 98-09-27 17:00:36 EST EAGLE 34.0.0
rept-stat-slk
SLK LSN CLLI PST SST AST
1201,A lsnsspn2 ----- OOS-MT-DSBLD Unava ----
1201,B lsnstpi ----- OOS-MT-DSBLD Unava ----
1202,A lsnstpn ----- IS-NR Avail ----
1202,B lsnstpi ----- IS-NR Avail ----
1203,A lsnstpa ----- IS-NR Avail ----
1203,B lsnscpa ----- IS-NR Avail ----
1205,A lsnscpi ----- IS-NR Avail ----
1205,B lsnsspi1 ----- IS-NR Avail ----
1207,A lsnstpa ----- IS-NR Avail ----
1207,B lsnspa1 ----- IS-NR Avail ----
1211,A lsnstpn ----- IS-NR Avail ----
1211,B lsnsspn1 ----- IS-NR Avail ----
Command Completed.
```

6. Enter the following command to inhibit the card and disconnect it from the IMT bus.

```
rmv-card:loc=xxxx
```

Where `xxxx` location used in 3 and 4.

7. Remove the card, per the card replacement procedure described in the section titled [Replacing a Card in the EAGLE](#)..

Place the new card into its place. Be sure the revision numbers are compatible (if in doubt, contact the [My Oracle Support \(MOS\)](#)).

8. Enter the following command to download generic program loads and database information:

```
alw-card:loc=xxxx
```

Where `xxxx` location used in 6.

9. Enter the following command to determine which links are serviced by this card:

```
rept-stat-card:loc=xxxx
```

Where `xxxx` is the location of the replaced card.

 **Note:**

The signaling link alarms will be present until the links are restored in 11.

10. Examine the output from 9.



Refer to [Corrective Maintenance](#) to clear any **GPL** related alarms on the newly replaced card before continuing.

11. Enter the following command to return the links to service.

Make sure this is done on all links:

```
act-slk:loc=xxxx:port=y
```

Where xxxx location used in 3 and 4 and y are the ports used in 3 and 4.

12. Enter the following command to change the link status to **IS-NR**.

Make sure this is done on both ports, a and b.

```
unhb-slk:loc=xxxx:port=y
```

Where xxxx location used in 3 and 4 and y are the ports used in 3 and 4.

13. Enter the following command to verify the status of the card and its associated links:

```
rept-stat-card:loc=xxxx
```

Where xxxx is the card location. The following is an example of the possible output.

```
RLGHNCXA03W 98-09-27 16:43:42 EST EAGLE 34.0.0
CARD VERSION TYPE APPL PST SST AST
1201 024-002-000 LIMDS0
SS7ANSI
 IS-NR Active -----
ALARM STATUS = No Alarms.
IMT VERSION = 024-001-000
PROM VERSION = 024-001-000
IMT BUS A = Conn
IMT BUS B = Conn
SLK A PST = IS-NR LS=lsnssp2 CLLI=-----
SLK B PST = IS-NR LS=lsnstpi CLLI=-----
SCCP SERVICE CARD = 1212
Command Completed.
```

14. Enter the following command to verify the links are properly aligned and are returned to full service:


```
rept-stat-slk
```

The following is an example of the possible output.

```
RLGHNCXA03W 98-09-27 17:00:36 EST EAGLE 34.0.0
rept-stat-slk
SLK LSN CLLI PST SST AST
1201,A lsnssp2 ----- IS-NR Avail ----
1201,B lsnstpi ----- IS-NR Avail ----
1202,A lsnstpn ----- IS-NR Avail ----
1202,B lsnstpi ----- IS-NR Avail ----
1203,A lsnstpa ----- IS-NR Avail ----
1203,B lsnscpa ----- IS-NR Avail ----
1205,A lsnscpi ----- IS-NR Avail ----
1205,B lsnspil ----- IS-NR Avail ----
1207,A lsnstpa ----- IS-NR Avail ----
1207,B lsnspa1 ----- IS-NR Avail ----
1211,A lsnstpn ----- IS-NR Avail ----
```

```
1211,B lsnssp1 ----- IS-NR Avail -----
Command Completed.
```

**Figure A-6 E5-ATM-B LEDs**



| LED          | Color          | Description                                                |
|--------------|----------------|------------------------------------------------------------|
| APPL PROC    | OFF            | No power                                                   |
|              | RED            | Transitioning or Error                                     |
|              | AMBER          | Not Active                                                 |
|              | GREEN          | Card is up and application is running                      |
| IMT (A/B)    | RED            | Card is not attached to IMT bus                            |
|              | GREEN          | Card is attached to IMT bus                                |
| PORT (0/1/2) | RED            | Port not provisioned                                       |
|              | RED blinking   | Loss of signal                                             |
|              | AMBER          | Remote alarm condition or loss of cell delineation         |
|              | AMBER blinking | Loss of Frame Synchronization                              |
|              | GREEN          | E1/T1 framing is established                               |
| LINK (0/1/2) | RED            | Signaling Link is not provisioned                          |
|              | RED blinking   | Signaling Link Out Of Service                              |
|              | AMBER          | Signaling Link is ready to start alignment                 |
|              | AMBER blinking | Signaling Link alignment in progress                       |
|              | GREEN blinking | Signaling Link alignment successful, awaiting far end INSV |
|              | GREEN          | Signaling Link is aligned                                  |
| PORT (3)     | OFF            | Not used                                                   |
| LINK (3)     | OFF            | Not used                                                   |

## A.8 SS7 and IP7 Card Replacement

This **Link Interface Module (LIM)** provides access to remote **SS7**, **IP** and other network elements, such as a Signaling Control Point (**SCP**). This card is equipped with an industry-standard **ATM**, or **DS0** interface.

The types of Link Interface Modules (**LIM**)s currently available are:


- LIM
  - The E5-E1/T1-B
  - SLIC
1. Enter the following command to determine which links are serviced by this card:

```
rept-stat-card:loc=xxxx
```

Where xxxx is the card location. The following is an example of the possible output.

```
RLGHNCXA03W 98-09-27 16:43:42 EST EAGLE 34.0.0
CARD VERSION TYPE APPL PST SST AST
1201 021-002-000 LIMDS0 CCS7ITU IS-NR Active -----
ALARM STATUS = * 0022 Clock B for card failed.
IMT VERSION = 021-001-000
PROM VERSION = 021-001-000
IMT BUS A = Conn
IMT BUS B = Fault
SLK A PST = IS-NR LS=lsnssp2 CLLI=-----
SLK B PST = IS-NR LS=lsnstpi CLLI=-----
SCCP SERVICE CARD = 1212
Command Completed.
```

2. See [Determine Card Changeout Time](#) procedure to determine when to change the card.

 **Note:**

The `inh-slk` command will be rejected if inhibiting the link would cause a **DPC** to become unavailable.

3. Enter the following command to inhibit the links on both ports of this card (a and b).

```
inh-slk:loc=xxxx:port=y
```

Where xxxx location of the card from 1 and y is the port.

4. Enter the following command to change the status of the link to out of service - maintenance disabled (`oos-mt-dsbl`).

Enter the same location and ports from 3

```
dact-slk:loc=xxxx:port=y
```

Where xxxx location used in 3 and y are the ports used in 3 .

5. Enter the following command to ensure the signaling link status is `oos-mt-dsbl` (out of service - maintenance disabled).

```
rept-stat-slk
```

The following is an example of the possible output.

```
RLGHNCXA03W 98-09-27 17:00:36 EST EAGLE 34.0.0
rept-stat-slk
SLK LSN CLLI PST SST AST
1201,A lsnssp2 ----- IS-NR Avail ----
1201,B lsnstpi ----- OOS-MT-DSBLD LPBK ----
1202,A lsnstpn ----- IS-NR Avail ----
```

```

1202,B lsnstpi ----- IS-NR Avail ----
1203,A lsnstpa ----- IS-NR Avail ----
1203,B lsnscpa ----- IS-NR Avail ----
1205,A lsnscpi ----- IS-NR Avail ----
1205,B lsnsspi1 ----- IS-NR Avail ----
1207,A lsnstpa ----- IS-NR Avail ----
1207,B lsnsspa1 ----- IS-NR Avail ----
1211,A lsnstpn ----- IS-NR Avail ----
1211,B lsnsspn1 ----- IS-NR Avail ----
Command Completed.

```

6. Enter the following command to inhibit the card and disconnect it from the IMT bus.

```
rmv-card:loc=xxxx
```

Where xxxx location used in 3 and 4 .

7. Remove the **LIM/E5E1T1-B/SLIC**, per the card replacement procedure described in the section titled [Replacing a Card in the EAGLE](#)..

Place the new **SS7LIM** into its place. Be sure the revision numbers are compatible (if in doubt, contact the [My Oracle Support \(MOS\)](#) )

).

8. Enter the following command to download generic program loads and database information from the **E5-TDM** card to the new **LIM/E5E1T1-B/SLIC**:

```
alw-card:loc=xxxx
```

Where xxxx location used in 6 .

9. Enter the following command to determine which links are serviced by this card:

```
rept-stat-card:loc=xxxx
```

Where xxxx is the location of the replaced card.

 **Note:**

The signaling link alarms will be present until the links are restored in 11.

10. Examine the output from 9.

See [Corrective Maintenance](#) to clear any **GPL** related alarms on the newly replaced card before continuing.

11. Enter the following command to return the links to service.

Make sure this is done on all links:

```
act-slk:loc=xxxx:port=y
```

Where xxxx location used in 3 and 4 and y are the ports used in 3 and 4.

12. Enter the following command to change the link status to **IS-NR**.

Make sure this is done on both ports, a and b.

```
unhb-slk:loc=xxxx:port=y
```

Where xxxx location used in 3 and 4 and y are the ports used in 3 and 4.

13. Enter the following command to verify the status of the card and its associated links:

rept-stat-card:loc=xxxx

Where xxxx is the card location. The following is an example of the possible output.

```

RLGHNCXA03W 98-09-27 16:43:42 EST EAGLE 34.0.0
CARD VERSION TYPE APPL PST SST AST
1201 024-002-000 LIMDS0
SS7ANSI
 IS-NR Active -----
ALARM STATUS = No Alarms.
IMT VERSION = 024-001-000
PROM VERSION = 024-001-000
IMT BUS A = Conn
IMT BUS B = Conn
SLK A PST = IS-NR LS=lsnssp2 CLLI=-----
SLK B PST = IS-NR LS=lsnstpi CLLI=-----
SCCP SERVICE CARD = 1212
Command Completed.

```

- Enter the following command to verify the links are properly aligned and are returned to full service:

rept-stat-slk


The following is an example of the possible output.

```

RLGHNCXA03W 98-09-27 17:00:36 EST EAGLE 34.0.0
rept-stat-slk
SLK LSN CLLI PST SST AST
1201,A lsnssp2 ----- IS-NR Avail ----
1201,B lsnstpi ----- OOS-MT-DSBLD LPBK ----
1202,A lsnstpn ----- IS-NR Avail ----
1202,B lsnstpi ----- IS-NR Avail ----
1203,A lsnstpa ----- IS-NR Avail ----
1203,B lsnscpa ----- IS-NR Avail ----
1205,A lsnscpi ----- IS-NR Avail ----
1205,B lsnssp1 ----- IS-NR Avail ----
1207,A lsnstpa ----- IS-NR Avail ----
1207,B lsnspa1 ----- IS-NR Avail ----
1211,A lsnstpn ----- IS-NR Avail ----
1211,B lsnssp1 ----- IS-NR Avail ----
Command Completed.

```

Figure A-7 DS0A-LIM LEDs



| LEDs      | Descriptions                                                                                                                                                                                                                                                   |
|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| APPL PROC | RED – Application processor is not running or is failing diagnostics.<br>AMBER – LIM-DS0A is loading an application or is being polled (may be prevented from loading by maintenance out of service condition).<br>GREEN – LIM-DS0A is running an application. |
| IMTA      | RED – LIM-DS0A is off IMT bus A.<br>AMBER – LIM-DS0A is on IMT bus A, but testing is not complete.<br>GREEN – LIM-DS0A is on IMT bus A.<br>BLANK – Communication processor is not operating.                                                                   |
| IMTB      | RED – LIM-DS0A is off IMT bus B.<br>AMBER – LIM-DS0A is on IMT bus B, but testing is not complete.<br>GREEN – LIM-DS0A is on IMT bus B.<br>BLANK – Communication processor is not operating.                                                                   |
| PORT A    | RED – Link is out of service.<br>GREEN – Link is aligned and in service.                                                                                                                                                                                       |
| PORT B    | RED – Link is out of service.<br>GREEN – Link is aligned and in service.                                                                                                                                                                                       |

## A.9 E5-ENET-B Module

The term E5-ENET refers to the E5-ENET-B (P/N 870-2971-xx).

The E5-ENET-b module (refer to [Figure A-8](#)) can run different applications. Removal and replacement procedures differ depending on the application.




**Note:**

If this card is removed, the link supported by this card becomes out of service.

For removal and replacement procedures for a like-for-like card:

- If the E5-ENET-B card is operating with signaling interfaces such as IPLIM, IPGW or IPSG, refer to [IP SIGTRAN on E5-ENET-B](#).
- If the E5-ENET-B card is operating with signaling interfaces such as EROUTE, refer to [EROUTE on E5-ENET-B](#).

Figure A-8 E5-ENET-B LEDs



Front Faceplate LED Indicators

| LED       | Status | Description                           |
|-----------|--------|---------------------------------------|
| APPL PROC | Off    | No power                              |
|           | Red    | Card is booting                       |
|           | Amber  | Card is loading                       |
|           | Green  | Card is up and application is running |
| IMT A     | Red    | Not connected to bus                  |
|           | Amber  | Testing not complete                  |
|           | Green  | Active and connected to the bus       |
| IMT B     | Red    | Not connected to bus                  |
|           | Amber  | Testing not complete                  |
|           | Green  | Active and connected to the bus       |

EROUTE/SLAN

| LED   | ACT                                                                    | LINK                        |
|-------|------------------------------------------------------------------------|-----------------------------|
| Red   | Signaling links inactive, or 1 or more active links are out-of-service | N/A                         |
| Green | All active links are in-service                                        | Ethernet signal detected    |
| Off   | Card nonfunctional                                                     | No Ethernet signal detected |

ACT Status LED states for IPLIMx/IPSG

| SLK States (Port A or Port B)          | ACT Status LED |
|----------------------------------------|----------------|
| No links configured                    | Off            |
| All provisioned links are OOS-MT-DSBLD | Red            |
| Sync                                   | Green          |

ACT Status LED states for IPGWx

| IPGWx SLK PST                            | ACT Status LED |       |
|------------------------------------------|----------------|-------|
|                                          | A0             | B0    |
| None configured (card must be inhibited) | Off            | Off   |
| OOS-MT-DSBLD                             | Red            | Red   |
| IS-NR or IS-ANR                          | Green          | Green |

## A.9.1 IP SIGTRAN on E5-ENET-B

The term E5-ENET refers to the E5-ENET-B (P/N 870-2971-xx).

Use this procedure to remove and replace an E5-ENET-B card running an application such as IPLIM, IPLIMI, IPGWI, SS7IPGW, or IPSG, or SLIC running the IPSG application.



 **Note:**

See the "Conversion of SLIC Cards" section in *Database Administration - System Management* for 32-bit to 64-bit conversion and vice versa.

See the "EAGLE Card Applications and GPLs" table in *Database Administration - System Management* for details on the flash and application GPLs that are run/required based on different card configurations.

1. Enter the following command to determine which links are serviced by this card.

```
rept-stat-card:loc=xxxx
```

Where xxxx is the card location.

The following is an example of the possible output.

```
rlghncxa03w 06-06-01 16:43:42 EST EAGLE 46.6.0.0
CARD VERSION TYPE GPL PST SST AST
1301 082-000-039 E5-ENET IPLHC IS-NR Active

ALARM STATUS = No Alarms.
BLMCAP GPL version = 126-002-000
IMT BUS A = Conn
IMT BUS B = Disc
SIGNALING LINK STATUS
 SLK PST LS CLLI E5IS
 A IS-NR ls1m2pa ----- INACTIVE
 B OOS-MT ls1m2pa ----- INACTIVE
 A1 OOS-MT ls1m2pa ----- INACTIVE
 B1 OOS-MT ls1m2pa ----- INACTIVE
 A2 OOS-MT ls1m2pa ----- INACTIVE
 B2 OOS-MT ls1m2pa ----- INACTIVE
 A3 OOS-MT ls1m2pa ----- INACTIVE
 B3 OOS-MT ls1m2pa ----- INACTIVE

Command Completed.
;
```

2. Refer to [Determine Card Changeout Time](#) procedure to determine when to change the card.
3. Enter the following command to inhibit the links on both ports of this card (a and b):

```
inh-slk:loc=xxxx:port=y
```

 **Note:**

This step is not applicable for IPSPG-M3UA and IPGW links.

Where xxxx is the location of the card and y is the port.

 **Note:**

The `inh-slk` command will be rejected if inhibiting the link would cause a **DPC** to become unavailable.

The following is an example of the possible output.

```
rlghncxa03w 05-01-07 11:11:28 EST EAGLE5 33.0.0
Inhibit Link message sent to card
;
```

4. Enter the following command to change the status of the link to out of service - maintenance disabled (`oos-mt-dsblld`).

```
dact-slk:loc=xxxx:port=y
```

Where `xxxx` is the card location and `y` is the port used.

The following is an example of the possible output.

```
rlghncxa03w 04-01-07 11:11:28 EST EAGLE5 33.0.0
Deactivate Link message sent to card
;
```

5. Enter the following command to ensure the signaling link status is `oos-mt-dsblld` (out of service - maintenance disabled).

```
rept-stat-slk
```

The following is an example of the possible output.

```
RLGHNCXA03W 98-09-27 17:00:36 EST EAGLE 34.0.0
rept-stat-slk
SLK LSN CLLI PST SST AST
1201,A lsnssp2 ----- IS-NR Avail ----
1201,B lsnstpi ----- OOS-MT-DSBLD LPBK ----
1202,A lsnstpn ----- IS-NR Avail ----
1202,B lsnstpi ----- IS-NR Avail ----
1203,A lsnstpa ----- IS-NR Avail ----
1203,B lsnscpa ----- IS-NR Avail ----
1205,A lsnscpi ----- IS-NR Avail ----
1205,B lsnspi1 ----- IS-NR Avail ----
1207,A lsnstpa ----- IS-NR Avail ----
1207,B lsnspa1 ----- IS-NR Avail ----
1211,A lsnstpn ----- IS-NR Avail ----
1211,B lsnssp1 ----- IS-NR Avail ----
Command Completed.
```

6. Enter the following command to inhibit the card and disconnect it from the IMT bus.

```
rmv-card:loc=xxxx
```

Where `xxxx` is the location.

The following is an example of the possible output.

```
rlghncxa03w 04-01-07 11:11:28 EST EAGLE 31.3.0
Card has been inhibited.
;
```

- Remove the E5-ENET card per the card replacement procedure described in the section titled [Replacing a Card in the EAGLE](#).

Place the new E5-ENET card into its place. Be sure the revision numbers are compatible (if in doubt, contact [My Oracle Support \(MOS\)](#)).

- Enter the following command to verify GPL versions:

```
rept-stat-gpl:loc=xxxx,
```

Where `xxxx` is the location of the replaced card.

The following is an example of the possible output:

```
eaglestp YY-MM-DD hh:mm:ss TTTT EAGLE XX.x.x-YY.yy.y
GPL CARD RUNNING APPROVED TRIAL
IPSG XXXX ----- XXX-XXX-XXX XXX-XXX-XXX
 ZZZZZZ YYY-YYY-YYY YYY-YYY-YYY YYY-YYY-YYY

Command Completed.
```

Where `ZZZZZZ` is the Flash GPL name (BLMCAP, BLSLC32, for example). If the Flash GPL is not getting displayed, then wait for the card to be back on the IMT and run the command again.

- If replacing an E5-ENETB card with a SLIC card, change the card type to SLIC using the `chg-card:type=slic:loc=xxxx` command,

Where `xxxx` is the location of the replaced card.

- Examine the output from

Refer to [Corrective Maintenance](#) to clear any Flash GPL related alarms on the newly replaced card before continuing.

- Enter the following command to put the card back into service:

```
alw-card:loc=xxxx
```

where `xxxx` is the card location used in [6](#)

The following is an example of a possible output:

```
Command Accepted - Processing
eagle3 02-01-18 18:02:20 EST EAGLE5 41.2.0-62.69.65
alw-card:loc=1112
Command entered at terminal #1.
;
eagle3 02-01-18 18:02:20 EST EAGLE5 41.2.0-62.69.65
Card has been allowed.
;
eagle3 02-01-18 18:02:20 EST EAGLE5 41.2.0-62.69.65
Command Completed.
;
```

12. Enter the following command to return the links to service.

```
act-slk:loc=xxxx:port=y
```

Where `xxxx` is the location and `y` are the ports used in 3 and 4.

Make sure this is done on all links.

The following is an example of the possible output.

```
tekelecstp 05-01-21 17:00:36 EST EAGLE5 33.0.0
Activate Link message sent to card
;
```

13. Enter the following command to change the link status to **IS-NR**:

```
unhb-slk:loc=xxxx:port=y
```

 **Note:**

This step is not applicable for IPSG-M3UA and IPGW links.

Make sure this is done on both ports, *a* and *b*.

Where `xxxx` is the location used in 3 and 4 and `y` are the ports used in the same steps, respectively.

The following is an example of the possible output.

```
rlghncxa03w 03-03-23 13:20:59 EST EAGLE 31.3.0
Allow Link message sent to card
;
```

14. Enter the following command to verify the status of the card and its associated links.

```
rept-stat-card:loc=xxxx
```

Where `xxxx` is the card location.

The following is an example of the possible output.

```
rlghncxa03w 06-06-01 16:43:42 EST EAGLE 46.6.0.0
CARD VERSION TYPE GPL PST
SST
1301 082-000-039 E5-ENET IPLHC IS-NR
Active -----
ALARM STATUS = No Alarms.
BLMCAP GPL version = 126-002-000
IMT BUS A = Conn
IMT BUS B = Disc
SIGNALING LINK STATUS
 SLK PST LS CLLI E5IS
 A IS-NR ls1m2pa -----
INACTIVE
 B OOS-MT ls1m2pa -----
INACTIVE
 A1 OOS-MT ls1m2pa -----
```

```

INACTIVE
 B1 OOS-MT ls1m2pa ----- INACTIVE
 A2 OOS-MT ls1m2pa ----- INACTIVE
 B2 OOS-MT ls1m2pa ----- INACTIVE
 A3 OOS-MT ls1m2pa ----- INACTIVE
 B3 OOS-MT ls1m2pa ----- INACTIVE

```

Command Completed.

;

15. Enter the following command to verify the links are properly aligned and are returned to full service.

```
rept-stat-slk
```

The following is an example of the possible output.

```

RLGHNCXA03W 98-09-27 17:00:36 EST EAGLE 34.0.0
rept-stat-slk
SLK LSN CLLI PST SST AST
1201,A lsnssp2 ----- IS-NR Avail ----
1201,B lsnstpi ----- OOS-MT-DSBLD LPBK ----
1202,A lsnstpn ----- IS-NR Avail ----
1202,B lsnstpi ----- IS-NR Avail ----
1203,A lsnstpa ----- IS-NR Avail ----
1203,B lsnscpa ----- IS-NR Avail ----
1205,A lsnscpi ----- IS-NR Avail ----
1205,B lsnsspi1 ----- IS-NR Avail ----
1207,A lsnstpa ----- IS-NR Avail ----
1207,B lsnsspa1 ----- IS-NR Avail ----
1211,A lsnstpn ----- IS-NR Avail ----
1211,B lsnssp1 ----- IS-NR Avail ----
Command Completed.

```

Procedure complete.

## A.9.2 EROUTE on E5-ENET-B

The term E5-ENET refers to either the E5-ENET-B (P/N 870-2971-xx).

Use this procedure to remove and replace an E5-ENET-B card running an application such as EROUTE.

1. Enter the following command to determine what **TCP/IP** data links are configured.

```
rept-stat-card
```

The following is an example of a possible output.

```

rlghncxa03w 10-01-09 16:35:57 IST EAGLE 46.0.0

CARD VERSION TYPE GPL PST SST AST
1101 125-020-000 TSM GLS IS-NR Active

1102 128-002-000 LIMATM ATMHC IS-NR Active

```

```

 1103 125-020-000 E5SM4G SCCPHC IS-NR
Active -----
 1105 125-020-000 E5SM4G SCCPHC IS-NR
Active -----
 1106 130-001-000 TSM GLSHC IS-NR
Active -----
 1109 125-020-000 HIPR2 HIPR2 IS-NR
Active -----
 1110 125-020-000 HIPR2 HIPR2 IS-NR
Active -----
 1111 125-020-000 IPSM IPS IS-NR
Active -----
 1112 125-020-000 EDSM MCP IS-NR
Active -----
 1113 070-019-002 E5MCAP OAMHC IS-NR
Standby -----
 1114 ----- E5TDM IS-NR
Active -----
 1115 070-019-002 E5MCAP OAMHC IS-NR
Active -----
 1116 ----- E5TDM IS-NR
Active -----
 1117 ----- E5MDAL IS-NR
Active -----
 1201 125-020-000 LIMDS0 SS7ANSI IS-NR
Active -----
 1202 ----- LIMCH SS7ANSI OOS-MT-DSBLD
Manual -----
 1203 125-020-000 LIMCH SS7ANSI IS-NR
Active -----
 1209 125-020-000 HIPR2 HIPR2 IS-NR
Active -----
 1210 125-020-000 HIPR2 HIPR2 IS-NR
Active -----
 1211 125-020-000 LIMATM ATMANSI IS-NR
Active -----
 1213 125-020-000 LIME1ATM ATMITU IS-NR
Active -----
 1301 048-019-022 LIME1 SS7ANSI IS-NR
Active -----
 1303 125-022-000 LIME1 SS7ANSI IS-NR
Active -----
 1305 125-022-000 LIME1 CCS7ITU IS-NR
Active -----
 1309 125-017-000 HIPR2 HIPR2 IS-NR
Active -----
 1310 125-017-000 HIPR2 HIPR2 IS-NR
Active -----
 2101 104-002-000 LIMV35 CCS7ITU IS-NR
Active -----
 2103 128-018-000 DCM IPLHC IS-NR
Active -----
 2107 104-001-000 LIMCH CCS7ITU IS-NR
Active -----

```

```

 2109 128-022-000 HIPR2 HIPR2 IS-NR Active

 2110 128-022-000 HIPR2 HIPR2 IS-NR Active

 2111 128-018-000 STC ERTHC IS-NR Active

 1213 053-000-058 E5ENET IPSG IS-NR Active

 Command Completed.
;

```

2. Enter the following command to determine the status of the **TCP/IP** data link assigned to the card to be replaced.

```
rept-stat-dlk
```

The following is an example of the possible output.

```

rlghncxa03w 10-01-27 17:00:36 EST EAGLE 42.0.0
DLK PST SST AST
1104 IS-NR Active ----
1206 IS-NR Active ALMINH
Command Completed.
;

```

3. Note the status of the **TCP/IP** data link.
  - If the link is out of service - maintenance disabled (**OOS-MT-DSBLD**), go to 5.
  - If the link is not out of service, go to the next step.
4. Enter the following command to change the status of the **TCP/IP** data link to **OOS-MT-DSBLD**.

```
canc-dlk:loc=xxxx
```

Where xxxx is the card location.

The following is an example of a possible output.

```

rlghncxa03w 04-01-27 17:00:36 EST EAGLE 31.3.0
Deactivate Link message sent to card.
Command Completed.
;

```

5. Enter the following command to inhibit the card and disconnect it from the IMT bus.

```
rmv-card:loc=xxxx
```

Where xxxx is the card location.

 **Note:**

If this is the last type **ENET** card in the system, the `:force=yes` parameter must be used with this command.

The following is an example of a possible output.

```
rlghncxa03w 04-01-07 11:11:28 EST EAGLE 31.3.0
Card has been inhibited.
;
```

- Remove the **E5-ENET**, per the card replacement procedure described in the section titled [Replacing a Card in the EAGLE](#).

Place the new **E5-ENET-B** into its place. Be sure the revision numbers are compatible (if in doubt, contact [My Oracle Support \(MOS\)](#)).

- Enter the following command to put the new **E5-ENET-B** card back into service and connect it to the IMT bus.

```
alw-card:loc=xxxx
where xxxx = card location.
```

The following is an example of a possible output.

```
rlghncxa03w 04-01-07 11:11:28 EST EAGLE 31.3.0
Card has been allowed.
;
```

- Enter the following command to return the **TCP/IP** data link to service.

```
act-dlk:loc=xxxx
where xxxx is the card location.
```

The following is an example of a possible output.

```
rlghncxa03w 04-01-17:00:36 EST EAGLE 31.3.0
Activate Link message sent to card.
Command Completed.
;
```

- Enter the following command to verify the status of the card and its associated **TCP/IP** data link.

```
rept-stat-card
```

The following is an example of a possible output.

```
rlghncxa03w 10-01-09 16:35:57 IST EAGLE 46.0.0

CARD VERSION TYPE GPL PST
SST AST
1101 125-020-000 TSM GLS IS-NR
Active -----
1102 128-002-000 LIMATM ATMHC IS-NR
Active -----
1103 125-020-000 E5SM4G SCCPHC IS-NR
Active -----
1105 125-020-000 E5SM4G SCCPHC IS-NR
Active -----
1106 130-001-000 TSM GLSHC IS-NR
Active -----
```



|       |             |          |         |              |         |
|-------|-------------|----------|---------|--------------|---------|
| 1109  | 125-020-000 | HIPR2    | HIPR2   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1110  | 125-020-000 | HIPR2    | HIPR2   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1111  | 125-020-000 | IPSM     | IPS     | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1112  | 125-020-000 | EDSM     | MCP     | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1113  | 070-019-002 | E5MCAP   | OAMHC   | IS-NR        | Standby |
| ----- |             |          |         |              |         |
| 1114  | -----       | E5TDM    |         | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1115  | 070-019-002 | E5MCAP   | OAMHC   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1116  | -----       | E5TDM    |         | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1117  | -----       | E5MDAL   |         | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1201  | 125-020-000 | LIMDS0   | SS7ANSI | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1202  | -----       | LIMCH    | SS7ANSI | OOS-MT-DSBLD | Manual  |
| ----- |             |          |         |              |         |
| 1203  | 125-020-000 | LIMCH    | SS7ANSI | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1209  | 125-020-000 | HIPR2    | HIPR2   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1210  | 125-020-000 | HIPR2    | HIPR2   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1211  | 125-020-000 | LIMATM   | ATMANSI | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1213  | 125-020-000 | LIME1ATM | ATMITU  | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1301  | 048-019-022 | LIME1    | SS7ANSI | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1303  | 125-022-000 | LIME1    | SS7ANSI | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1305  | 125-022-000 | LIME1    | CCS7ITU | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1309  | 125-017-000 | HIPR2    | HIPR2   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1310  | 125-017-000 | HIPR2    | HIPR2   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 2101  | 104-002-000 | LIMV35   | CCS7ITU | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 2103  | 128-018-000 | DCM      | IPLHC   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 2107  | 104-001-000 | LIMCH    | CCS7ITU | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 2109  | 128-022-000 | HIPR2    | HIPR2   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 2110  | 128-022-000 | HIPR2    | HIPR2   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 2111  | 128-018-000 | STC      | ERTHC   | IS-NR        | Active  |
| ----- |             |          |         |              |         |
| 1213  | 053-000-058 | E5ENET   | IPSG    | IS-NR        | Active  |

```

 Command Completed.
;
```

10. Enter the following command to verify that the **TCP/IP** data link has returned to full service.

```
rept-stat-dlk
```

The following is an example of the possible output.

```
rlghncxa03w 10-01-27 17:00:36 EST EAGLE 42.0.0
DLK PST SST AST
1104 IS-NR Active ----
1206 IS-NR Active ALMINH
Command Completed.
;
```

11. Procedure is complete.

## A.10 Database Services Module (DSM)

### Description

**DSM** (Figure A-10) cards are related to the **TSM/DCM** family, but differ by having an **AMD K-6** processor and from 1 to 4 **GB** of memory on an applique board. The **DSM** card also differs from the **TSM** cards by having ethernet ports. The **DSMs** run a version of the **SCCP** application that has been ported to the VxWorks **OS**. To differentiate the **DSM-VxWorks-SCCP** from the **SCCP** that runs on the **TSM** cards, the **DSM** version has been named **VSCCP**. The extra memory is required to hold a copy of the **RTDB**. Ethernet ports are required to connect to the **EPAP** to download the **RTDB**. Multiple **DSMs** are used to provide a means of load balancing in high-traffic situations. Each **DSM** contains an identical database. Furthermore, the **DSM RTDBs** need to be identical to the one maintained by the **EPAPs**.

#### Note:

If there are provisioning scripts, such as LARG data, the DSM replacement activity should be coordinated with the DB/Admin operations to avoid extended provision otherwise RADB resets may occur.

1. Enter the following command to determine which cards are in service.

```
rept-stat-card:loc=xxxx
```

Where **xxxx** is the **DSM** card location.

This will indicate which link interface modules (**LIMs**) will be affected by removal of the **DSM** card.

2. Enter the following command to determine the number of **DSM** cards in service providing **GTT**.

```
rept-stat-sccp
```

The following is an example of the possible output.

```

RLGHNCXA03W 98-02-04 15:10:19 EST EAGLE 34.0.0
SCCP SUBSYSTEM REPORT IS-NR Active -----
GSM SUBSYSTEM REPORT IS-NR Active -----
INP SUBSYSTEM REPORT IS-ANR Restricted -----
 ASSUMING MATE'S LOAD
 INPQS: SSN STATUS = Allowed MATE SSN STATUS = Prohibited

SCCP Cards Configured= 4 Cards IS-NR= 2 Capacity Threshold = 100%
CARD VERSION PST SST AST MSU USAGE CPU
USAGE

1212 103-001-000 IS-NR Active ALMINH 45% 30%
1301 P 103-001-000 IS-NR Active ----- 35% 40%
1305 ----- OOS-MT Isolated ----- 0% 0%
2112 ----- OOS-MT-DSBLD Manual ----- 0% 0%

SCCP Service Average MSU Capacity = 40% Average CPU Capacity = 35%
AVERAGE CPU USAGE PER SERVICE:
 GTT = 15% GFLEX = 5% GPORT = 10%
 INPMR = 2% INPQS = 3%
TOTAL SERVICE STATISTICS:
 SERVICE SUCCESS ERRORS WARNINGS FORWARD TO GTT TOTAL
 GTT: 1995 5 - - 2000
 GFLEX: 500 1 4 10 515
 GPORT: 800 0 2 3 805
 INPMR: 50 5 0 15 70
 INPQS: 499 1 - - 500
Command Completed.

```

**▲ Caution:**

Inhibiting/removing all DSM cards at one time will cause an SCCP nodal outage.

3. Enter the following command to remove the **DSM** card from service.

**▲ Caution:**

Removing/inhibiting the last IS-NR DSM card will cause an SCCP outage on the affected node. Before removing the last IS-NR DSMP card from service, ensure the mated STP DSM cards are IS-NR and capable of supporting the rerouted SCCP traffic.

```
rmv-card:loc=xxxx
```

Where xxxx is the **DSM** card location.

If this is the last **DSM** card in service, the:**force=yes** parameter must be specified.

4. Remove the **DSM** card, per the card replacement procedure described in the section titled [Replacing a Card in the EAGLE](#).

Place the new **DSM** card into its place. Be sure the revision numbers are compatible (if in doubt, [My Oracle Support \(MOS\)](#)).

5. Enter the following command to return the **DSM** card into service.

```
alw-card:loc=xxxx
```

Where xxxx is the **DSM** card location.

This causes the **MASP** to begin downloading tables to the new **DSM** card. When the card has been successfully loaded (there will be a response on the terminal that downloading is complete). This can take up to 4 hours.

6. Enter the following command to verify the card is operational and providing **SCCP** services.

```
rept-stat-sccp
```

The following is an example of the possible output.

```
RLGHNCXA03W 98-02-04 15:10:19 EST EAGLE 34.0.0
SCCP SUBSYSTEM REPORT IS-NR Active -----
GSM SUBSYSTEM REPORT IS-NR Active -----
INP SUBSYSTEM REPORT IS-ANR Restricted -----
 ASSUMING MATE'S LOAD
 INPQS: SSN STATUS = Allowed MATE SSN STATUS = Prohibited

SCCP Cards Configured= 4 Cards IS-NR= 2 Capacity Threshold = 100%
CARD VERSION PST SST AST MSU USAGE
CPU USAGE

1212 103-001-000 IS-NR Active ALMINH
45% 30%
1301 P 103-001-000 IS-NR Active -----
35% 40%
1305 ----- OOS-MT Isolated -----
0% 0%
2112 ----- OOS-MT-DSBLD Manual -----
0% 0%

SCCP Service Average MSU Capacity = 40% Average CPU Capacity
= 35%
AVERAGE CPU USAGE PER SERVICE:
 GTT = 15% GFLEX = 5% GPORT = 10%
 INPMR = 2% INPQS = 3%
TOTAL SERVICE STATISTICS:
 SERVICE SUCCESS ERRORS WARNINGS FORWARD TO GTT
TOTAL
```

|        |      |   |   |    |      |
|--------|------|---|---|----|------|
| GTT:   | 1995 | 5 | - | -  | 2000 |
| GFLEX: | 500  | 1 | 4 | 10 | 515  |
| GPORT: | 800  | 0 | 2 | 3  | 805  |
| INPMR: | 50   | 5 | 0 | 15 | 70   |
| INPQS: | 499  | 1 | - | -  | 500  |

Command Completed.

## A.11 E5-SM8G-B Card Replacement

The term E5-SM4G refers to either the E5-SM8G-B (P/N 870-2990-01).

The E5-SM8G-B card is a database service module (DSM) designed to operate in the EAGLE shelf. The E5-SM8G-B is a replacement for the DSM card (P/N 870-1984-xx) and the E5-SM4G card. Ethernet ports connect to the EPAP to download the RTDB. Multiple cards are used to provide a means of load balancing in high-traffic situations. Each card contains an identical database. Furthermore, the E5-SM4G RTDBs need to be identical to the one maintained by the EPAPs.

### Note:

See the "Conversion of SM8G-B Cards" section in *Database Administration - System Management* for 32-bit to 64-bit conversion and vice versa.

### Note:

If there are provisioning scripts, such as LARG data, the E5-SM4G replacement activity should be coordinated with the DB/Admin operations to avoid extended provision otherwise RADB resets may occur.

1. Enter the following command to determine which cards are in service. This will indicate which link interface modules (LIMs) will be affected by removal of the E5-SM4G card.

```
rept-stat-card:loc=xxxx
```

Where xxxx is the E5-SM4G card location.

2. Enter the following command to determine the number of E5-SM4G cards in service providing GTT.

```
rept-stat-sccp
```

The following is an example of the possible output.

```
RLGHNCXA03W 98-02-04 15:10:19 EST EAGLE 34.0.0
SCCP SUBSYSTEM REPORT IS-NR Active -----
GSM SUBSYSTEM REPORT IS-NR Active -----
INP SUBSYSTEM REPORT IS-ANR Restricted -----
ASSUMING MATE'S LOAD
INPQS: SSN STATUS = Allowed MATE SSN STATUS = Prohibited

SCCP Cards Configured= 4 Cards IS-NR= 2 Capacity Threshold = 100%
CARD VERSION PST SST AST MSU USAGE CPU
USAGE
```

```


1212 103-001-000 IS-NR Active ALMINH
45% 30%
1301 P 103-001-000 IS-NR Active -----
35% 40%
1305 ----- OOS-MT Isolated -----
0% 0%
2112 ----- OOS-MT-DSBLD Manual -----
0% 0%


```

```

SCCP Service Average MSU Capacity = 40% Average CPU Capacity
= 35%

```

```

AVERAGE CPU USAGE PER SERVICE:
GTT = 15% GFLEX = 5% GPORT = 10%
INPMR = 2% INPQS = 3%

```

```

TOTAL SERVICE STATISTICS:
SERVICE SUCCESS ERRORS WARNINGS FORWARD TO GTT
TOTAL
GTT: 1995 5 - -
2000
GFLEX: 500 1 4 10
515
GPORT: 800 0 2 3
805
INPMR: 50 5 0 15
70
INPQS: 499 1 - -
500

```

Command Completed.

**▲ Caution:**

Inhibiting/removing all E5-SM4G cards at one time will cause an SCCP nodal outage.

3. Enter the following command to remove the E5-SM4G card from service. If this is the last E5-SM4G card in service, the `:force=yes` parameter must be specified.

**▲ Caution:**

Removing/inhibiting the last IS-NR E5-SM4G card will cause an SCCP outage on the affected node. Before removing the last IS-NR E5-SM4G card from service, ensure the mated STP E5-SM4G cards are IS-NR and capable of supporting the rerouted SCCP traffic.

```
rmv-card:loc=xxxx
```

Where xxxx is the E5-SM4G card location.

4. Remove the E5-SM4G card, per the card replacement procedure described in [Replacing a Card in the EAGLE](#). Place the new E5-SM8G-B card into its place. Be sure the revision numbers are compatible (if in doubt, contact the [My Oracle Support \(MOS\)](#)).
5. Enter the following command Use the `alw-card` command to return the E5-SM4G card into service. This causes the MASP to begin downloading tables to the new E5-SM8G-B card.

```
alw-card:loc=xxxx
```

Where xxxx is the E5-SM8G-B card location.

This causes the MASP to begin downloading tables to the new E5-SM8G-B card. When the card has been successfully loaded (there will be a response on the terminal that downloading is complete). This can take up to 4 hours.

6. Enter the following command to verify the card is operational and providing SCCP services.

```
rept-stat-sccp
```

The following is an example of the possible output.

```
RLGHNCXA03W 98-02-04 15:10:19 EST EAGLE 34.0.0
SCCP SUBSYSTEM REPORT IS-NR Active -----
GSM SUBSYSTEM REPORT IS-NR Active -----
INP SUBSYSTEM REPORT IS-ANR Restricted -----
 ASSUMING MATE'S LOAD
 INPQS: SSN STATUS = Allowed MATE SSN STATUS = Prohibited

SCCP Cards Configured= 4 Cards IS-NR= 2 Capacity Threshold = 100%
CARD VERSION PST SST AST MSU USAGE CPU
USAGE

1212 103-001-000 IS-NR Active ALMINH 45% 30%
1301 P 103-001-000 IS-NR Active ----- 35% 40%
1305 ----- OOS-MT Isolated ----- 0% 0%
2112 ----- OOS-MT-DSBLD Manual ----- 0% 0%

SCCP Service Average MSU Capacity = 40% Average CPU Capacity = 35%


AVERAGE CPU USAGE PER SERVICE:
GTT = 15% GFLEX = 5% GPORT = 10%
INPMR = 2% INPQS = 3%

TOTAL SERVICE STATISTICS:
SERVICE SUCCESS ERRORS WARNINGS FORWARD TO GTT TOTAL
GTT: 1995 5 - - 2000
GFLEX: 500 1 4 10 515
GPORT: 800 0 2 3 805
INPMR: 50 5 0 15 70
```

```
INPQS: 499 1 - -
500
```

Command Completed.

**Figure A-9 E5-SM8G-B LEDs**



**Front Faceplate LED Indicators**

| LED       | Status | Description                               |
|-----------|--------|-------------------------------------------|
| APPL PROC | Off    | No power                                  |
|           | Red    | Card is booting                           |
|           | Amber  | Card is loading                           |
|           | Green  | Card is up and application is running     |
| IMT A     | Red    | Not connected to bus                      |
|           | Amber  | Testing not complete                      |
|           | Green  | Active and connected to the bus           |
| IMT B     | Red    | Not connected to bus                      |
|           | Amber  | Testing not complete                      |
|           | Green  | Active and connected to the bus           |
| ACT       | Off    | Card non-functional                       |
|           | Red    | No signal detected                        |
|           | Green  | Signal detected                           |
| PORT      | Off    | Card non-functional                       |
|           | Amber  | Data link active operating at 1 Gbps      |
|           | Green  | Data link active operating at 10/100 Mbps |

## A.12 E5-ENET-B Card Replacement

This procedure is for the replacement of E5-ENET-B (P/N 870-2971-xx) cards running IPS. The E5-ENET-B can be exchanged with IPSM cards running IPS, without any changes in provisioning information.

When command ENT-CARD is issued for IPSHC, the APPL parameter would be specified as IPS and TYPE would be specified as IPSM. The determination of actual **GPL** that needs to be loaded on the card is made by **OAM** based on the hardware board identification provided by the card itself .

1. Enter the following command to retrieve the terminal types and port numbers:

```
rtrv-trm
```



The following is an example of the possible display of the terminal settings with the IP User Interface feature enabled and three IPSM cards equipped.

```
rlghncxa03w 03-11-01 16:02:08 EST EAGLE 31.3.0
TRM TYPE COMM FC TMOUT MXINV DURAL
1 VT320 9600 -7-E-1 SW 0 5 00:01:00
2 VT320 9600 -7-E-1 SW 0 5 00:01:00
3 VT320 9600 -7-E-1 SW 0 5 00:01:00
4 KSR 9600 -7-E-1 SW 0 5 00:01:00
5 NONE 9600 -7-E-1 SW 30 5 00:01:00
6 NONE 9600 -7-E-1 SW 30 5 00:01:00
7 NONE 9600 -7-E-1 SW 30 5 00:01:00
8 NONE 9600 -7-E-1 SW 30 5 00:01:00
9 VT320 9600 -7-E-1 SW 0 5 00:01:00
10 VT320 9600 -7-E-1 SW 0 5 00:01:00
11 VT320 9600 -7-E-1 SW 0 5 00:01:00
12 KSR 9600 -7-E-1 SW 0 5 00:01:00
13 NONE 9600 -7-E-1 SW 30 5 00:01:00
14 NONE 9600 -7-E-1 SW 30 5 00:01:00
15 NONE 9600 -7-E-1 SW 30 5 00:01:00
16 NONE 9600 -7-E-1 SW 30 5 00:01:00
```

```
TRM TYPE LOC TMOUT MXINV DURAL
17 TELNET 1201 60 5 00:30:00
18 TELNET 1201 60 5 00:30:00
19 TELNET 1201 60 5 00:30:00
20 TELNET 1201 60 5 00:30:00
21 TELNET 1201 60 5 00:30:00
22 TELNET 1201 60 5 00:30:00
23 TELNET 1201 60 5 00:30:00
24 TELNET 1201 60 5 00:30:00
25 TELNET 1203 60 5 00:30:00
26 TELNET 1203 60 5 00:30:00
27 TELNET 1203 60 5 00:30:00
28 TELNET 1203 60 5 00:30:00
29 TELNET 1203 60 5 00:30:00
30 TELNET 1203 60 5 00:30:00
31 TELNET 1203 60 5 00:30:00
32 TELNET 1203 60 5 00:30:00
33 TELNET 1208 60 5 00:30:00
34 TELNET 1208 60 5 00:30:00
35 TELNET 1208 60 5 00:30:00
36 TELNET 1208 60 5 00:30:00
37 TELNET 1208 60 5 00:30:00
38 TELNET 1208 60 5 00:30:00
39 TELNET 1208 60 5 00:30:00
40 TELNET 1208 60 5 00:30:00
```

;

```
 LNP LNP
TRM TRAF LINK SA SYS PU DB DB SUB UIMRD
1 YES YES YES YES YES YES YES YES YES
2 YES YES YES YES YES YES YES YES YES
3 YES YES YES YES YES YES YES YES YES
4 YES YES YES YES NO YES YES YES YES
5 YES YES YES YES YES YES YES YES YES
```

|    |     |     |     |     |     |     |     |     |     |     |
|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 6  | NO  | YES | YES | YES | YES | YES | YES | YES | YES | YES |
| 7  | NO  | YES | YES | YES | YES | YES | YES | YES | YES | YES |
| 8  | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES |
| 9  | YES | YES | YES | YES | YES | YES | YES | YES | YES | YES |
| 10 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 11 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 12 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 13 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 14 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 15 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 16 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 17 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 18 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 19 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 20 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 21 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 22 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 23 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 24 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 25 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 26 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 27 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 28 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 29 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 30 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 31 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 32 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 33 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 34 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 35 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 36 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 37 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 38 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 39 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |
| 40 | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  | NO  |

|     | APP  | APP |      |     |     |     |     |      |     |     |      |     |
|-----|------|-----|------|-----|-----|-----|-----|------|-----|-----|------|-----|
| TRM | SERV | SS  | CARD | CLK | DBG | GTT | GWS | MEAS | MON | MPS | SEAS |     |
| 1   | YES  | YES | YES  | YES | YES | YES | YES | YES  | YES | YES | YES  | NO  |
| 2   | YES  | YES | YES  | YES | YES | YES | YES | YES  | YES | YES | YES  | NO  |
| 3   | YES  | YES | YES  | YES | YES | YES | YES | YES  | YES | YES | YES  | NO  |
| 4   | YES  | YES | YES  | YES | YES | NO  | YES | YES  | YES | YES | YES  | NO  |
| 5   | YES  | YES | YES  | YES | YES | YES | YES | YES  | YES | YES | YES  | NO  |
| 6   | YES  | YES | YES  | YES | YES | YES | YES | YES  | YES | YES | YES  | NO  |
| 7   | NO   | YES | YES  | YES | YES | YES | YES | YES  | YES | YES | YES  | NO  |
| 8   | YES  | YES | YES  | YES | YES | YES | YES | YES  | YES | YES | YES  | YES |
| 9   | YES  | YES | YES  | YES | YES | YES | YES | YES  | YES | YES | YES  | YES |
| 10  | NO   | NO  | NO   | NO  | NO  | NO  | NO  | NO   | NO  | NO  | NO   | NO  |
| 11  | NO   | NO  | NO   | NO  | NO  | NO  | NO  | NO   | NO  | NO  | NO   | NO  |
| 12  | NO   | NO  | NO   | NO  | NO  | NO  | NO  | NO   | NO  | NO  | NO   | NO  |
| 13  | NO   | NO  | NO   | NO  | NO  | NO  | NO  | NO   | NO  | NO  | NO   | NO  |
| 14  | NO   | NO  | NO   | NO  | NO  | NO  | NO  | NO   | NO  | NO  | NO   | NO  |
| 15  | NO   | NO  | NO   | NO  | NO  | NO  | NO  | NO   | NO  | NO  | NO   | NO  |
| 16  | NO   | NO  | NO   | NO  | NO  | NO  | NO  | NO   | NO  | NO  | NO   | NO  |
| 17  | NO   | NO  | NO   | NO  | NO  | NO  | NO  | NO   | NO  | NO  | NO   | NO  |

```

18 NO NO NO NO NO NO NO NO NO NO NO
19 NO NO NO NO NO NO NO NO NO NO NO
20 NO NO NO NO NO NO NO NO NO NO NO
21 NO NO NO NO NO NO NO NO NO NO NO
22 NO NO NO NO NO NO NO NO NO NO NO
23 NO NO NO NO NO NO NO NO NO NO NO
24 NO NO NO NO NO NO NO NO NO NO NO
25 NO NO NO NO NO NO NO NO NO NO NO
26 NO NO NO NO NO NO NO NO NO NO NO
27 NO NO NO NO NO NO NO NO NO NO NO
28 NO NO NO NO NO NO NO NO NO NO NO
29 NO NO NO NO NO NO NO NO NO NO NO
30 NO NO NO NO NO NO NO NO NO NO NO
31 NO NO NO NO NO NO NO NO NO NO NO
32 NO NO NO NO NO NO NO NO NO NO NO
33 NO NO NO NO NO NO NO NO NO NO NO
34 NO NO NO NO NO NO NO NO NO NO NO
35 NO NO NO NO NO NO NO NO NO NO NO
36 NO NO NO NO NO NO NO NO NO NO NO
37 NO NO NO NO NO NO NO NO NO NO NO
38 NO NO NO NO NO NO NO NO NO NO NO
39 NO NO NO NO NO NO NO NO NO NO NO
40 NO NO NO NO NO NO NO NO NO NO NO

```

;

2. Enter the following command to change the state of the appropriate card to the out of service - maintenance disabled state:

```
inh-card:loc=xxxx:force=yes
```

where xxxx is the card location stenciled on the shelf of the EAGLE. Following is an example of the output:

```

RLGHNCXA03W 00-06-05 11:11:28 EDT EAGLE 34.0.0
Card has been inhibited.

```

3. Remove and replace the card as described in the section titled, [Replacing a Card in the EAGLE](#).
4. Enter the following command to load and activate the approved **GPL** onto the inhibited card:

```
flash-card:code=appr:loc=xxxx:force=yes
```

where xxxx is the card location used in the previous step. The optional `force=yes` is used to force the command to work on an IS-NR card. Links provisioned on the card are inhibited during command execution. The card and inhibited links are restored to their previous state when the command is completed

Following is an example of the possible output using card location 1112:

```

Command Accepted - Processing

tekelecstp 18-01-18 16:06:22 MST EAGLE 46.5.1.5.0-73.3.0
flash-card:code=appr:force=yes:loc=1112
Command entered at terminal #1.

```

```

;

tekelecstp 18-01-18 16:06:55 MST EAGLE 46.5.1.5.0-73.3.0
Flash Card: FLASH GPL required to be downloaded on card 1112
BLMCAP : Running version 143-001-000 Expected version
143-002-000

;

tekelecstp 18-01-18 16:07:14 MST EAGLE 46.5.1.5.0-73.3.0
Flash Card: Downloading BLMCAP on card 1112
Flash Card: Card(s) will reset after the flash GPL download.

;

tekelecstp 18-01-18 16:07:56 MST EAGLE 46.5.1.5.0-73.3.0
Flash Card: Activating BLMCAP on card 1112

;

tekelecstp 18-01-18 16:08:25 MST EAGLE 46.5.1.5.0-73.3.0
Flash Card: Card 1112 flash activation complete.

;

Flash Card: Activating links on card 1112.

;

tekelecstp 18-01-11 16:09:11 EST EAGLE5 39.0.0
Command Completed.

;

```

5. After the card has been reloaded (a message appears to confirm completion of the load), enter the following command to verify the database is consistent (same level as the other cards in the system).

```
rept-stat-card
```

The following is an example of the possible output.

```

tekelecstp 07-02-25 10:02:42 EST EAGLE 37.0.0
CARD VERSION TYPE GPL PST
SST AST
1201 128-013-026 IPSM IPS IS-NR
Active -----
ALARM STATUS = No Alarms.
BPDCM GPL version = 128-013-012
IMT BUS A = Conn
IMT BUS B = Conn

Command Completed.

```

## A.13 Replacing Cards with SLIC Hardware

The SLIC card supports multiple applications. The `chg-card` command parameters differ depending on the hardware being replaced. See the "EAGLE Card Applications and GPLs" table in *Database Administration - System Management* for details on the flash and application GPLs that are run/required based on different card configurations.

1. Refer to specific card replacement procedures ("SS7 and IP7, HC-MIM Card Replacement," "E5-ENET-B Card Replacement," "E5-SM8G-B Card Replacement") to complete the replacement steps.
2. Enter the following command when the card replacement procedure states the old card is to be removed and the new card is to be inserted into the system (for the applications that support `type=slic`, as shown in the "EAGLE Card Applications and GPLs" table):

```
chg-card:type=slic:loc=xxxx
where xxxx is the card location.
```

## A.14 Database Communications Module (DCM)

The database communication module (**DCM**) (Figure A-10) provides access to a remote host for use by the **STP LAN** feature. The **DCM** consists of a 80486-based main assembly and an ethernet applique. Connection to a host is achieved through an ethernet **LAN** using the **TCP/IP** protocol.

If this card is removed, the **TCP/IP** data link supported by this card becomes out of service. Any data to be transmitted to the remote **TCP/IP** host connected by this **TCP/IP** data link is lost.

The **DCM** can only be inserted in the odd numbered card slots of the shelf. Slot 09 of each shelf contains the **IPMX** card; thus the **DCM** cannot be inserted in slot 09. The **DCM** can be inserted in the control shelf, but only in slots 01, 03, 05, 07, and 11. Slots 13, 15, and 17 refer to the extension shelf only. The **DCM** occupies two card slots, so the even numbered card slot adjacent to the odd numbered slot where the **DCM** has been inserted must be empty as shown in Table A-2. The **DCM** is connected to the network through the odd numbered card slot connector.

**Table A-2 DCM Card Locations**

| Location of the DCM | Empty Card Location | Location of the DCM | Empty Card Location |
|---------------------|---------------------|---------------------|---------------------|
| Slot 01             | Slot 02             | Slot 11             | Slot 12             |
| Slot 03             | Slot 04             | Slot 13             | Slot 14             |
| Slot 05             | Slot 06             | Slot 15             | Slot 16             |
| Slot 07             | Slot 08             | Slot 17             | Slot 18             |

The Double-Slot Enhanced **Database** Communications Module is a version of the **DCM** that includes more main memory and better processing performance. The double-slot **EDCM** can be placed in any slot odd or even that is provisioned. Physically the next higher slot can not be provisioned for a card because of the double-slot **EDCM** card width.

1. Enter the following command to determine what **TCP/IP** data links are configured:`rept-stat-card`
2. Enter the following command to determine the status of the **TCP/IP** data link assigned to the card to be replaced:`rept-stat-dlk`

The following is an example of the possible output.

```
RLGHNCXA03W 97-09-27 17:00:36 EST EAGLE 34.0.0
DLK PST SST AST
1104 IS-NR Avail ----
```


```
1206 IS-NR Avail ALMINH
Command Completed.
```

3. If the status of the **TCP/IP** data link is not out of service - maintenance disabled (**OOS-MT-DSBLD**), use the `canc-dlk` command to change the status of the **TCP/IP** data link to **OOS-MT-DSBLD**.`canc-dlk:loc=xxxx`  
Where `xxxx` is the card location.
4. Enter the following command to inhibit the card and disconnect it from the IMT bus.  
If this is the last **DCM** in the system, the `:force=yes` parameter must be used with this command.`rmv-card:loc=xxxx`Where `xxxx` is the card location.
5. Remove the **DCM**, per the card replacement procedure described in the section titled [Replacing a Card in the EAGLE](#).  
Place the new **DCM** into its place. Be sure the revision numbers are compatible (if in doubt, contact the [My Oracle Support \(MOS\)](#)).
6. Enter the following command to put the new **DCM** card back into service and connect it to the IMT bus:`alw-card:loc=xxxx`  
where `xxxx` = card location.
7. Enter the following command to return the **TCP/IP** data link to service:`act-dlk:loc=xxxx`  
where `xxxx` = card location.
8. Enter the following command to verify the status of the card and its associated **TCP/IP** data link:`rept-stat-card`
9. Enter the following command to verify that the **TCP/IP** data link has returned to full service:`rept-stat-dlk`

The following is an example of the possible output.

```
RLGHNCXA03W 97-09-27 17:00:36 EST EAGLE 34.0.0
DLK PST SST AST
1104 IS-NR Avail ----
1206 IS-NR Avail ALMINH
Command Completed.
```

Figure A-10 DCM LEDs



| LEDs      | Descriptions                                                    |
|-----------|-----------------------------------------------------------------|
| APPL PROC | RED – Critical alarm condition detected.<br>GREEN – No alarm    |
| IMT A     | RED – Major alarm condition detected.<br>GREEN – No alarm       |
| IMT B     | AMBER – Minor alarm condition detected.<br>GREEN – No alarm     |
| PORT A    | GREEN – PORT A is the active PORT.<br>RED – PORT A is inactive  |
| PORT B    | GREEN – PORT B is the active PORT.<br>RED – PORT B is inactive. |

## A.15 Measurement Collection and Polling Module (E5-MCPM)

### Note:

Throughout this document, the term MCPM refers to the **E5-MCPM-B** (P/N 870-3089-xx) card unless specifically noted otherwise.

The primary **MCPM** card performs all measurements collection and reporting functions and provides on-card **RAM** storage for collected data and scheduled reports. The Secondary **MCPM** provides a redundant backup for the Primary card, and assumes collection and reporting responsibilities on the loss of the Primary. **TCP/IP** connections are used to deliver measurement reports from the Primary **MCPM** card to the customer via an **FTP** client. The **FTP** configuration can be customized to support automatic transfer of scheduled reports from the client to the server.

1. Enter the following command to determine the status of the **MCPM** cards.  
`rept-stat-meas`
2. Enter the following command to remove the faulty **MCPM** card from service.  
If this is the last **MCPM** card in service, the `:force=yes` parameter must be specified:

```
rmv-card:loc=xxxx
```

where xxxx is the **MCPM** card location.

3. Remove the **MCPM** card, per the card replacement procedure described in the section titled [Replacing a Card in the EAGLE](#).

Place the new **MCPM** card into its place. Be sure the revision numbers are compatible (if in doubt, [My Oracle Support \(MOS\)](#)).

4. Enter the following command to return the **MCPM** card into service.

```
alw-card:loc=xxxx
```

Where xxxx is the **MCPM** card location.

This causes the **MASP** to begin downloading tables to the new **MCPM** card. When the card has been successfully loaded (there will be a response on the terminal that downloading is complete). This can take up to 10 minutes.

 **Note:**

If the card has not loaded in 30 minutes, enter the `init-card` command to re-boot the **MCPM** card.

5. Enter the following command to verify the card is operational:

```
rept-stat-meas
```

## A.16 Replacing a Card in the EAGLE

This procedure describes the physical removal and replacement of a card in the EAGLE system.

 **Note:**

Before removing or reseating a card, the card must be taken out of service.

Card replacement procedures in this section refer to this procedure. Locate and perform the appropriate replacement procedure for the card in order to properly take the card out of service.

 **warning:**

Failure to follow appropriate removal procedures may result in equipment damage.

 **warning:**

Before performing any maintenance procedures on the EAGLE, make sure you wear a wrist strap connected to the wrist strap grounding point of the EAGLE.




 **warning:**

This procedure may interrupt service. When possible, perform maintenance during low traffic and database provisioning periods, such as the maintenance window.

1. Locate the card to be removed.
2. Use both hands to open injector/ejector module locking tabs out from the faceplate of the card.

Push the inject/eject clamps outward from the card's faceplate (top clamp in the "UP" position, bottom clamp in the "DOWN" position). Pull the levers away from the shelf until they are parallel to the floor. Gently pull the card towards you until the card clears the shelf.

**Figure A-11 Push Inject/Eject Clamps Outward**



3. Place the card you have removed in an electrostatic discharge (ESD) protective container, or place the card in the spare card storage shelf.
4. Be sure that the replacement card has the same part number and revision number as the card you have just removed (unless this is an upgrade).
5. Open the ejector levers on the replacement card.

Carefully align the card's edges with the top and bottom card guides. Then push the card along the length of the card guides until the rear connectors on the card engage the mating connectors on the target shelf backplane.

6. Press the left edge of the card's faceplate using constant pressure until you feel the card's progress cease.

To ensure proper seating, the tabs must be held in the release position until the locking tabs can engage with the upper and lower flange on the shelf.

 **warning:**

Do not impact the faceplate in order to mate the connectors. Any impact to the card's faceplate can damage the faceplate, the pins, or the connectors.

7. Push in the top and bottom inject/eject clamps.

This locks the card in place and ensures a strong connection with the pins on the target shelf backplane.

**Figure A-12 Push in Inject/Eject Clamps**



Push in the inject/eject clamps to lock the card in place.

8. Verify that both IMT bus **LEDs** are green.
9. Record the activity in the site maintenance log.
10. Return to the appropriate card removal/replacement procedure to return the card to service (such as initializing, flashing, and allowing).

 **Note:**

If any UAMs are generated in the system after the card comes into service, refer to *Maintenance Guide* to find the recommended steps in diagnosing and clearing the UAM.

## A.17 Replacing Cards in the Holdover Clock

### Failed Clock Input (CI) Card Replacement


#### Description

Use this procedure to replace a failed clock input (**CI**) card in shelves equipped with **ST3** clock cards. The input card **FAIL** lamp should be lit.

1. If the shelf is equipped with **ST3** cards and the input card **FAIL** lamp is not lit, check the status of the **SRCACT/SRCACTIVE** lamp.  
If lit, press the transfer (**XFR**) button on either input card. If the input card **FAIL** lamp is lit, go to 2. The **SRCACT/SRCACTIVE** lamp on the other input card lights and the lamp goes off.
2. Remove the failed card or the card to be removed from the shelf.
3. Set the option switches on the replacement card to the correct settings.  
(See *Installation Guide*.) Wait for the input card to acquire the input reference signal (about 40 seconds). Then, press the **XFR** button to make the new input card active.

**CI, Clock Interface Card, Holdover Clock**

**Figure A-13 Holdover Clock CI Card LEDs**



### A.17.1 Non-Failed Clock Input (CI) Card Replacement

**Description**

Use this procedure to replace non-failed clock input (**CI**) cards which have valid input reference signals.

1. Remove the input reference signal to the shelf associated with the clock input card to be removed.

**▲ Caution:**

Removing a non-failed clock input card with a valid input reference signal from a shelf equipped with **ST3** cards, causes the **DCD** system outputs to run and hit all the network elements timed from the **DCD** system. To properly remove a non-failed clock input card, the input reference must be removed first. This squelches the **CI** card output. This does not apply to failed input cards.

Perform one of the following:

- a. If the reference input has a miscellaneous **SYNC** jack at the **DSX-1**, insert an open plug or the end of a patch card in the **SYNC** jack to squelch the input reference signal. If the input reference has an external bridging repeater, insert an open plug or the end of a patch cord in the **OUT** jack at the bridging repeater to squelch the input reference signal.
- b. If the input reference signal is directly cabled from the source to the **DCD** shelf, either lift the leads of the **TB12** or **TB13** wire-wrap terminals on the backplane of the **DCD** shelf, or short the tip (T) and ring (R) together at **TB12** or **TB13** on the backplane.

**▲ Caution:**

Use a clip cord that is no longer than two inches. A longer clip cord may not appear as a short to the **CI** card and the input reference may continue to drive it.

The **DS1** lamp should be off and the **FAIL** lamp lit on the **CI** card. If this is not true, do not proceed. This indicates the input reference has not been removed.

2. Remove the **CI** card.  
This has no effect on the outputs.
3. Set the option switches on the replacement card to the correct settings.  
(See *Installation Guide*.) The **DS1** lamp should be off and the **FAIL** lamp lit on the **CI** card.
4. Restore the input reference by removing the open plug, clip cord, or reconnecting the leads to **TB12** or **TB13** wire-wrap terminals on the **DCD** shelf backplane.
5. Wait for the input card to acquire the input reference signal (about 40 seconds).  
If you want the new **CI** card to be active, press the **XFR** button.

## A.17.2 ST3 Card Replacement

### Description

Use this procedure to replace **ST3** cards. The only time an **ST3** card should be replaced is if the **FAIL** lamp is lit, or if it is in the **ST A** slot and the **LOCK** or **LOCK** and **FAIL** lamps are not lit and the network elements receiving timing from the shelf are reporting slips. (However, the second condition is more likely a timing loop rather than a bad **ST3** card.)

 **Note:**

The **ST3** card in slot B (**ST B**) in shelves equipped with **ST3** clock cards may be removed from the shelf without any negative effect to the output, regardless if the **ST3** has failed. If an **ST3** is installed and not failed in slot A (**ST A**), it is the preferred source for the output cards. If you remove the card from the shelf, it may cause a hit to the outputs.

1. Remove the **ST3** card from the shelf.

If it is in slot A and has not failed, the **ST B** clock card automatically become the preferred source for the outputs. The **TO** cards **ST** and **INPUT** lamps should remain green.

 **Note:**

There may be a one-time phase hit to the outputs. If **ST A** has failed, the **ST B** clock card is already the preferred source for the outputs. If **ST B** is being replaced, it is in standby and may be removed without negative effect to the outputs.


2. Insert the replacement card in the shelf.

Lock it into place by rotating the locking lever downward. The **FAIL** lamp should remain lit until it has acquired the frequency and phase of the input reference signal and then go off (about one minute). If **ST A** is being replaced, it automatically becomes the preferred source for the output when the **FAIL** and **LOCK** lamps go off. The **TO** cards **ST** and **INPUT** lamps should remain lit.

 **Note:**

If you are replacing both **ST3** cards, allow five minutes for the first card to stabilize before replacing the other.

Figure A-14 Holdover clock ST3 card LEDs



 **Note:**

If the **FAIL** and **LOCK** LEDs are both illuminated, the **ST3** is in holdover mode and the card has not failed.


### A.17.3 MIS Card Replacement

**Description**

The Maintenance Interface System (**MIS**) card may be removed or inserted into the shelf at any time without a negative effect to the operation of the shelf. The office alarms and shelf status (except for the battery alarm) do not function while the **MIS** card is removed from the shelf.

1. Remove the **MIS** card from the shelf.
2. Insert the replacement card.

**Figure A-15 Holdover Clock MIS Card LEDs**



| LEDs     | Descriptions                                                                                                     |
|----------|------------------------------------------------------------------------------------------------------------------|
| FAIL     | RED - this card or its power supply has failed.<br>BLANK - no card or power supply failure detected.             |
| CRITICAL | RED - holdover clock system has failed.<br>BLANK - no holdover clock system failure detected.                    |
| MAJOR    | RED - holdover clock system or any holdover clock card has a major alarm.<br>BLANK - no major alarm detected.    |
| MINOR    | YELLOW - holdover clock system or any holdover clock card has a minor alarm.<br>BLANK - no minor alarm detected. |
| ACO      | GREEN - the ACO push button has been pressed to silence the alarm during an alarm state.                         |

## A.17.4 TOCA Card Replacement

When an **MCA-5** is installed in the **MCA** slot, an **HS** protection switch automatically activates when the **TOFAIL** or **PORTALM** lamp is lit. If the **TOPORTALM** lamp is lit, you must determine whether it is actually a card port failure, or a shorted or unterminated cable external to the shelf. If you determine that the **PORTALM** is actually a port failure on the card, replace the **TO** card.

1. Verify that an **HS** protection switch has been activated.

If an automatic protection switch has been activated, the output protection button lamps are lit over the failed card and **HSTO** card. The **MCA-5 AUTO** lamp flashes for 6 seconds during the automatic protection switch activation, and then lights steadily.

2. If an **HS** protection is not activated, manually activate a switch by simultaneously pressing the output protection buttons over the **TO** card with **FAIL** or **PORTALM** lamp lit and a like **HSTO** card.

The output protection button lamps should light over the failed **TO** card and a like **HSTO** card, and the **MCA-5 MAN** lamp flashes until the switch is released.

 **Caution:**

The **TO** cards must not be removed without first activating an **HS** protection switch to minimize the loss of output signals. The possible output loss times are as follows:

- a. **TO** card removal: up to 6 seconds
  - b. Port or card failure: up to 3 seconds
  - c. Manual switch activation/deactivation: approximately one ms.
3. Remove the **TO** card from the shelf.


Set the option switches on the replacement card to the correct settings. Insert the replacement card. The **FAIL** lamp on the replacement card should remain off and the **INPUT** lamp should light. The **ST** lamp should also light if the system is equipped with clock cards.

4. Wait 10 seconds after all the lamps normalize to allow the card to warm-up and generate outputs.
5. Press the lit output protection button for the **HSTO** card slot until the lamp goes out.

The lamp over the output protection button should go off. This releases the **HS** protection switch and puts the replacement card online.




**Figure A-16 Holdover Clock TOCA Card LEDs**



| LEDs     | Descriptions                                                                                                                                                                                                                 |
|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FAIL     | RED - this card has failed or there is a loss of all input references to this card.<br>BLANK - no card or input reference failure detected.                                                                                  |
| PORT ALM | RED - if one to five outputs have failed or have been externally shorted.<br>BLANK - no output failures detected.                                                                                                            |
| ST       | GREEN - an active clock is supplying the input reference for this card.<br>BLANK - no active clock detected.                                                                                                                 |
| INPUT    | GREEN - card is receiving a reference signal from one or more of the following: clock input A, clock input B, clock card A, clock card B.<br>BLANK - card is not receiving a reference signal from any of the above sources. |
| 500'     | not used                                                                                                                                                                                                                     |
| 1000'    | not used                                                                                                                                                                                                                     |

**Figure A-17 Holdover Clock MCA Card LEDs**



## A.18 Fan Assembly P/N 890-0001-xx

The Fan Assembly P/N 890-0001-xx is used for cooling shelves in the **EAGLE** frame. The assembly includes 3 fan units and a controller card.

### **Caution:**

Do not perform procedures to [Replace Fan Assembly](#) if the Fan Assembly is used to cool shelves with **HCMIM** or **HIPR2** cards. contact the [My Oracle Support \(MOS\)](#).

Refer to the following procedures to:

- [Replace the Fan Unit](#)
- [Replace Fan Controller Card](#)
- [Replace Fan Assembly](#)


## A.18.1 Replace the Fan Unit

### ▲ Caution:

Be careful when removing fans. Fan blades are exposed along the sides and back of the units. The fan blade speeds of remaining fans will increase after any fan is removed.

1. Loosen the two captive screws used to secure the fan to be replaced.  
Fan 1 is located next to the Fan controlled card.

**Figure A-18 Fan Unit Mounting Screws**



2. Firmly grasp the fan and pull straight out.  
The corresponding **LED** on the fan controller card is now red.
3. Insert the replacement fan into the appropriate slot and secure the two captive screws.  
The replaced fan should immediately come up to speed and the speeds of other fans should return to normal. The corresponding **LED** on the fan controller card is now green.

## A.18.2 Replace Fan Controller Card

1. Remove Fan 1 by removing the two captive screws used to secure Fan 1 (Refer to [Replace Fan Assembly](#)).

### ▲ Caution:

Be careful when removing fans. Fan blades are exposed along the sides and back of the units. The fan blade speeds of Fan 2 and **FAN 3** will increase after **FAN 1** is removed.

Fan 1 is located next to the Fan card. Firmly grasp Fan 1 and pull straight out.

2. Remove the fan controller card by removing the two captive screws used to secure the fan controller card.

Remove Fan Controller **Card** by pulling straight out.

3. Insert the replacement fan controller card into the appropriate slot and secure the two captive screws.
4. Insert Fan 1 back into the space next to the fan controller card and secure (finger tighten) using the two captive screws.

Fan 1 should immediately come up to speed and the speeds of Fans 2 and 3 should return to normal.

## A.18.3 Replace Fan Assembly

### **Caution:**

Do not perform this procedures if the Fan Assembly is used to cool shelves with **HCMIM** or **HIPR2** cards. contact [My Oracle Support \(MOS\)](#).

The following procedures are used to replace Fan Assembly P/N 890-0001-xx when it is used to cool shelves not populated with **HCMIM** or **HIPR2** cards.


- [Procedure - Power Down the Fan Assembly](#)
- [Procedure - Remove Fan Cables and Fan Assembly](#)
- [Procedure - Install the Fan Assembly](#)
- [Procedure - Power Up the Fan Assembly](#)

### A.18.3.1 Procedure - Power Down the Fan Assembly

Use the following procedure to power down the fan assembly.

1. The fuse card located on the Fuse and **Alarm** Panel is marked **FAN A** and **FAN B**. Fuse positions 6, 12, and 18 are the correct locations on the **FAP** faceplate. The fans are fused at 3As, with blue flags per feed. Remove the appropriate fuse for the fan assembly being replaced according to the following:
  - Fuse position 6 is for the fan unit directly below the x100 shelf.
  - Fuse position 12 is for the fan directly below the x200 shelf.
  - Fuse position 18 is for the fan directly below the x300 shelf.
2. When both the A side and B side power is removed from the fan unit, all of the **LEDs** on the fan controller card (located on the left side of the front of the fan unit) are no longer illuminated and the all fan motors are off.

Figure A-19 Fan card with LEDs on front of fan assembly unit




### A.18.3.2 Procedure - Remove Fan Cables and Fan Assembly

Use the following procedure to remove fan cables and fan assembly.

1. At the fan assembly, place fiber paper on the shelf below where the fan is to be replaced. This ensures that nothing drops into the area or equipment below.
2. From the front of the frame remove the fan filter from the fan assembly.
3. From the rear of the fan unit, loosen the screws on the fan unit connector marked **FAN A POWER**. Remove the connector from the fan unit.
4. From the rear of the fan unit, loosen the screws on the fan unit connector marked **FAN B POWER**. Remove the connector from the fan unit.
5. Remove the screws from the the left and right sides of the rear of the fan tray bracket. There are two screws on each side. These screws must be removed from the rear of the frame.

**Figure A-20 Fan Assembly Rear Bracket Screws.**

Screws to be removed. Note: total of 4, 2 on each side




6. With the screws removed, carefully push on the rear of the unit until the fan assembly moves forward about an inch.
7. From the front of the frame remove the fan assembly from the the fan bracket. For easier removal, tilt the unit as it is removed.

### A.18.3.3 Procedure - Install the Fan Assembly

Use the following procedure to install the fan assembly.

1. Remove the new fan unit from the container. The fan unit is shipped with the three fans already installed.

**Figure A-21 Fan Assembly**



2. Insert the fan unit into the fan bracket. Tilt the unit up as it is pushed in and completely inserted into the bracket. After insertion, be sure the front of the fan unit is recessed about 1/2 inch from the front frame rails to allow the door to close.

**Figure A-22 Fan tray inserted into fan tray bracket in the frame - front view**



3. When the fan unit is aligned and in place, attach the fan unit to the fan tray bracket by tightening the screws on the left and right sides of the rear of the fan tray bracket. There are two screws on each side. These screws must be tightened from the rear of the frame.


**Figure A-23 Tighten rear fan tray screws**



4. From the front of the frame install the fan filter into the fan assembly.

5. At this time check and tighten all screws, including the screws holding the side brackets to the frame (if necessary). The side bracket screws should be tightened fully from the rear of the frame. Use a long hex driver or flat head screw driver.

**Figure A-24 Tighten fan side bracket screws**



6. Connect the fan cable at the rear of the fan assembly on the J9 connector to the **FAN A POWER**.
7. Connect the fan cable at the rear of the fan assembly on the J8 connector to the **FAN B POWER**.
8. Remove the piece of fiber paper on the top of the shelf below where the fan assembly was installed. This procedure is complete.

**▲ Caution:**

Before powering up the fans, ensure that the shelf directly above the fan does not contain any empty slots. Install an air management card in any empty slots to ensure proper air flow. These filler cards have no electrical connection to the system. See [Replacing a Card in the EAGLE](#) for general card installation guidelines.

### A.18.3.4 Procedure - Power Up the Fan Assembly

Use the following procedure to power up the fan assembly.

All fans are fused at 3A (blue) per feed.


**▲ Caution:**

Before powering up the fans, ensure that the shelf directly above the fan does not contain any empty slots. Install an air management card in any empty slots to ensure proper air flow. These filler cards have no electrical connection to the system. See [Replacing a Card in the EAGLE](#) for general card installation guidelines.



1. After the fan is installed, the powering up process depends on the shelf location.
  - a. The fuse cards located on the Fuse and **Alarm** Panel are marked **FAN A** and **FAN B**, fuse positions 6, 12, and 18 are marked correct locations on the **FAP** faceplate.
  - b. Fuse position 6 is for the fan unit directly below the x100 shelf.
  - c. Fuse position 12 is for the fan directly below the x200 shelf.
  - d. Fuse position 18 is for the fan directly below the x300 shelf.
  - e. All fans are to be fused at 3As, with blue flags, per feed.
  - f. Fill out the fuse card completely.
  - g. Ensure the FAP fuse location for the fan is properly labeled.
2. Fifteen seconds after both the A side and B side power is connected to the fan assembly all of the **LEDs** on the fan controller card (located on the left side of the front of the fan assembly) are green.

**Figure A-25 Fan card with LEDs on front of fan assembly**



3. When the fans are powered up and running, a test must be conducted to ensure proper service.

Go to the system terminal.

4. Check to see if the fan feature is activated.

At the terminal, enter the command:

```
rtrv-feat
```

Example output:

```
rlghncxa03w 04-01-28 11:34:04 EST EAGLE 34.0.0.
```

EAGLE FEATURE LIST

|         |       |          |       |         |       |
|---------|-------|----------|-------|---------|-------|
| GTT     | = on  | GWS      | = off | NRT     | = off |
| X25G    | = off | LAN      | = off | CRMD    | = off |
| SEAS    | = off | LFS      | = off | MTPRS   | = off |
| FAN     | = off | DSTN5000 | = off | WNP     | = off |
| CNCF    | = off | TLNP     | = off | SCCPCNV | = off |
| TCAPCNV | = off | IPISUP   | = off | DYNRTK  | = off |
| X252000 | = off | INP      | = off | PLNP    | = off |
| NCR     | = off | ITUMTPRS | = off | SLSOCB  | = off |
| EGTT    | = off | VGTT     | = off | MGTT    | = off |
| MPC     | = off | ITUDUPPC | = off | GFLEX   | = off |
| GPORT   | = off | MEASPLAT | = off | TSCSYNC | = off |
| E5IS    | = off |          |       |         |       |

;

If the fan feature is off (illustrated in the example), go to 5. Otherwise, go to 6.

5. At the terminal, enter the command: `chg-feat:fan=on`

With this command the user will perform the tests beginning with 7.

6. At the terminal, enter the command: `rept-stat-trbl`

Check to see that there are no fan errors. Specifically, check that there are no "#302 Cooling Fan Failure" errors. Next, perform the tests beginning with 7.

7. Fan Verification (perform 7 through 12 for each fan assembly).

Move to the rear of the frame and remove the A **POWER** cable from the **FAN** unit. Result: Fan 2 and Fan 3 **LEDs** will blink as the fans speed up to maximum speed. This may take up to 15 seconds. Once maximum speed has been reached Fan 2 and Fan 3 **LEDs** on the Fan Controller card will be solid green. Fan 1 **LED** should be red. The controller **LED** should be blinking green. Fan 1 should stop running and the **MINORLED** should be lit.

8. At the system terminal enter the command: `rept-stat-trbl`

Test each fan to ensure that the alarm and the units are working correctly. The terminal reports:

```
302 Cooling Fan Failure
```

9. Replace the A **POWER** cable on the back of the **FAN** unit and secure the connector.

Result: All fans are running and the **MINORLED** is not lit. The terminal reports:

```
303 Cooling Fans Normal
```

10. Remove the B **POWER** cable from the **FAN** unit.

Result: Fan 1 and Fan 2 **LEDs** will blink as the fans speed up to maximum speed. This may take up to 15 seconds. Once maximum speed has been reached Fan 1 and Fan 2 **LEDs** will be solid green. Fan 3 **LED** should be red. The fan controller **LED** should be blinking. Fan 3 should stop running and the **MINORLED** should be lit.

11. At the system terminal enter the command: `rept-stat-trbl`

Test each fan to ensure that the alarm and the units are working correctly. The terminal reports:

```
302 Cooling Fan Failure
```

12. Replace the B **POWER** cable on the back of the **FAN** unit and secure the connector.

Result: The fans are running and the **MINORLED** is not lit. The terminal reports:

```
303 Cooling Fans Normal
```

13. Repeat 7 through 12 for each fan unit installed.

This procedure is complete.

# B

## Holdover Clock Troubleshooting Procedures

### B.1 Introduction

Most alarm conditions in the holdover clock are not out-of service or service-affecting conditions. The system is designed with redundant power, reference inputs, clock input cards, stratum clock cards and output card protection switching.

The only true out-of-service condition is when all power is lost to a shelf, or all reference inputs and both stratum clock cards fail. Before taking any action on the system, such as removing cards, first consider the following troubleshooting guidelines:

- Do not touch the shelf until you have analyzed the condition and know the possible result of any planned corrective actions.
- Do not touch the shelf until you have been properly grounded.
- Both major and minor alarms in the shelf require immediate attention. But, very few alarms in the holdover clock system are service affecting. Improper corrective actions could be service affecting.
- Do not remove an **ST3** clock card from the shelf, unless you are certain it is the cause of the condition. This is especially true if the **ST** clock card(s) is (are) in the holdover mode (the **HOLD OV/HOLDOVER** lamp is lit, or the **HOLD OV/HOLDOVER** and **INP TOL** lamps are lit). Removing both **ST** clock cards in this condition causes total loss of all outputs from the shelf and/or system.
- Write down any alarm and normal lamp conditions in the shelf. These will help you to determine where to look for the cause of the condition.

### B.2 Interpreting System Alarms, Lamps And Trouble Isolation

Alarms generated by the holdover clock are reported through the Eagle. All alarm conditions are defined in [Corrective Maintenance](#).

When troubleshooting, write down all abnormal and normal lamp conditions for the shelf with the alarm lamp lit on the **SAI** card. This will assist in analyzing and isolating the cause of the condition. Do not start removing or replacing cards to attempt to clear alarms, as it could lead to crashing EAGLE.

Tables to aid in troubleshooting are listed in the following sections. Once the basic trouble has been isolated and it has been determined that an individual card is defective, perform the appropriate card replacement procedure in [Card Removal/Replacement Procedures](#).

**Table B-1 Input and ST3 Alarm Conditions**

| SAI/<br>MISLAMPS                     | ABNORMAL<br>CARD<br>LAMPS                                                                                                                                                                                                                                | ACTIVATED<br>OFFICE ALARMS<br>AND SHELF<br>STATUS                                                                                                                                                                                       | ACTIVATED<br>CLOCK STATUS A<br>AND B | CONDITION<br>TYPE # (NOTE) |
|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|----------------------------|
| <b>MAJOR</b> and<br><b>MINOR</b> lit | <b>ST3</b> A and B<br>= <b>FAIL</b> ,<br><b>LOCK</b> , and<br>REF B lit                                                                                                                                                                                  | Visual = <b>MAJOR</b> and<br><b>MINOR</b><br><b>Shelf</b> Status =<br><b>MAJSI</b> , <b>MINSI</b> , and<br><b>CLKL</b> .<br>( <b>HOLDOVERALAR</b><br><b>M</b> switch <b>SW3</b> on<br>backplane is set to<br><b>MAJ</b> or <b>MIN</b> ) | None                                 | 1                          |
| <b>MAJOR</b> and<br><b>MINOR</b> lit | Input cards A<br>and B = <b>FAIL</b><br>lit,<br>frequency/bit<br>rate lamp off,<br><b>SRFL</b> lit ( <b>ACI</b><br>only)<br><b>ST3</b> A and B<br>= <b>FAIL</b> ,<br><b>LOCK</b> , and<br>REF B lit                                                      | Visual = <b>MAJOR</b> and<br><b>MINOR</b><br><b>Shelf</b> Status =<br><b>MAJSI</b> , <b>MINSI</b> , and<br><b>CLKL</b> .<br>( <b>HOLDOVERALAR</b><br><b>M</b> switch <b>SW3</b> on<br>backplane is set to<br><b>MAJ</b> or <b>MIN</b> ) | None                                 | 2                          |
| <b>MINOR</b> lit                     | Input card A<br>or B = <b>FAIL</b> lit,<br>frequency/bit<br>rate lamp off<br>or lit, <b>SRFL</b> lit<br>( <b>ACI</b> only)<br><b>ST3</b> A and B<br>= <b>REF</b> (A or<br>B) lamp lit<br>(associated<br>with input<br>card with<br><b>FAIL</b> lamp off) | Visual = <b>MINOR</b><br><b>Shelf</b> Status =<br><b>MINSI</b> , and <b>CLKL</b><br>( <b>HOLDOVERALAR</b><br><b>M</b> switch <b>SW3</b> on<br>backplane is set to<br><b>MAJ</b> or <b>MIN</b> )                                         | None                                 | 3                          |
| <b>MINOR</b> lit                     | <b>ST3</b> A and B<br>= <b>LOCK</b> lit                                                                                                                                                                                                                  | Visual = <b>MINOR</b><br><b>Shelf</b> Status = <b>MINSI</b><br>( <b>HOLDOVERALAR</b><br><b>M</b> switch <b>SW3</b> on<br>backplane is set to<br><b>MAJ</b> or <b>MIN</b> )                                                              | None                                 | 4                          |

**Table B-1 (Cont.) Input and ST3 Alarm Conditions**

| SAI/<br>MISLAMPS                                         | ABNORMAL<br>CARD<br>LAMPS                                                                                                                                                                                               | ACTIVATED<br>OFFICE ALARMS<br>AND SHELF<br>STATUS                                                                                                                                                                  | ACTIVATED<br>CLOCK STATUS A<br>AND B | CONDITION<br>TYPE # (NOTE) |
|----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|----------------------------|
| <b>MINOR</b><br>periodically<br>lights, then<br>goes off | Input card A<br>and/or B =<br><b>FAIL</b><br>periodically<br>goes on and<br>off. First<br>occurrence<br>only the<br><b>SRCACT/<br/>SRCACTIVE</b><br>on <b>FAIL</b> card<br>goes off and<br>lights on the<br>other card. | Visual = Periodic<br><b>MINOR</b><br><b>Shelf</b> Status =<br>Periodic <b>MINSI</b> and<br><b>CLKL</b><br>( <b>HOLDOVERALAR</b><br><b>M</b> switch <b>SW3</b> on<br>backplane set to<br><b>MAJ</b> or <b>MIN</b> ) | None                                 | 5                          |
| <b>MAJOR</b> lit                                         | <b>ST3</b> A or B =<br><b>FAIL</b> lit                                                                                                                                                                                  | Visual = <b>MAJOR</b><br><b>Shelf</b> Status =<br><b>MAJSI</b><br>( <b>HOLDOVERALAR</b><br><b>M</b> switch <b>SW3</b> on<br>backplane is set to<br><b>MAJ</b> or <b>MIN</b> )                                      | None                                 | 6                          |

For the corrective action to take for each condition type, refer to [Table B-2](#).

**Table B-2 Input and ST3 Corrective Actions**

| CONDITIONTYPE<br># (From<br><a href="#">Table B-1</a> ) | CONDITION AND PROBABLE<br>CAUSE                                                                                                                                            | CORRECTIVE ACTION                                                                                                                                  |
|---------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| 1                                                       | No input cards installed. Outputs are as accurate as free-running clock cards. Timed network elements reporting high slip rate.                                            | Install at least one input card.(See Appendix A).                                                                                                  |
| 2                                                       | Input references A and B have failed (frequency/bit rate lamp off) or have exceeded <b>BPV</b> , <b>OOF</b> , or excessive zeros parameters (frequency/bit rate lamp lit). | Check input reference connections at the shelf and source ends. Reconnect if required. Isolate and repair input reference facilities, if required. |
|                                                         | The input reference facility framing format rearranged from D4 to <b>ESF</b> , or vice versa, and the input card options were not changed to match it.                     | Change the option switch settings to match the current framing format. See <i>Installation Guide</i> .                                             |
|                                                         | The input reference has been recently reassigned, and the signal amplitude is too high.                                                                                    | Wire a 100 ohm, 1/4 watt resistor across T and R input terminals on the shelf backplane.                                                           |
|                                                         | Both input cards have failed.                                                                                                                                              | Replace both input cards (See Appendix A).                                                                                                         |

**Table B-2 (Cont.) Input and ST3 Corrective Actions**

| CONDITIONTYPE # (From Table B-1) | CONDITION AND PROBABLE CAUSE                                                                                                                                                                                      | CORRECTIVE ACTION                                                                                                                                                                                                                                                                              |
|----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3                                | Input reference A or B has failed (frequency/bit rate lamp off) or has exceeded <b>BPV</b> , <b>OOF</b> , or excessive zeros parameters (frequency/bit rate lamp lit).                                            | Check input reference connections at the shelf and source ends. Reconnect if required. Isolate and repair input reference A or B facility (if required).                                                                                                                                       |
|                                  | Input card A or B has failed.                                                                                                                                                                                     | Replace the input card with the <b>FAIL</b> lamp lit (See Appendix A).                                                                                                                                                                                                                         |
|                                  | The input reference facility framing format rearranged from D4 to <b>ESF</b> , or vice versa, and the input card options were not changed to match it.                                                            | Change the option switch settings to match the current framing format.                                                                                                                                                                                                                         |
|                                  | The input reference has been recently reassigned, and the signal amplitude is too high.                                                                                                                           | Wire a 100 ohm, 1/4 watt resistor across T and R input terminals on the shelf backplane.                                                                                                                                                                                                       |
| 4                                | Active input reference has exceeded pull-in range of <b>ST3</b> cards. Timed network elements reporting high slip rate.                                                                                           | Press transfer ( <b>XFR</b> ) pushbutton on either input card to switch <b>SRC</b> (source) <b>ACTIVE</b> lamp to the other input card. <b>ST3 A</b> and <b>B LOCK</b> lamps go off in less than 40 seconds.<br><br>Isolate source of frequency offset on input reference facility and repair. |
| 5                                | Input reference facility (A and/or B) line coding rearranged from <b>AMI</b> to <b>B8ZS</b> and input card(s) option switches were not set to match the change. Input card <b>BPV</b> spec periodically exceeded. | Change input card(s) option switch settings from <b>AMI</b> to <b>B8ZS</b> .                                                                                                                                                                                                                   |
| 6                                | <b>ST3 A</b> or <b>B</b> card has failed and squelched its outputs. Outputs are receiving their reference from the <b>ST3</b> with its <b>FAIL</b> lamp off. Outputs are not affected.                            | Replace the <b>ST3</b> card (A or B) with the <b>FAIL</b> lamp lit (Appendix A).                                                                                                                                                                                                               |



**Note:**

For a description of each condition type, refer to [Table B-3](#).

**Table B-3 Shelf and Output Alarm Conditions - Not Related to Input and ST Conditions**

| SAI/MISLAMPS                                        | ABNORMAL SHELF AND CARD LAMPS                                                                                                                                                                                                                                                                                                                      | ACTIVATED OFFICE ALARMS AND SHELF STATUS                                                                                                    | ACTIVATED CLOCK STATUS A AND B                                                                 | CONDITION TYPE # (NOTE) |
|-----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|-------------------------|
| None lit                                            | All lamps on all cards are off                                                                                                                                                                                                                                                                                                                     | Visual = <b>CRITICAL (MISONLY), MAJOR, and MINOR</b><br>Shelf Status = <b>CRTSI (MIS only), MAJSI, MINSI, and BATTALM</b>                   | None                                                                                           | 1                       |
| <b>MINOR</b> lit                                    | <b>MCA-5 = All 10 PORTALM</b> lamps lit                                                                                                                                                                                                                                                                                                            | Visual = <b>MINOR</b><br>Shelf Status = <b>MINSI</b>                                                                                        | None                                                                                           | 2                       |
| <b>MINOR</b> lit                                    | Any <b>TO</b> card = <b>PORTALM</b> lit<br>Output protection pushbutton lamps = Lamp over <b>TO</b> card with <b>PORTALM</b> lit, and like <b>HSTO</b> card light for a short period of time (approx 3 seconds) then goes off<br><b>MCA-5 = AUTO</b> lamp flashes for approx 6 seconds when <b>HS</b> protection switch is activated and released. | Visual = <b>MINOR</b><br>Shelf Status = <b>MINSI</b> and <b>PRTA (SW1 positions 3 and 5 on MCA-5 set to MAJ or MIN)</b>                     | None                                                                                           | 3                       |
| <b>MINOR</b> lit                                    | <b>Shelf</b> fuse A or B = Lamp lit                                                                                                                                                                                                                                                                                                                | Visual = <b>MINOR</b><br>Shelf Status = <b>MINSI</b> , and <b>BATTALM. POWERALARM</b> switch <b>SW2</b> on backplane is set to <b>MIN</b> ) | None                                                                                           | 4                       |
| <b>MAJOR</b> lit                                    | Any <b>TO, ST, or MCA-5 = FAIL</b> lit                                                                                                                                                                                                                                                                                                             | Visual = <b>MAJOR</b><br>Shelf Status = <b>MAJSI (MCA-5 SW1, positions 3 and 5 set to MAJ)</b>                                              | Visual = <b>MAJOR</b><br>Shelf Status = <b>MAJSI (MCA-5 SW1, positions 3 and 5 set to MAJ)</b> | 5                       |
| <b>FAIL</b> and <b>MAJOR</b> lit ( <b>MIS</b> only) | <b>MIS = FAIL</b> lit                                                                                                                                                                                                                                                                                                                              | Visual = <b>MAJOR</b><br>Shelf Status = <b>MAJSI</b>                                                                                        | None                                                                                           | 5                       |



**Table B-3 (Cont.) Shelf and Output Alarm Conditions - Not Related to Input and ST Conditions**

| SAI/MISLAMPS                                                                                                                                                                                                                                                                   | ABNORMAL SHELF AND CARD LAMPS                                                                                                                                                                           | ACTIVATED OFFICE ALARMS AND SHELF STATUS                                                                                                                                                                                                                                                                                       | ACTIVATED CLOCK STATUS A AND B | CONDITION TYPE # (NOTE) |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|-------------------------|
| <b>MAJOR</b> and <b>MINOR</b> lit                                                                                                                                                                                                                                              | <b>Shelf</b> fuse A or B = Lamp lit                                                                                                                                                                     | Visual = <b>MAJOR Shelf</b> Status = <b>MAJSI</b> , <b>MINSI</b> , and <b>BATTALM</b> . ( <b>POWERALARM</b> switch <b>SW2</b> on backplane is set to <b>MAJ</b> )                                                                                                                                                              | None                           | 4                       |
| <b>MAJOR</b> and <b>MINOR</b> lit                                                                                                                                                                                                                                              | Any <b>TO</b> card = <b>FAIL</b> lamp lit<br>Output protection pushbutton lamp = Lamps lit over <b>TO</b> with <b>FAIL</b> lamp lit and like <b>HSTO</b> card ( <b>HS</b> protection switch activated). | Visual = <b>MAJOR</b> and <b>MINOR Shelf</b> Status = <b>MAJSI</b> and <b>MINSI</b> ( <b>MCA-5 SW1</b> , positions 3 and 5 set to <b>MIN</b> )                                                                                                                                                                                 | None                           | 5                       |
| <b>MAJOR</b> and <b>MINOR</b> lit<br>or<br><b>MINOR</b> lit<br>or None lit<br>( <b>MAJOR</b> and <b>MINOR</b> lit if <b>MCA-5 SW1</b> , positions 3 and 5 set to <b>MAJ</b> ; if <b>SW1</b> set to <b>MIN</b> , then <b>MIN</b> lit; if set to <b>NOALARM</b> , then None lit) | Output protection pushbutton lamps = Lamps over <b>TO</b> cards and <b>HS</b> cards alternately light and then go off.                                                                                  | Visual = <b>MAJOR</b> and <b>MINOR</b> or <b>MINOR</b> or None<br><b>Shelf</b> Status = <b>MAJSI</b> and <b>MINSI</b> or <b>MINSI</b> or None<br>( <b>MAJOR</b> and <b>MINOR</b> if <b>MCA-5</b> card <b>SW1</b> set to <b>MAJ</b> ; <b>MINOR</b> if <b>SW1</b> set to <b>MIN</b> ; none if <b>SW1</b> set to <b>NOALARM</b> ) | None                           | 6                       |
| <b>MINOR</b> lit<br>or<br><b>MAJOR</b> and <b>MINOR</b> lit<br>( <b>MINOR</b> if <b>MCA-5 SW1</b> , positions 3 and 5, are set to <b>MIN</b> or <b>NOALARM</b> ; <b>MAJOR</b> and <b>MINOR</b> lit if set to <b>MAJ</b> )                                                      | Any <b>TO</b> card = <b>PORTALM</b> lit<br>Output protection pushbutton lamps = Lamps lit over <b>TO</b> card with <b>PORTALM</b> lit, and like <b>HSTO</b> card.                                       | Visual = <b>MINOR</b> or <b>MAJOR</b> and <b>MINOR Shelf</b> Status = <b>MINSI</b> and <b>PRTA</b> or <b>MAJSI</b> , <b>MINSI</b> , and <b>PRTA</b> ( <b>MINOR</b> if <b>SW1</b> positions 3 and 5 on <b>MCA-5</b> set to <b>MIN</b> or <b>NOALARM</b> ; <b>MAJOR</b> and <b>MINOR</b> if set to <b>MAJ</b> )                  | None                           | 7                       |

**Table B-3 (Cont.) Shelf and Output Alarm Conditions - Not Related to Input and ST Conditions**

| SAI/MISLAMPS                                                                                                                                                                                                                                                | ABNORMAL SHELF AND CARD LAMPS                                                                                                                  | ACTIVATED OFFICE ALARMS AND SHELF STATUS                                                                                                                                                                                                                                                                                         | ACTIVATED CLOCK STATUS A AND B | CONDITION TYPE # (NOTE) |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|-------------------------|
| <p><b>MINOR</b> lit<br/>or<br/><b>MAJOR</b> lit<br/>or<br/>None lit<br/>(<b>MINOR</b> lit if <b>MCA-5 SW1</b>, positions 3 and 5 set to <b>MIN</b>; if <b>SW1</b> set to <b>MAJ</b>, then <b>MAJOR</b> is lit; if set to <b>NOALARM</b>, then None lit)</p> | <p>Output protection pushbutton lamps = Lamps lit over a <b>TO</b> card and like <b>HSTO</b> cards<br/><b>MCA-5 = MAN</b> lamp is flashing</p> | <p>Visual = <b>MINOR</b><br/>or<br/><b>MAJOR</b><br/>or<br/>None<br/><b>Shelf Status = MINSI</b><br/>or<br/><b>MAJSI</b><br/>or<br/>None<br/>(<b>MINOR</b> lit if <b>MCA-5 SW1</b>, positions 3 and 5 set to <b>MIN</b>; if <b>SW1</b> set to <b>MAJ</b>, then <b>MAJOR</b> is lit; if set to <b>NOALARM</b>, then None lit)</p> | <p>None</p>                    | <p>8</p>                |



**Note:**

For the corrective action to take for each condition type, refer to [Table B-4](#).

**Table B-4 Shelf and Output Corrective Actions - Not Related to Input and ST Conditions**

| CONDITIONTYPE # | CONDITION AND PROBABLE CAUSE                                                                                                                                                                                                         | CORRECTIVE ACTIONS                                                                                                                                                                                                                                                            |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1               | Loss of Battery A and B to shelf. All outputs are squelched. Causes could be from operating error, office battery source failure, blown fuses, or a component failure, e.g., isolation diode which shorts battery to battery return. | <ol style="list-style-type: none"> <li>1. Determine cause of loss of battery and repair.</li> <li>2. Restore office battery source.</li> <li>3. Replace blown fuses in battery distribution bays, miscellaneous fuse bays, and panels, and/or on <b>DCD</b> shelf.</li> </ol> |

**Table B-4 (Cont.) Shelf and Output Corrective Actions - Not Related to Input and ST Conditions**

| CONDITIONTYPE<br>#<br>(FROM Table B-3) | CONDITION AND PROBABLE CAUSE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | CORRECTIVE ACTIONS                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2                                      | <p>Communication between <b>MCA-5</b> and <b>TO</b> cards is not functioning.</p> <p>Microprocessor on the <b>MCA-5</b> is failed or garbled.</p> <p>Does not affect outputs. Automatic <b>TO</b> protection switching function disabled. Manual <b>TO</b> protection switching function is still operational.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <ol style="list-style-type: none"> <li>1. No <b>TO</b> cards in shelf. Install at least one <b>TO</b> card.</li> <li>2. No input references or input cards, and no clock cards installed. Install at least one clock (<b>ST</b>) card (See Appendix A.)</li> <li>3. <b>MCA-5</b> communications bus or microprocessor garbled. Remove and reinsert the <b>MCA-5</b> card to clear bus and microprocessor.</li> <li>4. <b>MCA-5</b> microprocessor failed. Replace <b>MCA-5</b> card (Appendix A).</li> </ol>                                                                                                                                                                                                   |
| 3                                      | <p><b>HS</b> protection switch activated, then released because of:</p> <ul style="list-style-type: none"> <li>• Unterminated cable on <b>TOTA</b> or <b>TOTL</b> output,</li> <li>or,</li> <li>• Shorted cable on <b>TO</b> output.</li> </ul> <p>When the condition occurred, an <b>HS</b> protection switch was activated, <b>PORTALM</b> on <b>TO</b> goes off, and lights on the <b>HSTO</b> card, output protection pushbutton lamps over the <b>TO</b> and <b>HS</b> light, <b>MCA-5 AUTO</b> lamp flashes, <b>HS</b> protection switch releases, <b>PORTALM</b> on <b>HSTO</b> goes off and lights on <b>TO</b>, output protection pushbutton lamps go off, and <b>MCA-5 AUTO</b> lamp stops flashing (duration = 3 to 6 seconds). Non-failed ports on <b>TO</b> with <b>PORTALM</b> lit lost output for one millisecond during <b>HS</b> protection switch activation and release. Failed <b>TO</b> port is out of service.</p> | <ol style="list-style-type: none"> <li>1. Press and hold the output protection pushbutton over the <b>TO</b> card with <b>PORTALM</b> lamp lit. <b>MCA-5</b> lights <b>PORTALM</b> lamp(s) of failed <b>TO</b> port. Release pushbutton.</li> <li>2. Isolate and repair cable or <b>NE</b> connected to that <b>TO</b> port.</li> <li>3. If port connection is new and not yet terminated at <b>NE</b>, then either insert disabling pin in that port's disabling jack on <b>TO</b> card faceplate, or remove cable from output wire-wrap panel, or place an appropriate resistor termination across tip (T) and ring (R) of cable at <b>NE</b> end, until ready to connect cable at <b>NE</b> end.</li> </ol> |
| 4                                      | <p>Loss of Battery A or B to shelf. Does not affect outputs. Causes could be from operating error, blown fuse, or a component failure, e.g., isolation diode which shorts battery to battery return.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <ol style="list-style-type: none"> <li>1. Determine cause of loss of battery and repair.</li> <li>2. Replace blown fuses in battery distribution bays, miscellaneous fuse bays, and panels, and/or on <b>DCD</b> shelf.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 5                                      | <p><b>Card</b> with <b>FAIL</b> lamp lit has failed, except for input card which causes a <b>MINOR</b> alarm when its <b>FAIL</b> lamp lights. Outputs are not affected if <b>MCA-5</b> and <b>HS</b> slots are equipped.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | <p>Replace the card with the <b>FAIL</b> lamp lit (Appendix A). Release <b>HS</b> protection switch, if activated, by pressing lit <b>HS</b> pushbutton until switch releases.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

**Table B-4 (Cont.) Shelf and Output Corrective Actions - Not Related to Input and ST Conditions**

| CONDITIONTYPE<br>#<br>(FROM <a href="#">Table B-3</a> ) | CONDITION AND PROBABLE CAUSE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | CORRECTIVE ACTIONS                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 6                                                       | A <b>TO</b> card's microprocessor has lost its ability to process data. The <b>TO</b> cards are alternately being switched to <b>HS</b> protection and then released. One millisecond loss of outputs each time a <b>TO</b> is switched to or released from <b>HS</b> protection.                                                                                                                                                                                                                                                                | Manually switch each <b>TO</b> card to the <b>HS</b> , replace the <b>TO</b> card (Appendix A) and release the <b>HS</b> switch. Continue until the malfunctioning <b>TO</b> card is located and removed from the shelf.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 7                                                       | Output port failed on <b>TO</b> card with <b>PORTALM</b> lamp lit. <b>HS</b> protection switch activated. Loss of output on failed port. Other output on same <b>TO</b> lost for one millisecond when <b>HS</b> protection switch activated.<br><br>When condition occurred, an <b>HS</b> protection switch was activated, <b>PORTALM</b> lamp on <b>TO</b> card remained lit, output protection pushbutton lamps over <b>TO</b> and <b>HS</b> slots lit, and <b>MCA-5</b> card's <b>AUTO</b> lamp flashes for 6 seconds and then lights steady. | <ol style="list-style-type: none"> <li>1. Press and hold the output protection pushbutton over the <b>TO</b> card with the <b>PORTALM</b> lamp lit. <b>MCA-5</b> lights <b>PORTALM</b> lamp(s) of failed <b>TO</b> port. Release pushbutton.</li> <li>2. Remove <b>TO</b> card with <b>PORTALM</b> lamp lit.</li> <li>3. Set option switch settings on the replacement <b>TO</b> card identical to settings on removed <b>TO</b> card.</li> <li>4. Insert replacement <b>TO</b> card in shelf slot and wait 10 seconds for <b>TO</b> to warm-up. Verify <b>ST</b>, <b>INPUT</b> and <b>OPTION</b> lamps are lit and <b>PORTALM</b> and/or <b>FAIL</b> lamps are not lit.</li> <li>5. Press output protection pushbutton over <b>HSTO</b> until pushbutton lamps go out (releases <b>HS</b> switch). <b>MCA-5</b> card's <b>AUTO</b> lamp flashes for 6 seconds and then lights steady.</li> </ol> |
| 8                                                       | <b>TO</b> card manually switched to <b>HSTO</b> card                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Release the manual <b>HS</b> switch by pressing the lit pushbutton over the <b>HSTO</b> card for 3 seconds.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |



**Note:**

For a description of each condition type, refer to [Table B-3](#).

# C

## Part Numbers

### C.1 Overview

This chapter lists the part numbers of Oracle equipment, components, cables, and miscellaneous parts described in this manual.

Each table provides the item name, part number, and related notes. Items are listed by their name (as described in this manual) in alphabetical order. Shaded part numbers indicate that the item is obsolete or no longer shipped. Unless the item is indicated as obsolete, the item is still supported in the field.

 **Note:**

Oracle reserves the right to ship compatible part numbers or revisions for new installations and replacements. Always check the latest Hardware Baseline for your release. The latest hardware baseline can be found in the Feature Notice of your release.

RoHS 5/6 - As of July 1, 2006, all products that comprise new installations shipped to European Union member countries will comply with the **EU Directive 2002/95/EC "RoHS"** (Restriction of Hazardous Substances). The exemption for lead-based solder described in the Annex will be exercised. RoHS 5/6 compliant components will have unique part numbers and are identified as the International part number in this manual.

 **Note:**

International part numbers will eventually replace North American part numbers to make all part numbers RoHS compliant. The items of either part number are of equivalent function or quality otherwise.



**WEEE** - All products shipped to European Union member countries comply with the **EU Directive 2002/96/EC**, Waste Electronic and Electrical Equipment. All components that are **WEEE** compliant will be appropriately marked. For more information regarding Oracle's **WEEE** program, contact your sales representative.

## C.2 Cables, Adapters

**Table C-1 EAGLE Cables, Connectors, and Power Cords**

| Name                                    | Part Numbers  |               | Note                                                                                          |
|-----------------------------------------|---------------|---------------|-----------------------------------------------------------------------------------------------|
|                                         | North America | International |                                                                                               |
| Adapter, 15-Pin to 26-Pin               | 830-0425-01   | ---           |                                                                                               |
| Adapter cables                          | 830-0846-01   | 830-1183-01   | backplanes -03 and -04 for source timing and <b>HS</b> clock cable<br>830-0873-xx             |
| <b>Alarm</b> cable                      | 830-0543-01   | ---           | Holdover Clock                                                                                |
| <b>Alarm</b> cable                      | 830-0638-xx   | 830-1163-xx   | see Filtered Rack <b>Alarm</b> cable                                                          |
| <b>AlarmNETRA</b> Server Cable          | 830-0900-xx   | ---           |                                                                                               |
| <b>ATM</b> Cable                        | 830-0987-xx   | ---           | <b>SCSI/DB44</b>                                                                              |
| <b>ATME1/T1</b> cable                   | 830-0959-xx   | ---           | <b>EMS; DB-44 to RJ45</b> 4 Port                                                              |
| B Clock Cable                           | 830-0404-xx   | ---           | replaced by 830-0398-xx ( <b>NA</b> ) or 830-1150-xx ( <b>I</b> )<br>both are for <b>HMUX</b> |
| B Clock Cable                           | 830-0398-xx   | 830-1150-xx   |                                                                                               |
| A and B Frame Clock cable               | ---           | ---           | see B Clock Cable                                                                             |
| <b>BITS</b> clock cable                 | 830-0226-xx   | 830-1146-xx   | Backplanes -03 and -04                                                                        |
| <b>BITS</b> clock cable                 | 830-0873-xx   | ---           | Backplane -06                                                                                 |
| <b>BNC</b> pen end cable                | 830-0625-xx   | 830-1161-xx   |                                                                                               |
| <b>BNC</b> to <b>BNC</b> cable assembly | 830-0624-xx   | 830-1160-xx   |                                                                                               |
| Breaker-to-Terminal Strip Power Cable   | 830-0866-xx   | 830-1236-xx   |                                                                                               |
| <b>CD-ROM</b> Cable                     | 830-0421-xx   | ---           |                                                                                               |
| Frame Ground cable                      | 830-0715-xx   | 830-1171-xx   | <b>ESP</b>                                                                                    |
| Composite clock cable                   | ---           | ---           | See <b>BITS</b> clock cable                                                                   |
| Converter                               | 804-0176-01   | ---           |                                                                                               |
| Crossover ( <b>CAT-5</b> ) Cable        | 830-0723-xx   | 830-1173-xx   |                                                                                               |
| Crossover Patch Panel Cable             | 830-0789-xx   | 830-1178-xx   | <b>DCM</b>                                                                                    |
| <b>DB-26</b> to <b>RJ-45</b>            | 830-1102-02   | 830-1102-02   | for new installations, with shielded Cat 5E cable; <b>E5-ENET</b>                             |

Table C-1 (Cont.) EAGLE Cables, Connectors, and Power Cords

| Name                                                                     | Part Numbers  |               | Note                                                                                                                |
|--------------------------------------------------------------------------|---------------|---------------|---------------------------------------------------------------------------------------------------------------------|
|                                                                          | North America | International |                                                                                                                     |
| <b>DB-26 to DB-26</b>                                                    | 830-1103-02   | 830-1103-02   | for current installations that use <b>DCM</b> cable, 830-0978-xx. Does not support Gigabit Ethernet; <b>E5-ENET</b> |
| <b>DCM</b> , 100- <b>BASETX</b> Interface to unterminated -xx            | 830-0711-xx   | ---           |                                                                                                                     |
| <b>DCM_100 BASETX</b> Interface_DB26 to Non-shielded <b>RJ45</b>         | 830-0978-xx   | ---           |                                                                                                                     |
| <b>DCM</b> 100BASE <b>TX</b> Interface_DB26 to <b>RJ45</b> Plus to Minus | 830-0788-xx   | 830-1177-xx   |                                                                                                                     |
| Drive Power Cable                                                        | 830-0224-xx   | ---           |                                                                                                                     |
| <b>DS1</b> Cable                                                         | 830-0849-xx   | 830-1184-xx   |                                                                                                                     |
| <b>E1</b> cable                                                          | 830-0622-xx   | 830-1233-xx   |                                                                                                                     |
| <b>E1</b> patch cable                                                    | 830-0605-02   | 830-1116-02   |                                                                                                                     |
| <b>E1-T1MIM</b> 22 <b>AWG</b>                                            | 830-0932-01   | 830-1106-xx   |                                                                                                                     |
| <b>E1/T1MIMLIM</b> Cable                                                 | 830-0948-01   | 830-1197-xx   | 4 Port 24 <b>AWG</b>                                                                                                |
| <b>E1/T1MIMLIM</b> to <b>MPL</b> Adapter                                 | 830-0949-01   | 830-1197-01   |                                                                                                                     |
| E5-ENET Fast Copy Adapter - Lower                                        | 830-1343-01   |               |                                                                                                                     |
| E5-ENET Fast Copy Adapter - Upper                                        | 830-1343-02   |               |                                                                                                                     |
| E5-MASP Ethernet Adapter                                                 | 830-1333-02   | 830-1333-02   | Connects to J-17 and J19 on Ctrl shelf backplane 06/07 for E5-OAM Integrated Meas                                   |
| Ethernet cable*                                                          | 830-0788-xx   | 830-1177-xx   | <b>DCM</b> , <b>DSM</b> and <b>EDCM</b>                                                                             |
| External alarm cable                                                     | 830-0435-xx   | 830-1151-xx   |                                                                                                                     |
| Fan cable                                                                | 830-0690-01   | ---           | <b>AC</b> power                                                                                                     |
| Fan power/alarm cable                                                    | 830-0609-01   | 830-1157-01   | incl. with fan assembly                                                                                             |
| Fifty Position Cable Hard Drive I/O                                      | 830-0656-01   | ---           |                                                                                                                     |
| Filter Rack <b>Alarm</b> Cable                                           | 830-0638-xx   | 830-1163-xx   |                                                                                                                     |
| Force Transition <b>Card</b>                                             | 850-0496-01   | ---           |                                                                                                                     |
| Frame Ground cable                                                       | 830-0715-xx   | 830-1171-xx   | <b>ESP</b>                                                                                                          |
| Ground Breaker Panel-to-Frame cable                                      | 830-0830-01   | 830-1181-01   | <b>ESP</b>                                                                                                          |

**Table C-1 (Cont.) EAGLE Cables, Connectors, and Power Cords**

| Name                                      | Part Numbers  |               | Note                                                    |
|-------------------------------------------|---------------|---------------|---------------------------------------------------------|
|                                           | North America | International |                                                         |
| Ground Hub-to-Frame cable                 | 830-0822-xx   | ---           | <b>ESP</b>                                              |
| Hazard Ground Cable                       | 830-0257-xx   | ---           |                                                         |
| High Speed ( <b>BITS</b> ) Clock Cable    | 830-0873-xx   | 830-1189-xx   |                                                         |
| High Speed Source Timing Adapter          | 830-0846-01   | 830-1183-01   |                                                         |
| <b>HMUX</b> Adapter Cable                 | 830-0857-01   | 830-1185-01   |                                                         |
| 1/0 Green Ground Cable                    | 690-0108-07   | 690-0108-R07  |                                                         |
| IMT Cable                                 | 830-1344-xx   | 830-1344-xx   |                                                         |
| Interface Cable                           | 830-0366-xx   | 830-1149-xx   |                                                         |
| Local Maintenance Center Cable            | 830-0231-xx   | 830-1144-xx   |                                                         |
| Loop Back Cable Adapter                   | 830-0763-01   | 830-1176-xx   |                                                         |
| <b>MMI</b> Port Cable                     | 830-0708-xx   | 830-1169-xx   |                                                         |
| Modem/Terminal Cable                      | 830-0709-xx   | 830-1170-xx   |                                                         |
| Multi-port <b>LIM</b> Diagnostic Cable    | 803-0029-0    | ---           |                                                         |
| Multi-port <b>LIM DS0</b> cable           | 830-0772-xx   | ---           | 26 <b>AWG</b> , inactive                                |
| Multi-port <b>LIM DS0</b> cable           | 830-0892-xx   | 830-1194-xx   | 24 <b>AWG</b> , inactive                                |
| Multi-Port Power Cable                    | 830-0814-xx   | 830-1282-xx   |                                                         |
| Network Cable                             | 830-0710-xx   | 830-1257-xx   |                                                         |
| Null Modem Cable                          | 830-0759-xx   | ---           |                                                         |
| Null-Modem for Terminal Cable             | 830-0859-xx   | 830-1186-xx   |                                                         |
| Output panel frame ground cable           | 690-0009      | ---           |                                                         |
| Pin Protector Assembly                    | 830-0880-01   | ---           | use with clock cable replacement (66 min for 6 shelves) |
| Power Cable                               | 830-0315-xx   | 830-1147-xx   |                                                         |
| Power Cable, -48V                         | 830-0651-xx   | ---           |                                                         |
| Power Cable, <b>DC</b> , <b>BP</b> to Hub | 830-0868-xx   | 830-1235-xx   |                                                         |
| Power Cable, <b>DC</b> , Netra 1400       | 830-0814-xx   | 830-1282-xx   |                                                         |
| Power Cable, <b>MPS</b>                   | 830-0965-xx   |               |                                                         |
| Power Ring                                | 830-0908-xx   | ---           | <b>AXi</b>                                              |
| Rack <b>Alarm</b> Cable                   | ---           | ---           | see Filtered Rack <b>Alarm</b> cable                    |
| <b>RAID</b> Power Cable                   | 830-0872-xx   | ---           | <b>DC</b>                                               |
| Remote Maintenance Center Cable           | 830-0233-xx   | 830-1146-xx   |                                                         |



Table C-1 (Cont.) EAGLE Cables, Connectors, and Power Cords

| Name                                                | Part Numbers  |               | Note                                                                  |
|-----------------------------------------------------|---------------|---------------|-----------------------------------------------------------------------|
|                                                     | North America | International |                                                                       |
| <b>RJ45/RJ45</b> Cable ( <b>CAT-5</b> )<br>(Yellow) | 830-0888-xx   | ---           |                                                                       |
| <b>RJ45/RJ45</b> Cable ( <b>CAT-5</b> )<br>(Blue)   | 830-0889-xx   | 830-1192-xx   |                                                                       |
| <b>RJ45</b> to 9 Pin Adapter                        | 830-0917-01   | ---           |                                                                       |
| Row <b>Alarm</b> Cable                              | 830-0232-xx   | 830-1145-xx   |                                                                       |
| Router Power Cable                                  | 830-0869-xx   | 830-1188-xx   | <b>DC</b>                                                             |
| <b>RS232</b> Cable                                  | 830-0527-xx   | 830-1152-xx   |                                                                       |
| <b>ATM</b> Cable                                    | 830-0987-xx   | ---           | <b>SCSI/DB44</b>                                                      |
| Serial I/O Transition <b>Card</b>                   | 850-0514-01   | ---           |                                                                       |
| Serial Interface Converter<br>Cable                 | 830-0531-01   | ---           | inactive                                                              |
| Serial Interface/Modem<br>Adapter                   | 830-0531-03   | 830-1153-03   | use with 830-0394-xx                                                  |
| Serial Interface/Modem<br>Adapter                   | 830-0531-04   | 830-1153-04   | use with 830-0535-xx                                                  |
| Serial <b>DB44</b> to <b>DB9</b> (X4) cable         | 830-0972-01   | 830-1231-01   | 36-inch T1x00 <b>AS</b>                                               |
| Serial Interface, Terminal,<br>Printer Adapter      | 830-0531-02   | 830-1153-02   | use with 830-0394-xx                                                  |
| Straight Through Cable<br>( <b>CAT-5</b> )          | 830-0724-xx   | ---           | <b>RJ-45 CAT-5E</b>                                                   |
| Straight Through Cable (Patch<br>Panel)             | ---           | ---           | see <b>DCM 100BASE TX</b> Interface_DB26 to <b>RJ45</b> Plus to Minus |
| Switch-to-Frame Ground Cable                        | 830-0884-01   | ---           |                                                                       |
| Terminal/Converter Cable                            | 830-0528-01   | ---           |                                                                       |
| Terminal/Printer Cable                              | 830-0535-xx   | 830-1154-xx   |                                                                       |
| Terminal/Server Serial Cable                        | ---           | 830-1201-xx   | DB9F/DB15M Serial w/Flow Control                                      |
| Terminal/Server Serial Port<br>Adapter              | 830-0915-01   | ---           | RJ45-DB15M Adapter_NTW                                                |
| Terminal/Server Serial Port<br>Adapter              | 830-0915-02   | ---           | RJ45-DB15M Adapter_MRV                                                |
| Terminal/Server Serial Port<br>Adapter              | 830-0915-03   | ---           | RJ45-DB15M Adapter_EAGLE/Cyclades                                     |
| Tone and Announcement<br>Server <b>Alarm</b> Cable  | 830-0901-xx   | ---           |                                                                       |
| <b>T1LIM</b> -to- <b>MPL</b> Cable Adapter          | 830-0895-01   | ---           |                                                                       |
| <b>T1MIM</b> cable                                  | 830-0894-xx   | ---           |                                                                       |

**Table C-1 (Cont.) EAGLE Cables, Connectors, and Power Cords**

| Name                   | Part Numbers  |               | Note                       |
|------------------------|---------------|---------------|----------------------------|
|                        | North America | International |                            |
| Terminal cable adapter | ---           | ---           | see Terminal/Printer cable |

\* See [Customer Supplied Ethernet Cable Requirements](#) for customer-supplied Ethernet cable requirements.

## C.3 Customer Supplied Ethernet Cable Requirements

If a customer chooses to supply their own Ethernet cables for EAGLE (customer-supplied cables are not subject to Oracle warranty), the following requirements must be met:

Customer-supplied Ethernet cables for EAGLE must be shielded, meet the industry standard, and avoid dissimilar metals at the RJ45 connector interface. The required standards include:

Metallization (30 or 50µ in. Au over 50µ in. Ni), at the connector interface. The wire required follows: Category 5E SFTP 26AWG 7/34 tinned copper 4 PR per IEC 11801, TIA/EIA 568B, EN 50173 with Overall shield, 26 AWG stranded T.C. drain wire, UL CMR, C(UL) CMR rating, or other agency listing.

Signaling Cables (for example, T1, ATM) are EAGLE proprietary and must be purchased from Oracle.

## C.4 Components

**Table C-2 EAGLE Components**

| Acronym    | Name                                            | Part Numbers    |                  | Note                                                                   |
|------------|-------------------------------------------------|-----------------|------------------|------------------------------------------------------------------------|
|            |                                                 | North America   | International    |                                                                        |
| ---        | Air Management <b>Card</b>                      | 870-1824-0<br>1 | 870-1824-0<br>2  | single slot, needed for empty slots when using Fan Tray<br>890-0001-02 |
| ---        | Breaker Panel <b>Alarm Card</b>                 | 804-1489-0<br>1 | 804-1489-<br>R01 |                                                                        |
| <b>CI</b>  | Clock Interface <b>Card</b><br>(Holdover Clock) | 804-0165-0<br>1 | ---              |                                                                        |
| <b>DSM</b> | <b>Database</b> Service Module                  | 870-2371-0<br>8 | 870-2371-1<br>3  | 1GB                                                                    |

Table C-2 (Cont.) EAGLE Components

| Acronym     | Name                                                                                      | Part Numbers               |               | Note                                                                |
|-------------|-------------------------------------------------------------------------------------------|----------------------------|---------------|---------------------------------------------------------------------|
|             |                                                                                           | North America              | International |                                                                     |
| E5-APP-B    | EAGLE Application B Card                                                                  | 870-3096-XX                |               | See <i>EAGLE Application B Card Hardware and Installation Guide</i> |
| E5-ATM-B    | E5-ATM-B Interface Module                                                                 | 870-2972-01                | 870-2972-01   |                                                                     |
| E5-E1T1-B   | E5-E1T1-B Interface Module                                                                | 870-2970-xx                |               |                                                                     |
| E5-ENET-B   | E5-ENET-B Interface Module                                                                | 870-2971-01                | 870-2971-01   |                                                                     |
| E5-MASP     | E5 Maintenance Administration Subsystem Processor Card                                    | 7346924<br>870-2903-01     |               |                                                                     |
| E5-MCPM-B   | E5-MCPM-B Measurements Collection and Polling Module                                      | 870-3089-01                | 870-3089-01   |                                                                     |
| E5-MDAL     | E5 Maintenance Disk and Alarm Card                                                        | 7346923<br>870-2900-01     |               |                                                                     |
| E5-SM8G-B   | E5-SM8G-B DSM Module                                                                      | 870-2990-01                | 870-2990-01   |                                                                     |
| <b>EDCM</b> | Enhanced <b>Database</b> Communications Module                                            | 870-2197-01                | ---           | double-slot<br>Pre-IP <sup>7</sup> SG 4.0                           |
| HIPR2       | High-Speed IMT Packet Router 2 Module                                                     | 7333484<br>870-2872-01     | 870-2872-01   | Replaces IPMX, HMUX, HIPR                                           |
| <b>IPMX</b> | Interprocessor Message Transport Power and Multiplexer                                    | 870-1171-01                | ---           | replaced by <b>HMUX</b>                                             |
| <b>MCA</b>  | Matrix Controller Automatic (Holdover Clock)                                              | 000-0028-xx                | ---           |                                                                     |
| <b>MCAP</b> | Maintenance Administration Subsystem ( <b>MAS</b> ) Communications Applications Processor | 870-1013-xx<br>870-1307-xx | ---           | Replaced by <b>GPSM-II</b> as of 30.0                               |
| <b>MIS</b>  | Maintenance Interface System <b>Card</b> (Holdover Clock)                                 | 804-0175-xx                | ---           |                                                                     |
| <b>MPS</b>  | Multi-purpose Server                                                                      | 890-1287-xx<br>890-1374-xx | ---           | <b>OEM</b> Open System                                              |

**Table C-2 (Cont.) EAGLE Components**

| Acronym     | Name                                               | Part Numbers  |               | Note                       |
|-------------|----------------------------------------------------|---------------|---------------|----------------------------|
|             |                                                    | North America | International |                            |
| <b>SLIC</b> | Service and Link Interface Card                    | 7094646       |               | Runs multiple applications |
| <b>TOCA</b> | Timing Output Composite Automatic (Holdover Clock) | 804-0166-xx   | ---           |                            |

## C.5 Frames, Backplanes, FAPs, and Fans

**Table C-3 EAGLE Frames, Backplanes, FAPs, and Fans**

| Acronym   | Name                                  | Part Numbers  |               | Note                                                |
|-----------|---------------------------------------|---------------|---------------|-----------------------------------------------------|
|           |                                       | North America | International |                                                     |
| <b>BP</b> | Breaker Panel                         | 804-1423-01   | 804-1423-R01  |                                                     |
| <b>BP</b> | Breaker Panel                         | 870-1814-01   | ---           |                                                     |
|           | <b>Control Shelf</b><br>Backplane -02 | 850-0330-02   | ---           | inactive                                            |
|           | <b>Control Shelf</b><br>Backplane -03 | 850-0330-03   | ---           | inactive                                            |
|           | <b>Control Shelf</b><br>Backplane -04 | 850-0330-04   | ---           |                                                     |
|           | <b>Control Shelf</b><br>Backplane -05 | 850-0330-05   | ---           | not active                                          |
|           | <b>Control Shelf</b><br>Backplane -06 | 850-0330-06   | 850-0330-07   | shelves 6 and 7 no longer supported                 |
|           | <b>Control Shelf</b><br>Backplane     | 7333412       |               | ROHS number                                         |
|           | <b>E1</b> Backplane                   | 850-0459-01   | 850-0459-02   |                                                     |
|           | <b>Extension Shelf</b><br>Backplane   | 850-0356-01   | ---           | inactive                                            |
|           | <b>Extension Shelf</b><br>Backplane   | 850-0356-02   | ---           | inactive                                            |
|           | <b>Extension Shelf</b><br>Backplane   | 850-0356-03   | ---           | inactive                                            |
|           | <b>Extension Shelf</b><br>Backplane   | 850-0356-04   | 850-0356-06   |                                                     |
|           | <b>Extension Shelf</b><br>Backplane   | 7333417       |               | ROHS number                                         |
|           | Fan Assembly                          | 7315823       |               | ROHS number                                         |
|           | Fan Assembly                          | 890-0001-02   | 890-0001-04   | All systems with <b>HCMIMs</b><br><b>EAGLE 33.0</b> |

Table C-3 (Cont.) EAGLE Frames, Backplanes, FAPs, and Fans

| Acronym    | Name                        | Part Numbers          |                            | Note                               |
|------------|-----------------------------|-----------------------|----------------------------|------------------------------------|
|            |                             | North America         | International              |                                    |
|            | Fan Assembly                | 890-1038-01           | 890-1038-03<br>890-1038-04 | Standard frame<br>Heavy Duty frame |
|            | Filter, fan tray            | 551-0032-01           | ---                        |                                    |
|            | Fan filter                  | 551-0022-01           | ---                        |                                    |
| <b>FAP</b> | Fuse and <b>Alarm</b> Panel | 860-0434-01           | 860-0434-03<br>860-0434-04 | Heavy Duty Frame                   |
| <b>FAP</b> | Fuse and <b>Alarm</b> Panel | 870-1606-02 Rev C     | ---                        | Standard Frame<br>60 Amp feeds     |
| <b>FAP</b> | Fuse and <b>Alarm</b> Panel | 870-1606-02 Rev B     | ---                        | Standard<br>40 Amp feeds           |
| <b>FAP</b> | Fuse and <b>Alarm</b> Panel | 870-2320-028 Rev J    | 870-2320-04                | Heavy Duty Frame<br>60 Amp feeds   |
| <b>FAP</b> | Fuse and <b>Alarm</b> Panel | 870-2320-01 Rev A - I | 870-2320-03                | Heavy Duty Frame<br>40 Amp feeds   |
| <b>FAP</b> | Fuse and <b>Alarm</b> Panel | 870-0243-08 Rev C     | ---                        | Control/<br>Extension Frame        |
| <b>FAP</b> | Fuse and <b>Alarm</b> Panel | 870-0243-09 Rev C     | ---                        | Misc Frame                         |
|            | <b>FAP</b> Jumper Board     | 870-1641-01           | ---                        |                                    |
|            | <b>FAP</b> Jumper Board     | 870-1641-02           | ---                        |                                    |
|            | Heavy Duty Frame            | 860-0434-01           | ---                        |                                    |
| <b>FAP</b> | Fuse and <b>Alarm</b> Panel | 870-2804-01           | 870-2804-01                | Control/<br>Extension Frame        |
|            | <b>FAP</b> Shorting Board   | 870-2805-01           | 870-2805-01                |                                    |
|            | <b>FAP</b> Jumper Board     | 870-2806-01           | 870-2806-01                |                                    |

## C.6 Labels

Table C-4 EAGLE Labels

| Name                      | Part Numbers |
|---------------------------|--------------|
| Label, Control frame      | 658-0486-01  |
| Label, Extension frame 00 | 658-0486-02  |

**Table C-4 (Cont.) EAGLE Labels**

| <b>Name</b>                           | <b>Part Numbers</b> |
|---------------------------------------|---------------------|
| Label, Extension frame 01             | 658-0486-03         |
| Label, Extension frame 02             | 658-0486-04         |
| Label, Extension frame 03             | 658-0486-05         |
| Label, Extension frame 04             | 658-0486-06         |
| Label, Miscellaneous frame 00         | 658-0374-01         |
| Label, Miscellaneous frame 01         | 658-0374-02         |
| Label, Heavy Duty Frame               | 658-0374-01         |
| Label, <b>CF-00, Shelf 1</b>          | 658-0490-01         |
| Label, <b>CF-00, Shelf 2</b>          | 658-0490-02         |
| Label, <b>CF-00, Shelf 3</b>          | 658-0490-03         |
| Label, <b>EF-00, Shelf 1</b>          | 658-0490-04         |
| Label, <b>EF-00, Shelf 2</b>          | 658-0490-05         |
| Label, <b>EF-00, Shelf 3</b>          | 658-0490-06         |
| Label, <b>EF-01, Shelf 1</b>          | 658-0490-07         |
| Label, <b>EF-01, Shelf 2</b>          | 658-0490-08         |
| Label, <b>EF-01, Shelf 3</b>          | 658-0490-09         |
| Label, <b>EF-02, Shelf 1</b>          | 658-0490-10         |
| Label, <b>EF-02, Shelf 2</b>          | 658-0490-11         |
| Label, <b>EF-02, Shelf 3</b>          | 658-0490-12         |
| Label, <b>EF-03, Shelf 1</b>          | 658-0490-13         |
| Label, <b>EF-03, Shelf 2</b>          | 658-0490-14         |
| Label, <b>EF-03, Shelf 3</b>          | 658-0490-15         |
| Label, <b>EF-04, Shelf 1</b>          | 658-0490-16         |
| Label, Field Tool Identification      | 658-0941-01         |
| Label, Field Tool Identification wrap | 658-0941-02         |

## C.7 Miscellaneous Parts

**Table C-5 EAGLE Miscellaneous Part Numbers**

| <b>Name</b>               | <b>Part Numbers</b>  |                      | <b>Note</b>                         |
|---------------------------|----------------------|----------------------|-------------------------------------|
|                           | <b>North America</b> | <b>International</b> |                                     |
| <b>Drives</b>             |                      |                      |                                     |
| Dual <b>CD-RW/DVD-ROM</b> | 870-2746-01          | 870-2746-02          | T1x00 <b>AS</b>                     |
| Disk Drive, 120GB         | 804-1804-01          | 804-1804-R01         | <b>ULTRAATA/100/133_7200</b><br>RPM |
| <b>Panels</b>             |                      |                      |                                     |
| <b>Alarm</b> side panel   | 870-0259-02          | ---                  |                                     |

Table C-5 (Cont.) EAGLE Miscellaneous Part Numbers

| Name                                           | Part Numbers  |               | Note                                              |
|------------------------------------------------|---------------|---------------|---------------------------------------------------|
|                                                | North America | International |                                                   |
| <b>Alarm</b> indicator lamps                   | 525-0067-R01  | ---           |                                                   |
| Blank side panel                               | 840-0017-02   | ---           |                                                   |
| Gray tinted plastic rear covers                | 654-0075-01   | 654-0075-R01  |                                                   |
| Brackets, unit separation                      | 652-0609-01   | 652-0609-02   |                                                   |
| Bracket                                        | 652-0954-01   | 652-0954-02   | Fan                                               |
| <b>Kits</b>                                    |               |               |                                                   |
| Cable Rack Mounting Kit                        | 804-1571-01   | ---           | Heavy duty frame                                  |
| Cable Rack Mounting Kit                        | 804-0219-01   | 804-0219-R01  | raised floor                                      |
|                                                | 804-0219-02   | 804-0219-R02  |                                                   |
| External tooth washers                         | 606-0062-01   | ---           | fan bracket                                       |
| Diode Board A                                  | 870-1608-01   | ---           |                                                   |
| Diode Board A                                  | 870-1608-03   | ---           |                                                   |
| Diode Board B                                  | 870-1608-02   | ---           |                                                   |
| Diode Board B                                  | 870-1608-04   | ---           |                                                   |
| Diode Upgrade kit                              | 840-0139-01   | ---           | For 870-1606-02                                   |
| Diode Upgrade kit                              | 840-0139-02   | ---           | For 870-2320-01                                   |
| <b>E1</b> Interface Kit                        | 890-1037-01   | 890-1037-06   |                                                   |
| Mounting hardware kit                          | 840-0092-01   | 840-0092-03   | For heavy duty frame.<br>South America/India only |
| <b>Brackets, Screws, and other small items</b> |               |               |                                                   |
| Brackets, unit separation                      | 652-0609-01   | 652-0609-02   |                                                   |
| Bracket                                        | 652-0954-01   | 652-0954-02   | Fan                                               |
| Bracket, fan tray                              | 652-0012-01   | 652-0012-02   | Fan tray                                          |
| Bracket, side, fan tray                        | 652-0015-01   | 652-0015-02   | Fan tray                                          |
| Heat-shrink                                    | 804-0229-01   | ---           |                                                   |
| Heat-shrink                                    | 804-0228-01   | ---           |                                                   |
| Lugs, # 6 two-hole                             | 502-0085-01   | 502-0085-R01  | <b>FAP</b> connector                              |
| <b>#6 AWG</b>                                  | 690-0131-01   | 690-0131-R01  |                                                   |
| 1/0 pink lug                                   | 804-0977-01   | 804-0977-R01  |                                                   |
| Pin Protector Assembly                         | 830-0880-01   |               |                                                   |
| Screws (12)                                    | 601-0010-01   | ---           |                                                   |
| Screws                                         | 600-0193-01   | ---           | 12x24 .500 cs zinc<br>fan bracket                 |
| Terminal lug                                   | 804-0817-02   | 804-0817-R02  |                                                   |
| Terminating resistor                           | 104-0032-01   | ---           | <b>E1</b> backplane                               |

## C.8 Power Cords for Peripherals

**Table C-6 Power Cords for Peripherals**

| Country        | Part Number   | Country        | Part Number   |
|----------------|---------------|----------------|---------------|
| <b>USA</b>     | Cord provided | Latvia         | 804-1185-R01  |
| Argentina      | 804-1185-R02  | Liechtenstein  | 804-1185-R11  |
| Australia      | 804-1185-R02  | Lithuania      | 804-1185-R01  |
| Austria        | 804-1185-R01  | Luxembourg     | 804-1185-R01  |
| Belgium        | 804-1185-R01  | Malaysia       | 804-1185-R03  |
| Brazil         | 804-1185-R01  | Malta          | 804-1185-R03  |
| Bulgaria       | 804-1185-R01  | Mexico         | Cord provided |
| Canada         | Cord provided | Monaco         | 804-1185-R01  |
| Chile          | 804-1185-R01  | Netherlands    | 804-1185-R01  |
| China          | 804-1185-R09  | New Zealand    | 804-1185-R02  |
| Columbia       | Cord provided | Norway         | 804-1185-R01  |
| Cyprus         | 804-1185-R03  | Peru           | 804-1185-R01  |
| Czech Republic | 804-1185-R01  | Philippines    | Cord provided |
| Denmark        | 804-1185-R04  | Poland         | 804-1185-R01  |
| Egypt          | 804-1185-R01  | Portugal       | 804-1185-R01  |
| Estonia        | 804-1185-R01  | Romania        | 804-1185-R01  |
| Finland        | 804-1185-R01  | Russia         | 804-1185-R01  |
| France         | 804-1185-R07  | Saudi Arabia   | Cord provided |
| Germany        | 804-1185-R01  | Singapore      | 804-1185-R03  |
| Greece         | 804-1185-R01  | Slovakia       | 804-1185-R01  |
| Hong Kong      | 804-1185-R03  | South Africa   | 804-1185-R06  |
| Hungary        | 804-1185-R01  | South Korea    | 804-1185-R01  |
| Iceland        | 804-1185-R01  | Spain          | 804-1185-R01  |
| India          | 804-1185-R06  | Sweden         | 804-1185-R01  |
| Ireland        | 804-1185-R03  | Switzerland    | 804-1185-R11  |
| Israel         | 804-1185-R12  | Taiwan         | Cord provided |
| Italy          | 804-1185-R07  | Turkey         | 804-1185-R01  |
| Ivory Coast    | 804-1185-R01  | United Kingdom | 804-1185-R03  |
| Japan          | 804-1185-R10  | United Arab    | 804-1185-R03  |