Oracle® Communications EAGLE Application Processor

Upgrade/Installation Guide

Release 17.1

G35527-01

June 2025



Oracle Communications EAGLE Application Processor Upgrade/Installation Guide, Release 17.1

Copyright © 2000, 2025, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notices are applicable:

U.S. GOVERNMENT END USERS: Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third party content, products, and services unless otherwise set forth in an applicable agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

CAUTION: Use only the guide downloaded from the Oracle Technology Network (OTN) (http://www.oracle.com/technetwork/indexes/documentation/oracle-comms-tekelec-2136003.html). Before running upgrade on your system, access the My Oracle Support web portal (https://support.oracle.com) and review any Knowledge Alerts that may be related to the System Health Check or the I Upgrade.

Upgrade/Installation Guide

MY ORACLE SUPPORT

My Oracle Support (https://support.oracle.com) is your initial point of contact for all product support and training needs. A representative at Customer Access Support can assist you with My Oracle Support registration.

Call the Customer Access Support main number at 1-800-223-1711 (toll-free in the US) or call the Oracle Support hotline for your local country from the list at http://www.oracle.com/us/support/contact/index.html. When calling, make the selections in the sequence shown below on the Support telephone menu:

- For Technical issues such as creating a new Service Request (SR), select 1.
- For Non-technical issues such as registration or assistance with My Oracle Support, select 2.
- For Hardware, Networking and Solaris Operating System Support, select 3.

You are connected to a live agent who can assist you with My Oracle Support registration and opening a support ticket.

My Oracle Support is available 24 hours a day, 7 days a week, 365 days a year.

Acronyms

This section provides an alphabetized list of acronyms used in the document.

Table 1. Acronyms

AS	Application Server
E5-APP-B	E5 Based Application Card
OCEPAP	Oracle Communication EAGLE Provisioning Application Processor
GA	General Availability
IPM	Initial Product Manufacture
LA	Limited Availability
MPS	Multi-Purpose Server
MOS	My Oracle Support
OSDC	Oracle Software Delivery Cloud
SM	Service Module
TPD	Tekelec Platform Distribution

What's New in this Guide

This section introduces the documentation updates for Release 17.1 in Oracle Communications EAGLE Application Processor Upgrade/Installation Guide.

Release 17.1 – G35527-01, June 2025

- Added <u>Appendix A.53</u> to list the steps to exchange keys between OL8 based PDBonly and OL6 based Non-Prov.
- Added step 40 in <u>Procedure 11</u> to add reference to the procedure to exchange keys between OL8 based PDBonly and OL6 based Non-Prov.
- Added steps 1 and 5 in <u>Procedure A.32</u>, <u>Post upgrade EuiDB database restore</u> to add the commands to verify verify the MIN_DSM_MEM_SIZE and PDB_SUB_CAPACITY.
- Added the phase "Change DB architecture from Compact to eXtreme on Non-Prov site" in sections <u>3.1.6</u> and 3.1.7.
- Added the notes in <u>Procedure A.51, MySQL RPM Upgrade Procedure</u> to mention this procedure is only applicable if upgrading from EPAP 17.0.0.x to 17.0.0.y (where $0 \le x \le 5$ and $y \ge 6$) or from 17.0.0.x (where $0 \le x \le 5$) to 17.1.y via migration and The EPAP GUI will not be accessible after this procedure.
- Updated step 5 in <u>Procedure 15, Preupgrade Backups</u> to provide information about upgrading via migration from EPAP 17.0.0.x to 17.0.0.y.

TABLE OF CONTENTS

1	INTRODUCTION	12
	Purpose and Scope	12
	References	12
	1.1.1 External	12
	1.1.2 Internal (Oracle)	
	Software Release Numbering	
	Terminology	
	Recommendations	
	Requirements	
2	GENERAL DESCRIPTION	16
	Upgrading Provisionable mixed EPAP Mated Pairs	17
	Backout Provisionable mixed EPAP Mated Pairs	18
	Upgrading EPAP Non-Provisionable MPS Servers	
	2.1.1 Upgrading Non-Provisional MPS pairs in Mixed EPAP configuration	18
	2.1.2 Upgrading Non-Provisional MPS pairs in dual PDBonly configuration	
	Backout EPAP Non-provisionable MPS servers	
	2.1.3 Backout Non-Provisionable MPS pairs in dual PDBonly configuration	
	2.1.4 Backout Non-Provisionable MPS pairs in mixed EPAP configuration	
	g. a	
3	UPGRADE OVERVIEW	21
	Upgrade Provisioning Rules	21
	Required Materials	
	Installation Phases	
	3.1.1 Installation Phases for Mixed and Non-Provisionable EPAP	
	3.1.2 Installation Phases for Standalone PDB	
	Full Upgrade Phases	
	3.1.3 Full Upgrade Phases for Mixed EPAP without live provisioning	
	3.1.4 Full Upgrade Phases for Non-Provisionable EPAP with or without live	
	provisioning	31
	3.1.5 Full Upgrade Phases for Dual Mixed with live provisioning	
	3.1.6 Full Upgrade Phases for Standalone PDB without live provisioning	
	3.1.7 Full upgrade Phases for Dual PDBonly with live provisioning	
	Dual Upgrade Upgrade Phases	
	3.1.8 Dual Image Upgrade Phases for Mixed EPAP without Live Provisioning	
	3.1. 9 Dual Image Upgrade Phases for Dual Mixed EPAP without Live Provisioning	
	3.1.10 Dual Image Upgrade Phases for Non-Provisionable EPAP with or without	
	live provisioning	53
	3.1.11 Dual Image Upgrade Phases for Dual Mixed with live provisioning	
	3.1.12 Dual Image Upgrade Phases for Standalone PDB without live provisioning	
	3.1.13 Dual Image Upgrade Phases for Dual PDBonly with live provisioning	
	Backout Phases	
	3.1.14 Backout Phases for Mixed and Non-Provisionable EPAP	03
	3.1.15 Backout Phases for Standalone PDB	
	Log Files	
	LUY FIIES	04
4	DB ARCHITECTURE OVERVIEW	65
~		

		architecture change in Customer Network	
		architecture change from Compact to Extreme	
	Change DB Arch	nitecture from COMPACT to eXtreme to support EAGLE release	3
	46.7.0.0.0(eXtre	me feature)	67
		es to change DB Architecture to eXtreme (Standalone PDB)	
		es to change DB architecture to eXtreme (First Non-Prov site)	
		es to change DB architecture to eXtreme (Remaining Non-Prov	
	11110 1 1140	oo to onango 22 aronnootare to oxtrome (rtomaning rtom rive	0.100,
5	UPGRADE PRE	PARATION	71
•		ograde environment	
		grade or installation is required	
		uirements	
		heck	
	System Health C	(ICON	10
6	SOFTWARE INS	TALLATION PROCEDURES	70
υ.		guration on server A	
		guration on server B	
		•	
		n on server B	
		tall Application on server A	
		itch Configuration	
		onfigure Sync Network Redundancy	
		onfiguring the application	
		ovision data from GUI	
	Procedure 13 Cl	nange DB Architecture	153
7		RADE PROCEDURES	
	Procedure 14 As	ssess MPS server's readiness for upgrade	160
	Procedure 15 Pr	eupgrade Backups	162
	Procedure 16 Pr	eupgrade system time check	164
	Procedure 17 Cl	neck 9dig counts before moving to eXtreme architecture	166
	Procedure 18 Up	ograde Server B	167
		ograde server A	
		un RTDB Converter	
		eboot EAGLE Cards	
		ccept Upgrade	
		eys exchange between active and standby PDB	
	1 1000daio 20 ikk	by a change between delive and standby 1 bb	200
8	SOFTWARE REC	OVERY PROCEDURES	205
		up	
		kout	
		erver B Backout	
		ackout both Server A and B	
		op the Pdba software	
		· ·	
	Procedure 27 Re	estart PDBA Software (Post-Backout and Post-Upgrade)	228
۸.		NEDIC DDOCEDUDES	222
Αl		NERIC PROCEDURES	
		Perform System Health Check	
		Validate Upgrade Media	
	Procedure A.3	System Configuration Backup	240

Procedure A.4 Exe	ecute parse9Dig script	.242
Procedure A.5 Incr	ease rtVolume size for Non-prov	.244
Procedure A.6 PDE	B Backup	.247
Procedure A.7 RTI	DB Backup	.251
Procedure A.8 Euil	DB Backup	.254
Procedure A.9 RTI	DB Reload from PDBA	.256
Procedure A.10 R7	FDB Restore	.259
Procedure A.11 R7	FDB Reload from Remote	.263
Procedure A.12 IS	O Image download from Oracle Software Delivery Cloud	.267
	M MPŠ Server with TPD 8.6.0	
	andalone PDB Segmented Configuration	
	assword change for EPAP System Users	
	5-APP-B Halt/Shutdown	
	ocedure to Configure EPAP switch ports and EAGLE SM cards to	
	-Eagle RTDB download speed	.289
Procedure A.18 Up	ograde SSL certificate from SHA-1 to SHA-512	.310
	able Epap VIP And Deactivate PDBA Proxy Feature	
	nable EPAP PDBA Proxy and EPAP VIP Optional Features	
	onfigure DSM Min Mem Size	
	estart Mysql service for PDB on Query Server	
Procedure A.23 Ge	et parse9Dig file from EPAP 16.3 ISO	.334
	ocedure to add/edit the /etc/minirc.mate file	
	onfigure the Auto Backup	
	TOP ACTIVE PDBA AND VERIFY REPL LOGS	
	Backup before upgrade	
	ar replication logs	
	nove remote PDBA IP	
	et RTDB Homing Policy to remote PDBA	
	inge MySql engine schema	
	t upgrade EuiDB database restore	
	t upgrade PDB database restore	
	Remote PDBA IP Address	
	s exchange between active PDB and standby PDB	
	DB restore after Upgrade	
	solve the false accept upgrade alarm situation	
	version from mixed EPAP to StandalonePDB+Non-Prov EPAP	
	e snapshot of uiEdit parameters	
	e the EPAP 16.3/16.4 additional configurations	
	onfigure Additional EPAP configurations	
	npare EuiDB parameters	
	B Restore	
	DB Homing Policy to self PDBA	
Procedure A 45 Bac	kout of MPS A and MPS B in Mixed and Non-Prov	.397
	kout of PDBonly site	
	Il Image Upgrade Procedure	
	tchover PDBA state	
	Il Image Upgrade Known Issues Fix	
	ept/Reject the Dual Image Upgrade	
Procedure A 51 MyS	SQL RPM Upgrade Procedure	417

	A.52 Post MySQL RPM upgrade PDB Restore Procedure A.53 Keys exchange between OL 8 based PDBonly and OL6 based Non-	423
APPENDIX B	INTERCONNECTION DIAGRAM	428
APPENDIX C	TELCO TO CISCO SWITCH REPLACEMENT	430
SWITCH REF	LACEMENT	430
SWITCH CO	NFIGURATION	436
APPENDIX D	SWOPS SIGN OFF	447
APPENDIX E	CUSTOMER SIGN OFF	448
ΔΡΡΕΝΟΙΧ Ε	MAJOR CHANGES IN EPAP 17.0	449

List of Figures

Figure 1: Example of a step that indicates the Server on which it needs to be executed	14
Figure 2: Initial Application Installation Path	16
Figure 3: Full upgrade Path – EPAP 17.0.0.0.0-b.b.b	
Figure 4: Dual Image Upgrade Path – EPAP 17.0.0.0.0-b.b.b Error! Bookmark not def	fined.
Figure 5: EPAP Mated Pairs	18
Figure 6: EPAP Mated Pairs with Non-Provisioning MPS Servers	19
Figure 7: Slide the Ejector Switch	288
Figure 8: Release Lever	289
Figure 9: Interconnectivity Diagram for Sync Network Redundancy (Eth04 used for Sync Network)	428
Figure 10: Default Interconnectivity Diagram (Eth04 used for Backup Provisioning Network)	429
List of Tables	
Table 1. Acronyms	4
Table 2. Terminology	14
Table 3: Upgrade time for EPAP 17.0 PROV EPAP - Mixed EPAP (Compact DB)/ PDBonly(eXtreme DB))21
Table 4: Upgrade time for EPAP 17.0 Non-PROV EPAP	22
Table 5: System Configuration Information	23
Table 6: User Password Table	
Table 7: Installation Phases for Mixed EPAP and Non-Provisional EPAP	25
Table 8: Installation Phases for Standalone PDB	
Table 9: Full Upgrade Phases for Mixed and Non-Provisionable EPAP	30
Table 10: 3.1.4 Full Upgrade Phases for Non-Provisionable EPAP with or without live provisioning37	
Table 11: Full Upgrade Phases for Dual Mixed with live provisioning	47
Table 12: Full Upgrade Phases on Standalone PDB	
Table 13: Full Upgrade Phases Dual PDBonly	
Table 14: Dual Image Upgrade Phases for Mixed EPAP without Live Provisioning	56
Table 15: Dual Image Upgrade Phases for Standalone PDB without Live Provisioning Error! Bookmar defined.	k not
Table 16: Backout Phases for Mixed and Non-Provisionable EPAP	63
Table 17: Backout Phases for Standalone PDB	
Table 19: Phases to change DB Architecture to eXtreme (Standalone PDB)	68
List of Procedures	
Procedure 1: Setting up the upgrade environment	71
Procedure 2: Determine if upgrade or installation is required	
Procedure 3: Verifying Pre-Upgrade Requirements and Capturing Upgrade Data	77
Procedure 4: System Health Check	78
Procedure 5: Pre-Install Configuration on Server A	79

Procedure 6: Pre-Install Configuration on Server B	85
Procedure 7: Install the Application on Server B	91
Procedure 8: Install the Application on Server A	98
Procedure 9: Switch Configuration	105
Procedure 10: Procedure to Configure Sync Network Redundancy	
Procedure 11: Configuring the Application	123
Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as de	signated by
customer)	
Procedure 13: Change the DB Architecture	
Procedure 14: Assess the MPS Server's Readiness for Upgrade	
Procedure 15: Pre Upgrade Backups	162
Procedure 16: Pre-Upgrade System Time Check	164
Procedure 17: Check 9dig counts before moving to eXtreme architecture	166
Procedure 18: Upgrade Server B	167
Procedure 19: Upgrade Server A	183
Procedure 20: Run RTDB Converter	198
Procedure 21: Reboot EAGLE Cards	199
Procedure 22 : Accept upgrade	200
Procedure 23: Keys exchange between active PDB and standby PDB	203
Procedure 24: Server B Backout	206
Procedure 25: Backout both MPS A and B	
Procedure 26: Stop the PDBA Software	227
Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade	229

1 INTRODUCTION

Purpose and Scope

This document describes methods utilized and procedures executed to perform the following tasks:

- a. An initial installation of the EPAP 17.1 application software if it is not currently installed on an in-service E5-APP-B system running a release of TPD 8.X
- b. A full upgrade on an in-service E5-APP-B system running an EPAP Release 16.3.x/16.4.x
- c. A dual image upgrade upgrade on an in-service E5-APP-B system running an EPAP release 17.0.x

The audience for this document consists of Oracle customers and the following groups: Software System, Product Verification, Documentation, and Customer Service including Software Operations and NPI. This document provides step-by-step instructions to execute any MPS upgrade or installation using an ISO image.

This document does not address requirements relating to the interaction, if any, between EAGLE and MPS upgrade. This document does not address feature activation.

Note:

- service <service name> start/stop should not be used on EPAP 17.1 onwards. Instead, systemctl start/stop <service name> should be used.
- EPAP 16.4 introduced a new parameter LSBLSET in the DN table. EPAP releases prior to 16.4 do not have LSBSSET in their DN table. Customers who use LSBLSET in their provisioning and upgrading their EPAP network from EPAP 16.3 to a higher release (16.4/17.1) need to make sure they provision LSBLSET ONLY after they have upgraded the whole network with EPAP 17.1. When customers have DUAL PDBA (DUAL Mixed-EPAP or DUAL PDBonly), after upgrading one site from 16.3 to EPAP 17.1, that upgraded site should not be made Active if the customer uses LSBLSET in their provisioning. If EPAP 17.1 Active PDB site upgrades a DN with LSBLSET parameter, the EPAP 16.3 EPAPs will reject that update as they do not have LSBLSET parameter in their DB. Further provisioning at the Standby PDBA and Non-PROVS will be barred once one upgrade fails to replicate to Standby PDBA or Non-PROVs.

References

1.1.1 External

[1] EAGLE Application Processor (EPAP) Administration Guide, E54368-01, latest revision, Oracle

Upgrade/Installation Guide

[2] EPAP 16.4 Administration Manual, Oracle

1.1.2 Internal (Oracle)

The following are references internal to Oracle. They are provided here to capture the source material used to create this document. Internal references are only available to Oracle's personnel.

- [1] TEKELEC Acronym Guide, MS005077, revision 2.35, September 2005.
- [2] Software Upgrade Procedure Template, TM005074, Current Version
- [3] Integrating MPS into the Customer Network, TR005014, version 3.1, October 2009
- [4] TPD Initial Product Manufacture TPD 8.6, Latest revision
- [5] PFS EPAP 17.1, Latest revision
- [6] EPAP Administration Manual for EPAP 17.1, Latest version
- [7] EPAP Linkset Based Blocklisting, CGBU 042015


Software Release Numbering

Refer to Engineering Release Notes or other appropriate document with the most recent build numbers in order to identify the proper components (software loads, GPLs, etc.) that comprise the product's software release.

Terminology

Multiple servers may be involved with the procedures in this manual. Therefore, most steps in the written procedures begin with the name or type of server to which the step applies. For example:

Each step has a checkbox for every command within the step that the technician should check to keep track of the progress of the procedure.



1	MPS A: Verify all	Materials are listed in Material List (Section 0)
П	materials	
	required are	
	present	

Figure 1: Example of a step that indicates the Server on which it needs to be executed

Other terminology follows.

Table 2. Terminology

Backout (abort)	The process to take a system back to a Source Release prior to completion of upgrade to Target release. Includes preservation of
	databases and system configuration.
Mixed EPAP	An EPAP where both PDB and RTDB databases reside.
Non-provisionable (Non-	An EPAP server hosting a Real Time DB without any provisioning
prov) EPAP	interfaces to external provisioning applications. Non-Prov servers are
prov) EFAF	connected to a pair of Provisionable EPAP(mixed-EPAP or PDBonly) from
	where they get their updates.
Provisionable EPAP	An EPAP server hosting PDB with provisioning interfaces to AS. Both
Provisionable EPAP	Mixed EPAP and Standalone PDB are Provisionable EPAP.
Source release	
	Software release to upgrade from.
Split Mirror	Systems that use software RAID instead of hardware RAID can use the
	software RAID mirrors as a backout mechanism.
	Conceptually in a software RAID1 with two disks there are two sides to
	the mirror; let them be side A and side B. For a system with multiple
	software RAID devices, each device will have an A side and a B side. For
	an upgrade with a BACKOUT_TYPE=SPLIT_MIRROR the upgrade will break
	the mirrors at the beginning of the upgrade and perform the upgrade on
	the Asides of the mirrors. The other sides of the mirrors (B sides) are left
	intact in their pre-upgrade state throughout the duration of the upgrade.
	When a backout is performed the system is rebooted into the same
	'backout environment'. Inside this 'backout environment' the RAID
	mirrors are rebuilt from the B sides of the arrays, thus restoring the
	system to the pre-upgrade state
Standalone PDB	Also known as 'PDB Only', this type of EPAP shall have PDB database only.
	No RTDB database shall exist on the standalone PDB site.
Target release	Software release to upgrade to.
Upgrade media	USB media or ISO image for E5-APP-B.
Dual Image Upgrade	This process upgrades both the Application as well as the TPD version on
(DIU)	the system together. This provides a faster method to upgrade the setup.

Recommendations

This procedure should be followed thoroughly utilizing the steps as written. When planning to run upgrade on the server, contact My Oracle Support at least 48 hours before the upgrade process has been planned to be initiated. In the event any unexpected results are returned while executing steps in this procedure, halt the activity and contact My Oracle Support for assistance.

Upgrade/Installation Guide

Read the following notes on procedures:

- While performing the upgrade, do not open the epapconfig menu if it is not mentioned in the procedure. Do not run anything in the setup that is not documented in the install/upgrade manual.
- 2. Any procedure completion times are estimates. Times may vary due to differences in database size, user experience, and user preparation.
- 3. The shaded area within response steps must be verified in order to successfully complete that step.
- 4. Output displayed in the procedures' response steps is presented. Actual output varies depending on system. Output is presented for reference only.
- 5. Where possible, command response outputs are shown as accurately as possible. However, exceptions may include the following:
 - Information such as time and date.
 - ANY information marked with "XXXX." Where appropriate, instructions are provided to determine what output should be expected in place of "XXXX."
- 6. After completing each step and at each point where data is recorded from the screen, the technician performing the procedure must check each step. A checkbox has been provided beneath each step number for this purpose.
- 7. Captured data is required for future support reference if My Oracle Support is not present during the execution of procedures.
- 8. In procedures that require a command to be executed on a specific MPS, the command is prefaced with MPS A: or MPS B:
- 9. User Interface menu items displayed in this document were correct at the time the document was published but may appear differently at time that this procedure is executed.
- 10. During DIU (Dual Image Upgrade), do not open the GUI or start the software explicitly.
- 11. Do not provision data during the DIU process as it might lead to data loss.
- 12. Copy the commands in a text editor to verify their format before running them in the CLI rather than pasting them directly from the document to the CLI.

Requirements

- Screen logging is required throughout the procedure. These logs should be made available to My Oracle Support in the event their assistance is needed.
- Target-release USB media or ISO image

2 GENERAL DESCRIPTION

This document defines the step-by-step actions performed to execute a software upgrade of an inservice MPS running the EPAP application from the source release to the target release on **E5-APP-B-01/02**.

For the EPAP application, some steps in this procedure refer to the PDB application feature on the MPS A of the

MPS pair. The EPAP application makes it optional for a newly installed MPS A node to be configured as a Provisioning (PDB) node (upgrades of MPS A nodes already configured as a provisioning node does not change this configuration).

Note: Refer to Media and Documentation section of Release Notes 17.1 for correct TPD and EPAP Release

Note: If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

The EPAP upgrade paths are shown in the figures below. The general timeline for all processes to perform a software incremental upgrade, from pre-upgrade backups to a final system health check, is also included below.

Figure 2: Initial Application Installation Path





Figure 3: Upgrade Paths - EPAP 17.1.0.0.0-b.b.b

Upgrading Provisionable mixed EPAP Mated Pairs

Current deployments of the EPAP support two geographically separated EPAP systems that are "mated", meaning they communicate and replicate PDB information between the two sites. An EPAP system is a pair of MPS servers (an **A** and a **B** node). Hence, a mated pair of EPAP systems consists of four MPS servers, an **A** and a **B** node for each EPAP system (see Figure 4: EPAP Mated Pairs). EPAP allows more than two EPAP systems in a related configuration (up to 22 Non-Provision able MPS servers).

This document describes upgrade (and, if necessary, backout) of the EPAP software on one system, that system consisting of two MPS servers (A and B).



Upgrade/Installation Guide

Figure 4: EPAP Mated Pairs

Upgrade of provisionable EPAP(mixed-EPAP) mated pairs must be carried out in the following order:

- Ensure PDB databases are at the same level. Make ensure that all PDB databases are in sync before proceeding.
- 2. Local MPS-B
- 3. Local MPS-A (Standby PDBA)
- 4. Remote MPS-B
- 5. Remote MPS-A (Active PDBA)

NOTE: Since the PDBA software is not running immediately after an upgrade, the syscheck utility will alarm the fact that the PDBA is not running on the local and remote EPAP A-servers.

Backout Provisionable mixed EPAP Mated Pairs

Backout of Provisionable EPAP (mixed-EPAP) Mated Pairs should be done in the reverse order that the upgrade was performed:

- 1. Identify a PDB backup that was made prior to upgrade, on the EPAP release that backout will target. Note that backout always carries the risk of losing data, should a restore from database backup become necessary.
- 2. Remote MPS-A (Active PDBA)
- 3. Remote MPS-B
- 4. Local MPS-A (Standby PDBA)
- 5. Local MPS-B

On a backout of an upgrade, the server will remain in runlevel 3 (no applications running). The user will be required to manually reboot the server to bring it back into service and a syscheck can be performed.

Upgrading EPAP Non-Provisionable MPS Servers

EPAP Non-Provisional MPS pairs can connect to: Mixed EPAP or Standalone PDB.

2.1.1 Upgrading Non-Provisional MPS pairs in Mixed EPAP configuration

EPAP provides the ability to expand the concept of a mated pair of EPAP systems to have up to 24 EPAP systems (48 MPS servers total) configured such that two of the MPS-A servers will run the PDBA software and RTDB software both and handle provisioning (Provisionable nodes) and the other 22 MPS-B and 22 MPS-A servers will only run the RTDB software, taking their updates from the two Provisionable (mixed-EPAP or PDBonly) MPS-A servers.

Upgrade/Installation Guide

IP/WAN Network **EPAP EPAP EPAP EPAP** System #1 System #2 System #3 System #N MPS A MPS A MPS A MPS A (Provisionable) (Provisionable) MPS B MPS B MPS B MPS B

An example showing 4 EPAP systems, two of which are provisioning nodes.

Figure 5: EPAP Mated Pairs with Non-Provisioning MPS Servers

In such a configuration, it is required that the EPAP system containing the provisionable MPS servers are upgraded first, before any EPAP system containing the non-provisionable MPS servers are upgraded. Upgrade of such configuration must be carried out in the following order:

Mixed EPAP (with standby PDBA)

- 1. Mixed EPAP (MPS B)
- 2. Mixed EPAP (MPS A

Mixed EPAP (with active PDBA)

- 3. Mixed EPAP (MPS B)
- 4. Mixed EPAP (MPS A)

Non-provisionable EPAPs (All Non-Provs)

- 5. Non-Provisionable (MPS B)
- 6. Non-Provisionable (MPS A)

2.1.2 Upgrading Non-Provisional MPS pairs in dual PDBonly configuration

EPAP provides the ability to separate the RTDB from PDB to create two architectures: Standalone PDB running PDB process only and Non-Provisionable running RTDB only. Up to 22 Non-Provisional EPAP

Upgrade/Installation Guide

mated pairs are connected to 2 Standalone PDB that are configured as Active/Standby. In such a configuration, it is required that the Prov servers must be upgraded first followed by the Non-Provs and should be carried out in the following order:

- 1. Standby PDBonly
- 2. Active PDBonly
- 3. Non-Prov (MPS B)
- 4. Non-Prov (MPS A)

Backout EPAP Non-provisionable MPS servers

EPAP Non-Provisional MPS pairs can connect to: Mixed EPAP or Standalone PDB.

2.1.3 Backout Non-Provisionable MPS pairs in dual PDBonly configuration

Backout of Non-Provisionable MPS pairs in Standalone configuration should be done in the reverse order that the upgrade was performed. Please follow the below mentioned steps for backout:

- 1. Non-Provisionable (MPS A)
- 2. Non-Provisionable (MPS B)
- 3. Standby PDBonly
- 4. Active PDBonly

On a backout of an upgrade, the server will remain in runlevel 3 (no applications running). The user will be required to manually reboot the server to bring it back into service and a syscheck can be performed.

2.1.4 Backout Non-Provisionable MPS pairs in mixed EPAP configuration

Backout of EPAP Non-provisionable MPS pairs in mixed EPAP configuration should be done in the reverse order that the upgrade was performed:

Non-provisionable EPAP

- 1. Non-Provisionable (MPS A)
- 2. Non-Provisionable (MPS B)

Mixed EPAP (with Standby PDBA)

- 3. Mixed EPAP (MPS A)
- 4. Mixed EPAP (MPS B)

Mixed EPAP (with Active PDBA)

- 5. Mixed EPAP (MPS A)
- 6. Mixed EPAP (MPS B)

Upgrade/Installation Guide

3 UPGRADE OVERVIEW

Upgrade Provisioning Rules

Provisionable Dual Mixed EPAP and dual PDBonly EPAPs can be upgraded with both live provisioning ON or Off,please refer <u>section 3.1.6</u> and <u>section 3.1.8</u>.

Provisionable Single Mixed and Single PDBonly EPAPs can be upgraded with live provisioning OFF only, please refer section 3.1.3 and section 3.1.7.

Non-Provisionable EPAPs can be upgraded with both live provisioning ON or OFF, please refere <u>section</u> 3.1.5.

The PDBA software remains stopped on the server which is being upgraded even after upgrade is done until asked to start the software as mentioned in the upgrade procedures.

Note: It is very important that any Legacy UpdateAny legacy update must be accepted before proceeding for Dual Image Upgrade.

The following table describes the typical time required to upgrade to EPAP release 17.1. The data represents what was observed in the lab test. The timing required in actual upgrade might vary. The data is provided to gauge the approximate time required for the upgrade and prepare for proper maintenance window.

Note:

All Non-PROVs can be upgraded within normal maintenance window of 6-8 hours. PROV EPAPS (Mixed-EPPA/No-PROVS) might need extended time based on the amount of data. Customers who have DUAL PROV sites (Mixed-EPAP/PDB only EPAP) can upgrade with Live provisioning ON.

Table 3: Upgrade time for EPAP 17.1 PROV EPAP - Mixed EPAP (Compact DB)/ PDBonly(eXtreme DB)

DB	DN Count	IMSI Count	IMEI Count	Backup time	Restore	Overall
Architecture					Time	upgrade
						time
						(Backup
						Time + Full
						Upgrade
						Time +
						Restore
						Time)
Compact	40M	0	0	3 minutes	30 minutes	4 hours
Compact	80M	0	0	6 minutes	1 hour	5 hours
Compact	120M	0	0	12 minutes	2 hour 45	7 hours
					minutes	

Compact	160M	0	0	15 minutes	4 hours and 30 minutes	8 hours
Compact	200M	0	0	25 minutes	6 hours 20 minutes	10 hours
Compact	240M	0	0	30 minutes	8 hours	12 hours
Compact	240M	240M	48M	27 minutes	7 hours	12 hours
eXtreme	240M	0	0	30 minutes	8 hours	12 hours
eXtreme	300M	0	0	35 minutes	11 hours	15 hours
eXtreme	360M	0	0	40 minutes	11 hours 50 minutes	17 hours
eXtreme	0	240M	0	15 minutes	30 minutes	7 hours
eXtreme	480M	555M	45M	26 minutes	6.5 Hrs	11 hours
eXtreme	420M	300M	180M	45 minutes	13.5 Hr	17 hours
eXtreme	480M	555M	45M	55 Minutes	13 Hours	17 hours

Table 4: Upgrade time for EPAP 17.1 Non-PROV EPAP

DB	DN Count	IMSI Count	IMEI Count	Backup time	Restore	Overall
Architecture					Time	upgrade
						time
Compact	240M DN	240M	48M	30 Minutes	42 minutes	5 hours
eXtreme	0	240M	0	15 minutes	30 minutes	5 hours
eXtreme	480M	555M	45M	1 hour 18	2 hours	8 hours
				minutes		

Required Materials

- For Mixed EPAP or Non-Provisional EPAP: Two (2) target-release USB media (Greater than 2GB of size) or a target-release ISO file. For Standalone PDB: One (1) target-release USB media(Greater than 2GB of size) or a target-release ISO file
- A terminal and null modem cable to establish a serial connection.
- Write down the system configuration information.

Description	Information
PROVISIONABLE (Yes/No)	
PDBA state (Active/Standby)	
Provisioning IP (IPv4)	
Provisioning Mask (IPv4)	

Provisioning Default Router IP (IPv4)	
Provisioning IP (IPv6)	
Provisioning Netmask (IPv6)	
Provisioning Default Router IP (IPv6)	
NTP1 IP (IPv4/IPv6)	
NTP2 IP (IPv4/IPv6)	
NTP3 IP (IPv4/IPv6)	
Local VIP	
Remote VIP	
Local PDBA IP (IPv4)	
Local PDBA IP (IPv6)	
Remote PDBA IP (IPv4/IPv6)	
Remote PDBA B IP (IPv4/IPv6)	
RTDB Homing	
Time Zone	
PDBA Proxy Feature	
Others	

Table 5: System Configuration Information

• Passwords for users on the local system:

EPAP USERS						
login	MPS A password	MPS B password				
epapconfig						
epapdev						
(needed for backout						
only)						
root						
epapall						
(needed for GUI						
access)						
admusr						

Table 6: User Password Table

Installation Phases

The following table illustrates the progression of the installation process by procedure with estimated times. The estimated times and the phases that must be completed may vary due to differences in typing ability and system configuration. The phases outlined in Table 7 and Table 8 are to be performed in the order they are listed.

3.1.1 Installation Phases for Mixed and Non-Provisionable EPAP

Phase	Ti	osed me nutes)	Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS Servers.	Procedure 1
Verify install	5	20	Verify this should be an install.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for install are met.	Procedure 3
Pre-install health check	5	40	Run the syscheck utility to verify that all servers are operationally sound.	Procedure 4
Configure Server 1A	5	45	Set hostname, designation, function and time.	Procedure 5
Configure Server 1B	5	50	Set hostname, designation, function and time.	Procedure 6
Install Servers	30	80	Install software on sides 1A and 1B	Procedure 7 Procedure 8
Configure Switches	30*	110*	Configure the Switches	Procedure 9
Post-install application processing	30	140	Perform first time configuration.	Procedure 11
Post-upgrade health check	5	145	Run the syscheck utility to verify all servers are operationally sound.	Procedure 4

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This	Cum.		
	Step			
**Configure Auto	5	150	Configure Auto Backup from PDB	<u>Procedure</u>
Backup			GUI on Provisionable EPAP's, this	A.25
			backup will also get scheduled on	
Note: Skip this step if			attached Non-Prov sites present on	
the EPAP is			the setup.	
configured as Non-			•	
Provisionable.				
Check EPAP-EAGLE	20	170	Configure and verify that EAGLE SM	0
connectivity speed			cards are getting auto-negotiated to	
			1000Mbps/Full Duplex	

Table 7: Installation Phases for Mixed EPAP and Non-Provisional EPAP

Note:

• If configuring 4 switches, add 30 minutes to the current setup. Configuring Auto backup is a compulsory step to enable PDB-RTDB translogs pruning.

3.1.2 Installation Phases for Standalone PDB

Note: In the procedures below, skip the steps which need to be performed on MPS B, since MPS B is not present in the Standalone PDB configuration".

Phase	Tii	osed me nutes)	Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS Servers.	Procedure 1
Verify install	5	20	Verify this should be an install.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for install are met.	Procedure 3
Pre-install health check	5	40	Run the syscheck utility to verify that all servers are operationally sound.	Procedure 4

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Configure Server 1A	5	45	Set hostname, designation, function and time.	Procedure 5
Install Server	30	75	Install software on sides 1A	Procedure 7
Post-install application processing	30	105	Perform first time configuration. Refer to Procedure A.14 to configure the Standalone PDB in segmented network configuration.	Procedure 11
Post-upgrade health check	5	110	Run the syscheck utility to verify all servers are operationally sound.	Procedure 4
**Configure Auto Backup. Note: Perform this step once Non- Provisionable EPAPs are attached to this Standalone PDB	5	115	Configure Auto Backup from PDB GUI on Provisionable EPAP's, this backup will also get scheduled on attached Non-Prov sites present on the setup.	Procedure A.25

Table 8: Installation Phases for Standalone PDB

Full Upgrade Phases

The following table illustrates the progression of the full upgrade process by procedure with estimated times and may vary due to differences in typing ability and system configuration. The procedures outlined below are to be performed in the order they are listed.

Note: Before proceeding with the Full Upgrade process, refer to <u>Upgrading Provisionable mixed EPAP</u> <u>Mated Pairs</u> and <u>Upgrading EPAP Non-Provisionable MPS Servers</u> to get the overview of the EPAP setup and upgrade order.

^{*}NOTE: The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

^{**}NOTE: Configuring Auto backup is a compulsory step to enable PDB-RTDB translog pruning.

3.1.3 Full Upgrade Phases for Mixed EPAP without live provisioning

Note: Do not add DN and DNBlock with lsblset parameter until all nodes in the network are migrated to EPAP 17.1 successfully.

Phase	Tii	osed me nutes) Cum.	Activity	Procedure
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Full upgrade	5	20	Verify this should be a Full upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for Full Upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
EPAP 16.3/16.4/17.1 RTDB and EuiDB Backups	*See notes below	*See notes below	Backup application databases and other pertinent information in case of backout required	Procedure A.6 Procedure A.7 Procedure A.8
Take snapshot of uiEdit parameters	15	70	Take a snapshot of uiEdit parameters to be compared after migration is complete	Procedure A.39
Change MySql engine schema	15	85	Change mysql schema from myiasm to innoDB Note: This procedure is not to be performed if migrating from 17.0.0.x.	Procedure A.31
Save the EPAP 16.3/16.4/17.1 additional configurations	20	105	Save the NTP, EMS, QS, Automatic PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations, HTTP configurations	Procedure A.40
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15

Phase	Tii	osed me nutes)	Activity	Procedure
	This Step	Cum.		
Pre-upgrade system time check	5	110	Pre-upgrade system time check.	Procedure 16
IPM E5-APP-B Server	45	155	This Procedure will IPM the E5-APP-B Server	Procedure A.13
			Note: IPM will be performed on both MPS A and B	
Configure Server 1A	5	160	Set hostname, designation, function and time.	<u>Procedure 5</u>
Configure Server 1B	5	170	Set hostname, designation, function and time.	Procedure 6
Install Servers	30	200	Install software on sides 1A and 1B	Procedure 7 Procedure 8
Configure Switches	30	230	Configure the Switches	Procedure 9
Post-install application processing	30	260	Perform first time configuration.	Procedure 11
Post upgrade health check	5	265	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
RTDB Conveter	40	305	Run RTDB converter tool from Compact-to-Compact or Extreme-to- Extreme	Procedure 20
			Note : Applicable only in case of full upgrade from EPAP 16.3.1 to 17.1	
Post upgrade EuiDB restore	5	310	Restore EuiDB database	Procedure A.32
Restore PDB Backup	*See notes below	*See notes below	Restore EPAP 16.3.1/16.4.1/17.0.0.x PDB backup taken before fresh installation	Procedure A.33
Restore RTDB Backup	*See notes below	*See notes below	Restore EPAP 16.3/16.4/17.0.0.x RTDB backup taken before fresh installation	Procedure A.36
Reload RTDB from mate	30	340	Reload RTDB from mate on Non-prov MPS B.	Procedure A.11

Phase	Tiı	osed me nutes) Cum.	Activity	Procedure
	Step			
Reconfigure Additional EPAP configurations NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS. Also, QS is not supported in EPAP 17.1 release. However, continue to note down the Query srver details for future reference.	45	385	Reconfigure the EMS, QS, Automatic PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations Note: If HTTP was enabled before migration, then reconfigure the HTTP configuration by disabling the configuration first and then enabling the configuration again from EPAP GUI	Procedure A.41
Take snapshot of uiEdit parameters on upgraded EPAP 17.1 servers	10	395	Take a snapshot of uiEdit parameters to be compared after migration is complete.	Procedure A.39
Compare uiEdit parameters	10	405	Compare the snapshot taken in EPAP 17.0.0.y with the one taken on the EPAP 16.3/16.4 /17.1 before migration	Procedure A.42
Start the PDB software	10	415	Re-activate the PDB on the Provisionable MPS A servers (PDBonly in this case).	Procedure 27
Clear the Replication logs.	20	435	Clear the replication logs before connecting both the PDBAs NOTE:Perform this procedure in case of dual mixed EPAP.	Procedure A.28

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Exchange the keys between active EPAP site and standby EPAP site	30	465	Keys exchange between active and standby EPAP sites. NOTE: Perform this procedure in case of dual mixed EPAP.	Procedure A.35
***Configure Auto Backup	5	470	Configure Auto Backup from EPAP GUI on Provisionable EPAP's, this backup will get scheduled on attached Non-Prov sites present on the setup.	Procedure A.25
Reboot EAGLE Cards	*See notes below	*See notes below	Reboot Eagle Cards to reload updated DB	Procedure 21
Accept the upgrade after successful soak period. NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given.	5	This is done in a separat e MTC.	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 22

Table 9: Full Upgrade Phases for Mixed and Non-Provisionable EPAP

Note:

- The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data. The time needed to restore PDB backup (MysqlDump) is dependent on the amount of PDB database.
- If configuring 4 switches, add 30 minutes to the current setup.
- The time needed to reload EAGLE cards is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

Upgrade/Installation Guide

- Configuring auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

Full Upgrade Phases for Dual Mixed EPAP without live provisioning

This procedure lists the procedure to upgrade Dual Mixed EPAP servers without live provisioning.

Phase	Activity	Procedure
Upgrading when both servers are on EPAP 16.3.1 or 16.4.1 release	Upgrade Standby PDBA site on EPAP 16.3.1 or 16.4.1 to EPAP 17.1	Procedure 3.1.3
Upgrading when one server is on EPAP 17.1 and other is on EPAP 16.3.1 or 16.4.1	Switchover PDBA sites to make server on EPAP 17.1 as Active PDBA site and server on EPAP 16.3.1 or 16.4.1 to standby site	If EPAP 16.3.1 or 16.4.1 is Active PDBA site from EPAP GUI, do a switchover PDBA to make it standby site before upgrade.
Upgrade EPAP 16.3.1	Upgrade Standby PDBA site on EPAP	Procedure 3.1.3
or 16.4.1 site	16.3.1 or 16.4.1 to EPAP 17.1	

3.1.4 Full Upgrade Phases for Non-Provisionable EPAP with or without live provisioning

Note: This procedure can be used in with or without live provisioning scenario.

Table 10: Full Upgrade Phases for Non-Provisionable EPAP with or without live provisioning

	Elapsed Time			
Phase	(Mi	inutes)	Activity	Procedure
	Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Full upgrade	5	20	Verify this should be a Full upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for Full Upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
EPAP 16.3/16.4/17.1 RTDB and EuiDB Backups	*See notes belo w	*See notes below	Backup application databases and other pertinent information in case of backout required	Procedure A.7 Procedure A.8
Take snapshot of uiEdit parameters	10	65	Take a snapshot of uiEdit parameters to be compared after migration is complete	Procedure A.39
Change MySql engine schema	15	80	Change mysql schema from myiasm to innoDB Note: This procedure is not to be performed if migrating from 17.0.0.x.	Procedure A.31
Pre-upgrade Backup Save the EPAP	*See notes belo w	*See notes below	Backup application databases and other pertinent information. Note: PDB Backup is not required so steps mentioned in the procedure to take PDB backup can be skipped Save the NTP, EMS, QS, Automatic	Procedure 15
16.3/16.4/17.1 additional configurations			PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations, HTTP configurations	<u>A.40</u>
Pre-upgrade system time check	5	105	Pre-upgrade system time check.	Procedure 16

		ipsed ime		
Phase	(Minutes)		Activity	Procedure
	This	Cum.		
	Step			
IPM E5-APP-B Server	45	150	This Procedure will IPM the E5-APP-B Server	Procedure A.13
			Note: IPM will be performed on both MPS A and B	
Configure Server 1A	5	155	Set hostname, designation, function and time.	Procedure 5
Configure Server 1B	5	160	Set hostname, designation, function and time.	Procedure 6
Install Servers	30	190	Install software on sides 1A and 1B	Procedure 7 Procedure 8
Configure Switches	30	210	Configure the Switches	Procedure 9
Post-install application processing	30	240	Perform first time configuration.	Procedure 11
Full upgrade health check	5	245	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Change DB architecture from Compact to eXtreme on Non-Prov site Read note carefully. Note 1: Applicable in	45	290	Change DB architecture from compact to Extreme	Procedure 13
case of full upgrade from 16.3.1/16.4.1 in Extreme mode to 17.1 Extreme Note 2: This step not needed in				
Compact (16.3/16.4) -> compact (17.1), compact- (16.3/16.4) >eXtreme (17.1)				

	Elapsed Time Phase (Minutes)			
Phase			Activity	Procedure
	This	Cum.		
	Step			
RTDB Converter	*See	*See	Run RTDB converter tool from	<u>Procedure</u>
	notes	notes	Compact-to-Compact or Extremet-	<u>20</u>
	belo	below	to-Extreme on non-prov node	
	W		depending upon the DB	
			acrchitecture before Full upgrade	
			Note: Applicable only in case of full	
			upgrade from EPAP 16.3.1 to 17.1.	
Post upgrade EuiDB	5	295	Restore EuiDB database	Procedure
restore				<u>A.32</u>
Restore RTDB Backup	*See	*See	Restore EPAP 16.3/16.4/17.0.0.x	Procedure
	notes	notes	RTDB	<u>A.36</u>
	belo	below	backup taken before fresh	
	W		installation	
Reload RTDB from mate	30	325	Reload RTDB from mate on Non-prov	<u>Procedure</u>
			MPS B.	<u>A.11</u>
Reconfigure Additional	45	370	Reconfigure the EMS, QS, Automatic	<u>Procedure</u>
EPAP configurations			PDB-RTDB backup, Configure file	<u>A.41</u>
			transfer, schedule EPAP Tasks	
NOTE: After EPAP			configurations	
upgrade, if EMS is not				
able to receive alarms			Note: If HTTP was enabled before	
from EPAP, delete the			migration, then reconfigure the	
EPAP from EMS			HTTP configuration by disabling the	
discovery screen and then rediscover the			configuration again from EDAR	
EPAP on EMS.			the configuration again from EPAP GUI	
EPAP OII EIVIS.			GOI	
Also, QS is not				
supported in EPAP 17.1				
release but continue to				
note down the Query				
srver details for future				
reference.				
Take snapshot of uiEdit	10	380	Take a snapshot of uiEdit parameters	<u>Procedure</u>
parameters on			to be compared after migration is	<u>A.39</u>
upgraded EPAP 17.1			complete.	
servers				

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Compare uiEdit parameters	10	390	Compare the snapshot taken in EPAP 17.0.0.y with the one taken on the EPAP 16.3/16.4/17.0.0.x before migration	Procedure A.42
Reboot EAGLE Cards	*See notes belo w	*See notes below	Reboot Eagle Cards to reload updated DB	Procedure 21
Accept the upgrade after successful soak period NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given. NOTE: After EPAP	5	This is done in a separat e MTC.	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 22
upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS.				

Note:

- The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.
- The time needed to restore PDB backup (MysqlDump) is dependent on the amount of PDB database.
- This procedure cannot specify an exact length of time since different customers have different amounts of application data.
- If configuring 4 switches, add 30 minutes to the current setup.

- The time needed to reload EAGLE cards is dependent on the amount of application data. This
 procedure cannot specify an exact length of time since different customers have different amounts
 of application data.
- Configuring Auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

3.1.4 Full Upgrade Phases for Dual Mixed with live provisioning

Note: Refer to Appendix E for things to be taken care while performing full upgrade with live provisioning.

Note: Do not add DN and DNBlock with lsblset parameter until all nodes in the network are migrated to EPAP 17.1 successfully.

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Full upgrade	5	20	Verify this should be a Full upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
EPAP 16.3/16.4/	*See	*See	Backup application databases and	Procedure A.6
17.1 RTDB, EuiDB and PDB Backups	notes below	notes below	other pertinent information in case of backout required	Procedure A.7 Procedure A.8
Take snapshot of uiEdit parameters	15	70	Take a snapshot of uiEdit parameters to be compared after migration is complete	Procedure A.39

Clear the repl logs	15	85	Verify that replication logs are cleared between active and standby EPAP's	Procedure A.28
Reset RTDB homing policy	15	100	Modify the RTDB homing policy	Procedure A.30
Remove remote PDBA IP from Standby PDBA site Note: Make sure remote PDBA is present in Active PDBA site. Refer Appendix E.	15	115	Delete the remote (Active) PDBA IP on Standby PDBA via epapconfig menu	Procedure A.29
Change MySql engine schema	15	130	Change mysql schema from myiasm to innoDB Note: This procedure is not to be performed if migrating from 17.0.0.x.	Procedure A.31
Save the EPAP 16.3/16.4/17.0.0.x additional configurations	20	150	Save the NTP, EMS, QS, Automatic PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations, HTTP configurations	Procedure A.40
Pre-upgrade Backup Note: Take PDB backup from the node migrated first in the network. Refer to Procedure A.6. Note: If the network speed between two PDBAs is very slow, follow the original procedure to perform PDBA backup via MySQL dump process.	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15

Defeate			1	1
Refer to				
Procedure A.27.		4==		
Pre-upgrade	5	155	Pre-upgrade system time check.	Procedure 16
system time check				
IPM E5-APP-B	45	200	This Procedure will IPM the E5-APP-	Procedure A.13
Server			B Server	
			Note: IPM will be performed on	
			both MPS A and B	
Configure Server	5	205	Set hostname, designation, function	Procedure 5
1A			and time.	
Configure Server	5	210	Set hostname, designation, function	Procedure 6
1B			and time.	
Install Servers	30	240	Install software on sides 1A and 1B	Procedure 7
				Procedure 8
Configure	30	270	Configure the Switches	Procedure 9
Switches				
Post-install	30	300	Perform first time configuration	Procedure 11
application			Refer to Procedure A.14 to	
processing			configure the Standalone PDB in	
p. 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2			segmented network configuration.	
			Note: Do not start the PDBA	
			software after creating PDB.	
Full upgrade	5	305	Run the syscheck utility to verify the	Procedure 4
health check			MPS server is operationally sound.	
RTDB Converter	40	345	Run RTDB converter tool from	Procedure 20
		0.0	Compact-to-Compact or Extreme-to-	
			Extreme	
			zxtreme	
			Note : Applicable only in case of full	
			upgrade from EPAP 16.3.1 to 17.1.	
Post upgrade	5	350	Restore EuiDB database	Procedure A.32
EuiDB restore	ر	330	INCSTOLE ERIDD RETENDS	1 Tocedule A.32
	*See	*See	Restore EPAP 16.3.1/16.4.1/17.0.0.x	Procedure A.33
Note: Make sure		notes	1	FIOCEGUIE A.55
that before	notes below	below	PDB backup taken before fresh installation	
restoring the	below	DEIOW	IIIStaliation	
Standby PDBA, if				
the extreme DB is				
present on the				
setup then the				
PDB capacity				
should be set as				
per the DB				
capacity via				
epapconfig menu				

1	[1	1	
Restore PDB Backup.				
Note: If Second PDBA site is getting migrated, take backup from the already upgraded site and restore it on the PDBA node getting migrated. Refer Procedure A.43 and Procedure A.6 for PDB Backup.				
Note: If the network speed between two PDBAs is very slow, follow the original procedure to restore PDBA via MySQL dump process. Refer to Procedure A.33.				
Restore RTDB Backup	*See notes below	*See notes below	Restore EPAP 16.3.1/16.4.1/17.0.0.x RTDB backup taken before fresh installation	Procedure A.36
Reload RTDB from mate	30	380	Reload RTDB from mate on Non- prov MPS B	Procedure A.11
Exchange the keys between active EPAP site and standby EPAP site	30	410	Keys exchange between active and standby EPAP sites.	Procedure A.35
Reset RTDB homing policy on Non-Prov nodes	*See notes below	*See notes below	Modify the RTDB homing to Non- Upgraded PDBA on Non-Prov Nodes	Procedure A.30
Note: 1. Non-Prov must be homed to the				

Non-Upgraded PDBA (This applicable in case of first PDBA site upgrade) 2. Skip this step during the second PDBA site migration				
Reset RTDB homing policy on Prov PDBA	15	425	In case of Mixed EPAP node being migrated then RTDB homing must point to its own PDBA (Self)	Procedure A.44
Reconfigure Additional EPAP configurations NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS. Also, QS is not supported in EPAP 17.1. release but continue to note down the Query srver details for future reference.	45	470	Reconfigure the EMS, QS, Automatic PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations. Note: If HTTP was enabled before migration, then reconfigure the HTTP configuration by disabling the configuration first and then enabling the configuration again from EPAP GUI	Procedure A.41
Take snapshot of uiEdit parameters on upgraded EPAP 17.0.0.y servers	10	480	Take a snapshot of uiEdit parameters to be compared after migration is complete	Procedure A.39
Compare uiEdit parameters	10	490	Compare the snapshot taken in EPAP 17.0.0.y with the one taken on the EPAP 16.3/16.4 /17.0.0.x before migration	Procedure A.42

Start the PDB software	10	500	Re-activate the PDB on the Provisionable MPS A servers (PDBonly in this case). Note: Step only necessary during upgrade of a Provisionable mated EPAP pair (mixed EPAP).	Procedure 27
**Configure Auto Backup.	5	505	Configure auto backup to schedule RTDB Auto-Backup on NonProvisionable EPAP	Procedure A.25
Accept the upgrade after successful soak period NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given. NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS.	5	This is done in a separate MTC.	Accept the upgrade on both MPS-A after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 22

Table 11: Full Upgrade Phases for Dual Mixed with live provisioning

- When the Non-Upgraded PDBA site (Currently on 16.3.1/16.4.1) will be upgraded, do the following:
 - a. Perform switchover on the Non-Upgraded site (currently on 16.3.1/16.4.1) to make it as Standby PDBA.
 - b. The already upgraded site (on EPAP 17.1) will be the newly Active PDBA.
 - c. Then follow the Table 11 Full Upgrade Phases Dual Mixed with Live Provisioning to perform the upgrade.

- The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.
- The time needed to restore PDB backup (MysqlDump) is dependent on the amount of PDB database.
- This procedure cannot specify an exact length of time since different customers have different amounts of application data.
- If configuring 4 switches, add 30 minutes to the current setup.
- The time needed to reload EAGLE cards is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.
- Configuring auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

3.1.6 Full Upgrade Phases for Standalone PDB without live provisioning

Note: Do not add DN and DNBlock with lsblset parameter until all nodes in the network are migrated to EPAP 17.1 successfully.

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Full upgrade	5	20	Verify this should be a Full upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14

EPAP 16.3/16.4/17.0.0.x EuiDB and PDB Backups	*See notes below	*See notes below	Backup application databases and other pertinent information in case of backout required	Procedure A.6 Procedure A.8
Take snapshot of uiEdit parameters	15	70	Take a snapshot of uiEdit parameters to be compared after migration is complete	Procedure A.39
Change MySql engine schema	15	85	Change mysql schema from myiasm to innoDB Note: This procedure is not to be	Procedure A.31
Save the EPAP 16.3/16.4/17.1 additional configurations	20	105	performed if migrating from 17.0.0.x. Save the NTP, EMS, QS, Automatic PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations, HTTP configurations	Procedure A.40
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information. Note: Copy database files (PDB and EuiDB) to backup server.	Procedure 15
Pre-upgrade system time check	5	110	Pre-upgrade system time check.	Procedure 16
IPM E5-APP-B Server	45	155	This Procedure will IPM the E5-APP-B Server	Procedure A.13
Configure Server 1A	5	160	Set hostname, designation, function, and time.	Procedure 5
Install Server	30	190	Install software on sides 1A	Procedure 7
Post-install application processing	30	220	Perform first time configuration Refer to Procedure A.14 to configure the Standalone PDB in segmented network configuration. Note: Do not start the PDBA software after creating PDB.	Procedure 11
Full upgrade health check	5	225	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Change DB architecture from Compact to eXtreme on Non-Prov site Read the note carefully.	45	270	Change DB architecture from compact to Extreme	Procedure 13

Note 1: Applicable in case of full upgrade from 16.3.1/16.4.1 in Extreme mode to 17.1 Extreme Note 2: This step not needed in Compact (16.3/16.4) -> compact (17.1), compact- (16.3/16.4) >eXtreme (17.1). Post upgrade EuiDB restore	5	275	Restore EuiDB database taken before fresh installation	Procedure A.32
Reconfigure Additional EPAP configurations NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS. Also, QS is not supported in EPAP 17.1 release, but continue to note down the Query srver details for future reference.	*See notes below 45	*See notes below 320	Restore EPAP 16.3/16.4/17.0.0.x PDB backup taken before fresh installation Reconfigure the EMS, QS, Automatic PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations. Note: If HTTP was enabled before migration, then reconfigure the HTTP configuration by disabling the configuration first and then enabling the configuration again from EPAP GUI.	Procedure A.33 Procedure A.41
Take snapshot of uiEdit parameters on upgraded EPAP 17.0.0.y servers	10	330	Take a snapshot of uiEdit parameters to be compared after migration is complete.	Procedure A.39
	10	340	Compare the snapshot taken in EPAP	Procedure A.42

Compare uiEdit parameters			17.0.0.y with the one taken on the EPAP 16.3/16.4/17.0.0.x before migration.	
Start the PDB software.	10	350	Re-activate the PDB on the upgraded PDB server	Procedure 27
**Configure Auto Backup.	5	355	Configure auto backup to schedule RTDB Auto-Backup on NonProvisionable EPAP.	Procedure A.25
Accept the upgrade after successful soak period NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given. NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS.	5	This is done in a separate MTC.	Accept the upgrade on both MPS-A after sufficient soak period of around 1-7 days. (Depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 22

Table 12: Full Upgrade Phases on Standalone PDB

- The time needed to backup application data is dependent on the amount of application data. This
 procedure cannot specify an exact length of time since different customers have different amounts
 of application data.
- Configuring Auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 16.4. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

3.1.7 Full upgrade Phases for Dual PDBonly with live provisioning

Note: Refer Appendix E for things to be taken care while performing full upgrade with live provisioning **Note**: Do not add DN and DNBlock with Isblset parameter until all nodes in the network are migrated to EPAP 17.1 successfully.

Phase	Ti	osed me nutes)	Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Full upgrade	5	20	Verify this should be a Full upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
EPAP 16.3/16.4/17.1 EuiDB and PDB Backups	*See notes below	*See notes below	Backup application databases and other pertinent information in case of backout required	Procedure A.6 Procedure A.8
Take snapshot of uiEdit parameters	10	65	Take a snapshot of uiEdit parameters to be compared after migration is complete	Procedure A.39
Clear the repl logs	15	80	STOP ACTIVE PDBA AND VERIFY REPL LOGS	Procedure A.28
Remove remote PDBA IP from Standby PDBA site	15	95	Delete the remote (Active) PDBA IP on Standby PDBA via epapconfig menu	Procedure A.29
Note: Make sure remote PDBA is present in Active PDBA site Refer Appendix E.				

Reset RTDB homing policy to remote PDB	15	110	Modify the RTDB homing policy to active preferred alternate allowed	Procedure A.30
Change MySql engine schema	15	125	Change mysql schema from myiasm to innoDB Note: This procedure is not to be	Procedure A.31
Save the EPAP 16.3/16.4/17.1 additional configurations	20	145	performed if migrating from 17.0.0.x. Save the NTP, EMS, QS, Automatic PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations, HTTP configurations	Procedure A.40
Pre-upgrade Backup Note: Take PDB backup from the node migrated first in the network Refer to Procedure 6.	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	150	Pre-upgrade system time check.	Procedure 16
IPM E5-APP-B Server	45	195	This procedure will IPM the E5-APP-B Server	Procedure A.13
Configure Server 1A	5	200	Set hostname, designation, function and time.	Procedure 5
Install Server	30	230	Install software on sides 1A	Procedure 7
Post-install application processing	30	260	Perform first time configuration Refer to Procedure A.14 to configure the Standalone PDB in segmented network configuration. Note: Do not start the PDBA software after creating PDB.	Procedure 11
Full upgrade health check	5	265	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Change DB architecture from Compact to eXtreme Read the note carefully.	45	310	Change DB architecture from compact to Extreme	Procedure 13

Note 1: Applicable in case of full upgrade from 16.3.1/16.4.1 in Extreme mode to 17.1 Extreme. Note 2: This step not needed in Compact (16.3/16.4) -> compact (17.1), compact- (16.3/16.4) >eXtreme (17.1).				
Post upgrade EuiDB restore	5	315	Restore EuiDB database	Procedure A.32
Note: Make sure that before restoring the Standby PDBA, if the extreme DB is present on the setup then the PDB capacity should be set as per the DB capacity via epapconfig menu. Restore PDB Backup. Note: If Second PDBA site is getting migrated, take backup from the already upgraded site and restore it on the PDBA node getting migrated. Refer to Procedure A.43 for PDB Restore and Procedure A.6 for PDB Backup.	*See notes below	*See notes below	Restore EPAP 16.3/16.4/17.0.0.x PDB backup taken before fresh installation.	Procedure A.33
Exchange the keys between active and standby PDB	30	345	Key exchange between Active PDB and Standby PDB	Procedure A.35

Reconfigure Additional EPAP configurations NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS. Also, QS is not supported in EPAP 17.1 release but note down the Query srver details for future reference.	45	390	Reconfigure the EMS, QS, Automatic PDB-RTDB backup, Configure file transfer, schedule EPAP Tasks configurations. Note: If HTTP was enabled before migration, then reconfigure the HTTP configuration by disabling the configuration first and then enabling the configuration again from EPAP GUI.	Procedure A.41
Take snapshot of uiEdit parameters on EPAP 17.1 servers.	10	400	Take a snapshot of uiEdit parameters to be compared after migration is complete.	Procedure A.39
Compare uiEdit parameters	10	410	Compare the snapshot taken in EPAP 17.1 with the one taken on the EPAP 16.3/16.4 before migration.	Procedure A.42
Start the PDB software.	10	420	Reactivate the PDB on the Provisionable MPS A servers (PDBonly in this case). Note: Step only necessary during upgrade of a Provisionable mated EPAP pair (mixed EPAP + PDBonly).	Procedure 27
**Configure Auto Backup.	5	425	Configure auto backup to schedule RTDB Auto-Backup on NonProvisionable EPAP.	Procedure A.25
Reboot EAGLE Cards	*See notes below	*See notes below	Reboot Eagle Cards to reload updated DB	Procedure 21

Accept the upgrade after successful soak period. NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given.	5	This is done in a separate MTC.	Accept the upgrade on both MPS-A after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 22
NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS.				

Table 13: Full Upgrade Phases Dual PDBonly

- When the Non-Upgraded PDBA site (Currently on 16.3.1/16.4.1) will be upgraded, do the following:

 a. Perform switchover on the Non-Upgraded site(Currently on 16.3.1/16.4.1) to make it as

 Standby PDBA.
 - b. The already upgraded site (on EPAP 17.1) will be the newly Active PDBA.
 - c. Then follow the Table 13 Full Upgrade Phases Dual PDBonly above to perform the upgrade.
- The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.
- Configuring Auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

Dual Upgrade Upgrade Phases

Note: DIU upgrade is not yet supported in EPAP.

The following table illustrates the progression of the various Dual Image Upgrade (DIU) process by procedure with phases, their estimated duration, and the procedure to be performed in every phase. The estimated duration of each upgrade phase may vary due to the differences in the typing ability and system configuration. The procedures outlined in the following tables are to be run in the same order.

Note: Before proceeding with the Dual Image Upgrade procedure, refer to section <u>Upgrading Provisionable</u> <u>mixed EPAP Mated Pairs</u> and <u>Upgrading EPAP Non-Provisionable MPS Servers</u> to get the overview of the EPAP setup and upgrade order.

3.1.8 Dual Image Upgrade Phases for Mixed EPAP without Live Provisioning

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Dual Image Upgrade	5	20	Verify this should be a Dual Image Upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Upgrade MPS B	30	90	Execute the upgrade procedure on MPS B.	Procedure A.47
Upgrade MPS A	30	120	Execute the upgrade procedure on MPS A.	Procedure A.47

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Post-upgrade health check	5	125	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Clear the Replication logs.	20	430	Clear the replication logs before connecting both the PDBAs.	Procedure A.28
			Note: Perform this procedure in case of dual mixed EPAP.	
Exchange the keys between active EPAP site and standby EPAP	30	465	Keys exchange between active and standby EPAP sites.	Procedure A.35
site			Note: Perform this procedure in case of dual mixed EPAP.	
Switchover PDBA to Active	5	130	Switchover the PDBA state to Active	Procedure A.48
Configure Switches	30**	160**	Re-configure the switch and verify that EAGLE SM cards are getting auto negotiated to 1000Mbps/Full Duplex.	Procedure 9
			Note: Skip this step if speed is already set to 1000Mbps/Full Duplex.	
Post-upgrade Backups	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Accept the upgrade after successful soak period. NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given.	5	This is done in a separat e MTC.	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure A.50

Table 14: Dual Image Upgrade Phases for Mixed EPAP without live provisioning

Note:

- The time needed back up PDB data depends on the amount of application data. The duration of this procedure cannot specify an exact length of time to be specified as different customers have different amounts of application data.
- The time needed to restore PDB backup (MysqlDump) depends on the volume of data in the PDB database.
- The time needed to reload EAGLE cards depends on the amount of application data. The duration of this procedure cannot be specified as different customers have different amounts of application data.
- If configuring 4 switches, add 30 minutes to the current setup.
- Configuring auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

3.1. 9 Dual Image Upgrade Phases for Dual Mixed EPAP without Live Provisioning

This procedure lists the procedure to upgrade Dual Mixed EPAP servers without live provisioning.

Phase	Activity	Procedure
Upgrading when both servers are on EPAP are on the 17.0.0.2 and above release.	Upgrade Standby PDBA site on EPAP 17.0.0.2 and above release to the latest EPAP release. After this switchover, upgrade the setup PDBA to Active and then upgrade the Standby PDBA site.	Refer to Procedure 3.1.9

3.1.10 Dual Image Upgrade Phases for Non-Provisionable EPAP with or without live provisioning

Upgrade/Installation Guide

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Dual Image Upgrade	5	20	Verify this should be a Dual Image Upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Upgrade MPS B	30	90	Perform the upgrade procedure on MPS B.	Procedure A.47
Upgrade MPS A	30	120	Perform the upgrade procedure on MPS A.	Procedure A.47
Post-upgrade health check	5	125	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Configure Switches	30**	165**	Re-configure the switch and verify that EAGLE SM cards are getting auto negotiated to 1000Mbps/Full Duplex. Note: Skip this step if speed is	Procedure 9
			already set to 1000Mbps/Full Duplex.	
Post-upgrade Backups	*See notes below	*See notes below	Back up application databases and other pertinent information.	Procedure 15

Phase	Ti	psed me nutes)	Activity	Procedure
Filase	This Step	Cum.	Activity	Flocedule
Accept the upgrade after successful soak period. NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given.	5	This is done in a separat e MTC.	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to verify that everything works fine after the upgrade.	Procedure A.50

Table 14: Dual Image Upgrade Phases for Non-Provisionable EPAP with or without live provisioning Note:

- The time needed to back up application data depends on the amount of application data. The duration of this procedure cannot specify an exact length of time sincebe specified as different customers have different amounts of application data.
- The time needed to restore PDB backup (MysqlDump) depends on the volume of data in the PDB database.
- The time needed to reload EAGLE cards depends on the amount of application data. The duration of this procedure cannot specify an exact length of time sincebe specified as different customers have different amounts of application data.
- If configuring 4 switches, add 30 minutes to the current setup.
- Configuring auto backup is a mandatory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

3.1.11 Dual Image Upgrade Phases for Dual Mixed with live provisioning

Phase	Ti	osed me nutes) Cum.	Activity	Procedure
	Step	cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Dual Image Upgrade	5	20	Verify this should be a Dual Image Upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
Pre-upgrade Backup Note: Take PDB backup from the node migrated first in the network. Refer to Procedure A.6. Note: If the network speed between two PDBA's is very slow, follow the original procedure to perform PDBA backup via MySQL dump process. Refer to Procedure A.27.	*See notes below	*See notes below	Back up application databases and other pertinent information.	Procedure 15
Clear the repl logs	15	85	Verify that replication logs are cleared between active and standby EPAPs.	Procedure A.28
Reset RTDB homing policy	15	100	Modify the RTDB homing policy.	Procedure A.30

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Remove remote PDBA IP from Standby PDBA site Note: Make sure remote PDBA is present in Active PDBA site. Refer Appendix E.	15	115	Delete the remote (Active) PDBA IP on Standby PDBA via epapconfig menu.	Procedure A.29
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Upgrade MPS B	30	90	Perform the upgrade procedure on MPS B.	Procedure A.47
Upgrade MPS A	30	120	Perform the upgrade procedure on MPS A.	Procedure A.47
Post-upgrade health check	5	125	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Exchange the keys between active EPAP site and standby EPAP site	30	410	Keys exchange between active and standby EPAP sites.	Procedure A.35
Reset RTDB homing policy on Non-Prov nodes Note: 1. Non-Prov must be homed to the Non-Upgraded PDBA (This applicable in case of first PDBA site upgrade) 2. Skip this step during the second PDBA site migration.	*See notes below	*See notes below	Modify the RTDB homing to Non- Upgraded PDBA on Non-Prov Nodes	Procedure A.30
Reset RTDB homing policy on Prov PDBA.	15	425	If Mixed EPAP node is migrated, then RTDB homing must point to its own PDBA (Self).	Procedure A.44

Phase	Tii	osed me nutes)	Activity	Procedure
	This Step	Cum.		
Configure Switches	30**	165**	Re-configure the switch and verify that EAGLE SM cards are getting auto negotiated to 1000Mbps/Full Duplex. Note: Skip this step if speed is already set to 1000Mbps/Full Duplex.	Procedure 9
Post-upgrade Backups	*See notes below	*See notes below	Back up application databases and other pertinent information.	Procedure 15
Accept the upgrade after successful soak period NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given.	5	This is done in a separat e MTC.	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure A.50

Table 14: Dual Image Upgrade Phases for Dual Mixed with live provisioning

- When the non-upgraded PDBA site (Currently on 17.1) will be upgraded, do the following:
 - a. Perform switchover on the non-upgraded site (Currently on 17.y) to make it as Standby PDBA.
 - b. The already upgraded site (on EPAP 17.1) will be the newly Active PDBA.
 - c. Then follow the above table Dual Image Upgrade Phases Dual Mixed with Live Provisioning to perform the upgrade.
- The time needed to back up application data depends on the amount of application data. The duration of this procedure cannot specify an exact length of time to be specified as different customers have different amounts of application data.
- The time needed to restore PDB backup (MysqlDump) depends on the amount of data in the PDB database.
- The duration of this procedure cannot specify an exact length of time sincebe specified as different customers have different amounts of application data.

- The time needed to reload EAGLE cards depends on the amount of application data. The duration of this procedure cannot specify an exact length of time to be specified as different customers have different amounts of application data.
- If configuring 4 switches, add 30 minutes to the current setup.
- Configuring auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

3.1.12 Dual Image Upgrade Phases for Standalone PDB without live provisioning

Phase	Ti	psed me nutes)	Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify incremental upgrade	5	20	Verify this should be an incremental upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Upgrade MPS A	30	90	Perform the upgrade procedure on MPS A.	Procedure A.47
Post-upgrade health check	5	95	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Switchover PDBA to Active	5	100	Switchover the PDBA state to Active	Procedure A.48
Post-upgrade Backups	*See notes below	*See notes below	Back up application databases and other pertinent information.	Procedure 15
Accept the upgrade after successful soak period. NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given.	5	This is done in a separat e MTC.	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure A.50

Table 10:5: Dual Image Upgrade Phases for Standalone PDB without live provisioning

3.1.13 Dual Image Upgrade Phases for Dual PDBonly with live provisioning

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify incremental upgrade	5	20	Verify this should be an incremental upgrade.	Procedure 2

^{*}NOTE: The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

Phase	Tir (Mir This	osed me nutes) Cum.	Activity	Procedure
Pre-upgrade check	Step 15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
Remove remote PDBA IP from Standby PDBA site	15	95	Delete the remote (Active) PDBA IP on Standby PDBA via epapconfig menu	Procedure A.29
Note: Make sure remote PDBA is present in Active PDBA site Refer Appendix E.				
Clear the repl logs	15	80	STOP ACTIVE PDBA AND VERIFY REPL LOGS	Procedure A.28
Reset RTDB homing policy to remote PDB	15	110	Modify the RTDB homing policy to active preferred alternate allowed	Procedure A.30
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Upgrade MPS A	30	90	Execute the Upgrade procedure on MPS A.	Procedure A.47
Post-upgrade health check	5	95	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Exchange the keys between active and standby PDB	30	300	Key exchange between Active PDB and Standby PDB	Procedure A.35
Post-upgrade Backups	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15

Phase	Tir	osed me nutes)	Activity	Procedure
	This Step	Cum.		
Accept the upgrade after successful soak period NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given.	5	This is done in a separat e MTC.	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure A.50

NOTE:

- When the non-upgraded PDBA site (Currently on 17.x) will be upgraded, do the following:
 - a. Perform switchover on the non-upgraded site (Currently on 17.xy) to make it as Standby PDBA.
 - b. The already upgraded site (on EPAP 17.y.0) will be the newly Active PDBA.
 - c. Then follow the above table Dual Image Upgrade Phases for Dual PDBonly with live provisioning to perform the upgrade.
- The time needed to back up application data depends on the amount of application data. The duration of this procedure cannot specify an exact length of time to be specified as different customers have different amounts of application data.
- The time needed to restore PDB backup (MysqlDump) depends on the volume of data in the PDB database. The duration of this procedure cannot be specified as different customers have different amounts of application data.
- The time needed to reload EAGLE cards depends on the amount of application data. The duration of this procedure cannot be specified as different customers have different amounts of application data.
- If configuring 4 switches, add 30 minutes to the current setup.
- Configuring auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.
- If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 17.1. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

Backout Phases

Note: Before proceeding with the backout process, refer to <u>section 2.1</u>, <u>section 2.2</u>, <u>section 2.3</u> and <u>section 2.4</u> to get the overview of the EPAP setup and the backout order.

3.1.14 Backout Phases for Mixed and Non-Provisionable EPAP

	Elapsed Time Phase (Hours or Minutes)				Procedure	
Phase			Activity	Impact		
	This Step	Cum				
Determine state of system	15- 30	15- 30	Investigate and determine the state of the MPS system. This may take anywhere from 15 to 30 minutes.	Cannot proceed with backout until failure analysis is complete. Some hand-fixes may be required before proceeding with backout.	Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section.	
Backout MPS A and B	900	915- 930	Backout MPS A and B.		Procedure A.45	
Configure Switches	30*	945- 960 *	Re-configure the switch and verify that EAGLE SM cards are getting auto negotiated to previous speed. Note: Skip this step if speed before upgrade was 1000Mbps/Full Duplex.	Verify that speed of switch is negotiated to previous speed.	Procedure 9	

Table 11: Backout Phases for Mixed and Non-Provisionable EPAP

3.1.15 Backout Phases for Standalone PDB

^{*}NOTE: If configuring 4 switches, add 30 minutes to the current setup.

Phase	Elapsed Time (Hours or Minutes)		Time (Hours or		Time (Hours or		Activity	Impact	Procedure
	This	Cum							
	Step	•							
Determine	15-	15-	Investigate and	Cannot proceed with	Contact My Oracle				
state of	30	30	determine the state of	backout until failure	Support following the				
system			the MPS system. This	analysis is complete.	instructions on the				
			may take anywhere	Some hand-fixes may	front page or the				
			from 15 to 30 minutes.	be required before	instructions in the				
				proceeding with	My Oracle Support				
				backout.	section.				
Backout	600	615-	Backout MPS A.						
PDBonly		630			Procedure A.46				
site.									
Start the	5	620-	Re-activate the PDB on		Procedure 27				
PDBA		635	the						
software			Provisionable(PDBonly)						
			MPS A servers.						

Table 127: Backout Phases for Standalone PDB

Log Files

All commands executed during an upgrade or installation, are logged in the

"/var/TKLC/log/upgrade/upgrade.log" file. This log file is automatically initiated when upgrade software is invoked. This log file is rolled every time an upgrade is initiated. A total of up to five upgrade log files are stored on the server.

The upgrade wrapper script, ugwrap, logs its actions also to the "/var/TKLC/log/upgrade/ugwrap.log" file. This log file is rolled every time ugwrap is initiated. A total of up to five ugwrap log files are stored on the server.

4 DB ARCHITECTURE OVERVIEW

A new parameter LSBLSET would be added to DN and DN Block tables. This parameter will be used along with CGPNBLSET parameter on EAGLE that would be configured in the linkset table on EAGLE. If the value of LSBLSET parameter for a DN/DN Block on EPAP is found to match with the CGPNBLSET parameter of linkset table on EAGLE, it will be considered as blocklisted DN/DN Block. IAM message will be released (i.e. send back to originator) from EAGLE for the corresponding DN/DN Block. In all other cases, the existing functionality will continue to hold true.

The existing DN/ DN Block table parameters that are configured in the GUI are stored in multiple SQL tables, the DN table for example has only two parameters dnID and PT(port type) parameters in it.

There are other tables (example dn_bl, dn_asd etc.) which help in storing the other parameters entered in GUI forms for DN and DNBlock.

While entering values write operation, is performed with the help of multiple joins with these supporting tables.

Finally, while displaying these values during retrieve operation the join of all the supporting tables is taken and the values fetched are displayed together.

The new parameter LSBLSET is part of dn_bl table and dnB_bl SQL tables for DN and DN Block respectively. This new parameter will be compatible only with eagle 46.9 release.

From EPAP 16.3 onwards different DB architectures are supported i.e., "Compact" and "Extreme". This was done to support enhanced DB capacity.

EPAP 16.4 also supports both compact and extreme architecture. Post upgrade user will remain on existing architecture and will have to change the architecture from compact to extreme as an optional step if required. In changing the DB Architecture from "Compact" to "eXtreme", the EPAP software shall restart to support the capacity expansion. Before the change in DB Architecture on EPAP, the connecting EAGLE must upgrade to the new release with SLIC cards. Also, the user has-to enable the EPAPX feature on eagle card to support the eXtreme feature. Refer to section 0 to change DB Architecture from Compact to eXtreme.

NOTE: Section <u>4.2</u> and <u>4.3</u> are only required if customer setup is on compact architecture and wants to change architecture to extreme. Others i.e. those who are already on extreme architecture or doesn't want to change to extreme architecture can skip these sections.

Overview of DB architecture change in Customer Network

Upgrade from EPAP 16.3.1/16.4.1 to EPAP 17.1 followed by DB Architecture conversion to support new LSBLSET parameter must be carried out as per the below table after upgrade is completed in same MTC window. Based on the existing DB Architecture either compact to compact converter script will be executed or extreme to extreme converter script will be executed. Follow procedure to identify DB architecture and run conversion script.

Table 18: DB Conversion

Base Release	Target Release	Data Base Architecture	Target Architecture	Converter Required
16.3.1	17.1	Compact	Compact	Compact to Compact converter to accommodate IsbIset parameter
16.3.1	17.1	Extreme	Extreme	Extreme to Extreme converter to accommodate IsbIset parameter
16.4.1	17.1	Compact	Compact	Compact to Compact converter to accommodate Isblset parameter
16.4.1	17.1	Extreme	Extreme	Extreme to Extreme converter to accommodate Isblset parameter

^{*}Note: Allow soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade. After getting convinced that system is working fine, accept the upgrade.

Overview of DB architecture change from Compact to Extreme

Upgrade from EPAP 16.3.1/16.4.1 to EPAP 17.1 followed by DB Architecture conversion from Compact to Extreme must be carried out in following order with different MTC window:

Note: This step is required only when EPAP 17.1 and Eagle are to run in eXtreme mode. If EPAP and Eagle are to run in COMPACT mode, skip this section.

Phase-1 (Upgrade the EPAPs to EPAP 17.1 release in COMPACT mode):

NOTE: If the network consists of Non-PROVs and Mixed-EPAP, move to Phase-2 (Change the Mode from COMPACT mode to eXtreme mode for one Non-PROV site) otherwise continue with the following steps if the setup consists of StandAlonePDB + Non-PROVS.

- **1.** First the Standalone PDBs will be upgraded to EPAP 16.4 in COMPACT mode. Refer to section 3.4 for the upgrade process.
- **2.** All non-PROVs should be upgraded to EPAP 17.1 in COMPACT mode. Refer to <u>section 3.4</u> for the upgrade process.

After this phase all EPAPs in the customer network are in EPAP 17.1 and are working in COMPACT mode.

Phase 2: Change the Mode from COMPACT mode to eXtreme mode for one Non-PROV site:

Execute the procedure in the following sequence.

Upgrade/Installation Guide

66 of 450 June 2025

- 1. Choose one EPAP-Eagle site from the customer network, which will be converted to eXtreme mode.
- 2. On the EAGLE, replace all non-SLIC SCCP cards to SLIC 64-bit SCCP cards. Change stpopts:EPAPX ON.
- On the connecting Non-Prov, change the mode from COMPACT to eXtreme. Refer to section 4.3 to change DB Architecture to eXtreme. The StandalonePDB should remain in COMPACT mode at this stage.
- 4. Restore RTDB on Non-Prov EPAP-A (refer to <u>Procedure A.10</u>) and after successfully restored RTDB on EPAP-A(refer to <u>Procedure A.11</u>), perform reload from mate on Non-Prov EPAP-B. Reload the Eagle from EPAP. Check that the DB downloads and EPAP-Eagle network work normally. Live provisioning flows all the way to Eagle. Let the node soak for some *time-period.

Phase 3: Change the Mode from COMPACT mode to eXtreme mode for whole network:

At this stage, we have seen that EPAP and Eagle are working fine in eXtreme mode. All the remaining Non-PROVs and StandAlone PDBs will be converted to eXtreme mode now. All the remaining Non-PROVs will be converted to eXtreme mode first. After all Non-PROVs are converted to eXtreme, the StandalonePDBs will be converted to eXtreme. For every site, before converting the EPAPs, connected eagles will have EPAPx feature ON.

- 1. First on the EAGLE, replace all non-SLIC SCCP cards to SLIC 64-bit SCCP cards. Change stpopts:EPAPX ON. Upgrade/Installation Guide 33 of 292 February 2023
- 2. On the connected Non-Prov, change the mode from Compact to eXtreme. Refer to <u>section</u>
 4.3 to change DB Architecture to eXtreme.
- 3. Reload the RTDB from already converted eXtreme mode RTDB in phase 1. Refer to Procedure A.11.
- 4. Reload the Eagle SM cards from the EPAP.
- Repeat steps 1 to 4 for all remaining Non-PROVs in the Customers network
- 6. Convert the StandalonePDBs to eXtreme mode.

Change DB Architecture from COMPACT to eXtreme to support EAGLE release 46.7.0.0.0 (eXtreme feature)

The following table illustrates the progression of the movement of DB Architecture from COMPACT to eXtreme by procedure with estimated times and may vary due to differences in typing ability and system configuration. The procedures outlined in below Table 18 are to be executed in the order they are listed.

Before proceeding with the change DB Architecture process, refer to section 4 and section 5 to get the overview of the DB Architecture and upgrade order.

Notes: 1. Skip this section for mixed EPAP as eXtreme feature not supported on mixed EPAP.

2. DB Architecture cannot be reverted to COMPACT once moved to eXtreme architecture.

Upgrade/Installation Guide

67 of 450 June 2025

4.1.1 Phases to change DB Architecture to eXtreme (Standalone PDB)

Phase	Ti	osed me nutes)	Activity	Procedure
	This Step	Cum.		
Check database before changing DB architecture to eXtreme.	40	40	Check 9dig counts for all DN/IMSI and IMEI before changing DB architecture to eXtreme.	Procedure 17
Change DB Architecture to eXtreme	40	80	Note: Skip this procedure on Mixed EPAP. Change DB Architecture from COMPACT to eXtreme. Note: If parsing gets failed at this stage then user needs to run it manually. Check 0 to execute it manually.	Procedure 13
Accept the upgrade after successful soak period	5	This is done in a separat e MTC	Accept the upgrade after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 21

Table 13: Phases to change DB Architecture to eXtreme (Standalone PDB)

4.1.2 Phases to change DB architecture to eXtreme (First Non-Prov site)

Elapsed Time Phase (Minutes)		Activity	Procedure	
	This Step	Cum.		
Check database before changing DB architecture to eXtreme.	*see notes below	*see notes below	NOTE:Perform this step on attached PDBonly EPAP if not already exececuted. Check 9dig counts for all DN/IMSI and IMEI before changing DB architecture to eXtreme.	Procedure 17
Take backup before moving to eXtreme architecture	**See notes below	**See notes below	Take RTDB backup if not already taken, before moving to eXtreme architecture. Note: Skip this step for PDBonly.	0
Change DB Architecture to eXtreme	5	5	Change DB Architecture from COMPACT to eXtreme Note: EPAPX feature must be "ON" on the connected eagle before procedure 13	Procedure 13
Restore RTDB backup on Non-prov.	240	245	Restore RTDB backup on Non-prov MPS A.	0
Reload RTDB from mate	10	255	Reload RTDB from mate on Non-prov MPS B.	0
Accept the upgrade after successful soak period	5	This is done in a separat e MTC	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 21

Table 20: Phases to change DB Architecture to eXtreme (First Non-prov site)

^{*}NOTE: The time for checking database will be added for attached PDBonly EPAP (Added in section 4.2.1).

^{}NOTE:** The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

4.1.3 Phases to change DB architecture to eXtreme (Remaining Non-Prov sites)

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Take backup before moving to eXtreme architecture	*See notes below	*See notes below	Take RTDB backup if not already taken, before moving to eXtreme architecture. Note: Skip this step for PDBonly.	0
Change DB Architecture to eXtreme	5	5	Change DB Architecture from COMPACT to eXtreme Note: EPAPX feature must be "ON" on the connected eagle before procedure 13	Procedure 13
Reload RTDB from remote	10	15	Reload the RTDB from remote(already in eXtreme mode) Note: Remote Non-Prov EPAP must be in eXtreme mode. (Which may be the first Non-Prov site converted in table 19 or any other remote EPAP which is already in eXtreme mode)	0
Reload RTDB from mate	10	25	Reload RTDB from mate on Non-prov MPS B.	0
Accept the upgrade after successful soak period	5	This is done in a separat e MTC	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 21

Table 21: Phases to change DB Architecture to eXtreme (Remaining Non-Prov sites)

^{*}NOTE: The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

5 UPGRADE PREPARATION

Setting up the upgrade environment

Procedure 1: Setting up the upgrade environment

S T E P #	This procedure sets up the upgrade environment. Windows are opened for both MPS servers. NOTE: Call My Oracle Support for assistance if modem access is the method use for upgrade. Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.				
1.	Upgrade can be done in two ways: A. Remotely B. Locally	Refer to Step 2 to 6 for executing remotely. Refer to Step 7 to 19 for executing locally.			
2.	Ensure MPS X: All the console/PuTTY Sessions.	1. 2. 3. 4. 5. 6.	the console/PuTTY sessions, make sure that the logging in enabled and e written to a file. For example, on a PuTTY session, do the following. Right click on the top bar in the PuTTY and choose "change setting". Click on "Logging". Select "Printable output". Click on "Browse" and choose where you want the logs to be written so that you can collect those later, if needed. Put a name which will serve better on a later date to understand, for example, name of the log file can be <server name="">_active_pdba_A_server_puttylog_ddmmyyyy. Click on "Save". Type a text "Putty Logging starts" in the PuTTY session and check that above text is logged in the PuTTY log file. the above six steps on every console/PuTTY session that will be used to</server>		

Procedure 1: Setting up the upgrade environment

3.	Access to the MPS servers is available through an IP network.	If not already logged in, then log in. <hostname> console login: admusr Password: <password></password></hostname>
	Step 3 and 4 provide console access to MPS-B from a remote location.	
	MPS A: Log in to the server as user "admusr".	
4.	MPS A: Start screen session	Run the following commands to start screen and establish a console session to MPS B.
		\$ screen -L
	MPS A: Connect to the console of MPS B.	Run the following command on E5-APP-B: \$ sudo minicom mate
		Note : Now user is connected to the console of MPS-B from a remote location.
5.	Step 5 and 6 provide console access to MPS-A from a	If not already logged in, then log in.
	remote location.	<pre><hostname> console login: admusr Password: <password></password></hostname></pre>
	MPS B: Log in to the server as user "admusr".	
6.	MPS B: Start screen session	Run the following commands to start screen and establish a console session to MPS A.
		\$ screen -L
	MPS B: Connect to the console of MPS A.	Run the following command on E5-APP-B: \$ sudo minicom mate Run the following command:
	Note down the timestamp in log.	\$ date
		Note : Now user is connected to the console of MPS-A from a remote location.

Procedure 1: Setting up the upgrade environment

		Note: If upgrade is to be performed from a remote location skip rest of the procedure. If upgrade is to be performed locally then follow step 7 to 19.			
7.	Ensure MPS X: All the console/PuTTY	On all the console/PuTTY sessions, make sure that the logging in enabled and logs are written to a file. For example, on a PuTTY session, do the following.			
	Sessions.	1. Right click on the top bar in the PuTTY and choose "change setting".			
		2. Click on "Logging".			
		3. Select "Printable output".			
		4. Click on "Browse" and choose where you want the logs to be written so that you can collect those later, if needed. Put a name which will serve better on a later date to understand, for example, name of the log file can be <server name="">_active_pdba_A_server_puttylog_ddmmyyyy.</server>			
		5. Click on "Save".			
		6. Type a text "Putty Logging starts" in the PuTTY session and check that above text is logged in the PuTTY log file.			
		Repeat the above six steps on every console/PuTTY session that will be used to enter commands or execute procedure of this document.			
8.	Establish a connection to MPS A.	Access to the MPS servers is not available through an IP network, Connect to the E5-APP-B card via the serial port			
		For connecting the E5-APP-B A card, disconnect the console cable from the serial port on the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for serial access by connecting the serial cable to the customer laptop's serial port. Cable part numbers - 830-1220-xx			
9.	Create a terminal window for MPS A. Note : Steps 9 to 12 make the serial connection to MPS-A	Create a terminal window e.g. open a putty session on the workstation and give it a title of "MPS A"			
10.	MPS A: Enable capture file and verify the correspondent file is created.	Enable the data capture and verify that the data capture file is created at the path specified.			
11.	Log in to MPS A.	<pre><hostname> console login: admusr password: <password></password></hostname></pre>			

Procedure 1: Setting up the upgrade environment

12.	MPS A: Start screen Session.	Run the following command to start screen and establish a console session with MPS A. \$ screen -L
		If for Standalone PDB, the procedure is complete. Otherwise, continue with the next step.
13.	Establish a connection to MPS B.	Access to the MPS servers is not available through an IP network, connect to the E5-APP-B card via the serial port.
	Note : Steps 13 to 17 make the serial connection to MPS-B	For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A card's adapter and use it for serial access by connecting the serial cable to the customer laptop's serial port. Cable part numbers - 830-1220-xx
14.	Create a terminal window for MPS B.	Create a terminal window e.g. open a putty session on the workstation and give it a title of "MPS B"
15.	MPS B: Enable capture file and verify a correspondent file is created.	Enable the data capture and verify that the data capture file is created at the path specified.
16.	Log in to MPS B.	<pre><hostname> console login: admusr password: <password></password></hostname></pre>
17.	MPS B: Start screen Session.	Run the following command to start screen and establish a console session with MPS B. \$ screen -L
18.	MPS A and B: Procedure Complete.	This procedure is complete.
19.	Note down the timestamp in log.	Run the following command: \$ date

Determine if upgrade or installation is required

Procedure 2: Determine if upgrade or installation is required

S	This procedure executes the steps required to determine if an upgrade of the system is		
T	required or an initial application installation is required.		
E	Check off $()$ each step as it is completed. Boxes have been provided for this purpose under each step number.		
P	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE .		
#	IF THIS I ROCEDURE PAILS, CONTACT MT ORACLE SOTTORT AND ASK FOR UT GRADE ASSISTANCE.		
1.	MPS A: Log in to MPS A. If not already logged in, login at MPS A as 'admusr'.		

Procedure 2: Determine if upgrade or installation is required

		<pre><hostname> console login: admusr password: <password> .</password></hostname></pre>
2.	MPS B: Log in to MPS B.	If not already logged in, login at MPS B as 'admusr'. <hostname> console login: admusr password: <password></password></hostname>
3.	MPS B: Determine if the application is currently installed on the servers.	Execute an rpm query command and examine the output: \$ rpm -qi TKLCepap
	(MPS B will be used to determine the current state of the servers. We will assume that the state of the A server is the same).	Name : TKLCepap Relocations: (not relocatable) Version : 170.0.8 Vendor: Tekelec Release : 0.68940 Build Date: Thu 29 Dec 2022 04:10:07 AM EST Install Date: Mon 02 Jan 2023 02:11:44 AM EST Build Host: localhost Group : Development/Build Source RPM: TKLCepap-170.0.8- 0.68940.src.rpm Size : 119091549 License: © TEKELEC 2005-2018 Signature : (none) Packager : <@ttekelec.com> URL : http://www.tekelec.com/ Summary : Oracle Communications EPAP Package Description : This is the Oracle Communications EAGLE Application Processor(EPAP) Package. The Package installs EPAP software. EPAP provides Provisioning Database Application (PDBA on A side) and Real Time Database (RTDB).
4.	MPS B: Observe the output from the rpm query.	The following is an example of what the output may look like: \$ appRev Install Time: Tue Jul 3 03:52:57 2018 Product Name: EPAP Product Release: 16.3.0.0.0_163.8.0 Base Distro Product: TPD Base Distro Release: 7.6.0.0.0_88.48.0 Base Distro ISO: TPD.install-7.6.0.0.0_88.48.0-OracleLinux6.9-x86_64.iso ISO name: EPAP-16.3.0.0.0_163.8.0-x86_64.iso

Procedure 2: Determine if upgrade or installation is required

		OS: OracleLinux 6.9
		If the output similar-to the above example is displayed, then skip to step 6. Otherwise, proceed to the next step.
5.	MPS B: Installation is required if the application is not present on the server, else upgrade is required.	If the application is not currently installed, output similar-to the example below will be returned from the rpm -qi command in step-3. If this is the case, then an application installation is required. Refer to <u>section 3.1.1</u> to perform EPAP installation.
		\$ rpm -qi TKLCepap package TKLCepap is not installed
		Skip to step 10.
6.	MPS B: Determine which version of the	Write Down the Release Number:
	application is present.	Release Number:
		If the release number on the MPS is less than the release number on the upgrade media, then an upgrade is required.
7.	Determine if Full Upgrade is required.	If the current release is 16.3.1/16.4.1and target release is 17.1, it is a FULL UPGRADE.
8.	Determine if an incremental Upgrade is required.	If the current release is 17.0.x.x and target release is 17.1 (x.x is less than the number y.y on the upgrade media), it is a Dual Image Upgrade.
9.	MPS A: Determine if it is Provisionable (either mixed-EPAP or	Run the following command to determine if the EPAP is Provisionable(either mixed-EPAP or PDBonly) or Non-Provisionable.
	PDBonly) or Non- Provisionable EPAP setup.	<pre>\$ uiEdit grep "PROVISIONABLE" "PROVISIONABLE_MPS" is set to "YES"</pre>
		If the above output contains "YES", then the EPAP is Provisionable(either mixed-EPAP or PDBonly). Otherwise, the EPAP is Non-Provisionable. Write down this information.
		EPAP setup type:
10.	MPS B: Determine if the current DB Architecture is	Run the following command to determine if the EPAP DB Architecture is Extreme or Compact.

Procedure 2: Determine if upgrade or installation is required

	compact or extreme.	<pre>\$ uiEdit grep "DB_ARCHITECTURE" "DB_ARCHITECTURE" is set to "COMPACT"</pre>
	(MPS B will be used to determine the current state of the servers. We	If the above output contains "COMPACT" or no output is displayed, then the EPAP DB Architecture is Compact.
	will assume that the state of the A server is the same).	If the above output contains "EXTREME", then the EPAP DB Architecture is Compact. Write down this information.
		EPAP DB Architecture type:
		Based on this information DB converter will be run.
11.	MPS A and B: Procedure Complete.	This procedure is complete.
12.	Note down the timestamp in log.	Run the following command: \$ date

Pre-upgrade requirements

Procedure 3: Verifying Pre-Upgrade Requirements and Capturing Upgrade Data

S	This procedure verifies	s that all pre-upgrade requirements have been met.				
T E	Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number.					
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR <u>UPGRADE ASSISTANCE</u> .					
1.	Verify all required materials are present.	Territy triat the materials hotel in opprate material list (section of the present)				
2.	Verify the availability of passwords for MPS systems. Refer to Table 6Error! Reference source not found. for the list of users.					
3.	Review provisioning rules.	Please review the Provisioning information as defined in Section Error! Reference source not found. If you do not understand the information provided in this section, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section				
4.	Verify and close active GUI Sessions.	Skip this step for fresh install.				
	On the menu, click User Administration->HTTP(s) Support->Terminate UI Sessions	Log in to EPAP GUI as uiadmin user. Terminate all the active GUI sessions from EPAP GUI.				

		A						Terminate Active UI Sessions
		Delete?	Session Id	User Id	User Name	Admin	IP Addr	Last Access
		0	44	99	uiadmin	YES	10.250.32.216	2017-06-20 07:04:11
		0	45	99	uiadmin	YES	10.250.32.216	2017-06-20 07:04:20
		0	46	99	uiadmin	YES	10.250.32.216	2017-06-20 07:04:33
		sessions.	sessions			Selected	Active Sessio	n" to delete all active
5.	Procedure Complete.	This prod	cedure is c	complete.				
6.	Note down the timestamp in	Run the	following	command	d:			
	log.	\$ date						

System Health check

Procedure 4: System Health Check

S	This procedure determines the health of the MPS System before beginning an upgrade.				
T					
E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.				
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE .				
1.	MPS A: Verify health of MPS A. Execute 0 on MPS A to verify the health of MPS A.				
2.	MPS B: Verify health of MPS B.	Execute 0 on MPS B to verify the health of MPS B.			
3.	Procedure Complete.	This procedure is complete.			
4.	Note down the timestamp in log.	Run the following command: \$ date			

6. SOFTWARE INSTALLATION PROCEDURES


Pre install configuration and initial installation of EPAP can be done on any of the server in the mated pair in any order. These operations can be done simultaneously on both the servers.

Pre-Install configuration on server A


Procedure 5: Pre-Install Configuration on Server A

S	This procedure provides instructions to perform pre-configuration for an initial install of the			
T	application.			
E				
P	Check off ($$) each step	as it is completed. Boxes have been provided for this purpose under each step number.		
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.			
	11 1110 1110 022 010			
IMP	ORTANT: Installation	of the Operating System on an Oracle Application Server should be completed		
befo	ore starting installation	on procedure. Refer to <u>Procedure A.13</u> or [4] for TPD installation guide.		
1.	Connect to the Server.	If not already connected, connect to the E5-APP-B card via the serial port.		
		For connecting the E5-APP-B A card, disconnect the console cable from the		
		serial port on the E5-APP-B B card's adapter. The cable should be disconnected		
		at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B		
		card's adapter and use it for serial access. Cable part numbers - 830-1220-xx		
2.	Log in as "admusr"	If not already logged in, then log in as "admusr":		
	user.	[hostname] consolelogin: admusr		
		password: password		
		passitora: passitora		
		passivora. passivora		
3.	Start platcfg	\$ sudo su - platcfg		
3.	Start platcfg utility.			
l	utility.	\$ sudo su - platcfg		
	utility. Navigate to the	\$ sudo su - platcfg Select Server Configuration and press [ENTER]		
4.	utility. Navigate to the Server	\$ sudo su - platcfg		
4.	utility. Navigate to the	\$ sudo su - platcfg Select Server Configuration and press [ENTER]		
4.	utility. Navigate to the Server Configuration	\$ sudo su - platcfg Select Server Configuration and press [ENTER] Main Menu Maintenance Diagnostics		
4.	utility. Navigate to the Server Configuration	\$ sudo su - platcfg Select Server Configuration and press [ENTER] Main Menu Maintenance Diagnostics Server Configuration		
4.	utility. Navigate to the Server Configuration	\$ sudo su - platcfg Select Server Configuration and press [ENTER] Main Menu Maintenance Diagnostics Server Configuration Remote Consoles		
4.	utility. Navigate to the Server Configuration	\$ sudo su - platcfg Select Server Configuration and press [ENTER] Main Menu Maintenance Diagnostics Server Configuration Remote Consoles Security		
4.	utility. Navigate to the Server Configuration	\$ sudo su - platcfg Select Server Configuration and press [ENTER] Main Menu Maintenance Diagnostics Server Configuration Remote Consoles		
4.	utility. Navigate to the Server Configuration	\$ sudo su - platcfg Select Server Configuration and press [ENTER] Main Menu Maintenance Diagnostics Server Configuration Remote Consoles Security Network Configuration		
4.	utility. Navigate to the Server Configuration	\$ sudo su - platcfg Select Server Configuration and press [ENTER] Main Menu Maintenance Diagnostics Server Configuration Remote Consoles Security Network Configuration		
4.	utility. Navigate to the Server Configuration	\$ sudo su - platcfg Select Server Configuration and press [ENTER] Main Menu Maintenance Diagnostics Server Configuration Remote Consoles Security Network Configuration		

Procedure 5: Pre-Install Configuration on Server A




Procedure 5: Pre-Install Configuration on Server A




Procedure 5: Pre-Install Configuration on Server A

If not blank, the values should be as follows for Mixed EPAP and Non-**Provisional EPAP:** 1. The Designation is "1A" for the A server 2. The Function field should be set to EPAP. If not blank, the values should be as follows for Standalone PDB. 1. The Designation is "1A" for the A server 2. The Function field should be set to PDBonly. If both the fields are blank or either value is not correct, then select Edit and press [ENTER]. If both values are correct, select **Exit**, press [ENTER] and skip the next step. 11. View the current Skip to Step 13 if Exit was selected in the previous step, otherwise if Edit was designation and selected, delete the current designation and function if already set, and type in function. the desired values. Enter the appriopriate designation in the Designation field (Note: the designation must be capitalized). Select OK and press [ENTER]. For Mixed EPAP or Non-Provisional EPAP, the following is a correct example: Edit Designation Designation: Function: **EPAP** OK Cancel For Standalone PDB, the following is a correct example: Edit Designation Designation: **PDBonly** Function: OK Cancel


Procedure 5: Pre-Install Configuration on Server A



Procedure 5: Pre-Install Configuration on Server A



Procedure 5: Pre-Install Configuration on Server A




Pre-Install configuration on server B


Procedure 6: Pre-Install Configuration on Server B

S T E P #	This procedure provides instructions to perform pre configuration for an initial install of the application. Check off (1) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.		
	MPORTANT: Installation of the Operating System on an Oracle Application Server should be completed efore starting installation procedure. Refer to Procedure A.13 or [4] for TPD installation.		
1.	Connect to the Server.	If not already connected, connect to the E5-APP-B card via the serial port. For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A cards' adapter and use it for serial access. Cable part numbers - 830-1220-xx	
2.	Log in as "admusr" user.	If not already logged in, then log in as 'admusr':	


Procedure 6: Pre-Install Configuration on Server B




Procedure 6: Pre-Install Configuration on Server B




Procedure 6: Pre-Install Configuration on Server B




Procedure 6: Pre-Install Configuration on Server B



Procedure 6: Pre-Install Configuration on Server B




Procedure 6: Pre-Install Configuration on Server B



Install Application on server B


S	This procedure insta	lls the application on the server.			
T E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.				
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.				
1.	MPS B: Install 1B.	MPS B: Install 1B. Perform Procedure in 0 or copy EPAP 16.3 ISO to /var/TKLC/upgrade directory.			
2.	Create a terminal window Log in to MPS B.	If not already connected, connect to the E5-APP-B card via the serial port. For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A card's adapter and use it for serial access. Cable part numbers - 830-1220-xx			
3.	MPS B: Login prompt is displayed.	<pre><hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname></pre>			

Procedure 7: Install the Application on Server B



8. MPS A: Select Early Upgrade Checks

Select the "Early Upgrade Checks" menu to verify that the system is ready for upgrade.



If the Early Upgrade Checks fail due to the ongoing syncing of raid mirrors, then wait until the resync is completed and run the "Early Upgrade Checks" again.

```
Early Checks failed for the next upgrade
Look at earlyChecks.log for more info
tarting Early Upgrade Checks at 1011413059
Running earlyUpgradeChecks() for Upgrade::EarlyPolicy::TPDEarlyChecks upgrade policy...
Verified server is not pending accept of previous upgrade
ERROR: Raid mirrors are syncing!
ERROR: md2 is syncing!
ERROR: earlyUpgradeChecks() code failed for Upgrade::EarlyPolicy::TPDEarlyChecks
ERROR: Failed running earlyUpgradeChecks() code
Hardware architectures match
Install products match.
No Application installed yet.. Skip alarm check!
ERROR: Early Upgrade Checks Failed!
User has requested just to run early checks.
No upgrade will be performed ..
Early Upgrade Checks finished at 1011413059
[admusr@epappri ~] $ cat /proc/mdstat
Personalities: [raid1]
md1: active raid1 sdb2[1] sda2[0]
    262080 blocks super 1.0 [2/2] [UU]
md2 : active raid1 sda1[0] sdb1[1]
    unused devices: <none>
```

Contact My Oracle Support following the instructions on the front page or the instructions in the **My Oracle Support** section, if the early upgrade checks fail due to any other reason.

Procedure 7: Install the Application on Server B

9.	MPS A: Navigate to the Initiate Upgrade menu	Select the Initiate Upgrade menu and press [ENTER]. Upgrade Menu Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Exit
10.	MPS B: Select the Upgrade Media.	The screen displays a message that it is searching for upgrade media. When the upgrade media is found, an Upgrade Media selection menu appears similar-to the example below. Select the desired upgrade media and press [ENTER]. Choose Upgrade Media Menu EPAP-17.0.0.3.0_170.19.0-x86_64.iso - 17.0.0.3.0_170.19.0 Exit
11.	MPS B: Upgrade proceeds.	The screen displays the following, indicating that the upgrade software is first validating the media, and then proceeding with the upgrade. No Application installed yet Skip alarm check! Verified all raid mirrors are synced. Early Upgrade Checks Have Passed! Early Upgrade Checks finished at 1447429031 Initializing upgrade information
12.	MPS B: Upgrade proceeds.	Many informational messages appear on the terminal screen as the upgrade proceeds. The messages are not shown here for clarity sake. When installation is complete, the server reboots.
13.	MPS B: Upgrade completed.	After the final reboot, the screen displays the login prompt as in the example below. Starting atd: [OK] ~~ /etc/rc4.d/S98ExQueue start ~~ ExQueue started. Starting TKLCe5appb: [OK]

		Checking network config files: [OK] Daemon is not running AlarmMgr daemon is not running, delaying by 1 minute ~~ /etc/rc4.d/S99Epap start ~~ EPAP configuration data not found. Exiting ~~ /etc/rc4.d/S99Pdba start ~~ EPAP configuration data not found. Exiting Starting smartd: [OK] Daemon is not running
		AlarmMgr daemon is not running, delaying by 1 minute TPDhpDiskStatus stop/pre-start, process 5527 TKLChwmgmtcli stop/pre-start, process 5508
		Oracle Linux Server release 6.9 Kernel 2.6.32-642.6.2.el6prerel7.4.0.0.0_88.32.0.x86_64 on an x86_64
14.	MPS B: Log in as "epapdev" user.	[hostname] consolelogin: epapdev password: password
15.	MPS B: Check the Upgrade log.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors and warnings were reported. \$ grep -i error /var/TKLC/log/upgrade/upgrade.log Check the output of the upgrade log. Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section, if the output contains any error except the following:
		[root@Salta-B core]# grep -i error /var/TKLC/log/upgrade/upgrade.log 1673985608::ERROR: run-r1841b65093e14801be5696ea62d92ac2 is not recognized as a systemd service! 1673985608::ERROR: Could not stop run-r1841b65093e14801be5696ea62d92ac2! 1673985608::ERROR: service_conf reconfig failed! [root@Salta-B core]#
		\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log
		Examine the output of the above command to determine if any warnings were reported.

16.	MPS B: Check that	Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section, if the output contains any warnings beside the following: [root@Salta-B core]# grep -i error /var/TKLC/log/upgrade/upgrade.log 1673985608::ERROR: run-r1841b65093e14801be5696ea62d92ac2 is not recognized as a systemd service! 1673985608::ERROR: Could not stop run-r1841b65093e14801be5696ea62d92ac2! 1673985608::ERROR: Service_conf reconfig failed! [root@Salta-B core]# grep -i warning /var/TKLC/log/upgrade/upgrade.log 1673985030:* write: WARNING:: Could not find configured path "/var/TKLC/epap/lob". 1673985031::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: Warning: Could not find configured path "/var/TKLC/epap/logs". 1673985031:: write: Warning: Could not find configured path "/var/TKL
	the upgrade	<pre>\$ grep "Upgrade returned success" /var/TKLC/log/upgrade/upgrade.log</pre>


	completed successfully.	
17.	MPS B: Check that the upgrade completed successfully.	Verify that the message "Upgrade returned success!" is displayed. If it is not, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section. 1399367207:: Upgrade returned success!
18.	Log in to MPS A via epapdev user and go to directory /usr/TKLC/epap/bi n and Run the following command: ./mysql_setup.pl	[epapdev@Salta-A ~]# ./mysql_setup.pl
19.	MPS B: Log in to MPS A via root user and update ssh_config to disable MD5 and MAC algorithm for security	Perform following steps to disable unsecure algorithm for ssh: 1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2, 3 and 4. Else go to step 5. 2. \$ sudo rcstool co /etc/ssh/ssh_config 3. \$ sudo sed -i -e '/MACs hmac-md5-96,hmac-sha1-96/d' /etc/ssh/ssh_config 4.\$ sudo rcstool ci /etc/ssh/ssh_config 5. \$ grep "MACs hmac-sha2-256,hmac-sha2-512" /etc/ssh/sshd_config If no output is displayed for above command continue to next command in steps else skip these steps 6. \$ sudo rcstool co /etc/ssh/sshd_config 7. \$ sudo sed -i '\$ a \\tMACs hmac-sha2-256,hmac-sha2-512' /etc/ssh/sshd_config 8. \$ sudo rcstool ci /etc/ssh/sshd_config 9. \$ sudo systemctl restart sshd
20.	Update the httpd.conf file to disable the Cache	Perform the following steps to disable Cache control no-store policy:

	control no-store policy.	1. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
		If the output contains "Header set Cache-Control no-store", Execute the below steps. If no output is displayed for the above command, skip the steps mentioned below.
		2. \$ sudo sed -i '/Cache-Control no-store/c\#Header set Cache-Control no-store' /etc/httpd/conf/httpd.conf
		3. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
		The output should be "#Header set Cache-Control no-store" showing that the line has been commented.
21.	MPS B: Install Complete.	Install Procedure is complete.
22.	Note down the	Run the following command:
	timestamp in log.	\$ date

Procedure 8 Install Application on server A

S	This procedure insta	This procedure installs the application on the server.	
T E P #	Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.		
1.	MPS A: Install EPAP on 1A.	Perform Procedure in 0 or copy EPAP 16.4 ISO to /var/TKLC/upgrade directory.	
2.	Create a terminal window and Log in to MPS A.	If not already connected, connect to the E5-APP-B card via the serial Port. For connecting the E5-APP-B A card, disconnect the console cable from the serial port on the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for serial access. Cable part numbers - 830-1220-xx	
3.	MPS A: Login prompt is displayed.	<pre><hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname></pre>	

Procedure 8: Install the Application on Server A



8.	MPS A: Select	Select the "Early Upgrade Checks" menu to verify that the system is ready for
	Early Upgrade	upgrade.
	Checks	Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Exit
		If the Early Upgrade Checks fail due to the ongoing syncing of raid mirrors, then wait until the resync is completed and run the "Early Upgrade Checks" again. Early Checks failed for the next upgrade Look at earlyChecks.log for more info tarting Early Upgrade Checks at 1011413059 Running earlyUpgradeChecks() for Upgrade::EarlyPolicy::TPDEarlyChecks upgrade policy Verified server is not pending accept of previous upgrade ERROR: Raid mirrors are syncing! ERROR: md2 is syncing! ERROR: earlyUpgradeChecks() code failed for Upgrade::EarlyPolicy::TPDEarlyChecks ERROR: Failed running earlyUpgradeChecks() code Hardware architectures match Install products match. No Application installed yet Skip alarm check! ERROR: Early Upgrade Checks Failed! User has requested just to run early checks. No upgrade will be performed Early Upgrade Checks finished at 1011413059
		[admusr@epappri ~] cat /proc/mdstat Personalities: [raid1] md1: active raid1 sdb2[1] sda2[0]
9.	MPS A: Navigate to the Initiate Upgrade menu	Select the Initiate Upgrade menu and press [ENTER].

Procedure 8: Install the Application on Server A

		Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Exit
	MPS A: Select the Upgrade Media.	The screen displays a message that it is searching for upgrade media. When the upgrade media is found, an Upgrade Media selection menu appears similar-to the example below. Select the desired upgrade media and press [ENTER]. Choose Upgrade Media Menu EPAP-17.0.0.3.0_170.19.0-x86_64.iso - 17.0.0.3.0_170.19.0 Exit
11.	MPS A: Upgrade proceeds.	The screen displays the output like following, indicating that the upgrade software is first running the upgrade checks, and then proceeding with the upgrade. No Application installed yet Skip alarm check! Verified all raid mirrors are synced. Early Upgrade Checks Have Passed! Early Upgrade Checks finished at 1447429031 Initializing upgrade information
12.	MPS A: Upgrade proceeds.	Many informational messages appear on the terminal screen as the upgrade proceeds. The messages are not shown here for clarity sake. When installation is complete, the server reboots.
13.	MPS A: Upgrade completed.	After the final reboot, the screen displays the login prompt as in the example below. Starting atd: [OK] ~~ /etc/rc4.d/S98ExQueue start ~~ ExQueue started. Starting TKLCe5appb: [OK] Checking network config files: [OK] Daemon is not running

		AlarmMgr daemon is not running, delaying by 1 minute
		~~ /etc/rc4.d/S99Epap start ~~
		EPAP configuration data not found. Exiting ~~ /etc/rc4.d/S99Pdba start ~~
		EPAP configuration data not found. Exiting
		Starting smartd: [OK]
		Daemon is not running
		AlarmMgr daemon is not running, delaying by 1 minute
		TPDhpDiskStatus stop/pre-start, process 5527
		TKLChwmgmtcli stop/pre-start, process 5508
		Oracle Linux Server release 6.9
		Kernel 2.6.32-642.6.2.el6prerel7.4.0.0.0_88.32.0.x86_64 on an x86_64
		Refrict 2.0.32 042.0.2.clop/ere//.4.0.0.0_00.32.0.800_04 0ff dff 800_04
14.	MPS A: Log in as	[hostname] consolelogin: epapdev
	"epapdev" user.	password: password
15.	MPS A: Check the	Figure 1 to 1 t
	Upgrade log.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors and warnings were reported.
-	opgrade log.	no errors and warnings were reported.
		\$ grep -i error /var/TKLC/log/upgrade/upgrade.log
		Check the output of the upgrade log. Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section, if the output contains any errors beside the following:
		[root@Salta-B core]# grep -i error /var/TKLC/log/upgrade/upgrade.log
		1673985608::ERROR: run-r1841b65093e14801be5696ea62d92ac2 is not recognized as a systemd service!
		1673985608::ERROR: Could not stop run-r1841b65093e14801be5696ea62d92ac2!
		1673985608::ERROR: service_conf reconfig failed!
		[root@Salta-B core]#
		\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log
		Examine the output of the above command to determine if any warnings were
		reported.
		Contact My Oracle Support following the instructions on the front page or the
		instructions in the My Oracle Support section, if the output contains any warnings beside the following:

		[root@Salta-B core]# grep -i error /var/TKLC/log/upgrade/upgrade.log 1673985608::ERROR: run-r1841b65093e14801be5696ea62d92ac2 is not
		recognized as a systemd service!
		1673985608::ERROR: Could not stop run-r1841b65093e14801be5696ea62d92ac2!
		1673985608::ERROR: service_conf reconfig failed!
		[root@Salta-B core]# grep -i warning /var/TKLC/log/upgrade/upgrade.log
		1673985030::* write: WARNING:: Could not find configured path
		"/var/TKLC/epap/db".
		1673985031::* write: WARNING:: Could not find configured path
		"/var/TKLC/epap/logs".
		1673985031::* write: WARNING:: Could not find configured path
		"/var/TKLC/epap/free".
		1673985031::* write: WARNING:: Could not find configured path
		"/var/TKLC/epap/db".
		"/var/TKLC/epap/rt".
		1673985031::* write: WARNING:: Could not find configured path
		1673985031::* write: WARNING:: Could not find configured path
		"/var/TKLC/epap/logs".
		1673985031::* write: WARNING:: Could not find configured path
		"/var/TKLC/epap/free".
		1673985033::useradd: warning: the home directory already exists.
		1673985476::2023-01-17T19:57:57.683121Z 0 [Warning] [MY-013746] [Server] A
		deprecated TLS version TLSv1 is enabled for channel mysql_main
		1673985478::2023-01-17T19:57:57.683144Z 0 [Warning] [MY-013746] [Server] A
		deprecated TLS version TLSv1.1 is enabled for channel mysql_main
		1673985478::2023-01-17T19:57:57.808924Z 6 [Warning] [MY-010453] [Server]
		root@localhost is created with an empty password! Please consider switching off
		theinitialize-insecure option.
		1673985551::WARNING: A new file was added to xml alarm filesreparsing xml
		1673985551::WARNING: FILE: /usr/TKLC/plat/etc/alarms/alarms_mps.xml
		1673985571::TKLCepap-HA
		######################################
		using root
		[root@Salta-B core]#
		Refer to section 3.7 to know more about logging.
16.	MPS A: Check that	\$ grep "Upgrade returned success" /var/TKLC/log/upgrade/upgrade.log
	the upgrade	
	completed	
	successfully.	
	•	

18.	MPS A: Check that the upgrade completed successfully. Log in to MPS B via epapdev user and go to directory /usr/TKLC/epap/bi n and Run the following command: ./mysql_setup.pl	Verify that the message "Upgrade returned success!" is displayed. If it is not, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section. 1399367207:: Upgrade returned success! [epapdev@Salta-A ~]# ./mysql_setup.pl
19.	MPS B: : Log in to MPS A via root user and update ssh_config to disable MD5 and MAC algorithm for security	Perform following steps to disable unsecure algorithm for ssh: 1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2, 3 and 4. Else go to step 5. 2. \$ sudo rcstool co /etc/ssh/ssh_config 3. \$ sudo sed -i -e '/MACs hmac-md5,hmac-md5-96,hmac-sha1-96/d' /etc/ssh/ssh_config 4.\$ sudo rcstool ci /etc/ssh/ssh_config 5. \$ grep "MACs hmac-sha2-256,hmac-sha2-512" /etc/ssh/sshd_config If no output is displayed for above command continue to next command in steps else skip these steps 6. \$ sudo rcstool co /etc/ssh/sshd_config 7. \$ sudo sed -i '\$ a \\tMACs hmac-sha2-256,hmac-sha2-512' /etc/ssh/sshd_config 8. \$ sudo rcstool ci /etc/ssh/sshd_config 9. \$ sudo systemctl restart sshd
20.	Update the httpd.conf file to disable the Cache control no-store policy	Perform the following steps to disable Cache control no-store policy: 1. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf

		If the output contains "Header set Cache-Control no-store", Execute the below steps. If no output is displayed for the above command, skip the steps mentioned below.
		2. sudo sed —i '/Cache-Control no-store/c\#Header set CacheControl no-store' / etc/httpd/conf/httpd.conf
		3. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
		The output should be "#Header set Cache-Control no-store" showing that the line has been commented.
21.	MPS A: Install Complete.	Install Procedure is complete.
22.	Note down the timestamp in log.	Run the following command: \$ date

Procedure 9 Switch Configuration


Procedure 9: Switch Configuration

S	This procedure Configures the Switches of a new Installed E5-APP-B EPAP Server Pair.		
T E P #	Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.		
1.	Make the cross- over cable connections.	NOTE: THIS IS IMPORTANT	
	connections.	CONNECT the cross-over cable from Port 1 of Switch1A to Port 1 of Switch1B .	
		DISCONNECT the cross-over cable from Port 2 of Switch1A to Port 2 of Switch1B .	
		Please make a note that the switch configuration should only be attempted by a skilled technician and not all.	
		All uplinks should be removed while switch configuration.	
		There should not be any loop in the switches during their configuration.	


Procedure 9: Switch Configuration

		Make sure to enable and start tftp service by using following commands if not started earlier: sudo systemctl start tftp sudo systemctl enable tftp
2.	MPS B: log in as "admusr" user.	[hostname] consolelogin: admusr password: <i>password</i>
3.	MPS B: Set Telco Switch with non- default speed.	Note : The default speed to be set on the switch is 1000Mbps. However, the recommended setting can be changed to 'auto', '1000/full' or '100/full'. At the EAGLE end, the operator can set the IP LINK to 'auto'.
4.	MPS B: Start platcfg utility.	\$ sudo su - platcfg
5.	MPS B: Navigate to the Network Configuration Menu.	On the platefg Main Menu, select Network Configuration and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Remote Consoles Network Configuration Security Exit
6.	MPS B: Navigate to the Configure Switch Menu.	On the Network Configuration menu, select Configure Switch and press [ENTER].

Procedure 9: Switch Configuration




Procedure 9: Switch Configuration



Procedure 9: Switch Configuration

		Select Exit and press [ENTER] to exit out of platcfg.
11.	MPS A: Connect to Server 1A.	Now that Switch 1B is configured, we need to configure switch 1A. Connect to server 1A to configure switch 1A [hostname] consolelogin: admusr password: password
12.	MPS A: Set Telco Switch with non- default speed.	Note: The default speed to be set on the switch is 1000Mbps. However, the recommended setting can be changed to 'auto', '1000/full' or '100/full'. At the EAGLE end, the operator can set the IP LINK to 'auto'. Otherwise proceed to step 13.
13.	MPS A: Start platcfg. utility	\$ sudo su - platcfg
14.	MPS A: Navigate to the Network Configuration Menu.	On the platefg Main Menu, select Network Configuration and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Security Exit
15.	MPS A: Navigate to the Configure Switch Menu.	On the Network Configuration menu, select Configure Switch and press [ENTER].

Procedure 9: Switch Configuration



Procedure 9: Switch Configuration



Procedure 9: Switch Configuration

20.	MPS A: Optional Configuration of	If the system is installed with 4 switches, proceed with the next step, otherwise skip to step 37.
21.	Switch 1C. Move Serial Cables.	On the front of switches 1A and 1B, unplug the serial cables connected to Console port and plug them in switches 1C and 1D Console port respectively.
22.	MPS A: Start platcfg utility.	\$ sudo su - platcfg
23.	MPS A: Navigate to the Network Configuration Menu.	On the platefg Main Menu, select Network Configuration and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Security Exit
24.	MPS A: Navigate to the Configure Switch Menu.	On the Network Configuration menu, select Configure Switch and press [ENTER]. Network Configuration Menu Network Interfaces SNMP Configuration Configure Network Routing Network Bridges Iptables Resolv IPSEC Configuration Stunnel Modify Hosts File Configure Switch Exit


Procedure 9: Switch Configuration



Procedure 9: Switch Configuration

		Press any key to continue Platform Configuration Utility Copyright (C) 2003, 2024, Oracle and/or its affiliates. All rights reserved. Hostname: Recife-B Main Menu Successfully enabled on switch switch1C. Reloading switch switch1C with defaults, please standby Switch switch1C successfully set to default configuration. Successfully started management VLAN on switch1C. Startup configuration created OK. Successfully uploaded startup config for switch1C. Removing config file switch1C.startup-config from /var/lib/tftpboot. Reloading switch switch1C, please standby Reload of switch switch1C complete. Switch switch1C successfully configured.
28.	MPS A: Exit out of	Use arrow keys to move between options <enter> selects Select Exit and press [ENTER] to return to the Network Configuration Menu.</enter>
	platcfg.	Select Exit and press [ENTER] to return to the Main Menu. Select Exit and press [ENTER] to exit out of platcfg.
29.	MPS B: Connect to Server 1B.	[hostname] consolelogin: admusr password: password
30.	MPS B: Start platcfg utility.	\$ sudo su - platcfg
31.	MPS B: Navigate to the Network	On the platcfg Main Menu, select Network Configuration and press [ENTER].


Procedure 9: Switch Configuration



Procedure 9: Switch Configuration



Procedure 9: Switch Configuration





Procedure 10 Configure Sync Network Redundancy


Note: This procedure will configure the E5-APP-B EPAP cards with the Sync Network Redundancy feature. This will use the Backup Provisioning Network ports, therefor the Backup Provisioning Network feature cannot be used.

Procedure 10: Procedure to Configure Sync Network Redundancy

S	This procedure will sync network redundancy in place of backup provisioning network.	
T	Note: Estimated times of completion is 00 minutes	
E	Note: Estimated time of completion is 90 minutes.	
P		
#		
1.	MPS A: Log in as "admusr" user to the serial console of E5-APP-B card.	[hostname] consolelogin: admusr password: password
2.	MPS A: Start platcfg utility.	\$ sudo su — platcfg
3.	MPS A: Navigate to the Network Configuration Menu.	On the platcfg Main Menu , select Network Configuration and press [ENTER].
		Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Security Exit
4.	MPS A: Navigate to the Network Interfaces Menu.	On the Network Configuration menu, select Network Interfaces and press [ENTER]. Network Configuration Menu Network Interfaces SNMP Configuration Configure Network Routing Network Bridges Iptables Resolv IPSEC Configuration Stunnel Modify Hosts File Configure Switch Exit







13.	MPS A: Take the backup of original net.conf.	<pre>\$ sudo cp /usr/TKLC/plat/etc/net.conf /usr/TKLC/plat/etc/net.conf_orig</pre>
14.	MPS A: Replace the network configuration file for sync	<pre>\$ sudo cp /usr/TKLC/plat/etc/net.sync.conf /usr/TKLC/plat/etc/net.conf</pre>
	network redundancy.	cp: overwrite `/usr/TKLC/plat/etc/net.conf'? y
15.	MPS A A: Take the backup of original vlan.conf.	<pre>\$ sudo cp /usr/TKLC/plat/etc/vlan.conf /usr/TKLC/plat/etc/vlan.conf_orig</pre>
16.	MPS A: Replace the vlan configuration file for sync	E5-APP-B Card:
	network redundancy.	Single Pair of Switch(18 SM Cards): vlan.sync.single_pair_switch.e5appb.conf
		(Ports 7 to 24 on switch 1A and ports 5 to 24 on switch 1B can be used for SM card connectivity)
		Two Pair of switches (40 SM Cards): vlan.sync.e5appb.conf
		(Ports 7 to 22 on switch 1A and ports 5 to 22 on switch 1B can be used for SM card connectivity, no change for switch 1C and 1D)
		For e.g., on T1200 server for Single pair of switches: \$ sudo cp /usr/TKLC/plat/etc/vlan.sync.single_pair_switch.t1200.conf /usr/TKLC/plat/etc/vlan.conf
		cp: overwrite `/usr/TKLC/plat/etc/vlan.conf'? y
17.	MPS A: Reconfigure the	\$ sudo netAdm init
	network interfaces.	Interface bond0 added
		Interface eth01 added
		Interface eth02 added
		Interface bond0.3 added
		Interface eth03 added
		Interface eth04 added
		Interface bond0.1 added
		Successfully configured network
18.	MPS A: Restart network service.	\$ sudo systemctl restart network
19.	MPS B	Repeat all the above steps on the MPS B.

20.	Network Connectivity	Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.
21.	Configure Switch 1B first and then Switch 1A using 0.	Perform 0 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.
22.	MPS A: Verify that ping mate is working.	\$ ping -c 4 mate
	is working.	PING mate (192.168.2.100) 56(84) bytes of data.
	Also ensure that the sync	64 bytes from mate (192.168.2.100): icmp_seq=1 ttl=64 time=0.189 ms
	redundancy is working fine by turning off one switch and	64 bytes from mate (192.168.2.100): icmp_seq=2 ttl=64 time=0.188 ms
	running ping mate.	64 bytes from mate (192.168.2.100): icmp_seq=3 ttl=64 time=0.166 ms
		64 bytes from mate (192.168.2.100): icmp_seq=4 ttl=64 time=0.143 ms
		mate ping statistics
		4 packets transmitted, 4 received, 0% packet loss, time 3001ms
		rtt min/avg/max/mdev = 0.143/0.171/0.189/0.022 ms
23.	MPS A: Reconfigure EPAP using epapconfig menu if the	\$ su - epapconfig
	configuration was done	Please follow the instructions written in 0.
	before configuring sync network redundancy.	
24.	Procedure complete.	Procedure is complete.
25.	Note down the timestamp in log.	Run the following command:
	-	\$ date

S	This procedure configures the application on the server.
T	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.
E P	
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.

1.	MPS A: Log on Server A.	[hostname] consolelogin: admusr password: password
2.	MPS A: Switch user to epapconfig.	<pre>\$ sudo su - epapconfig Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/security/User.pm line 904.</pre>
3.	MPS A: A note of caution appears. Evaluate the conditions listed. When all the conditions are satisfied, press Return to continue.	Caution: This is the first login of the text user interface. Please review the following checklist before continuing. Failure to enter complete and accurate information at this time will have unpredictable results. 1. The mate MPS servers (MPS A and MPS B) must be powered on. 2. "Initial Platform Manufacture" for the mate MPS servers must be complete. 3. The sync network between the mate MPS servers must be operational. 4. You must have the correct password for the epapdev user on the mate MPS server. 5. You must be prepared to designate this MPS as provisionable or non-provisionable. Press return to continue
4.	MPS A: Upon pressing Return you can now abort or proceed with the initial configuration. To continue with the configuration, enter Y.	Are you sure you wish to continue? [N]:Y

5.		Password of epapdev:
	MPS A:	ssh is working correctly.
1 🖳	For Mixed EPAP or	Password of root:
	Non-Provisionable	ssh is working correctly.
	EPAP: You are	Password of admusr:
	prompted for the	ssh is working correctly.
	epapdev, root and	Password of root:
	admusr user password	ssh is working correctly.
	on the mate MPS server	Building the initial database on side A. Stopping local slave
	in order to confirm the	Stopping remote slave
	secure shell keys are	EuiDB already exists.
	successfully exchanged.	FIPS integrity verification test failed.
	The example shows the	Starting local slave
	•	Starting remote slave
	output generated when	
	the correct password is	The provisioning architecture of the EPAP software allows for
	entered, the secure	exactly 2 customer provisionable sites. Additional sites that
	shell keys are	are to receive the data provisioned to the provisionable sites
	successfully exchanged,	should answer 'N' here.
	and the UI database is	
	set up on MPS A and	If there are only 2 mated sites, it is safe to answer `Y' here.
	MPS B at this site.	To this site manisismuhlan (VI. V
	Type Y if this site is	Is this site provisionable? [Y]: Y
	Provisionable(either	
	mixed-EPAP or	
	PDBonly), otherwise	
	Type N.	Caution: This is the first login of the text user interface.
	туре н.	Press return to continue
		Are you sure you wish to continue? [N]: Y
		Building the initial database on side A.
	For Standalone PDB:	Stopping local slave
	You are prompted for	No preexisting EuiDB database was detected.
	the System Number and	Set EPAP System Number: ES12345678
	Network Configuration	Enter the Network Configuration Type (1 for Single, 2 for Segmented): 2
	Type.	
	1,740.	
		EDAD Configuration Norw for standalone DDD.
6.	MPS A: The EPAP	EPAP Configuration Menu for standalone PDB:
	Configuration Menu is	
	displayed. Select choice	
	2, Configure Network	
	Interfaces Menu.	

Procedure 11: Configuring the Application

	EPAP Configuration Menu\
1 1	Display Configuration
2	Configure Network Interfaces Menu
3	Set Time Zone
1 4	Exchange Secure Shell Keys
5	Change Password
i 6	Platform Menu
7	Configure NTP Server
8	PDB Configuration Menu
9	Security
1 10	SNMP Configuration
	Configure Alarm Feed
12	Configure Query Server
13	Configure Query Server Alarm Feed
14	Configure SNMP Agent Community
15	DB Architecture Menu
e	Exit
(222)	,
EPAP	Configuration Menu for NON-Prov EPAP:

Procedure 11: Configuring the Application

		/EPAP Configuration Menu\
		/\
		1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10 SNMP Configuration
		11 Configure Alarm Feed
		Configure SNMP Agent Community
		DB Architecture Menu
		 e Exit
		\/
		Enter Choice: 2
7.	MPS A: The Configure Network Interfaces	Configuration Menu for Mixed EPAP and Non-Provisionable EPAP:
	Menu is displayed.	/Configure Network Interfaces Menu\
	Select choice 1, Configure Provisioning	1 Configure Provisioning Network
	Network.	2 Configure Sync Network
		3 Configure DSM Network
		4 Configure Backup Provisioning Network
		5 Configure Static NAT Addresses
		6 Configure Provisioning VIP Addresses

Procedure 11: Configuring the Application

		a Evit
		e Exit
		Enter Choice: 1
		Configuration Menu for Standalone PDB:
		/Configure Network Interfaces Menu\
		1 Configure Provisioning Network
		2 Configure Backup Provisioning Network
		3 Configure Static NAT Addresses
		Enter Choice: 1
8.	MPS A: The submenu	/Configure Provisiong Network Menu-\
	for configuring communications	1 IPv4 Configuration
	networks and other information is	2 IPv6 Configuration
	displayed.	 e Exit
		\/
		Enter Choice:
	Note: Enter choice "1"	Example output for Mixed EPAP and Non-Provisionable EPAP in IPv4 configuration:
	for IPv4 configuration. Otherwise, enter choice	
	"2" for IPv6	Enter Choice: 1
	configuration.	Verifying connectivity with mate
		EPAP A provisioning network IP Address: 10.75.141.47 EPAP B provisioning network IP Address: 10.75.141.48
		EPAP provisioning network netmask: 255.255.255.128
		EPAP provisioning network default router: 10.75.141.1
		Example output Standalone PDB in IPv4 configuration:
		EPAP A provisioning network IP Address:10.75.141.47
		EPAP provisioning network netmask:255.255.255.128 EPAP provisioning network default router:10.75.141.1
9.	MPS A: The Configure	Configuration Menu for Mixed EPAP and Non-Provisionable EPAP:
	Network Interfaces	/Configure Network Interfaces Menu\
	menu is displayed. Select choice e, Exit.	/\ 1 Configure Provisioning Network
	,	
		3 Configure DSM Network
		4 Configure Backup Provisioning Network
		i i com gar o zachap i orio oming nochork i

Procedure 11: Configuring the Application

		5	Configure Static NAT Addresses
		6	Configure Provisioning VIP Addresses
		e	 Exit /
		Enter	Choice: e
			ration Menu for Standalone PDB: -Configure Network Interfaces Menu\
		1	\ Configure Provisioning Network
			 Configure Backup Provisioning Network
		3	 Configure Static NAT Addresses
		 e	 Exit
			Choice: e
10.	MPS A: The EPAP Configuration Menu is displayed. Select choice 3, Set Time Zone.	EPAP (Configuration Menu for Non-prov EPAP:

Procedure 11: Configuring the Application

		/EPAP Configuration Menu\
		1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10 SNMP Configuration
		11 Configure Alarm Feed
		12 Configure SNMP Agent Community
		13 Mate Disaster Recovery
		14 DB Architecture Menu
		e Exit
		Enter Choice: 3
11.	MPS A: An important Caution statement is	Caution: This action requires a reboot of the affected MPS servers to activate the change. Operation of the EPAP software before the MPS servers are rebooted may have unpredictable
	displayed. After noting the caution, press Return to continue.	consequences. Press return to continue <return></return>
		Are you sure you wish to change the timezone for MPS A and B? [N]: Y
<u> </u>		1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -

	You are prompted for confirmation on setting the time zone for the MPS A and MPS B at this site for Mixed EPAP or Non-provisionable EPAP. For Standalone PDB, time zone for MPS A is prompted only. Enter y to confirm the change. (Pressing			
	Return accepts the default of 'N' (no), cancels the action and you are returned to the EPAP Configuration Menu). Type Y to set the time zone.			
12.	MPS A: The following prompt is displayed. If the time zone is known, it can be entered at the prompt. If the exact time zone value is not known, press Return, and a list of the valid names is displayed.	Enter a time zone:		
13.	If an incorrect time zone is entered or if only the Return key is pressed, a list of all available time zone values is displayed. Note: The time zone	Valid time zone files a Australia/Broken_Hill Australia/NSW Australia/North Australia/South Australia/Tasmania Australia/West Australia/Yancowinna Brazil/DeNoronha Canada/Atlantic Saskatchewan	re: Australia/LHI Australia/Queensland Australia/Victoria Australia/ACT Brazil/East Canada/Central	Brazil/Acre Brazil/West Canada/East-
	change does not take effect until the next time the MPS is rebooted.	Canada/Eastern Canada/Newfoundland Canada/Pacific Chile/Continental Chile/EasterIslandSample Output C	Canada/Mountain Canada/Yukon Etc/GMT ontinues utput below	Etc/GMT+1
		MST NZ-CHAT Poland ROK W-SU asia etcetera northamerica solar88 GB-Eire	MST7MDT PRC Portugal Singapore WET australasia europe pacificnew solar89 GMT	NZ PST8PDT ROC Turkey africa backward factory solar87 southamerica GMT+0

Procedure 11: Configuring the Application

		Cut. 1	SMT 10	CUT 11
		GMT+1	GMT+10	GMT+11
		GMT+12	GMT+13	GMT+2
		GMT+3	GMT+4	GMT+5
		GMT+6	GMT+7	GMT+8
		GMT+9	GMT-0	GMT-1
		GMT-10	GMT-11	GMT-12
		GMT-2	GMT-3	GMT-4
		GMT-5	GMT-6	GMT-7
		GMT-8	GMT-9	Greenwich
		Jamaica	Navajo	UCT
		UTC	Universal	zu]u
		010	oniversar	ZuTu
		Enter a time zone file	(relative to /usr/share/li	ih/zoneinfo): US/Fastern
			(. 2, 20.10.11.10, 1 00, 2000
14.		EPAP Configuration M	enu for Non-prov EPAP:	
	SERVER A: Enter			
—	choice 7, Configure	/EPAP Config	uration Menu	-\
	NTP Server Menu.	/		\
	MIF Server Menu.	1 Display Con	figuration	i
	NOTE: If an NTP	2 Configure N	etwork Interfaces Men	u
	server does not need to			
	be added at this time,	3 Set Time Zo	7.0	i i
	you can skip all steps			!
	related to option 7			
	Configure NTP Server	4 Exchange Se	cure Shell Keys	I
		11		1
	Menu, and proceed to	5 1 Champa Dana		
	the PDB	5 Change Password	I .	
	Configuration Menu			
	at step 20.	6 Platform Menu	nu	1
	-			
		7 Configure N		I
		8 PDB Configu	ration Menu	i i
		9 Security		I I
		10 SNMP Config	uration	i i
		•		
		11 Configure A	larm Feed	I I
		12 Configure 9	NMP Agent Community	i i
				1
		13 Mate Disast	er Recovery	I
		14 DB Archited	ture Menu	
				!
		e Exit		I .
		\		/
		Enter Choice: 7		
		I		

Procedure 11: Configuring the Application

15		
15.	MPS A: The EPAP Configure NTP Server	/EPAP Configure NTP Server Menu-\
	Menu is displayed. Enter choice 2, Add	1 Display External NTP Server
	External NTP Server.	2 Add External NTP Server
		3 Remove External NTP Server
		e Exit
		Enter Choice: 2
		/Add External NTP Server Menu-\
		/\ 1 IPv4 Configuration
		 2 IPv6 Configuration
		e Exit
	Note: Enter choice "1" to configure IPv4 NTP server. Otherwise, enter choice "2" to configure IPv6 NTP server.	Enter Choice:
16.	MPS A: You are prompted to confirm the action of adding a	Are you sure you wish to add new NTP Server? [N]: Y Enter the EPAP NTP Server IP Address: <ntp_server_ip_addr></ntp_server_ip_addr>
	new NTP Server. (Pressing Return would	External NTP Server [<ntp_server_ip_addr>] has been added.</ntp_server_ip_addr>
	accept the default of 'N'	Press return to continue <return></return>
	or 'no', and would cancel the action to add an external NTP server.) Type Y and press return.	
	NOTE: All NTP	
	Server IP addresses	
	shown are only examples.	
	CAUTIFIES.	
17.	MPS A: The	
	EPAP Configure NTP	/EPAP Configure NTP Server Menu-\ /\
	Server Menu is displayed.	1 Display External NTP Server
	alspiayea.	2 Add External NTP Server
		3 Remove External NTP Server

	Enter choice 1, Display External NTP Server.	
18.	MPS A: Verify the External NTP Server IP address is correct and press Return.	ntpserver1 <ipaddress> Press return to continue<return></return></ipaddress>
	NOTE : All NTP Server IP addresses shown are only examples.	
19.	MPS A: The EPAP Configure NTP Server Menu is displayed. Select choice e, Exit.	/EPAP Configure NTP Server Menu-\ 1 Display External NTP Server
20.	MPS A: The EPAP Configuration Menu is displayed. Select choice 8, PDB Configuration Menu. Note: Execute the step to do PDB Configuration Menu (except step 27) even if the EPAP is to be configured as Non- Provisionable.	PDB Configuration Menu for Non-prov EPAP:

Procedure 11: Configuring the Application

	EPAP Configuration Menu\
1 1	Display Configuration
	Configure Network Interfaces Menu
3	Set Time Zone
	Exchange Secure Shell Keys
5	Change Password
'	 Platform Menu
	 Configure NTP Server
8	 PDB Configuration Menu
1 9	 Security
·	 SNMP Configuration
-	 Configure Alarm Feed
1 12	 Configure SNMP Agent Community
1 13	 Mate Disaster Recovery
14	 DB Architecture Menu
į e	 Exit
,	/ choice: 8

Procedure 11: Configuring the Application

21.	AADO A. TL. O. C	PDB Configuration Menu for Mixed EPAP:
	MPS A: The Configure PDB Menu is displayed. Select choice 1.	/Configure PDB Menu\
		1 Configure PDB Network
		2 RTDB Homing Menu
		3 Change MPS Provisionable State
		4 Create PDB
		5 Change Auto DB Recovery State
		6 Change PDBA Proxy State
		e Exit
		PDB Configuration menu for Non-Provisionable EPAP:
		/Configure PDB Menu\ /\
		1 Configure PDB Network
		2 RTDB Homing Menu
		3 Change Auto DB Recovery State
	Note: Configure the	e Exit
	PDB network in the same format as that of the provisioning	Enter Choice: 1
	network format.	PDB Configuration Menu for Standalone PDB (for default DB Architecture: COMPACT):
		/Configure PDB Menu\
		1
		2 Create PDB
		3 Change Auto DB Recovery State
		e Exit /
		Enter Choice: 1

22.	MPS A: The PDB	PDB Network Configuration menu:
	Network Configuration	
	Menu is displayed.	
	Wiena is displayed.	
		/PDB Network Configuration Menu-\
		/\
	Select choice 1.	1 IPv4 Configuration
		2 IPv6 Configuration
		e Exit
		\/
		` '
		Enter Choice: 1
		Eliter Chorce. I
23.		
	Note: Do not provide	Following is the output on Mixed EPAP.
	the remote PDBA IP	
	address in case user is	Verifying connectivity with mate
	performing migration.	This MPS is configured to be provisionable. The EPAP local PDBA IPv4 address is currently set to <ip>. The EPAP local PDBA IPv6</ip>
		address is currently not configured.
	MPS A: Provide the IP	The EPAP local PDBA IPv4 Address is <ip>.</ip>
	address of the MPS A	EPAP remote PDBA IP Address [0.0.0.0]:
	on EAGLE A and the IP	EPAP remote PDBA B machine IP Address [0.0.0.0]: <b address="" ip="">
	address for the MPS A on EAGLE B where the	The server does not know of Will just exchange host keys for the name given!
	remote PDBA database	Password of epapdev: <epapdev password=""></epapdev>
	is to reside. Enter the	The state of the s
	password for MPS A on	
	EAGLE B. If	
	configuration of the	
	PDB network is	
	successful, the output	Fallowing is the autout on Man Devictor while FDAD
	confirms the secure	Following is the output on Non-Provisionable EPAP.
	shell keys are	Wanifering compactivity with mate
	successfully exchanged, as shown in the output	Verifying connectivity with mate This MPS is configured to be non-provisionable. You will be
	for	prompted for both of the remote PDBA addresses. Order does not
	Provisionable(mixed-	matter.
	EPAP and PDBonly)	
	MPSs	Enter one of the two PDBA IP addresses [0.0.0.0]: <ip address=""></ip>
	Note: If the default	Enter the other of the two PDBA IP addresses [0.0.0.0]: <ip address=""></ip>
	values shown are	
	correct press return to	
	accept them.	Following is the output on Standalone PDB.
	Otherwise, enter the	This MPS is configured to be provisionable. The EPAP local PDBA
	values and press	IPv4 address is currently set to <ip></ip>
	Return.	The EPAP local PDBA IPv6 address is currently not set.
		The EPAP local PDBA IPv4 Address is <ip>.</ip>

	In case of Non- Provisionable EPAP,provide the IP address of Active and Standby PDBA.	EPAP remote PDBA IP Address [0.0.0.0]:
24.	MPS A: Press Return to return to the Configure PDB Menu. Enter choice 2, RTDB Homing Menu.	Skip this step if EPAP configured as Standalone PDB.
25.	MPS A: The RTDB Homing Menu is displayed. Enter choice 3, Configure Standby RTDB Homing.	Skip this step for Standalone PDB. For Non-Prov Nodes: /RTDB Homing Menu

Procedure 11: Configuring the Application

		For Mixed EPAP :
		MPS Side A: hostname: Floater05 hostid: 4b0a6e8d Platform Version: 7.0.1-8.6.0.0.0_110.6.0 Software Version: EPAP 170.0.12-17.0.0.0.0_170.12.0 Wed Mar 29 05:59:19 EDT 2023
		/RTDB Homing Menu\ /
26.	MPS A: The RTDB Homing Menu is displayed. Enter e to exit.	Skip this step for Standalone PDB. /RTDB Homing Menu 1 Configure Specific RTDB Homing

27.	MPS A: Enter choice 3. Create PDB.	Note: Perform this step only for the Provisionable EPAP (Mixed EPAP or Standalone PDB). Skip this step if the EPAP is configured as Non-Provisionable.	
		The Menu for Mixed EPAP.	
	Note: Stop the EPAP software by answering 'Y', If you get the message to stop it. Note:	/Configure PDB Menu\	
		1 Configure PDB Network	
		2 RTDB Homing Menu	
		 3 Create PDB	
	While creating PDB database using the Create	4 Change Auto DB Recovery State	
	PDB option of the EPAP Configuration Menu,	 5 Change PDBA Proxy State	
	ensure that the value for remote PBD IP is set to	e Exit	
	0.0.0.0.	\/	
		Enter Choice:	
		Enter Choice: 3 The Menu for Standalone PDB(for default DB Architecture: COMPACT): /Configure PDB Menu	

20	NOTE	TOURIS ATTENDATED OUTDUT
28.	NOTE: The example output	TRUNCATED OUTPUT
	to the right has been truncated for brevity.	MyISAM file: /var/TKLC/epap/db/pdb/stats/pdbaStats.MYI is alreachecked Waiting for mysqlpdb to start done Removing local pdba status file. Removing remote pdba status file.
29.	MPS A: The Configure PDB Menu is displayed. Enter choice e, Exit. The Configure PDB Menu is displayed. Enter choice e, Exit.	The Configure PDB Menu for Mixed EPAP:
		/Configure PDB Menu\ /\
		1
		2 RTDB Homing Menu
		3 Change MPS Provisionable State
		4 Create PDB
		5 Change Auto DB Recovery State
		 e Exit
		Enter Choice: e
		The Configure PDB Menu for Standalone PDB:
		/Configure PDB Menu\
		1 Configure PDB Network
		2 Create PDB
		3 Change Auto DB Recovery State
		Enter Choice: e
		Eliter Choice. e
30.	MPS A: The EPAP Configuration Menu is displayed. Enter choice 1, Display Configuration.	

Procedure 11: Configuring the Application

		/EPAP Configuration Menu\
		1 Display Configuration
		Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		 5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		10 SNMP Configuration
		11 Configure Alarm Feed
		Configure Query Server
		13 Configure Query Server Alarm Feed
		14 Configure SNMP Agent Community
		15 Mate Disaster Recovery
		e Exit
		\/ Enter Choice: 1
31.	MPS A: The configuration information is	For Mixed EPAP and Non-Provisionable EPAP configured in IPv4 configuration, the configuration data shall look like:
	displayed. Verify that the configuration data displayed is correct.	EPAP A Provisioning Network IP Address = 10.75.141.55 EPAP A Provisioning Network IP Address v6 = Not configured EPAP B Provisioning Network IP Address v6 = Not configured Provisioning Network IP Address v6 = Not configured Provisioning Network Netmask = 255.255.255.128 Provisioning Network Prefix = Not configured Provisioning Network Default Router = 10.75.141.1 Provisioning Network Default Router v6 = Not configured EPAP A Backup Prov Network IP Address = Not configured EPAP B Backup Prov Network IP Address = Not configured EPAP B Backup Prov Network IP Address = Not configured EPAP B Backup Prov Network IP Address v6 = Not configured EPAP B Backup Prov Network IP Address v6 = Not configured EPAP B Backup Prov Network IP Address v6 = Not configured EPAP B Backup Prov Network IP Address v6 = Not configured Backup Prov Network Netmask = Not configured

```
Backup Prov Network Prefix V6

Backup Prov Network Default Router

Backup Prov Network Default Router v6

Backup Prov Network Default R
EPAP A Main DSM Network Address
EPAP B Main DSM Network Address
                                                                                             = 192.168.120.100
EPAP B Main DSM Network Address
EPAP A Backup DSM Network Address
                                                                                              = 192.168.120.200
                                                                                           = 192.168.121.100
= 192.168.121.200
EPAP B Backup DSM Network Address
EPAP IP Version
                                                                                              = IPV4
EPAP A HTTP Port
                                                                                              = 80
EPAP B HTTP Port
                                                                                               = 80
EPAP A HTTP SuExec Port
                                                                                               = 8001
EPAP B HTTP SuExec Port
                                                                                               = 8001
EPAP A Banner Connection Port
                                                                                              = 8473
EPAP B Banner Connection Port
                                                                                              = 8473
EPAP A Static NAT Address
                                                                                              = Not configured
                                                                                            = Not configured
EPAP B Static NAT Address
                                                                                              = 5873
PDBI Port
Remote MPS A Static NAT Address
                                                                                             = Not configured
Remote MPS A HTTP Port
                                                                                               = 80
Local Provisioning VIP
                                                                                               = Not configured
Remote Provisioning VIP
                                                                                               = Not configured
Local PDBA Address
Local PDBA Address v6
0000:0000:0000:0000:0000:0000:0000
                                                                                               = 10.75.141.55
Remote PDBA Address
                                                                                               = 0.0.0.0
Remote PDBA B Address
                                                                                               = 0.0.0.0
Time Zone
                                                                                               = America/New_York
PDB Database
                                                                                               = Exists
                                                                                               = 10.75.141.55
Preferred PDB
Allow updates from alternate PDB
                                                                                               = Yes
Auto DB Recovery Enabled
                                                                                               = No
PDBA Proxy Enabled
                                                                                               = No
Press return to continue...<return>
For Standalone PDB, the configuration data shall look like:
EPAP A Provisioning Network IP Address
EPAP B Provisioning Network IP Address
Provisioning Network Netmask
                                                                                               = 10.250.51.130
                                                                                              = Not configured
                                                                                               = 255.255.255.128
                                                                                              = Not configured
= 10.250.51.1
Provisioning Network Default Router
Provisioning Network Prefix
Provisioning Network Default Router v6 = Not configured EPAP A Backup Prov Network IP Address = Not configured
EPAP A Backup Prov Network IP Address v6 = Not configured
                                                                             = Not configured
= Not configured
Backup Prov Network Netmask
Backup Prov Network Recimies v6

Backup Prov Network Prefix v6

Backup Prov Network Default Router

Backup Prov Network Default Router v6

Configuration Type

= Not Configured

= Not configured

= SINGLE
EPAP IP Version
                                                                                              = IPv4
EPAP A HTTP Port
                                                                                              = 80
                                                                                              = 8001
EPAP A HTTP SuExec Port
EPAP A Banner Connection Port
                                                                                              = 8473
EPAP A Static NAT Address
                                                                                             = Not configured
PDBI Port
                                                                                              = 5873
Remote MPS A Static NAT Address
                                                                                              = Not configured
Remote MPS A HTTP Port
                                                                                               = Not configured
                                                                                          = 10.250.51.130
Local PDBA Address
Local PDBA Address v6
                                                                                          = Not configured
                                                                                          = 0.0.0.0
Remote PDBA Address
                                                                                          = US/Eastern
Time Zone
PDB Database
                                                                                          = Exists
Auto DB Recovery Enabled
```

Procedure 11: Configuring the Application

		Press return to continue <return></return>
32.	MPS A: The EPAP Configuration Menu is displayed. Enter choice e, Exit.	EPAP Configuration Menu for Non-Provisional EPAP: /EPAP Configuration Menu

Procedure 11: Configuring the Application

		INFO: Successfully configured Non-provisionable EPAP.
33.	Run the following commands on Non- Prov Nodes only: sed -i 's/mysqld, 2, 500000000000000000 2, -, -, -, -, 2, 5000000000000000 2, - /mysqld, 1, 5000000000000000 2, -, -, -, -, 1, 500000000000000 2, -/g' /usr/TKLC/epap/lib /syscheck_config_n on_prov	[root@Manaus-a ~]# sed -i 's/mysqld, 2, 500000000000000, -, -, -, -, -, 2, 500000000000000, -/mysqld, 1, 500000000000000, -, -, -, -, -, 1, 50000000000000, -/g' /usr/TKLC/epap/lib/syscheck_config_non_prov [root@Manaus-a ~]# sed -i 's/mysqld, 2, 50000000000000, -, -, -, -, -, 2, 50000000000000, -/mysqld, 1, 5000000000000, -, -, -, -, -, -, 1, 50000000000000, -/g' /usr/TKLC/plat/etc/syscheck/procrun.d/syscheck_config_prov
	sed -i 's/mysqld, 2, 50000000000000000 2, -, -, -, -, 2, 500000000000000 2, - /mysqld, 1, 500000000000000 2, -, -, -, -, 1, 50000000000000 2, -/g' /usr/TKLC/plat/etc/ syscheck/procrun.d /syscheck_config_p rov	
34.	Move the pdba binary file on Mixed and PDBonly server	[epapdev@Quito-a~]# cd /usr/TKLC/epap/bin [epapdev@Quito-a bin]# mv pdba pdba_stopped [epapdev@Quito-a bin]#

Procedure 11: Configuring the Application

	Note: This step is valid only when the user is	
35.	merforming migration. MPS A: The EPAP Configuration Menu is displayed. Select choice	EPAP Configuration Menu for mixed EPAP: /EPAP Configuration Menu\
	6 , Platform Menu.	/\
		1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		 6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		11 Configure Alarm Feed
		12 Configure Query Server
		13 Configure Query Server Alarm Feed
		14 Configure SNMP Agent Community
		15 Mate Disaster Recovery
		e Exit
		Enter Choice: 6
36.	MPS A: The Platform	Menu for Mixed EPAP and Non-Provisionable EPAP:
	Menu is displayed. Enter Choice 2, Reboot	/EPAP Platform Menu-\
	MPS.	
		2 Reboot MPS
		3 MySQL Backup

Procedure 11: Configuring the Application

		4 RTDB Backup
		5 PDB Backup
		\/ Enter Choice: 2
		CAUTION: Rebooting this MPS will stop all EPAP processes will prevent updating of the RTDB until the EPAP software is automatically re-started when the system comes back up. Are you sure you want to reboot the MPS? [N]: Menu for Standalone PDB: /EPAP Platform Menu-\ /
		4 PDB Backup
		e Exit
		Enter Choice: 2
		CAUTION: Rebooting this MPS will stop all EPAP processes will prevent updating of the RTDB until the EPAP software is automatically re-started when the system comes back up.
37.	MPS A: For Mixed EPAP	For Mixed EPAP and Non-Provisionable EPAP, a prompt is displayed:
	and Non-Provisionable EPAP you are prompted whether MPS A, MPS B or BOTH sides are to be rebooted. Select the default value of BOTH by pressing Return.	Reboot MPS A, MPS B or [BOTH]: <return></return>
	Note: In case of the Standalone PDB, no prompt is given and the server goes down for a reboot.	For Standalone PDB, the following is displayed.
		Reboot local MPS
		Broadcast message from root (pts/1) (Thu May 29 16:13:51 2014):
		The system is going down for reboot NOW!
38.	Move the pdba_stopped binary file on Mixed and PDBonly server	[epapdev@Quito-a bin]# mv pdba_stopped pdba [epapdev@Quito-a bin]#
	Note: This step is valid only when user is performing migration	

Procedure 11: Configuring the Application


39.	MPS A: The console logon appears at the system prompt signifying the EPAP initial configuration is completed.	<pre><hostname> login: admusr Password: Note: The console logon will be preceded by many lines of reboot output.</hostname></pre>
40.	Perform the procedure to exchange keys between OL 8 based PDBonly and OL6 based Non-Prov.	Perform the steps to exchange keys between OL 8 based PDBonly and OL6 based Non-Prov listed in Appendix A.53.
41.	Verify the MIN_DSM_MEM_SIZE and PDB_SUB_CAPACITY	Run the below commands to verify the MIN_DSM_MEM_SIZE and PDB_SUB_CAPACITY: uiEdit grep PDB_SUB_CAPACITY uiEdit grep DSM_MIN_MEM_SIZE uiEdit grep DB_ARCHITECTURE In case of Extreme DB, EPAP 17.1 supports 510M DNs. Hence, make sure to change the PDB_SUB_CAPACITY by performing the steps mentioned in Section 6.6 in EPAP Administration Guide.
42.	Connected PDBonly: Configure DSM Min Mem Size	Perform 0 only if the Non-Prov EPAP is installed and is connected to Standalone PDB server. Otherwise, skip this step if — a. This is Mixed EPAP b. This is non-prov EPAP and connected to mixed EPAP.
43.	Reconnect console cables.	On E5-APP-B card, reconnect the console cable between the serial port labeled 'S0' on E5-APP-B B card's adapter and the serial port labeled 'S1' on the E5-APP-B A card's adapter and the console cable between the serial port labeled 'S0' on E5-APP-B A card's adapter and the serial port labeled 'S1' on the E5-APP-B B card's adapter. Cable part numbers - 830-1220-xx
44.	Procedure complete.	Procedure is complete.
4 5.	Note down the timestamp in log.	Run the following command: \$ date

Procedure 12 Provision data from GUI


Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)

S	This procedure provision 1 NE and 1 DN from GUI on Active Site.
T	
E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.


Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)



Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)




Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)



Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)

7.	Enter ID as "12345", select Type "RN" and select Point Code as "None".	The screen should look like: Add an NE	
	None.	ID to add: Type: RN Point Code: Routing Indicator: Cancel Called Global Title: New Numbering Plan: Digit Action: None Type: RN Subsystem Number: New Nature of Address Indicator: New Translation Type: SRF IMSI:	
8.	Click on the "Add NE" button. Network Entity should be successfully added.	The screen should look like: Add an NE SUCCESS: Network Entity successfully created.	
9.	Select PDBA→Manage Data→Network Entity→Delete	The screen should look like: A Delete an NE ID to delete: Type: SP V Delete NE	
10.	Enter ID as "12345" and select Type "RN".	The screen should look like: A Delete an NE ID to delete: Type: RN Delete NE	
11.	Click on the "Delete NE" button. Network Entity should be successfully deleted.	The screen should look like: A Delete an NE SUCCESS: Network Entity successfully deleted.	
12.	View PDBA Status	The screen should look like:	-

Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)



Procedure 13 Change DB Architecture

Procedure 13: Change the DB Architecture

NOTE: Skip this procedure in following three cases:

- 1. EPAP 17.1 is a Mixed EPAP.
- 2. Extreme architecture is not required.

S	This procedure change the	This procedure change the DB Architecture from COMPACT to eXtreme.	
T E P #	Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.		
1.	MPS A: Log in as epapdev user.	[hostname] consolelogin: epapdev password: password	
2.	MPS A: Log in to epapconfig.	<pre>\$ sudo su - epapconfig Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.</pre>	
3.	MPS A: The EPAP	Note: Start Pdba software before executing this operation. EPAP Configuration Menu for Non-Provisionable:	

Configuration Menu is /----EPAP Configuration Menu-----\ displayed. Select choice 14 or 15, DB Architecture | 1 | Display Configuration Menu |----| | 2 | Configure Network Interfaces Menu | Note: Select choice 14 on | 3 | Set Time Zone Non-provisionable EPAP and 15 on PDBonly. 4 | Exchange Secure Shell Keys 5 | Change Password |----|-----------------| | 6 | Platform Menu 7 | Configure NTP Server | 8 | PDB Configuration Menu | 9 | Security |----| | 10 | SNMP Configuration | | 11 | Configure Alarm Feed | 12 | Configure SNMP Agent Community |----| | 13 | Mate Disaster Recovery | 14 | DB Architecture Menu | e | Exit Enter choice: 14 **EPAP Configuration Menu for standalone PDB:**

		/EPAP Configuration Menu\
		1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10 SNMP Configuration
		11 Configure Alarm Feed
		12 Configure Query Server
		13 Configure Query Server Alarm Feed
		14 Configure SNMP Agent Community
		15 DB Architecture Menu
		e Exit
		Enter choice: 15
4.	MPS A: The DB Architecture Menu is displayed. Select choice	
	1, Display current DB Architecture	/DB Architecture Menu\ /\
	Note: Default DB Architecture	1 Display Current DB Architecture
	is displayed.	2 Change DB Architecture to eXtreme
		e Exit
		Enter Choice: 1

		DB Architecture: COMPACT
5.	MPS A: The DB Architecture Menu is displayed. Select choice 2, Change DB Architecture to eXtreme NOTE: It may be asked to stop the EPAP software if it is running. Stop it by answering 'Y'.	Skip this step if DB Architecture already set to eXtreme. /DB Architecture Menu

		Caution: If this option is selected, the DB Architecture shall be changed from Compact to eXtreme and this architecture cannot be reverted. Please verify that all connected Non-Provisional Sites are running on eXtreme Architecture. It will take 30 minutes or more to populate the PDB 9Dig tables. Are you sure you want to change the DB Architecture from Compact to eXtreme? [N]: Y EPAP software is running. Stop it? [N]: Y PDBA software is running. Stop it? [N]: Y INFO: Populating the DN 9 Digit tables INFO: Populating the IMSI 9 Digit tables INFO: DB ARCHITECTURE changed to eXtreme. Press return to continue
6.	MPS A: The DB Architecture Menu is displayed. Select choice e, Exit	/DB Architecture Menu\ /\ 1 Display Current DB Architecture 2 Change DB Architecture to eXtreme e Exit
7.	MPS A: EPAP Configuration Menu is displayed. Select choice e, Exit	

		/EPAP Configuration Menu\
		/\ 1 Display Configuration
		2 Configure Network Interfaces Menu
		 3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10 SNMP Configuration
		11
		12 Configure Query Server
		13 Configure Query Server Alarm Feed
		Configure SNMP Agent Community
		 15 DB Architecture Menu
		e Exit
		\/
		Enter Choice: e
8.	MPS A: Start Epap and	Start Epap and Pdba software to reflect the changes.
0.	Pdba software.	Use the following command to start Epap: \$ systemctl start Pdba
		~~ /etc/init.d/Epap start ~~
	Note: Move to step 11 if it is configured as	"EPAP_RELEASE" is set to "0.617" EPAP application start Successful.
	PDBonly. Otherwise	\$ systemctl start Pdba
	continue to next step.	~~ /etc/init.d/Pdba start ~~ PDBA application start Successful.
9.	MPS B: Log on Server B.	[hostname] consolelogin: epapdev password: password

10.	MPS B: Start Epap software.	Start Epap software to reflect the changes. Use the following command to start Epap: \$ systemctl start Epap
		~~ /etc/init.d/Epap start ~~ "EPAP_RELEASE" is set to "0.617" EPAP application start Successful.
11.	Procedure complete.	Procedure is complete.
12.	Note down the timestamp in log.	Run the following command: \$ date

7 SOFTWARE UPGRADE PROCEDURES

Procedure 14 Assess MPS server's readiness for upgrade

Procedure 14: Assess the MPS Server's Readiness for Upgrade

S T	This procedure executes the steps required to assess the readiness of a system to be upgraded.			
E P	Check off $()$ each step as it is completed. Boxes have been provided for this purpose under each step number.			
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .			
1.	MPS B: Log in as the user "admusr".			
		<pre><hostname> console login: admusr password: <password></password></hostname></pre>		
2.	MPS B: Display the /etc/hosts configuration for the pdb entities.	If upgrading the first MPS B of a Provisionable mated pair, Run the following command to display the configuration of pdb entries:		
		\$ grep pdb /etc/hosts		
		Otherwise, skip to step 4.		
3.	MPS B: Verify the correct configuration	Below is an example of the output of the grep command:		
	for pdb entities in the /etc/hosts file.	192.168.55.176 host1-a pdba 192.168.61.76 host2-a prova-ip pdbb		
		If the command output contains 2 entries (pdba and pdbb are both configured), continue to the next step.		
		If the command output does not contain unique entries for pdba and pdbb, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section.		
4.	MPS B: Display the contents of the /var/TKLC/upgrade	Run the following command to display the presence of EPAP software ISO images:		
	directory.	\$ ls -la /var/TKLC/upgrade		
		Note: The file permissions and ownership may vary due to the different methods used to transfer the file.		
		Below is an example of the output of the 'ls -la' command for EPAP16.2: [root@Natal-A upgrade] # ls -la total 1785996 drwxrwxr-x. 3 root admgrp 4096 Jun 23 01:19 .		
		dr-xr-xr-x. 21 root root 4096 Jun 23 00:00 -rr 1 root root 904644608 Jun 23 01:19 EPAP-16.2.0.0.1_162.26.0-x86_64.iso		

Procedure 14: Assess the MPS Server's Readiness for Upgrade

5.	MPS B: Delete old ISO images.	Remove any ISO images that are not the target software ISO image using the following command:		
		# sudo rm -f /var/TKLC/upgrade/ <filename></filename>		
		Refer to step 6 to display the content of /var/TKLC/upgrade directory. Removed ISO should not be displayed.		
6.	MPS B: Determine when last reboot occurred.	\$ uptime		
	For any server up longer than 180 days would be a candidate for reboot during a maintenance window.	15:19:34 up 23 days, 3:05, 2 users, load average: 0.10, 0.13, 0.09		
7.	MPS B: Disk Integrity step: Executing self-test on the disk.	Run the following command: \$ sudo smartctl -t short /dev/sda		
	on the disk.	The output on E5-APP-B card would be like:		
		smartctl 5.43 2012-06-30 r3573 [x86_64-linux-2.6.32-642.6.2.el6prerel7.4.0.0.0_88.32.0.x86_64] (local build) Copyright (C) 2002-12 by Bruce Allen, http://smartmontools.sourceforge.net		
		=== START OF OFFLINE IMMEDIATE AND SELF-TEST SECTION === Sending command: "Execute SMART Short self-test routine immediately in off-line mode". Drive command "Execute SMART Short self-test routine immediately in off-line mode" successful.		
		Testing has begun. Please wait 1 minutes for test to complete.		
		Test will complete after Sat Feb 25 22:08:20 2017		
		Use smartctl -X to abort test. Note: Please wait for 5 minutes for the test to complete.		
8.	MPS B: Disk Integrity	•		
	step.	Run the following command: \$ sudo smartctl -l selftest /dev/sda		
	Contact My Oracle Support if the output shows any error/failure.	The output on E5-APP-B card would be like:		
		<pre>smartctl 5.43 2012-06-30 r3573 [x86_64-linux-2.6.32- 642.6.2.el6prerel7.4.0.0.0_88.32.0.x86_64] (local build) Copyright (C) 2002-12 by Bruce Allen, http://smartmontools.sourceforge.net</pre>		
		=== START OF READ SMART DATA SECTION === SMART Self-test log structure revision number 1 Num Test_Description Status Remaining LifeTime(hours) LBA of first error		

Procedure 14: Assess the MPS Server's Readiness for Upgrade

		# 1 Short offline	Completed	d with	out er	ror	00%	12435
9.	MPS B: Disk Integrity	Run the following command	l:					
	step	\$ sudo smartctl -a /dev	/sda gi	rep -i	LBA			
	Contact My Oracle Support if any output shows "Completed: read failure" or "Error: UNC xxx sectors".	The output would be like: 241 Total_LBAs_Written - 340851 242 Total_LBAs_Read - 1689714 Num Test_Description S LifeTime(hours) LBA_of_fi SPAN MIN_LBA MAX_LBA C		100	100 100 TUS	000 000 Remai	Old_age Old_age ning	Always
10.	MPS B: Disk Integrity Test.	Repeat steps 9 to 11 for the	/dev/sdb	disk dr	ive on	E5-APF	P-B card:	
11.	MPS B: Logout from "admusr".	Logout from the "admusr" user by executing the following command:						
		\$ exit						
12.	MPS A: Repeat checks on Server A.	Repeat steps-1 to 13 on MP	S A.					
13.	Procedure Complete.	This procedure is complete.						
14.	Note down the	Run the following command	l:					
	timestamp in log.	\$ date						

Procedure 15 Preupgrade Backups

Procedure 15: Preupgrade Backups

S	This procedure per	This procedure performs the pre and post upgrade backups.			
T E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.				
P #	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.			
1.	MPS A: Backup system configuration on MPS A.	Execute 0 to backup the system configuration on MPS A.			
2.	MPS B: Backup system configuration on MPS B.	Execute 0 to backup the system configuration on MPS B.			

Procedure 15: Preupgrade Backups

3.	MPS B: Backup RTDB database.	Perform Procedure A.7 to backup the RTDB database on MPS B. Note: Perform this step only while upgrading Mixed and Non-Prov Nodes.
	Note: If migrating from 17.0.0.x, skip this step.	
4.	MPS A: Backup EuiDB database.	Perform Procedure A.8 to backup the EuiDB database on MPS A.
	Note: If migrating from 17.0.0.x, skip this step.	
5.	MPS A: Backup PDB database. Note: If one of the provisioning sites is already upgraded to EPAP 17.0.0.x, follow	In case of upgrading via migration from EPAP 17.0.0.x to 17.0.0.y (where 0<= x <=5 and y >= 6) or from 17.0.0.x (where 0<= x <=5) to 17.1.y, perform Procedure A.51 to back up the PDB database. In other cases, perform Procedure A.27 PDB Backup before upgrade to back up
	Appendix A.6 to take PDB backup from	the PDB database.
	upgraded Provisioning site	Note : Only perform this step if the MPS-A is configured as a Provisionable node.
		Check the output of Procedure 2, step 9 to verify if MPS A is provisionable or not.
6.	Note down the timestamp in log.	Run the following command:
7.	Transfer the backup to remote server	\$ date Using SFTP (secure-FTP), transfer the backups to a remote, customer-provided computer. Enter "yes" when prompted if you want to continue to connect.

Procedure 15: Preupgrade Backups

		\$ cd /var/TKLC/epap/free
		\$ sftp <ip address="" computer="" of="" remote=""> Connecting to <ip address="" computer="" of="" remote=""> The authenticity of host '<ip address="" computer="" of="" remote="">' can't be established. DSA key fingerprint is 58:a5:7e:1b:ca:fd:1d:fa:99:f2:01:16:79:d8:b4:24. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added <ip address="" computer="" of="" remote="">' (DSA) to the list of known hosts. root@<ip address="" computer="" of="" remote="">'s password: sftp> cd <target directory=""></target></ip></ip></ip></ip></ip>
		sftp> put backup_file
		Note: put backups one by one
		Uploading backup_file
		sftp> bye
		If no customer provided remote computer for backups exist, transfer
		the backup file to the mate using the following command:
		\$ sudo chmod 667 /var/TKLC/epap/free/ <backup file=""> \$ su - epapdev \$ san /var/TKLC/epap/free/ hashup files</backup>
		<pre>\$ scp /var/TKLC/epap/free/<backup file=""> epapdev@mate:/var/TKLC/epap/free/</backup></pre>
8.	Procedure Complete.	This procedure is complete.

Procedure 16 Preupgrade system time check

Procedure 16: Pre-upgrade System Time Check

S T	This procedure pe	rforms the pre-upgrade system time check.		
E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.			
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .			
circo batt corr Che by r	umstances, either at tery failure, it is poss rect. If the system tirek the date/time on more than 15 minute	initial installation in the customer's network or due to power interruption and ible for an MPS server to have a system date/time value too large for NTP to me is 20 minutes or more off from the real time, NTP cannot correct it. both MPS-A and MPS-B servers, and correct the system time on any server off s from the real time. If not already logged in, then login at MPS A:		
	user "epapdev".	<pre><hostname> console login: epapdev password: <password></password></hostname></pre>		

2. 3.	MPS A: Execute the "date" command. MPS B: Log in as the user "epapdev".	Execute the "date" command and examine the result. \$ date Sat Feb 25 22:09:58 EDT 2018 If not already logged in, then login at MPS B: <hostname> console login: epapdev password: <password></password></hostname>
4.	MPS B: Execute the "date" command.	Execute the "date" command and examine the result. \$ date Sat Feb 25 22:09:58 EDT 2018
5.	Compare result to the real time.	Compare the result from the "date" command in the previous step to the real time. If the difference is 15 minutes or less, then this procedure is complete, otherwise if the difference exceeds 15 minutes, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section
6.	Procedure Complete.	This procedure is complete.
7.	Note down the timestamp in log.	Run the following command: \$ date

Procedure 17 Check 9dig counts before moving to eXtreme architecture

Procedure 17: Check 9dig counts before moving to eXtreme architecture

Note: This step is only required before converting DB architecture from Compact to Extreme

S	This proceduresh	ocks the Odia counts for all DN/IMCI and IMEI			
T	This procedurechecks the 9dig counts for all DN/IMSI and IMEI.				
E	Check off (\checkmark) each step as it is completed. Boxes have been provided for this purpose under each step number.				
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .				
Ver	ify the PDB data are	within 9dig limitation			
	the second of the Proofs for an	DN CEK			
	kimum 9dig limit for [kimum 9dig limit for [
	kimum 9dig limit for I				
	-				
1.	MPS A: Log in as the	If not already leaded in the placin of MADC A.			
	user "epapdev" on	If not already logged in, then login at MPS A: <hostname> console login: epapdev</hostname>			
	standalone PDB.	password: <password></password>			
2.	MPS A: Execute the	Execute the "parse9Dig" script and examine the result.			
	"parse9Dig" script on				
	standalone PDB.	Note: Stop the Pdba software before executing this script.			
		\$ /usr/TKLC/epap/config/parse9Dig all c			
		Get reference from the following snapshot:			
		[epapdev@Osorna-1B-PDBonly config]\$ /usr/TKLC/epap/config/parse9Dig all c			
		This utility will retrieve all digits for DB and parse them into 9Dig entries.			

		Utility Start Time: 06/13/18-20:51:48			
		Parsing DN digits into 9digits			
		INFO: DN 9dig count 2.			
		Parsing IMSI digits into 9digits			
		INFO: IMSI 9dig count: 9.			
		Parsing IMEI digits into 9digits			
		INFO: IMEI 9dig count: 1.			
		Utility End Time: 06/13/18-20:51:48 [epapdev@Osorna-1B-PDBonly config]\$			
		If any of the data type from DN/IMSI and IMEI exeeds the 9Dig limit, then DB Architecture cannot be changed to eXtreme.			

3.	MPS A: Start Pdba software.	Run the following command to start Pdba software on EPAP 16.3.1/16.4.1 servers: \$ service Pdba start /etc/init.d/Pdba start PDBA application start Successful. Run the following command to start Pdba software on EPAP 17.1 servers: \$ systemctl start Pdba
4.	MPS A: Procedure is complete.	This procedure is complete.

S	This procedure upgrades MPS B server.				
T E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.				
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .				
1.	Notify the potential users not to start the PDBA software during the duration of the upgrade.				
	The Prov servers (Mixed EPAP or PDBonly) upgrade must complete before the Non-Provisionable EPAP. For more details, see <u>Upgrading EPAP Non-Provisionable MPS Servers</u> .				
2.	Establish a connection to MPS B.	If access to the MPS servers is not available through an IP network, connect to the E5-APP-B card via the serial port.			
		For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A card's adapter and use it for serial access. Cable part numbers - 830-1220-xx Skip to step 7, if connected through serial console.			
3.	Create a terminal window and establish a	In a newly created terminal window labeled "MPS B – from MPS A", connect directly into MPS A.			


	connection by logging into MPS A. Log in to MPS A.	# ssh admusr@ <mps a=""> Password: <password></password></mps>
4.	MPS A: Start screen session.	Run the following commands to start screen and establish a console session to MPS B.
	MPS A: Connect to the console of MPS B.	\$ screen -L Run the following command on E5-APP-B: \$ sudo minicom mate If above command fails, then refer to Procedure A.24.
5.	MPS B: Login prompt is displayed.	<pre><hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname></pre>
6.	MPS B: Log in to the server as the user "epapdev".	<pre><hostname> console login: epapdev password: <password></password></hostname></pre>
7.	MPS B: Determine media available for upgrade.	Perform 0 or use an EPAP ISO image to perform upgrade.
8.	MPS B: Verify that it is an Incremental Upgrade or a Major upgrade	Check 0, Step 7 and 8. If the upgrade type is a split mirror upgrade, proceed with the following step. If it's Incremental, proceed to step 11
9.	MPS B: Disable syscheck fs module.	Run the following command to disable the syscheck fs module. \$ su - root Password: # syscheckAdmdisable disk fs
10.	MPS B: Create upgrade.conf for splitting mirrors.	Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps: 1. #vi /usr/TKLC/plat/etc/upgrade/upgrade.conf 2.If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line: BACKOUT_TYPE=SPLIT_MIRROR NOTE: Not performing this step will prevent any successful backout.

		Run the following command to verify that the above command has been executed successfully:
		# cat /usr/TKLC/plat/etc/upgrade/upgrade.conf
		The output should be: [root@MPS-B ~] # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf
		BACKOUT_TYPE=SPLIT_MIRROR
		# su – admusr
11.	MPS A: Log in to the server as the	Log in to MPS A:
	user "admusr".	<pre><hostname> console login: admusr password: <password></password></hostname></pre>
12.	MPS A: Check if	Run the following command to check if uiEdit variable is present or not.
	eagle_alarm_feed	\$ uiEdit grep "EAGLE_ALARM_FEED"
	variable is present in EuiDB.	"EAGLE_ALARM_FEED" is set to "ON"
		Note: If no output is displayed after above command is run, then run next step
		else skip next step.
13.	MPS A: Insert EAGLE_ALARM_FEE	NOTE: Skipping this step if EAGLE_ALARM_FEED variable is not present in EuiDB will cause upgrade to fail
	D variable in EuiDB	Run the following command to insert the missing variable in EuiDB.
		\$ /usr/bin/mysql -uroot –p <password> -B EuiDB -e "insert into econfig values ('EAGLE_ALARM_FEED','ON')"</password>
		Check if above command was successful. Output should be as displayed below:
		\$ echo \$?
		0
		Repeat Step 12 to check if value is inserted successfully in DB.
		Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section if this step fails.
14.	MPS A: Verify that	# sudo su – epapconfig
	the state of PDBA	
	Proxy Feature is No.	Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.

Note: Skip this step for Non-Prov and PDBonly EPAP. /----EPAP Configuration Menu-----\ /----\ 1 | Display Configuration | 2 | Configure Network Interfaces Menu | |----|------------------| | 3 | Set Time Zone |----| 4 | Exchange Secure Shell Keys | 5 | Change Password |----| 6 | Platform Menu |----| | 7 | Configure NTP Server ---|------------| 8 | PDB Configuration Menu 9 | Security |----| | 10 | SNMP Configuration | 11 | Configure Alarm Feed | 12 | Configure Query Server | 13 | Configure Query Server Alarm Feed | |----| | 14 | Configure SNMP Agent Community | |----| | 15 | Mate Disaster Recovery e | Exit \----/ Enter Choice: 1 EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116 EPAP B Provisioning Network IP Address = 192.168.61.116
Provisioning Network Netmask = 255.255.255.0
Provisioning Network Default Router = 192.168.61.1
EPAP A Backup Prov Network IP Address = Not configured
EPAP B Backup Prov Network IP Address = Not configured
Backup Prov Network Netmask = Not configured
Backup Prov Network Default Router = Not configured
EPAP A Sync Network Address = 192.168.2.100
EPAP B Sync Network Address = 192.168.2.200
EPAP A Main DSM Network Address = 192.168.120.100
EPAP B Main DSM Network Address = 192.168.121.100
EPAP B Backup DSM Network Address = 192.168.121.200
EPAP B Backup DSM Network Address = 192.168.121.200

		EPAP A HTTP Port EPAP B HTTP Port EPAP A HTTP SUEXEC PORT EPAP B HTTP SUEXEC PORT EPAP A Banner Connection Port EPAP B Banner Connection Port EPAP A Static NAT Address EPAP B Static NAT Address PDBI Port Remote MPS A Static NAT Address Remote MPS A HTTP Port Local Provisioning VIP Remote Provisioning VIP Local PDBA Address Remote PDBA Address Remote PDBA B Address Time Zone PDB Database Preferred PDB Allow updates from alternate PDB Auto DB Recovery Enabled PDBA Proxy Enabled If PDBA Proxy Enabled = Yes then Executive PDBA Proxy Enabled If PDBA Proxy Enabled = Yes then Executive PDBA For Add PDBA Setup to disable EPA	= Not configured = 80 = 192.168.15.152 = 192.168.15.172 = 192.168.16.115 = 192.168.16.116 = America/New_York = Exists = Standby = Yes = Yes = Yes
15.	MPS A:	Otherwise, if PDBA Proxy Enabled = No, the	
	Clear PDB replication logs	replication logs Otherwise, if PDBA Proxy Enabled = No, the	n skip this step.
16.	MPS A: Choose "e" to	MPS Side A:	
	exit.		

		/EPAP Configuration Menu\
		1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		 5 Change Password
		 6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		 9 Security
		10 SNMP Configuration
		 11 Configure Alarm Feed
		12 Configure Query Server
		Configure Query Server Alarm Feed
		14 Configure SNMP Agent Community
		 15 Mate Disaster Recovery
		e Exit
		\/
		Enter Choice: e
17.	MPS B: Log in to the server as the user	Log in to MPS B if not already logged in:
	"admusr".	<pre><hostname> console login: admusr password: <password></password></hostname></pre>
18.	MPS B: Execute the platcfg menu.	\$ sudo su – platcfg



		Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section, if the early upgrade checks fail due to any other reason.
22.	MPS B: Allow List NTP Alarms	 If the Early Upgrade Checks fail due to the NTP related alarms, then ignore the NTP alarms using the following commands: Exit the platcfg menu Change to root user using the "su –" command. vim /usr/TKLC/plat/etc/upgrade/upgrade.conf Edit the following line to include the NTP related alarms.
23.	MPS B: Select Initiate Upgrade.	Select the Initiate Upgrade menu and press [ENTER]. Upgrade Menu Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Accept Upgrade Reject Upgrade Exit
24.	MPS B: Select the Upgrade Media.	The screen will display a message that it is searching for upgrade media. Once the upgrade media is found, an Upgrade Media selection menu will be displayed similar to the example shown below.

		Select the upgrade media on ISO image. There should only be one selection available, as shown in the example below. If there is more than one selection available, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section Choose Upgrade Media Menu EPAP-17.0.0.3.0_170.17.0-x86_64.iso - 17.0.0.3.0_170.17.0 Exit
25.	MPS B: Upgrade proceeds.	The screen displays the following, indicating that the upgrade software is first running the early upgrade checks, and then proceeding with the upgrade. Replacing <seconds> with the value from the log. Starting Early Upgrade Checks at 1448399773 Running earlyUpgradeChecks() for Upgrade::EarlyPolicy::TPDEarlyChecks upgrade policy Verified server is not pending accept of previous upgrade Hardware architectures match Install products match. Whitelisted alarms: Verified server is alarm free! Verified server is alarm free! Verified all raid mirrors are synced. Early Upgrade Checks Have Passed! Early Upgrade Checks finished at 1448399780 Initializing upgrade information</seconds>
26.	MPS B: Upgrade proceeds.	Many informational messages will come across the terminal screen as the upgrade proceeds. Finally, after upgrade is complete, the server will reboot.
27.	MPS B: Upgrade completed.	After the final reboot, Press Enter the screen will display the login prompt, as shown in the example below. Starting smartd: [OK] Daemon is not running AlarmMgr daemon is not running, delaying by 1 minute TKLChwmgmtcli stop/pre-start, process 9750 TPDhpDiskStatus stop/pre-start, process 9782 Oracle Linux Server release 6.9 Kernel 2.6.32-696.20.1.el6prerel7.6.0.0.0_88.47.0.x86_64 on an x86_64 Arica-A login:
28.	MPS B: Log in to the server as the user "epapdev".	After upgrade, exit from the console and open new console using EPAP IP and login by epapdev user. <hostname> console login: epapdev password: <pre><pre><pre><pre>password</pre></pre></pre></pre></hostname>

		Note: The SSH login for root shall get enabled after the upgrade.
		Note: The 3311 logili for root shall get chabled after the appraise.
29.	MPS B: Verify the Upgrade.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors and warnings were reported. Check 0, Steps 7 and 8 to determine whether it is incremental or major upgrade. If it is major upgrade, then consider following error and warning.
		\$ grep -i error /var/TKLC/log/upgrade/upgrade.log
		Following errors shall be observed: 1530712922::ERROR: Config file is currently checked out! 1530712922::ERROR: LOCKED BY: platcfg 1530712922::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf 1530712922::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v .
		is30669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' 1530669414:: 1530669414:: 1530669414::
		1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414:: 1530669414:: 1530669414::myisamchk: error: 140 when opening MyISAM table
		1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' 1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
		'/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' 1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136. 1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136
		530094474::libsemanage.semanage_reload_policy: load_policy returned error code 2

Following statement for missing binary file shall be observed in upgrade.log:

1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory 1542631084::./upgrade_mysql: line 46: /usr/TKLC/epap/bin/pass_fetch: No such file or directory

[NOTE: It is observed only when MySQL upgraded from earlier version than 5.6.18

to version 5.7]

Contact My Oracle Support following the instructions on the front page or the instructions in the **My Oracle Support** section, if the output contains any error other than the above mentioned errors.

Also note that sometime a carriage return is inserted in the log file causing some of the error messages to appear truncated. This is acceptable and should be ignored.

\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log

Examine the output of the above command to determine if any warnings were reported.

Contact My Oracle Support following the instructions on the front page or the instructions in the **My Oracle Support** section, if the output contains any warnings beside the following:

```
1488951825::warning: CAPABILITY: service_hp-asrd_disabled 1488951825::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been updated...reparsing xml... 1530712185::WARNING: This capability is not defined in the default capabilities. 1530712186::WARNING: Nor is it defined in the current hardware ID's capabilities. 1530712186::WARNING: CAPABILITY: service__disabled 1530712186::WARNING: HARDWARE ID: E5APPB 1488951890::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7. 0.3.0.0_86.44.0.x86_64/weak-updates failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7. 0.3.0.0_86.44.0.x86_64/modules.softdep failed: No such file or directory 0.3.0.0_86.44.0.x86_84/modules.softdep failed: No such file or directory 0.3.0.0.0_86.44.0.x86_84/modules.softdep failed: No such file or directory 0.3.0.0.0_86.44.0.x86_84
```

```
1488951902::warning:
573.18.1.el6prerel7.
                                                                              erase unlink of /lib/modules/2.6.32-
      .3.0.0_86.44.0.x86_64/modules.order failed: No such file or directory
 1488951902::warning: 573.18.1.el6prerel7.
                                                                               erase unlink of /lib/modules/2.6.32-
 0.3.0.0_86.44.0.x86_64/modules.networking failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
 0.3.0.0_86.44.0.x86_64/modules.modesetting failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.drm failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.block failed: No such file or directory 1488951903::kexec-tools #warning: /etc/kdump.conf crea
                                                                                                                                  #warning: /etc/kdump.conf created as
 c/kdump.conf.rpmnew
 / tallip: confirment of the co
 1488952136::samhain
                                                                                                                                 warning: /etc/samhainrc created as
  /etc/
  samhainrc.rpmnew
 1488952138::php-common
                                                                                                                                 #warning: /etc/php.ini created as
 /etc/p
hp.ini.rpmnew
1488952209::initscripts
                                                                                                                                 ##warning: /etc/sysctl.conf created as
 etc/sysctl.conf.rpmnew
1488952260::mysql-commercial-server
                                                                                                                                 warning: /etc/my.cnf created as
 /etc/my.
cnf.rpmnew
1488952291::ntp
1488952291::ntp warning: /etc/ntp.conf created as /etc/n
tp.conf.rpmnew
1488952302::TKLCplat ###########warning:
/usr/TKLC/plat/
etc/pid_conf created as /usr/TKLC/plat/etc/pid_conf.rpmnew
1488952302::#warning: /usr/TKLC/plat/etc/service_conf created as /usr/TKLC/plat/etc/service_conf.rpmnew
1488952302::TKLCalarms ##warning:
/usr/TKLC/plat/etc/alarms/al
arms.xml saved as /usr/TKLC/plat/etc/alarms/alarms.xml.rpmsave
1488952328::alarmMgr ##warning:
/usr/TKLC/plat/etc/alarmMgr/
alarmMgr.conf created as /usr/TKLC/plat/etc/alarmMgr/alarmMgr.conf.rpmnew
1488952471::WARNING: This capability is not defined in the default capabilities.
1488952471::WARNING: Nor is it defined in the current hardware ID's
                                                                                                                                 warning: /etc/ntp.conf created as
 1488952471::WARNING: Nor is it defined in the current hardware ID's
 capabilities
 :488952471::WARNING: CAPABILITY: service__disabled
1488952471::WARNING: HARDWARE ID: E5APPB
1488952602::sudo warning: /ei
                                                                                                                                warning: /etc/sudoers created as
  /etc/su
 doers.rpmnew
1488952709::WARNING: /usr/TKLC/plat/etc/alarms/alarms_mps.xml has been
 updated.
 reparsing xml...
1488952718::TKLCepap-HA
 g: group root} does not exist - using root
1488952942::warning: erase unlink of /usr/TKLC/epap/bin/dbMigration failed:
 such file or directory
1488952949::WARNING: Module variable EXPECTED_CPUS is deprecated!
1488952951::WARNING: CONFIG:
  /usr/TKLC/plat/lib/Syscheck/modules/system/cpu/conf
 ig
1488952951::WARNING: Module variable EXPECTED_CPU_ALM is deprecated!
1488952951::WARNING: CONFIG:
/usr/TKLC/plat/lib/Syscheck/modules/system/cpu/conf
ig
```

```
If it is an incremental upgrade, then consider following error and
warning
$ grep -i error /var/TKLC/log/upgrade/upgrade.log
Following errors shall be observed:
1530712922::ERROR: Config file is currently checked out!
1530712922::ERROR: LOCKED BY: platcfg
1530712922::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf
1530712922::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v
.
1530669414::myisamchk: error: 140 when opening MyISAM-table
'/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI'
1530669414::myisamchk: error: 140 when opening MyISAM-table
'/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI'
1530669414::
1530669414::-
1530669414::
1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI'
1530669414::
1530669414::-
 1530669414
1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
1528826597::myisamchk: error: 140 when opening My'/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI
                                                                    140 when opening MyISAM-table
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'..
1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136. 1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.
530094474::libsemanage.semanage_reload_policy: load_policy returned error code
1530094474::libsemanage.semanage_reload_policy: load_policy returned error code 2.
.1494304768::ERROR: Config file is currently checked out!
1494304781::ERROR: LOCKED BY: platcfg
1494304781::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf
1494304781::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v
1496215832::Error : Table 'mysql.innodb_index_stats' doesn't exist
1496215832::Error : Table 'mysql.slave_master_info' doesn't exist
1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist
```

```
1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist
1496215832::Error : Table 'mysql.innodb_index_stats' doesn't exist
1496215832::Error : Table 'mysql.innodb_table_stats' doesn't exist
1496215832::Error : Table 'mysql.slave_master_info' doesn't exist
1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist
1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist
1496215832::Error : Table 'mysql.innodb_index_stats' doesn't exist
1496215832::Error : Table 'mysql.innodb_table_stats' doesn't exist
1496215832::Error : Table 'mysql.slave_master_info' doesn't exist
1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist
1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist
1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist
```

Following statement for missing binary file shall be observed in upgrade.log: 1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory 1542631084::./upgrade_mysq1: line 46: /usr/TKLC/epap/bin/pass_fetch: No such file or directory

[NOTE: It is observed only when MySQL upgraded from earlier version than 5.6.18

to version 5.7]

Contact My Oracle Support following the instructions on the front page or the instructions in the **My Oracle Support** section, if the output contains any error other than the above mentioned errors.

Also note that sometime a carriage return is inserted in the log file causing some of the error messages to appear truncated. This is acceptable and should be ignored.

\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log

Examine the output of the above command to determine if any warnings were reported.

Contact My Oracle Support following the instructions on the front page or the instructions in the **My Oracle Support** section, if the output contains any warnings beside the following:

```
1489042076::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been updated...rep arsing xml...
1489042124::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0.88.32.0.x86_64/weak-updates failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.order failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.networking failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.modesetting failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.drm failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.drm failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.block failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.block failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.block failed: No such file or directory 1489042197::warNING: /usr/TKLC/plat/etc/alarms/alarms_mps.xml has been updated...reparsing xml...
```

Refer to section 3.7 to know more about logging.

		NOTE: provRMTP core might be observed on EPAP after upgrade, if the EPAP is connected to EAGLE. The core should be ignored, it has no impact on traffic running from EPAP to EAGLE.
30.	MPS B: Verify the Upgrade.	\$ grep "Upgrade returned success" /var/TKLC/log/upgrade/upgrade.log
		Verify that the message "Upgrade returned success!" is displayed. If it is not, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section.
		1400786220:: Upgrade returned success!
31.	MPS B: Verify that it is an Incremental Upgrade or Major upgrade	Check Procedure 2, Steps 7 and 8. If the upgrade type is a Major upgrade, proceed with the following step. If it's Incremental, proceed to step 33.
32.	MPS B: Enable syscheck fs module.	Run the following command to enable the syscheck fs module. \$ sudo syscheckAdmenable disk fs
33.	MPS B: Upgrade is complete. Verify Health of MPS B	Execute 0 on MPS B to verify the health of MPS B. If this is a Major Upgrade, the syscheck utility will report the "3000000000000000000000000000000000000
34.	MPS B: Verify that if alarm to accept upgrade is present.	To verify alarm to accept upgrade execute following command: \$ alarmMgralarmStatus grep tpdServerUpgradePendingAccept Following output shall be observed:

		SEQ: 5 UPTIME: 112 BIRTH: 1498203542 TYPE: SET ALARM: TKSPLATMI33 tpdServerUpgradePendingAccept 1.3.6.1.4.1.323.5.3.18.3.1.3.33 32532 Processing Error Configuration Error
		Note: Disk mirroring does not start until the upgrade is accepted.
35.	MPS B: Update ssh_config to disable MD5 and MAC algorithm for security	Perform the following steps to disable unsecure algorithm for ssh: 1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2 and 3. Else go to step 4. 2. \$ sudo rcstool co /etc/ssh/ssh_config 3. \$ sudo sed -i -e '/MACs hmac-md5-96,hmac-sha1-96/d' /etc/ssh/ssh_config 4.\$ sudo rcstool ci /etc/ssh/ssh_config 4.\$ grep "MACs hmac-sha2-256,hmac-sha2-512" /etc/ssh/sshd_config If no output is displayed for above command continue to next command in step 5 and 6 else skip these steps 5. \$ sudo rcstool co /etc/ssh/sshd_config 6. \$ sudo sed -i '\$ a \\tmacs hmac-sha2-256,hmac-sha2-256,hmac-sha2-512' /etc/ssh/sshd_config 7. \$ sudo rcstool ci /etc/ssh/sshd_config 8. \$ sudo systemctl restart sshd
36.	Update the httpd.conf file to disable the Cache control no-store policy.	Perform the following steps to disable Cache control no-store policy: 1. \$ grep "Header set Cache-Control no-store" / etc/httpd/conf/httpd.conf If the output contains "Header set Cache-Control no-store", Execute the below steps. If no output is displayed for the above command, skip the steps mentioned below. 2. \$ sudo sed -i '/Cache-Control no-store/c\#Header set Cache-Control no-store' / etc/httpd/conf/httpd.conf 3. \$ grep "Header set Cache-Control no-store" / etc/httpd/conf/httpd.conf

		The output should be "#Header set Cache-Control no-store" showing that the line has been commented.
		4. \$ sudo systemctl restart httpd
37.	Reconnect console	On E5-APP-B card, reconnect the console cable between the serial port labeled
$ \sqcup $	cable.	'SO' on E5-APP-B B card's adapter and the serial port labeled 'S1' on the E5-APP-
		B A card's adapter. Cable part numbers - 830-1220-xx
38.	Procedure complete.	Procedure is complete.
39.	Note down the	Run the following command:
	timestamp in log.	\$ date

Procedure 19 Upgrade server A

S	This procedure upgra	This procedure upgrades the MPS-A server in the EPAP System.	
T E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.		
P #	IF THIS PROCEDURE I	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .	
1.	MPS A: Determine media available for upgrade.	Perform 0 or use an EPAP ISO image to perform upgrade.	
2.	Establish a connection to MPS A.	If access to the MPS servers is not available through an IP network, connect to the E5-APP-B card via the serial port.	
		For connecting the E5-APP-B A card, disconnect the console cable from the serial port on the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for serial access. Cable part numbers - 830-1220-xx Skip to step 6, if connected through serial console.	
3.	Create a terminal window and establish a connection by logging into MPS B. Log in to MPS B.	In a newly created terminal window labeled "MPS B", connect directly into MPS B. # ssh epapdev@ <mps b=""> Password: <password></password></mps>	
4.	MPS B: Start screen session.	Run the following commands to start screen and establish a console session to MPS A.	

	MPS B: Connect to the console of MPS A.	#su - root Password: \$ screen -L Run the following command on E5-APP-B: \$ sudo minicom mate If above command fails then refer to Procedure A.24.
5.	MPS A: Login prompt is displayed.	<pre><hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname></pre>
6.	MPS A: Log in to the server as the user "epapdev".	<pre><hostname> console login: epapdev password: <password></password></hostname></pre>
7.	MPS A: Verify that it is an Incremental Upgrade. or a Major Upgrade	Check 0, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with the following step. If it's Incremental, proceed to step 10.
8.	MPS A: Disable syscheck fs module.	\$ su - root Password: Run the following command to disable the syscheck fs module. # syscheckAdmdisable disk fs
9.	MPS A: Create upgrade.conf for splitting mirrors if this is a Major upgrade.	Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps: 1. #vi /usr/TKLC/plat/etc/upgrade/upgrade.conf 2.If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line: BACKOUT_TYPE=SPLIT_MIRROR NOTE: Not performing this step will prevent any successful backout.

		Run the following command to verify that the above command has been executed successfully:
		# cat /usr/TKLC/plat/etc/upgrade/upgrade.conf
		The output should be: [root@MPS-B ~] # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf
		BACKOUT_TYPE=SPLIT_MIRROR
10.	MPS A: Execute the platcfg menu.	\$ su - platcfg
11.	MPS A: Select the Maintenance submenu.	The platcfg Main Menu appears. On the Main Menu, select Maintenance and press [ENTER].
		Maintenance Diagnostics Server Configuration Network Configuration Security Remote Consoles Exit
12.	MPS A: Select the Upgrade submenu.	Select the Upgrade menu and press [ENTER]. Maintenance Menu Dual Image Upgrade Upgrade Patching Backup and Restore Restart Server Save Platform Debug Logs Platform Data Collector
13.	MPS A: Select the	Salact the "Early Ungrade Checks" many to verify that the system is ready for
	Early Upgrade Checks submenu.	Select the "Early Upgrade Checks" menu to verify that the system is ready for upgrade.

14.	MPS A: Allow List NTP Alarms	Upgrade Menu Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Accept Upgrade Reject Upgrade Exit If the Early Upgrade Checks fail due to the NTP related alarms, then execute step 15. Otherwise, skip to step 16. Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section, if the early upgrade checks fail, due to any other reason. 1) If the Early Upgrade Checks fail due to the NTP related alarms, then ignore the NTP alarms using the following commands: e. Exit the platcfg menu f. Change to root user using the "su —" command. g. vim /usr/TKLC/plat/etc/upgrade/upgrade.conf h. Edit the following line to include the NTP related alarms. EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2
		For example – To allowlist the NTP alarm "tpdNTPDaemonNotSynchronizedWarning" which has the alarm code TKLCPLATMI10, the above mentioned line should be edited as EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2,TKSPLATMI10
		Note: There should not be any space between two alarms i.e. between TKSPLATMI2 and TKSPLATMI10
		2) If the Early Upgrade Checks fail due to "Server Default Route Network Error", then this alarm shall be allowlisted in upgrade.conf file. To allowlist this alarm which has the alarm code TKSPLATMA14, the above mentioned line should be edited as EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2,TKSPLATMI10, TKSPLATMA14
15.	MPS A: Select Initiate Upgrade.	Select the Initiate Upgrade menu and press [ENTER].

		Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Accept Upgrade Reject Upgrade Exit
16.	MPS A: Select the Upgrade Media.	The screen will display a message that it is searching for upgrade media. Once the upgrade media is found, an Upgrade Media selection menu will be displayed similar to the example shown below. Select the upgrade media on ISO image. There should only be one selection available, as shown in the example below. If there is more than one selection available, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section. Choose Upgrade Media Menu EPAP-17.0.0.3.0_170.17.0-x86_64.iso - 17.0.0.3.0_170.17.0 Exit
17.	MPS A: Upgrade proceeds.	The screen displays the following, indicating that the upgrade software is first running the early upgrade checks, and then proceeding with the upgrade. Replacing <seconds> with the value from the log. Starting Early Upgrade Checks at 1448399773 Running earlyUpgradeChecks() for Upgrade::EarlyPolicy::TPDEarlyChecks upgrade policy Verified server is not pending accept of previous upgrade Hardware architectures match Install products match. Whitelisted alarms: Verified server is alarm free! Verified all raid mirrors are synced. Early Upgrade Checks Have Passed! Early Upgrade Checks finished at 1448399780 Initializing upgrade information</seconds>
18.	MPS A: Upgrade proceeds.	Many informational messages will come across the terminal screen as the upgrade proceeds. Finally, after upgrade is complete, the server will reboot.

19.	MPS A: Upgrade completed.	After the final reboot, Press Enter, the screen will display the login prompt, as shown in the example below. Starting smartd: [OK] Daemon is not running AlarmMgr daemon is not running, delaying by 1 minute TKLChwmgmtcli stop/pre-start, process 9750 TPDhpDiskStatus stop/pre-start, process 9782 Oracle Linux Server release 6.9 Kernel 2.6.32-696.20.1.el6prerel7.6.0.0.0_88.47.0.x86_64 on an x86_64 Arica-A login:
20.	MPS A: Log in to the	
	server as the user "epapdev".	<pre><hostname> console login: epapdev password: <password> Note: The SSH login for root shall get enabled after the upgrade.</password></hostname></pre>
21.	MPS A: Verify the Upgrade.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors and warnings were reported. Check 0, Steps 7 and 8 to determine whether it is incremental or major upgrade. If it is major upgrade then consider following \$ grep -i error /var/TKLC/log/upgrade/upgrade.log Following errors shall be observed: 1530712922::ERROR: Config file is currently checked out! 1530712922::ERROR: LOCKED BY: platcfg 1530712922::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf 1530712922::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf 1530712922::ERROR: ELEMENT: /var/TKLC/res/usr/TKLC/plat/etc/vlan.conf,v . 1530669414::myisamchk: error: 140 when opening MyISAM-table 1/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI 1530669414::myisamchk: error: 140 when opening MyISAM-table 1/var/TKLC/epap/db/pdb/mysql/db.MYI 1530669414::myisamchk: error: 140 when opening MyISAM-table 1/var/TKLC/epap/db/pdb/mysql/db.MYI 1530669414::myisamchk: error: 140 when opening MyISAM-table 1/var/TKLC/epap/db/pdb/mysql/db.MYI 1530669414::myisamchk: error: 140 when opening MyISAM-table 1/var/TKLC/epap/db/pdb/mysql/event.MYI 153069414::myisamchk: error: 140 when openi

```
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
1528826597::myisamchk: error:
                                                                 140 when opening MyISAM-table
  //var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136. 1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.
530094474::libsemanage.semanage_reload_policy: load_policy returned error code
1530094474::libsemanage.semanage_reload_policy: load_policy returned error code
                                            : Table 'mysql.innodb_index_stats' doesn't exist
: Table 'mysql.innodb_table_stats' doesn't exist
: Table 'mysql.slave_master_info' doesn't exist
: Table 'mysql.slave_relay_log_info' doesn't exist
: Table 'mysql.slave_worker_info' doesn't exist
: Table 'mysql.innodb_index_stats' doesn't exist
: Table 'mysql.innodb_table_stats' doesn't exist
: Table 'mysql.slave_master_info' doesn't exist
: Table 'mysql.slave_relay_log_info' doesn't exist
: Table 'mysql.slave_worker_info' doesn't exist
: Table 'mysql.innodb_index_stats' doesn't exist
: Table 'mysql.innodb_table_stats' doesn't exist
: Table 'mysql.slave_master_info' doesn't exist
: Table 'mysql.slave_master_info' doesn't exist
: Table 'mysql.slave_relay_log_info' doesn't exist
: Table 'mysql.slave_worker_info' doesn't exist
1496215832::Error
Following errors shall be observed if upgrade is performed on a setup which
was
converted from Prov to Non Prov:
                                               : Table 'pdb.LicenseInfo' doesn't exist
1529314607::Error
1529314607::status
                                               : Operation failed
1529314607::pdb.asd
1529314607::Error
1529314607::status
                                               : Table 'pop.asu
: Operation failed
                                                  Table 'pdb.asd' doesn't exist
1529314607::pdb.bucketContent
1529314607::Error : Table 'pdb.bucketContent' doesn't exist
1529314607::status : Operation failed
1529314607::pdb.bucketMap
1529314607::Error : Tal
1529314607::status : Ope
                                               : Table 'pdb.bucketMap' doesn't exist
: Operation failed
1529314607::pdb.commands
1529314607::Error : Table 'pdb.commands' doesn't exist
1529314607::status : Operation failed
1529314607::pdb.dn
1529314607::Error
1529314607::status
                                               : Table 'pdb.dn' doesn't exist
: Operation failed
1529314607::pdb.dn9dig
1529314607::Error
1529314607::status
                                               : Table 'pdb.dn9dig' doesn't exist
: Operation failed
1529314607::pdb.dnB_asd
Following statement for missing binary file shall be observed in upgrade.log:
```

1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory 1542631084::./upgrade_mysql: line 46: /usr/TKLC/epap/bin/pass_fetch: No such file or directory

[NOTE: It is observed only when MySQL upgraded from earlier version than 5.6.18

to version 5.7]

Contact My Oracle Support following the instructions on the front page or the instructions in the **My Oracle Support** section, if the output contains any error other than the above mentioned errors.

Also note that sometime a carriage return is inserted in the log file causing some of the error messages to appear truncated. This is acceptable and should be ignored.

\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log

Examine the output of the above command to determine if any warnings were reported.

Contact My Oracle Support following the instructions on the front page or the instructions in the **My Oracle Support** section, if the output contains any warnings beside the following:

```
1488951825::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been
updated...reparsing xml...
1530712185::WARNING: This capability is not defined in the default
capabilities
1530712186::WARNING: Nor is it defined in the current hardware ID's
capabilities.
1530712186::WARNING: CAPABILITY: service_
1530712186::WARNING: HARDWARE ID: E5APPB
                                                                         disabled
1530856895::mysql: [Warning] Using a password on the command line interface can
     insecure
1530857005::mysql: [Warning] Using a password on the command line interface can
be insecure.
1488951890::warning:
573.18.1.el6prerel7.
                                         erase unlink of /lib/modules/2.6.32-
0.3.0.0_86.44.0.x86_64/weak-updates failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.softdep failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.order failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.networking failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.modesetting failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.drm failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.block failed: No such file or directory 1488951903::kexec-tools #warning: /etc/kdump.conf creat
                                                                     #warning: /etc/kdump.conf created as
/ec/kdump.conf.rpmnew
c/kdump.conf.rpmnew
1488952115::ca-certificates #############warning:
/etc/pki/tls/ce
rts/ca-bundle.crt created as /etc/pki/tls/certs/ca-bundle.crt.rpmnew
1488952136::samhain
                                                                     warning: /etc/samhainrc created as
/etc/
samhainrc.rpmnew
1488952138::php-common
                                                                     #warning: /etc/php.ini created as
/etc/p
hp.ini.rpmnew
```

```
1488952209::initscripts
                                                                                ##warning: /etc/sysctl.conf created as
 etc/sysctl.conf.rpmnew
1488952260::mysql-commercial-server
                                                                                warning: /etc/my.cnf created as
/etc/my.
cnf.rpmnew
1488952291::ntp
                                                                                 warning: /etc/ntp.conf created as
tp.conf.rpmnew
1488952302::TKLCplat ##############warning:
/usr/TKLC/plat/etc/pid_conf.rpmnew
1488952302::#warning: /usr/TKLC/plat/etc/pid_conf.rpmnew
1488952302::#warning: /usr/TKLC/plat/etc/service_conf created as
/usr/TKLC/plat/
etc/service_conf.rpmnew
1488952320::TKLCalarms ###warning:
/usr/TKLC/plat/etc/alarms/al
arms.xml saved as /usr/TKLC/plat/etc/alarms/alarms.xml.rpmsave
1488952328::alarmMgr ###warning:
/usr/TKLC/plat/etc/alarmMgr/
alarmMgr.conf created as /usr/TKLC/plat/etc/alarmMgr/alarmMgr.conf.rpmnew
1488952471::WARNING: This capability is not defined in the default
capabilities.
1488952471::WARNING: Nor is it defined in the current hardware ID's
 /etc/n
 1488952471::WARNING: Nor is it defined in the current hardware ID's
 capabilities
:488952471::WARNING: CAPABILITY: service__disabled
1488952471::WARNING: HARDWARE ID: E5APPB
1488952602::sudo warning: /e
                                                                                warning: /etc/sudoers created as
 /etc/su
doers.rpmnew
1488952709::WARNING: /usr/TKLC/plat/etc/alarms/alarms_mps.xml has been
updated.
reparsing xml...
1488952718::ТКLСерар-НА
 g: group root} does not exist - using root
1488952942::warning: erase unlink of /usr/TKLC/epap/bin/dbMigration failed
No such file or directory 1488952949::WARNING: Module variable EXPECTED_CPUS is deprecated! 1488952951::WARNING: CONFIG:
/usr/TKLC/plat/lib/Syscheck/modules/system/cpu/conf
ig
1488952951::WARNING: Module variable EXPECTED_CPU_ALM is deprecated!
1488952951::WARNING: CONFIG:
/usr/TKLC/plat/lib/Syscheck/modules/system/cpu/config
 If it is an incremental upgrade then consider following
      grep -i error /var/TKLC/log/upgrade/upgrade.log
Following errors shall be observed:
1530712922::ERROR: Config file is currently checked out!
1530712922::ERROR: LOCKED BY: platcfg
1530712922::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf
1530712922::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v
.1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' 1530669414::
 1530669414:
1530669414::myisamchk: error: 140 when opening MyISAM-table
 1530669414:
1530009414..my/samichk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::
 1530669414::
 1530669414::
1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
```

```
1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
 1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
 1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
 1528826597::myisamchk: error: 140 when opening MyISAM-table
   /var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYi
 1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136. 1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.
 530094474::libsemanage.semanage_reload_policy: load_policy returned error code
 1530094474::libsemanage.semanage_reload_policy: load_policy returned error code
Following errors shall be observed if upgrade is performed on a setup which
 was
 converted from Prov to Non Prov:
1529314607::Error : Table 'pdb.asd' doesn't exist
1529314607::status : Operation failed
1529314607::Error : Table 'pdb.asd' doesn't exist
1529314607::status : Operation failed
1529314607::Error : Table 'pdb.bucketContent'
1529314607::Error : Table 'pdb.bucketContent' doesn't exist
1529314607::status : Operation failed
1529314607::Error .....

1529314607::status : Operation talleu

1529314607::pdb.bucketMap

1529314607::Error : Table 'pdb.bucketMap' doesn't exist

1529314607::status : Operation failed
 1529314607::status : Operation failed
1529314607::pdb.commands
1529314607::Error : Table 'pdb.commands' doesn't exist
```

```
1529314607::status
1529314607::pdb.dn
1529314607::Error
                                        : Operation failed
                                         : Table 'pdb.dn' doesn't exist
: Operation failed
1529314607::status :
1529314607::pdb.dn9dig
1529314607::Error :
                                         : Table 'pdb.dn9dig' doesn't exist
: Operation failed
1529314607::status : 0
1529314607::pdb.dnB_asd
```

Following statement for missing binary file shall be observed in upgrade.log: 1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory 1542631084::./upgrade_mysql: line 46: /usr/TKLC/epap/bin/pass_fetch: No such

file or directory

[NOTE: It is observed only when MySQL upgraded from earlier version than 5.6.18

to version 5.7]

Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section, if the output contains any error other than the above-mentioned errors.

Also note that sometime a carriage return is inserted in the log file causing some of the error messages to appear truncated. This is acceptable and should be ignored.

grep -i warning /var/TKLC/log/upgrade/upgrade.log

Examine the output of the above command to determine if any warnings were reported.

Contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section, if the output contains any warnings beside the following:


```
1489042076::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been
updated...rep
arsing xml...
1489042124::warning:
                                                          erase unlink of /lib/modules/2.6.32-
1489042124::Warning.
642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/weak-updates failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
1489042136::Warning. erase unlink of / Fib/modules/2.0.32 642.6.2.el6prerel7.4 0.0.0_88.32.0.x86_64/modules.order failed: No such file or directory 1489042136::Warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4 0.0.0_88.32.0.x86_64/modules.networking failed: No such file or directory 1489042136::Warning: erase unlink of /lib/modules/2.6.32-642.6.2.el6prerel7.4
642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.modesetting failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-
642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.drm failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-
642.6.2.el6prerel7.4
.0.0.0_88.32.0.x86_64/modules.block failed: No such file or directory 1489042197::WARNING: /usr/TKLC/plat/etc/alarms/alarms_mps.xml has been
updated.
 .reparsing xml...
```

Refer to section 3.7 to know more about logging.

22.	MPS A: Verify the	NOTE: provRMTP core might be observed on EPAP after upgrade, if the EPAP is connected to EAGLE. The core should be ignored, it has no impact on traffic running from EPAP to EAGLE. \$ grep, "Upgrade_returned_success"
	Upgrade.	\$ grep "Upgrade returned success" /var/TKLC/log/upgrade/upgrade.log
		Verify that the message "Upgrade returned success!" is displayed. If it is not, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section.
		1400793814:: Upgrade returned success!
23.	MPS A: Verify that it is an Incremental Upgrade. or Major Upgrade	Check 0, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with the following step. If it's Incremental, proceed to step 26.
24.	MPS A: Enable syscheck fs module.	\$ su - root Password:
		Run the following command to enable the syscheck fs module. # syscheckAdmenable disk fs
25.	MPS A: Upgrade is complete. Verify Health of MPS A	Execute 0 on MPS A to verify the health of MPS A. On a Provisionable(mixed-EPAP or PDBonly) MPS, expect that the syscheck
		utility will alarm the fact that the PDBA software is not running. This will appear as a "5000000000000000 – Server Application Process Error" alarm.
		If this is a Major Upgrade, the syscheck utility will report the "300000000000000 – Server Internal Disk Error" alarm as the disk mirroring is in progress.
		The alarm will be cleared after the completion of disk mirroring.
		Verify that no unexpected alarms are noted.
		If it is major upgrade, Proceed with 0 to upgrade SSL certificate.
26.	MPS A: Verify that if alarm to accept	To verify alarm to accept upgrade execute following command:
	upgrade is present.	\$ alarmMgralarmStatus grep tpdServerUpgradePendingAccept
		Following output shall be observed:
		SEQ: 5 UPTIME: 112 BIRTH: 1498203542 TYPE: SET ALARM: TKSPLATMI33 tpdServerUpgradePendingAccept 1.3.6.1.4.1.323.5.3.18.3.1.3.33 32532 Processing Error Configuration Error

		Note: Disk mirroring does not start until the upgrade is accepted.
27.	MPS B: Log in as epapdev user.	<pre><hostname> console login: epapdev password: <password></password></hostname></pre>
28.	MPS B: Reboot MPS B server.	Reboot MPS-B to disable the root login. Switch to root user. \$ su - root Password: Reboot the server: \$ reboot Wait til the reboot gets completed.
29.	MPS A: Enable PDBA proxy and VIP features.	If PDBA Proxy Enabled = Yes, in the step 14 of 0, then execute 0 to enable Epap PDBA Proxy and VIP Features. Otherwise, skip this step.
30.	MPS A: Check services for query server.	\$ epapdb -c queryservers If query server is not configured i.e. INFO: No Query Server Configured, then skip this step otherwise Execute 6 to restart MYSQL service for PDB on query server.
31.	MPS A: Update ssh_config to disable MD5 and MAC algorithm for security	Perform following steps to disable unsecure algorithm for ssh: 1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2 and 3. Else go to step 4. 2. \$ sudo rcstool co /etc/ssh/ssh_config 3. \$ sudo sed -i -e '/MACs hmac-md5,hmac-md5-96,hmac-sha1-96/d' /etc/ssh/ssh_config 4.\$ sudo rcstool ci /etc/ssh/ssh_config 4.\$ grep "MACs hmac-sha2-256,hmac-sha2-512" /etc/ssh/sshd_config If no output is displayed for above command continue to next command in step 5 and 6 else skip these steps 5. \$ sudo rcstool co /etc/ssh/sshd_config

		6. \$ sudo sed -i '\$ a \\tMACs hmac-sha2-256,hmac-sha2-512' /etc/ssh/sshd_config
		7. \$ sudo rcstool ci /etc/ssh/sshd_config
		8. \$ sudo systemctl restart sshd
32.	Update the httpd.conf file to	Perform the following steps to disable Cache control no-store policy:
	disable the Cache control no-store	1. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
	policy.	If the output contains "Header set Cache-Control no-store", Execute the below steps. If no output is displayed for the above command, skip the steps mentioned below.
		2. \$ sudo sed -i '/Cache-Control no-store/c\#Header set Cache-Control no-store' /etc/httpd/conf/httpd.conf
		3. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
		The output should be "#Header set Cache-Control no-store" showing that the line has been commented.
		4. \$ sudo systemctl restart httpd
33.	MPS A: If HTTP was enabled for EPAP	If HTTP was enabled before upgrade, follow below mentioned steps.
	GUI before upgrade,	Open EPAP GUI in HTTPS mode.
	follow this step	 Navigate to User Administration tab on GUI -> HTTP(S) support ->
	otherwise skip it.	Change Configuration.
		Disable HTTP mode, if it shows HTTP mode as enabled.
		Enable the HTTP mode again as shown in image below. The HTTP mode
		should get enabled successfully. Now you can open the EPAP GUI in HTTP mode.



Procedure 20 Run RTDB Converter

Procedure 20: Run RTDB Converter

S	•	RTDB converter to update rtdb database as per new schema. This procedure
T E	should not be run	on PDBonly setup.
P	Check off (√) each step	as it is completed. Boxes have been provided for this purpose under each step number.
#		
	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .
	**Note: This step ca	an be run simultaneously on MPS A and MPS B
1.	MPS A and B: Log	<hostname> console login: epapdev</hostname>
	in to the server as	password: <password></password>
	the user	
2.	"epapdev".	[epapdev@Ithaca-a ~]\$ su -
2.	MPS A and B: Switch to root	Password: <password></password>
	user.	***************************************
3.	MPS A and B: Start	\$ systemctl start Epap
	EPAP Services	~~ /etc/init.d/Epap start ~~
		HEDAD DELEACER'S AND HORSELE
		"EPAP_RELEASE" is set to "0.617"
4.	MPS A and B: Run	EPAP application start Successful. \$ cd /usr/TKLC/epap/bin
	RTDB converter	φ cu /usi/ikec/epap/biii
_	script	If system is in compact architecture as noted in step 10 of 0 run below
	30.160	command:
	Note: RTDB	\$./ rtdbEpap164CompactToCompactConvertTool
	softwares need to	
	be	If system is in extreme as noted in step 10 of 0 architecture run below
	running on MPS A	command:
	& B in order to run	command: \$./ rtdbEpap164ExtremeToExtremeConvertTool
	•	
	& B in order to run	
	& B in order to run	\$./ rtdbEpap164ExtremeToExtremeConvertTool
5.	& B in order to run the converter.	\$./ rtdbEpap164ExtremeToExtremeConvertTool Many informational Messages will be displayed on screen. If this script fails contact My Oracle Support.
5. □	& B in order to run	\$./ rtdbEpap164ExtremeToExtremeConvertTool Many informational Messages will be displayed on screen. If this script fails
	& B in order to run the converter. Reboot Eagle cards.	\$./ rtdbEpap164ExtremeToExtremeConvertTool Many informational Messages will be displayed on screen. If this script fails contact My Oracle Support. Perform the steps in Procedure 21 on the Eagle STP connected to the EPAP servers to reload SM cards.
6.	& B in order to run the converter. Reboot Eagle cards. Procedure is	\$./ rtdbEpap164ExtremeToExtremeConvertTool Many informational Messages will be displayed on screen. If this script fails contact My Oracle Support. Perform the steps in Procedure 21 on the Eagle STP connected to the EPAP
6.	& B in order to run the converter. Reboot Eagle cards.	\$./ rtdbEpap164ExtremeToExtremeConvertTool Many informational Messages will be displayed on screen. If this script fails contact My Oracle Support. Perform the steps in Procedure 21 on the Eagle STP connected to the EPAP servers to reload SM cards.
6.	& B in order to run the converter. Reboot Eagle cards. Procedure is complete	\$./ rtdbEpap164ExtremeToExtremeConvertTool Many informational Messages will be displayed on screen. If this script fails contact My Oracle Support. Perform the steps in Procedure 21 on the Eagle STP connected to the EPAP servers to reload SM cards. Procedure is complete.

Procedure 21 Reboot EAGLE Cards

Procedure 21: Reboot EAGLE Cards

S T E	This procedure reboots EAGLE cards to reload new RTDB. Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.			
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .			
1.	EAGLE : reboot all SM cards to reload new RTDB.	Note: Before rebooting EAGLE cards, check whether the EPAP software running or not. If EPAP software is not running then start it manually commands. Execute the below steps on EPAP:		
		\$ systemctl status Epap		
		Start the EPAP software, if the above command shows that software i running. If service EPAP shows that software is running, there is no ne next command.		
		\$ systemctl start Epap ~~ /etc/init.d/Epap start ~~ EPAP application started.		
		Login onto the connected EAGLE.		
		Reboot 1 SM card on the EAGLE and verify that it comes back to an IS state.		
		Then boot the rest of the EAGLE SM cards over 4 batches (booting 1/4 cards at a single time).		
2.	Procedure is complete	Procedure is complete.		
3. □	Note down the timestamp in log.	Run the following command:		
		\$ date		

Procedure 22 Accept Upgrade


Note: If the upgrade is accepted, Backout cannot be performed.

Procedure 22 : Accept upgrade

S T	This procedure accep	This procedure accept the upgrade to perform the upgrade process.	
E	Check off ($$) each step	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.	
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .		
11.	MPS: Log in as admusr.	Log in as admusr if not already loged in. <hostname> login: admusr Password: Note: The consele logen may proceed by many lines of report output</hostname>	
22.	MPS: Verify if alarmMgr process running.	Note: The console logon may preced by many lines of reboot output. \$ sudo ls /var/run/alarmMgr If the file exists, proceed to the next step. If the file does not exist, contact Oracle Customer Service.	
33.	MPS: Execute the platcfg menu.	\$ sudo su – platcfg	
44.	MPS: Select the Maintenance submenu.	The platcfg Main Menu, select Maintenance and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Network Configuration Security Remote Consoles Exit	
55.	MPS: Select the Upgrade submenu.	Select the Upgrade menu and press [ENTER] .	

Note: If the upgrade is accepted, Backout cannot be performed.

Procedure 22 : Accept upgrade



Note: If the upgrade is accepted, Backout cannot be performed.

Procedure 22 : Accept upgrade

		Setting POST_UPGRADE_ACTION to ACCEPT in upgrade info. Cleaning backout directory. Cleaning backout directory. Cleaning message from MOTD. No patch pending alarm on server so no MOTD update. Cleaning up RPM config backup files Checking / Checking / Checking /tmp Checking /var/TKLC Checking /var/TKLC Checking /var/TKLC/epap/rt Checking /var/TKLC/epap/logs Checking /var/TKLC/epap/free Starting cleanup of RCS repository. INFO: Removing '/etc/pam.d/system-auth' from RCS repository INFO: Removing '/etc/pam.d/password-auth' from RCS repository INFO: Removing '/etc/pam.d/password-auth' from RCS repository PRESS ANY KEY TO RETURN TO THE PLATCFG MENU. Note: If you still observe the accept upgrade message even after the disks get mirrored properly after accepting the upgrade for the first time, follow the steps mentioned in APPENDIX A.30 to remove the false accept upgrade alarm from the system.
88.	Procedure is complete Note down the timestamp in log.	Procedure is complete. Run the following command: \$ date

Procedure 23 Keys exchange between active and standby PDB

Procedure 23: Keys exchange between active PDB and standby PDB

S T	· ·	
E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.	
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .	
1.	MPS A: Log in to Active PDB EPAP as the user "epapdev".	If not already logged in, then log in at MPS A of active PDB EPAP: <hostname> console login: epapdev password: <password></password></hostname>
2.	MPS A: Verify that PDB entry are present in known_hosts file.	Execute following command to verify that pdb entry present in known_hosts file: \$ cat .ssh/known_hosts
		If entry is present, skip next step.
3.	MPS A: Exchange the keys from Active PDB	Run the following command on Active PDB: \$ ssh epapdev@ <remote ip="" pdb=""> Are you sure you want to continue connecting (yes/no)? <yes> Password: Snapshot for reference: [epapdev@Recife-A ~]\$ ssh epapdev@10.75.141.104 FIPS integrity verification test failed. The authenticity of host '10.75.141.104 (10.75.141.104)' can't be established. RSA key fingerprint is d4:d5:94:c6:57:1a:30:25:bc:b0:67:f9:f7:07:c6:68. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added '10.75.141.104' (RSA) to the list of known hosts. epapdev@10.75.141.104's password:</yes></remote>
4.	MPS A: Log in to Standby PDB EPAP as the user "epapdev".	If not already logged in, then log in at MPS A of standby PDB EPAP: <hostname> console login: epapdev password: <password></password></hostname>
5.	MPS: Exchange the keys from Standby PDB	Repeat the step 2 and step3 to exchange the keys from standby PDB as well.
6.	Procedure is complete	Procedure is complete.

Procedure 23: Keys exchange between active PDB and standby PDB

7.	Note down the timestamp in log.	Run the following command:
ш	timestamp in log.	\$ date

THIS COMPLETES THE UPGRADE

8 SOFTWARE RECOVERY PROCEDURES

Refer to this section only if there is a problem and it is desired to revert back to the pre-upgrade version of the software.

8.1 Backout Setup

The reason to perform a backout has a direct impact on any backout preparation that must be done. Since the reason cannot be known ahead of time, no definitive procedure can be written.

My Oracle Support personnel will have to have login access to the affected MPS server, probe the server for the root cause of the problem, and execute whatever setup or cleanup is necessary in order to prepare the MPS server for backout.

8.2 Perform Backout


No matter the initial cause of the upgrade problem, once all necessary corrective steps have been taken to prepare for the backout, then the following procedure can be executed to perform a backout. Refer to section 2.2 and section 2.4 for the Backout process overview.

S T	This procedure provides instructions to perform backout on MPS B server.		
E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.		
P #	Note:Perform this procedure if only MPS B has been upgraded successfully and MPS A is still at the		
	pre-upgrade release. Note: If the upgrade has been accepted, this procedure cannot be executed.		
1.	Terminate all previous	If not already connected, connect to the E5-APP-B card via the serial port.	
	connections (ssh).	For connecting the E5-APP-B B card, disconnect the console cable from the	
		serial port on the E5-APP-B A card's adapter. The cable should be disconnected	
		at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A cards adapter and use it for serial access. Cable part numbers - 830-1220-xx	
		Skip to step 5, if connected through serial console.	
2.	Create a terminal	In a newly created terminal window labeled "MPS B – from MPS A", connect	
	window and establish a	directly into MPS A.	
	connection by	# ssh admusr@ <mps a=""></mps>	
	logging into MPS A.	Password: <password></password>	
	Log in to MPS A.		
2			
3.	MPS A: Verify that the state of PDBA	# sudo su — epapconfig	
	Proxy Feature is No.	Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.	
	Note: Skip this step	/usr/iktc/plat/ilb/security/user.pm line 904.	
	for Non-Prov and		
	PDBonly EPAP.		


```
/----EPAP Configuration Menu-----\
| 1 | Display Configuration
   ---|------------------|
   2 | Configure Network Interfaces Menu |
    3 | Set Time Zone
   4 | Exchange Secure Shell Keys
   5 | Change Password
| 6 | Platform Menu
 |----|------------|
| 7 | Configure NTP Server
|----|
| 8 | PDB Configuration Menu
   9 | Security
   ---|------------------|
| 10 | SNMP Configuration
|----|
| 11 | Configure Alarm Feed
| 12 | Configure Query Server
|----|
| 13 | Configure Query Server Alarm Feed |
 | 14 | Configure SNMP Agent Community
 |----|
| 15 | Mate Disaster Recovery
|----|
\----/
Enter Choice: 1
EPAP A Provisioning Network IP Address = 192.168.61.115
EPAP B Provisioning Network IP Address = 192.168.61.116
Provisioning Network Netmask = 255.255.255.0
Provisioning Network Default Router = 192.168.61.1
EPAP A Backup Prov Network IP Address = Not configured
EPAP B Backup Prov Network IP Address = Not configured
Backup Prov Network Netmask = Not configured
Backup Prov Network Default Router = Not configured
EPAP A Sync Network Address = 192.168.2.100
EPAP B Sync Network Address = 192.168.2.200
EPAP A Main DSM Network Address = 192.168.120.100
EPAP B Main DSM Network Address = 192.168.121.100
EPAP B Backup DSM Network Address = 192.168.121.200
EPAP A HTTP Port = 80
EPAP A Provisioning Network IP Address = 192.168.61.115
EPAP A HTTP Port
EPAP B HTTP Port
                                           = 80
                                            = 80
EPAP A HTTP SuExec Port
                                           = 8001
EPAP B HTTP SuExec Port
                                           = 8001
EPAP A Banner Connection Port
EPAP B Banner Connection Port
                                           = 8473
                                           = 8473
```

4.	MPS A: Clear PDB replication logs	EPAP A Static NAT Address
5.	MPS A: Start screen session	Run the following commands to start screen and establish a console session to MPS B. \$ screen -L
	MPS A: Connect to the console of MPS B.	Run the following command on E5-APP-B: \$ sudo minicom mate If above command fails then refer to Procedure A.24
6.	MPS B: Login prompt is displayed.	<pre><hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname></pre>
7.	MPS B: Log in to the server as user "admusr".	If not already logged in, then log in. <hostname> console login: admusr Password: <password></password></hostname>

Procedure 24: Server B Backout



Procedure 24: Server B Backout



13.	MPS B: Verify the Backout.	If the backout was not successful and errors were recorded in the logs, then contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section for further instructions. If the backout was successful, then continue with the following step.
14.	MPS B: Reboot the MPS.	Perform the following commands to reboot the MPS: # sudo init 6
15.	MPS B: Reboot completed.	After the reboot, the screen will display the login prompt, as shown in the example below. ###################################
16. 17.	MPS B: Verify Health of MPS B. MPS B: Sync the time on both MPS A and MPS B.	Execute 0 on MPS B to verify the health of MPS B. Sync the time on both MPS A and B if it is different. Log in to MPS A: <hostname> console login: epapdev Password: <password> Check date and time on MPS A using following command: \$ date Sat Jul 7 01:35:18 EDT 2018 Log in to MPS B: <hostname> console login: epapdev Password: <password> Check date and time on MPS B using following command:</password></hostname></password></hostname>

18.	MPS B: Clear MySQL replication error banner message, if any	Examine the output of the above command to determine if any errors were reported related to MySQL replication such as: MySQL data replication error detected; Attempting to restart. Attempt to restart MySQL replication failed. Run the following command to copy the EuiDB database from B server to A server to clear any of the above observed MySQL replication error. Note: This utility should be executed only with epapdev user. \$ /usr/TKLC/epap/config/resetReplication Resetting MySql Replication This script will fix EuiDB replication by copying the database from one side of the pair to the other side and then resetting the MySql replication pointers. Are you sure you want to reset replication? (y/n) y Which side do you want to copy FROM? (A/B) [B]: B

19.	MPS B: Verify Health of MPS B	Connecting to local DB Connecting to mate DB Copying EuiDB to mate Stopping local slave Stopping mate slave Resetting local master Resetting local slave Resetting mate master Resetting mate slave Starting local slave Starting mate slave Starting mate slave Starting mate slave Resetting MySql Replication Completed If there is a failure in resetReplication, run the following commands: \$ mysql -uroot -peLapRoot -e "GRANT ALL ON EuiDB.* to elapdev@localhost" \$ mysql -uroot -peLapRoot -e "GRANT ALL ON EuiDB.* to elapdev@mate" Run the following command to verify that the banner messages related to the replication error are cleared after some time. # manageBannerInfo -1 Execute 0 on MPS B to verify the health of MPS B. If backout of major upgrade was performed, the syscheck utility will report the "3000000000000000000000000000000000000
		fe80::f64e:5ff:fe49:9b7f cannot be pinged!
20.	Reconnect console cable.	On E5-APP-B card, reconnect the console cable between the serial port labeled 'S0' on E5-APP-B B card's adapter and the serial port labeled 'S1' on the E5-APP-B A card's adapter. Cable part numbers - 830-1220-xx
21.	Procedure complete.	This procedure is complete.

22.	Note down the	Run the following command:
ш	timestamp in log.	\$ date

The application should now be running at the original software release level

Procedure 25 Backout both Server A and B

Procedure 25: Backout both MPS A and B

STEP#	This procedure provides instructions to perform backout on both MPS A and MPS B servers. Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. Note:Perform this procedure only if both MPS A and MPS B have been upgraded or partially upgraded and you wish to backout both servers to the previous version. Note: If the upgrade has been accepted, this procedure cannot be performed. Note: Database changes post upgrade and before backout might be lost after performing backout procedure		
1.	Terminate all previous connections (ssh).	If not already connected, connect to the E5-APP-B card via the serial port. For connecting the E5-APP-B A card, disconnect the console cable from the serial port on the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for serial access. Cable part numbers - 830-1220-xx Skip to step 6, if connected through serial console.	
2.	Create a terminal window and establish a connection by logging into MPS B.	In a newly created terminal window labeled "MPS A – from MPS B", connect directly into MPS B. # ssh admusr@ <mps b=""> Password: <password></password></mps>	
3.	MPS B: Start screen session.	Run the following commands to start screen and establish a console session to MPS A. \$ screen -L	

Procedure 25: Backout both MPS A and B


	MPS B: Connect to the console of MPS A.	Run the following command on E5-APP-B: \$ sudo minicom mate If above command fails then refer to Procedure A.24.
4.	MPS A: Log in prompt is displayed.	<pre><hostname> console login:</hostname></pre> Note: Hit enter if no login prompt is displayed.
5.	MPS A: Log in to the server as user "admusr".	Log in as 'admusr'. <hostname> console login: admusr Password: <password></password></hostname>
6.	MPS A: Verify that the state of PDBA Proxy Feature is No. Note: Skip this step for Non-Prov and PDBonly EPAP.	<pre># sudo su - epapconfig Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.</pre>

/EPAP Configuration Menu\
1 Display Configuration
2 Configure Network Interfaces Menu
3 Set Time Zone
4 Exchange Secure Shell Keys
 5 Change Password
 6 Platform Menu
 7 Configure NTP Server
 8 PDB Configuration Menu
 9 Security
 10 SNMP Configuration
 11 Configure Alarm Feed
 12 Configure Query Server
 13 Configure Query Server Alarm Feed
 14 Configure SNMP Agent Community
15 Mate Disaster Recovery
e Exit
Enter Choice: 1 EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116 EPAP B Provisioning Network Netmask = 255.255.255.0 EPAP B Backup Prov Network IP Address = Not configured EPAP B Backup Prov Network IP Address = Not configured EPAP B Backup Prov Network IP Address = Not configured EPAP B Backup Prov Network Netmask = Not configured EPAP A Sync Network Default Router = Not configured EPAP A Sync Network Address = 192.168.2.100 EPAP B Sync Network Address = 192.168.2.200 EPAP B Main DSM Network Address = 192.168.120.100 EPAP B Main DSM Network Address = 192.168.120.200 EPAP A Backup DSM Network Address = 192.168.121.100 EPAP B Backup DSM Network Address = 192.168.121.200 EPAP A HTTP Port = 80 EPAP A HTTP SUExec Port = 80 EPAP A HTTP SUExec Port = 8001 EPAP B Banner Connection Port = 8473 EPAP B Banner Connection Port = 8473

Procedure 25: Backout both MPS A and B

		EPAP A Static NAT Address
7.	MPS A: Clear PDB replication logs	If PDBA Proxy Enabled = Yes, then Execute Procedure A.26 to clear replication the logs. Otherwise, if PDBA Proxy Enabled = No, then skip this step.
8.	MPS A: Execute the platcfg menu.	\$ sudo su - platcfg
9.	MPS A: Select the Maintenance / Upgrade submenu	The platefg Main Menu, select Maintenance and press [ENTER]. Then select Upgrade menu and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Remote Consoles Security Network Configuration Exit

Procedure 25: Backout both MPS A and B



Procedure 25: Backout both MPS A and B

		Finally, after backout is complete, a message will be displayed stating that a reboot is required.
		The server will be at runlevel 3 and no applications are running. Proceed to the next step to verify the backout and manually reboot the server.
12.	MPS A: Verify the Backout.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors were reported.
		# grep -i error /var/TKLC/log/upgrade/upgrade.log # grep -i error /var/TKLC/log/upgrade/ugwrap.log
		Examine the output of the above commands to determine if any errors were reported.
		Refer to section 3.7 to know more about logging.
13.	MPS A: Verify the Backout.	If the backout was not successful and errors were recorded in the logs, then contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section for further instructions.
		If the backout <i>was</i> successful, then enter continue with the following steps:
14.	MPS A: Reboot the MPS.	Perform this step only on a backout of an incremental upgrade. Perform the following commands to reboot the MPS:
		# init 6
15.	MPS A: Backout completed.	After the reboot, the screen will display the login prompt, as shown in the example below.


Procedure 25: Backout both MPS A and B

		##################################
		1464603884: Upstart Job syscheck: started ####################################
		1464603884: Upstart Job tpdProvd: started ####################################
		1464603885: Upstart Job TKLCsnmp-subagent: started ####################################
		1464603886: Upstart Job ntdMgr: started ####################################
		Oracle Linux Server release 6.7 Kernel 2.6.32-573.18.1.el6prere17.0.3.0.0_86.44.0.x86_64 on an x86_64 devloan-01 login:
16.	MPS A: Verify Health of MPS A.	Execute 0 on MPS A to verify the health of MPS A
		The syscheck utility may report the "500000000000002 - Server Application Process Error" for PDBA, if the pdba software is not running. May also report following error: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
		* defaultroute: FAILURE:: The IPv6 default route at fe80::f64e:5ff:fe49:9b7f cannot be pinged!
17.	Terminate all previous	If not already connected, connect to the E5-APP-B card via the serial port.
	connections (ssh).	For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A cards adapter and use it for serial access.
		Skip to step 21, if connected through serial console.
18.	Create a terminal window and establish a	In a newly created terminal window labeled "MPS B – from MPS A", connect directly into MPS A.
	connection by logging in to MPS A.	# ssh epapdev@ <mps a=""> Password: <password></password></mps>

Procedure 25: Backout both MPS A and B

	Log in to MPS A.	
19.	MPS A: Start screen session.	Run the following commands to start screen and establish a console session to MPS B.
		\$ screen -L
	MPS A: Connect to the console of MPS	Run the following command on E5-APP-B: \$ sudo minicom mate
	B.	If above command fails then refer to Procedure A.24.
20.	MPS B: Login prompt is displayed.	<hostname> console login:</hostname>
	,	Note: Hit enter if no login prompt is displayed.
21.	MPS B: Log in to the server as user "epapdev".	<pre><hostname> console login: admusr Password: <password></password></hostname></pre>
22.	MPS B: Execute the platcfg menu	\$ sudo su — platcfg
23.	MPS B: Select the Maintenance/Upgra de submenu	The platcfg Main Menu appears. On the Main Menu, select Maintenance and press [ENTER]. Then select Upgrade menu and press [ENTER].
		Maintenance Diagnostics Server Configuration Remote Consoles Security Network Configuration Exit

Procedure 25: Backout both MPS A and B



Procedure 25: Backout both MPS A and B

	Finally, after backout is complete, a message will be displayed stating that a reboot is required.
	The server will be at runlevel 3 and no applications are running. Proceed to the next step to verify the backout and manually reboot the server.
MPS B: Verify the Backout.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors were reported.
	# grep -i error /var/TKLC/log/upgrade/upgrade.log # grep -i error /var/TKLC/log/upgrade/ugwrap.log
	Examine the output of the above commands to determine if any errors were reported.
	Refer to section 3.7 to know more about logging.
MPS B: Verify the Backout.	If the backout was not successful and errors were recorded in the logs, then contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section for further instructions.
	If the backout <i>was</i> successful, then enter continue with the following steps:
MPS B: Reboot the	Perform the following commands to reboot the MPS:
, in 3.	\$ init 6
MPS B: Log in to MPS B.	After the reboot, the screen will display the login prompt, as shown in the example below.
	1464603884: Upstart Job syscheck: started ####################################
	1464603884: Upstart Job tpdProvd: started ####################################
	1464603885: Upstart Job TKLCsnmp-subagent: started ####################################
	1464603886: Upstart Job ntdMgr: started####################################
	Oracle Linux Server release 6.7 Kernel 2.6.32-573.18.1.el6prere17.0.3.0.0_86.44.0.x86_64 on an x86_64 devloan-01 login:
	MPS B: Verify the Backout. MPS B: Reboot the MPS. MPS B: Log in to

Procedure 25: Backout both MPS A and B

30. Create a terminal window and establish a connection by logging into MPS A. Log in to MPS A	In a newly created terminal window labeled "MPS B – from MPS A", connect directly into MPS A. # ssh epapdev@ <mps a=""> Password: <password></password></mps>
MPS A: Rejoin previous screen session on MPS B	Run the following command to disconnect and then rejoin previous screen session: \$ screen -dr
MPS B: Sync the time on both MPS A and MPS B.	Sync the time on both MPS A and B if it is different. Log in to MPS A: <pre></pre>

Procedure 25: Backout both MPS A and B

		Done.
33.	MPS B: Log in to the server as user "epapdev".	<pre><hostname> console login: epapdev Password: <password></password></hostname></pre>
34.	MPS B: Clear MySQL replication error banner message, if any	Run the following command to check for MySQL replication error: \$ manageBannerInfo -1 Examine the output of the above command to determine if any errors were reported related to MySQL replication such as: MySQL data replication error detected; Attempting to restart Attempt to restart MySQL replication failed Run the following command to copy the EuiDB database from B server to A server to clear any of the above observed MySQL replication error. Note: This utility should be executed only with epapdev user \$ /usr/TKLC/epap/config/resetReplication Resetting MySql Replication This script will fix EuiDB replication by copying the database from one side of the pair to the other side and then resetting the MySql replication pointers. Are you sure you want to reset replication? (y/n) y Which side do you want to copy FROM? (A/B) [B]: B Copy the EuiDB from B to A? (y/n) y Removing the index and info files from EPAP A Replication files successfully removed from the mate server. Connecting to local DB Connecting to local DB Conpying EuiDB to mate Stopping local slave Stopping local slave Resetting mate master Resetting mate slave Resetting mate slave Resetting mate slave Starting mate slave Resetting mate slave Re

Procedure 25: Backout both MPS A and B

		\$ manageBannerInfo −1
35.	MPS B: Verify Health of MPS B	Execute 0 on MPS B to verify the health of MPS B.
36.	MPS A: Check if RTDB and PDBA databases are synchronized update this	Run the following command to check the RTDB and PDB database levels: \$ sudo dbstattool The outlook may look like: DBSTATTOOL Platform=EPAP
	Note: Skip this step for PDBonly setup.	pdb_level = 1399621904 (Fri May 9 03:51:44 2014) pdb_level = 1 rtdb_pdb_birthdate = 1399621904 (Fri May 9 03:51:44 2014) rtdb_begin_dsm_level = 1 rtdb_end_dsm_level = 1 rtdb_dsm_birthdate = 1400784912 (Thu May 22 14:55:12 2014) rtdb_dsm_status = 1 rtdb_load_state = 0 EAGLE_fmt_pdb_birthdate = 2152386348 (EAGLE format - be careful!) EAGLE_fmt_rtdb_dsm_birthdate = 1981720860 (EAGLE format - be careful!) EAGLE_fmt_rtdb_dsm_birthdate = 4003650604 (EAGLE format - be careful!) pdba_last_upd_ipaddr = 0 pdba_last_upd_timestamp = 0 (Wed Dec 31 19:00:00 1969) dbstattool_pad1 = 0 dbstattool_pad2 = 0 dbstattool_pad3 = 0 dbstattool_pad4 = 0 dbstattool_timestamp = 0 (Wed Dec 31 19:00:00 1969) rtdb_version = 4 Note down the RTDB and PDBA database levels. If they are not the same prior to backout, an RTDB reload from PDBA must be performed after backout!
37.	Reboot EAGLE Cards.	If the DB levels on EPAP and EAGLE matches and there is no alarm on EAGLE related to "RTDB reload is required", go to step 37. Reboot 1 SM card on the EAGLE and verify that it comes back to an IS-NR/Active state. If this is a Non-Provisionable EPAP, boot the rest of the EAGLE SM cards over 4 batches (booting 1/4 of the cards at a single time). If this is a Provisionable(mixed EPAP or PDBonly) EPAP, and the second MPS A on which backout has been executed, reboot the rest of the cards on both local and remote sides over 4 batches (booting 1/4 of the cards at a single time).
38.	Procedure is complete.	This procedure is complete.
39.	Note down the timestamp in log.	Run the following command: \$ date

The application should now be running at the original software release level

Procedure 26 Stop the Pdba software

Procedure 26: Stop the PDBA Software

S T E P #	Check off $()$ each step as it is c	of the PDBA software before major upgrade. completed. Boxes have been provided for this purpose under each step number. RE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE
	•	rmed, thenPerform this procedure ONLY after backout on all MPS servers in the s. Otherwise, skip this procedure until all MPS servers have been backed out.
1.	MPS A: Log in to the server as user "epapdev".	<pre><hostname> console login: epapdev Password: <password></password></hostname></pre>
2.	MPS A: Verify Health of MPS A.	If not done already, execute 0 on MPS A to verify the health of MPS A. Expect that the syscheck utility will report the 'Server Application Process Error' alarm for the fact that the PDBA software is not running. Besides the PDBA not running alarm, verify that no other abnormalities are noted. May also report following error: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
3.	MPS A: Verify that Pdba software running or not.	Run the command below to find if the pdba is running or not: \$ ps -aef grep pdba grep -v "grep" If the output contains an entry for the pdba, as shown below, then move to the next step. [epapdev@MPS A ~]\$ ps -eaf grep "pdba" grep -v "grep"

Procedure 26: Stop the PDBA Software

		epapdev 14165 11068 0 02:59 ? 00:00:07 /opt/TKLCappl/bin/pdba
4.	NADC A. T	Otherwise, skip the next step as Pdba software already stopped.
Ī.	MPS A: Turn off	Run the command below to find the current status of
	the	PDBA_REMOTE_PDBI_ALLOWED flag.
	PDBA_REMOTE_PD	Compande of Motol A wid will distance i DDDA DEMOTE DDDI ALLOWED
	BI_ALLOWED flag	[epapdev@Natal-A ~]\$ uiEdit grep -i PDBA_REMOTE_PDBI_ALLOWED
	to stop provisioning	Skip this stap if output of the above command is "DDDA DEMOTE DDDI ALLOWED"
	during upgrade.	Skip this step if output of the above command is "PDBA_REMOTE_PDBI_ALLOWED" is set to "OFF".
	Note: This step	
	must be performed	Turn off the PDBA_REMOTE_PDBI_ALLOWED flag by running below command if
	in case of upgrade	output of previous command is blank or not set to "OFF"
	and PDBA software	[epapdev@Natal-A ~]\$ uiEdit PDBA_REMOTE_PDBI_ALLOWED OFF
	needs to be	"PDBA_REMOTE_PDBI_ALLOWED" is set to "OFF"
	restarted, for this	
	change to take	
	effect.	
5.	MPS A : Stop the Pdba software.	Run the following command:
		[epapdev@Natal-A ~]\$ service Pdba stop
		~~ /etc/init.d/Pdba stop ~~
		PDBA application stopped.
6.	MPS A: Verify that	
	Pdba software	Repeat step 3.
	running or not	
7.	Procedure complete.	This procedure is complete.
8.	Note down the	Run the following command:
	timestamp in log.	\$ date

Procedure 27 Restart PDBA Software (Post-Backout and Post-Upgrade)

When upgrade is initiated on the first MPS-B, the PDBA software process is stopped on the MPS-A servers configured as **Provisionable**(mixed-EPAP or PDBonly). The PDBA software is intentionally left stopped, and so the operator performing the upgrade must restart the PDBA software after all MPS servers in a set of EPAP systems have been upgraded.

WARNING: If a backout of the MPS A and B units is conducted sometime after an upgrade has successfully completed and after Provisioning has been re-enabled, then the only

Upgrade/Installation Guide

228 of 450 June 2025 method of PDB restoration is from backup file. In this case, any new data provisioned since the successful completion of the upgrade will be lost and will need to be re-provisioned.

Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade

	This procedure restarts the PDBA software after upgrade of all associated MPS systems has been completed. Check off (1) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE. Dackout has been performed, thenPerform this procedure ONLY after backout on all MPS servers in the tire set of EPAP systems. Otherwise, skip this procedure until all MPS servers have been backed out.	
1.	Local MPS A: Log in to the server as user "epapdev".	<pre><hostname> console login: epapdev Password: <password></password></hostname></pre>
2.	Local MPS A: Verify Health of MPS A.	If not done already, execute 0 on MPS A to verify the health of MPS A. Expect that the syscheck utility will report the 'Server Application Process Error' alarm for the fact that the PDBA software is not running. Besides the PDBA not running alarm, verify that no other abnormalities are noted. May also report following error: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
3.	MPS A: Turn on the PDBA_REMOTE_PD BI_ALLOWED flag to enable PDB to accept updates from remote PDBI. Note: This step must be performed in case of upgrade and PDBA software	Run the command below to find the current status of PDBA_REMOTE_PDBI_ALLOWED flag. [epapdev@Natal-A ~]\$ uiEdit grep -i PDBA_REMOTE_PDBI_ALLOWED Turn on the PDBA_REMOTE_PDBI_ALLOWED flag. Skip this step if output of the above command is "PDBA_REMOTE_PDBI_ALLOWED" is set to "ON" or no output is displayed [epapdev@Natal-A ~]\$ uiEdit PDBA_REMOTE_PDBI_ALLOWED ON "PDBA_REMOTE_PDBI_ALLOWED" is set to "ON"

Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade

	needs to be restarted, for this change to take effect.	
4.	Move back the pdba binary from pdba_stopped to pdba	[root@Quito-a bin]# mv pdba_stopped pdba [root@Quito-a bin]#
5.	Local MPS A: Restart the PDBA software.	Run the command below to find if the pdba is running or not: \$ ps -aef grep pdba grep -v "grep"
	On the menu, click PDBA->Process	If the output contains an entry for the pdba, as shown below, then skip to the next step.
	Control->Start PDBA software	[epapdev@MPS A ~]\$ ps -aef grep pdba grep -v "grep" epapdev 23890 10248 0 Apr07 ? 00:01:18 /opt/TKLCappl/bin/pdba
		Otherwise, Log in to EPAP GUI by uiadmin user and start PDBA software.
		A
		Are you sure you want to start the PDBA software? Start PDBA Software
		Tue June 20 2017 06:42:43 EDT Copyright © 2000, 2017, Oracle and/or its affiliates. All rights reserved.
6.	Local MPS A: Verify PDBA is running.	Execute 0 on MPS A to verify the health of MPS A Verify that syscheck does <i>not</i> show that the PDBA is <i>not</i> running. May also report following error: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
7.	Remote MPS A: Log in to the server as user "epapdev".	<pre><hostname> console login: epapdev Password: <password></password></hostname></pre>
8.	Remote MPS A: Verify Health of MPS A.	Execute 0 on MPS A to verify the health of MPS A. Expect that the syscheck utility will alarm the fact that the PDBA software is not running. This will appear as a "5000000000000000 Server Application

Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade

		Process Error" alarm. Besides the PDBA not running alarm, verify that no other abnormalities are noted. May also report following error: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
9.	Remote MPS A: Restart the PDBA software.	Run the command below to find if the pdba is running or not: \$ ps -aef grep pdba grep -v "grep"
	On the menu, click PDBA->Process	If the output contains an entry for the pdba, as shown below, then skip to the next step.
	Control->Start PDBA software	epapdev 23890 10248 0 Apr07 ? 00:01:18 /opt/TKLCappl/bin/pdba
		Otherwise, Log in to EPAP GUI by uiadmin user and start PDBA software.
		A Start
		Are you sure you want to start the PDBA software?
		Start PDBA Software Tue June 20 2017 06:42:43 EDT
		Copyright © 2000, 2017, Oracle and/or its affiliates. All rights reserved.
10.	Remote MPS A: Verify PDBA is	Execute 0 on MPS A to verify the health of MPS A. Verify that syscheck does <i>not</i> show that the PDBA is <i>not</i> running.
	running.	May also report following error: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
		* defaultroute: FAILURE:: ping6 return non-zero code * defaultroute: FAILURE:: MAJOR::300000000000000000000000000000000000
		Route Network Error
		* defaultroute: FAILURE:: The IPv6 default route at fe80::f64e:5ff:fe49:9b7f cannot be pinged
11.	Procedure complete.	This procedure is complete.
12.	Note down the	Run the following command:
	timestamp in log.	

Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade

\$ date

THIS COMPLETES THE BACKOUT


APPENDIX A GENERIC PROCEDURES

Perform System Health Check

Appendix A.1 Perform System Health Check

S	This procedure perfo	rms a system health check on any MPS server.
T E	Check off ($$) each step a	as it is completed. Boxes have been provided for this purpose under each step number.
P #	IF THIS PROCEDURE I	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .
1.	Log in as the admusr user.	<pre><hostname> console login: admusr Password: <password></password></hostname></pre>
2.	Execute the platcfg menu.	\$ sudo su - platcfg
3.	Select the Diagnostics submenu.	The platefg Main Menu appears. On the Main Menu, select Diagnostics and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Security Remote Consoles Network Configuration Exit
4.	Select the Online Diagnostics submenu.	Select the Online Diagnostics submenu and press [ENTER]. Diagnostics Menu Online Diagnostics Network Diagnostics View Upgrade Logs Alarm Manager Platform Revision Exit •
5.	Select the Non- Verbose option.	Select the Non-Verbose option and press [ENTER].

Appendix A.1 Perform System Health Check



Appendix A.1 Perform System Health Check

		* defaultroute: FAILURE:: MAJOR::300000000000000000000000000000000000
		Network Error * defaultroute: FAILURE:: The IPv6 default route at fe80::f64e:5ff:fe49:9b7f cannot be pinged
8.	Constitution	If any other failures were detected by System Check, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section.
, 	Server clean-up to	Run the following command:
	create space.	\$ df -h /var/TKLC
		The output may look like:
		[root@Quito-a core]# df -h /var/TKLC Filesystem Size Used Avail
		Use% Mounted on
		/dev/mapper/vgroot-plat_var_tklc 7.8G 2.3G 5.1G 31% /var/TKLC
		Nowify that there is at least COOM in the Avail solvery. If not close we file wat i
		Verify that there is at least 600M in the Avail column. If not, clean up files until there is space available.
		CAUTION: Make sure you know what files you can remove safely before cleaning up. It is recommended that you only clean up files in the /var/TKLC/upgrade directory as this is a platform owned directory that should only contain ISO images. This directory should not be expected to contain images for any length of time as they can get purged.
		Also, Run the following command to check space in '/lib/module' directory.
		\$ df -h /lib/modules
		[root@Quito-a core]# df -h /lib/modules Filesystem Size Used Avail Use% Mounted on
		/dev/mapper/vgroot-plat_usr 7.8G 4.7G 2.8G 64%
		[root@Quito-a core]#
		Verify that the Use% column does not exceed the value 80%.
9.	Procedure complete.	Return to the procedure that you came here from.
10.	Note down the	Run the following command:
	timestamp in log.	\$ date

Validate Upgrade Media


This procedure is used to execute a validation of the Upgrade Media (typically an ISO image) separately from executing an upgrade. The upgrade process automatically validates the upgrade media. However, sometime the user may wish to perform just a validation before proceeding with upgrade, thus the reason for this separate process.

Validation could be performed on MPS A or B, however, this procedure specifies MPS X for simplicity.


Appendix A.2 Validate the Upgrade Media

S T E P #	This procedure provides instructions to perform a validation of the upgrade media on the MPS X server. This procedure assumes that the E5-APP-B card IPM procedure has been executed and the user has an EPAP Upgrade ISO image available. Check off (1) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE	
	ASSISTANCE.	
1.	MPS X: If necessary, log in to the server as the user "admusr".	If not already logged in to the MPS server, then log in as user "admusr". <hostname> console login: admusr password: <password></password></hostname>
2.	MPS X: Execute the platcfg menu.	\$ sudo su - platcfg
3.	MPS X: Select the Maintenance submenu.	The platefg Main Menu, select Maintenance and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Security Remote Consoles Network Configuration Exit In case of Dual Image Upgrade, Select the Dual Image upgrade menu and press [ENTER]

Appendix A.2 Validate the Upgrade Media



Appendix A.2 Validate the Upgrade Media




Appendix A.2 Validate the Upgrade Media


7.	MPS X: View the Validation results.	The results of the validation will be displayed, similar to the example below. Press the "enter" key to continue.
		Validating cdrom *********************************
8.	MPS X: Select the	PRESS ANY KEY TO RETURN TO THE PLATCEG MENU.
°.	Exit option.	Select the Exit option, and keep selecting the Exit option, until you reach the command line prompt or you return to another menu that you wish to use.
		Choose Upgrade Media Menu EPAP-17.0.0.3.0_170.19.0-x86_64.iso - 17.0.0.3.0_170.19.0 Exit
9.	MPS X: Procedure complete.	Media Validation is complete. Return to the procedure that you came here from.
10.	Note down the	Run the following command:
	timestamp in log.	\$ date

System Configuration Backup

Appendix A.3 System Configuration Backup



Appendix A.3 System Configuration Backup



Appendix A.3 System Configuration Backup

		Select the Exit option, and keep selecting the Exit option, until you reach the
		command line prompt.
9.	MPS X: Transfer	The backup file is in the /var/TKLC/bkp directory and will have a name like
	the backup file.	<pre><hostname>-plat-app-[date][time].tgz</hostname></pre>
		Run the following command to view the backup file: \$ 1s -1 /var/TKLC/bkp
		[admusr@Recife-a bkp] \$ ls -1 /var/TKLC/bkp/
		total 5836 -rw-rw 1 root sys 5972128 Sep 11 09:04 Recife-a-plat-app-201809110904.tgz
10.	MPS X: Transfer	Using SFTP (secure-FTP), transfer the ISO to a remote, customer-provided
	file to remote	computer. Enter "yes" when prompted if you want to continue to connect.
	machine.	
		\$ cd /var/TKLC/bkp
		\$ sftp <ip address="" computer="" of="" remote=""></ip>
		Connecting to <ip address="" computer="" of="" remote=""></ip>
		The authenticity of host ' <ip address="" computer="" of="" remote="">' can't be established.</ip>
		DSA key fingerprint is
		58:a5:7e:1b:ca:fd:1d:fa:99:f2:01:16:79:d8:b4:24.
		Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added <ip address="" computer="" of="" remote="">' (DSA) to</ip>
		the list of known hosts.
		root@ <ip address="" computer="" of="" remote="">'s password:</ip>
		sftp> cd <target directory=""></target>
		sftp> put <hostname>-plat-app-[date][time].tgz Uploading <hostname>-plat-app-[date][time].tgz to <hostname>-plat-</hostname></hostname></hostname>
		app-[date][time].tgz
		sftp> bye
		If no customer provided remote computer for backups exist, transfer the backup
		file to the mate using the following command:
		\$ sudo chmod 667 /var/TKLC/bkp/ <tgz file=""></tgz>
		\$ su - epapdev
11.	Drocodura	\$ scp /var/TKLC/bkp/ <tgz file=""> epapdev@remoteIP:<remote ip="" path=""></remote></tgz>
	Procedure complete.	Return to the procedure that you came here from.
12.	Note down the	Run the following command:
	timestamp in log.	
	thriestamp in log.	\$ date

Execute parse9Dig script

Appendix A.4 Execute parse9Dig script

S This procedure performs the Execution of parse9Dig script.

T			
E	Check off (√) each step as it i	s completed. Boxes have been provided for this purpose under each step number.	
P	THE STATE OF THE COURT OF THE C		
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .		
1.	MPS A: Log in as	If not already logged in, then login at MPS A:	
	the user	<pre><hostname> console login: epapdev</hostname></pre>	
	"epapdev" on	password: <password></password>	
	standalone PDB.		
2.			
2.	MPS A: Check if	Check whether "parse9Dig" script is present on setup or not.	
	"parse9Dig" script		
	is present on	Execute following command:	
	setup.	\$ Is -Irt /usr/TKLC/epap/config/parse9Dig	
		<pre>[epapdev@Natal-a-PDBonly ~]\$ 1s -lrt /usr/TKLC/epap/config/parse9Dig</pre>	
		-rwxr-xr-x 1 epapdev epap 12162 Oct 10 16:23	
		/usr/TKLC/epap/config/parse9Dig	
		If output is same as above then proceed to step 4 otherwise proceed with	
		following step.	
3.	MPS A: Execute		
	the "parse9Dig"	Note : Stop the Pdba software before executing this script.	
	script on	Run the "parse9Dig" script and examine the result.	
	standalone PDB.	Run the parsesbig script and examine the result.	
		\$/usr/TKLC/epap/config/parse9Dig all u	
		[epapdev@Osorna-1B-PDBonly config]\$ /usr/TKLC/epap/config/parse9Dig all u	
		This utility will retrieve all digits for DB and parse them into 9Dig entries.	

		Parsing DN digits into 9digits	
		INFO: DN 9dig count 2.	
		REPLACE INTO dn9dig VALUES (UNHEX("05000000000"),1), (UNHEX("06000000000"),1);	
		Parsing IMSI digits into 9digits	
		INFO: IMSI 9dig count: 9.	
		REPLACE INTO imsi9dig VALUES (UNHEX("0D001234567"),3), (UNHEX("06000000000"),1), (UNHEX("070000000 09"),1), (UNHEX("0800000044"),1), (UNHEX("08000000023"),2), (UNHEX("05000000000"),1), (UNHEX("0800000000000000000000000000000000000	
		Parsing IMEI digits into 9digits	
		INFO: IMEI 9dig count: 1.	
		REPLACE INTO imei9dig VALUES (UNHEX("0E012345678"),2);	
		Utility End Time: 06/13/18-21:24:31 _	

4.	MPS A: Procedure	This procedure is complete.
$ \sqcup$	is complete.	
5.	Note down the	Run the following command:
	timestamp in log.	\$ date

Increase rtVolume size for Non-prov

Appendix A.5 Increase rtVolume size for Non-prov

S T	This procedure incre	ease rtVolume size for Non-prov.	
E	Check off ($$) each step a	s it is completed. Boxes have been provided for this purpose under each step number.	
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .		
	e: Skip this procedure for	mixed EPAP and standalone EPAP.	
1.	MPS A: Log in to the server.	If not already logged in, then login at MPS A: <hostname> console login: epapdev Password: <password></password></hostname>	
2.	MPS A: Execute "rtdir_300gb" script for E5-APP-B cards with 300GB drive modules.	If EPAP is running on an E5-APP-B card with 300GB drive modules, perform this step. If instead, EPAP is running on an E5-APP-B card with 480GB drive modules, skip this step and go to step 3. Download the rtdir_300gb script zip file from My Oracle Support(MOS) (https://support.oracle.com). The zip file is available on MOS under Oracle	
		Communications EAGLE Application Processor 16.3.0.0.0. Place the zip file in the /tmp directory. Unzip the file: \$ unzip <zip file="" from="" mos="" name=""> \$ cat Readme.txt Follow the directions in the Readme.txt file.</zip>	
		Execute the following script: \$ sudo /usr/TKLC/epap/bin/rtdir_300gb	
		Warning: This utility would increase rtVolume for non-prov setup and this action is irreversible. Are you sure you want to continue?[Yes/No]: Yes	
		INFO: Increasing rt volume size for Non-provisionable EPAP. Please wait INFO: db space increased on 'A'. INFO: Stopping Epap, mysqlapp and mysqlpdb services Done. INFO: Starting Epap, mysqlapp and mysqlpdb services	

Appendix A.5 Increase rtVolume size for Non-prov

		Done. INFO: Successfully configured Non-provisionable EPAP.
		Following error related to MyISAM table shall be observed on CLI while executing rtdir script:
		myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/dolumns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' e2fsck 1.43-wIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on lvreduce invocation. Parent PID 25006: sh File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID 25350: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25359: sh File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID 25410: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25410: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh File descriptor 7 (socket:[102707]) leaked on lvextend i
3.	MPS A: Execute "rtdir" script for E5- APP-B cards with	If EPAP is running on an E5-APP-B card with 300GB drive modules, do notperform this step. Instead, execute step 2. If EPAP is running on an E5-APP-B card with 480GB drive modules, perform this step.
	480GB drive modules.	Execute the following script: \$ sudo /usr/TKLC/epap/bin/rtdir
		Warning: This utility would increase rtVolume for non-prov setup and this action is irreversible. Are you sure you want to continue?[Yes/No]: Yes
		INFO: Increasing rt volume size for Non-provisionable EPAP. Please wait INFO: db space increased on 'A'. INFO: Stopping Epap, mysqlapp and mysqlpdb services Done. INFO: Starting Epap, mysqlapp and mysqlpdb services Done.

Appendix A.5 Increase rtVolume size for Non-prov

		INFO: Successfully configured Non-provisionable EPAP.
		Following error related to MyISAM table shall be observed on CLI while
		executing rtdir script:
		CACCULING Fruit Script.
		myisamchk: error: 140 when opening MyISAM-table
		'/var/TKLC/epap/db/mysql/columns priv.MYI'
		myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI'
		myisamchk: error: 140 when opening MyISAM-table
		'/var/TKLC/epap/db/pdb/mysql/db.MYI' e2fsck 1.43-WIP (20-Jun-2013)
		File descriptor 7 (socket:[102707]) leaked on lvreduce invocation. Parent PID
		25006: sh resize2fs 1.43-WIP (20-Jun-2013)
		File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID
		25350: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID
		25359: sh
		resize2fs 1.43-WIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID
		25410: sh
		File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh
		myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
		/var/TKLC/epap/db/appconfig/Euibb/alarminfo.MYI myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
		'/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' myisamchk: error: 140 when opening MyISAM-table
		'/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		FIPS integrity verification test failed.
		FIPS integrity verification test failed.
		.WARNING: Reducing active logical volume to 8.00 GiB.
		THIS MAY DESTROY YOUR DATA (filesystem etc.).
4.	MPS A: Verify	[epapdev@Arica-1A ~]\$ df -h
	rtVolume size using	Filesystem Size Used Avail Use% Mounted on
	command "df -h".	/dev/mapper/vgroot-plat root
		976M 288M 637M 32% /
		tmpfs 3.9G 0 3.9G 0% /dev/shm
		/dev/md1 244M 40M 192M 18% /boot
		/dev/mapper/vgroot-plat_tmp
		976M 2.0M 923M 1% /tmp
		/dev/mapper/vgroot-plat_usr
		3.9G 2.5G 1.2G 68% /usr
		/dev/mapper/vgroot-plat_var 976M 206M 720M 23% /var
		/dev/mapper/vgroot-plat_var_tklc
		3.9G 1.8G 1.9G 49% /var/TKLC
		/dev/mapper/vgroot-db
		5.8G 4.3G 1.2G 79% /var/TKLC/epap/db
		/dev/mapper/vgroot-free
		320G 5.3G 298G 2% /var/TKLC/epap/free
		/dev/mapper/vgroot-logs
		20G 89M 19G 1% /var/TKLC/epap/logs
		/dev/mapper/vgroot-rt
		82G 3.3G 75G 5% /var/TKLC/epap/rt
		IEDEDGETMATICE_IA ~IV

Appendix A.5 Increase rtVolume size for Non-prov

		Vgroot-rt size should be greater than 80G.	
5.	MPS B: Execute "rtdir" or "rtdir_300gb" script.	After successfully converted rtVolume size on MPS A, repeat steps 2, 3, and 4 on MPS B.	
6.	MPS B: Procedure completed.	This procedure is completed.	
7.	Note down the timestamp in log.	Run the following command: \$ date	

PDB Backup

S T E P #	This procedure performs a PDB backup on the EPAP server configured as a Provisionable (mixed-EPAP or PDBonly) node. This procedure should only be performed on the active PDBA. Note: Only one PDB Backup is allowed, to be stored. In case another backup is required, workaround is to setup the remote transfer of the existing pdb backup and then delete it. Check off (1) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.	
1.	MPS A: Log in to the server.	If not already logged in, then log in to MPS A: <hostname> console login: epapdev Password: <password></password></hostname>
2.	Run syscheck.	Run the following command: \$ syscheck Note: syscheck may report following error which can be ignored: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
3.	Verify the System Check executed successfully.	Running modules in class disk OK

	In particular, verify	Running modules in class net
	that the PDBA	OK Running modules in class proc
	process is running	ОК
	by noting that	Running modules in class system OK
	syscheck does not	Running modules in class hardware OK
	generate an alarm against the PDBA process.	The log is available at:>/var/TKLC/log/syscheck/fail_log
		If the syscheck utility reports the "50000000000000 – Server Application
		Process Error" alarm, restart the PDBA and execute syscheck again. The above
		alarm should be removed. If the above alarm is not removed, contact My Oracle
		Support following the instructions on the front page or the instructions in the My Oracle Support section
4.		iviy Oracle Support Section
	System Check Verifies that PDBA is running.	If the syscheck does not report any errors, proceed to the next step. Otherwise, if any other failures were detected by System Check, contact My Oracle Support following the instructions on the front page or the instructions in the My Oracle Support section. Note: syscheck may report following error which can be ignored:
		* defaultroute: FAILURE:: MINOR::500000000040000 Platform Health Check
		Failure
		* defaultroute: FAILURE:: ping6 return non-zero code
		* defaultroute: FAILURE:: MAJOR::300000000000000000000000000000000000
		Default Route Network Error
		* defaultroute: FAILURE:: The IPv6 default route at fe80::f64e:5ff:fe49:9b7f cannot be pinged
5.	Log in to epapconfig.	\$ su - admusr
	8 to obapoo8.	\$ sudo su — epapconfig
		Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.
6.	Main menu is	Menu for mixed-EPAP:
-	displayed. Select	/EPAP Configuration Menu\ /\
	Platform Menu.	1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu

10 SNMP Configuration 11 Configure Alarm Feed 12 Configure Query Server	
11 Configure Alarm Feed 	
12 Configure Query Server	
13 Configure Query Server Alarm Feed	
14 Configure SNMP Agent Community	
15 Mate Disaster Recovery	
e Exit	
Enter Choice: 6	
7. Platform menu is displayed. Select PDB Backup. Menu for standard EPAP designation: /EPAP Platform Menu-\	
1 Initiate Upgrade	
2 Reboot MPS	
\ \/	
Enter Choice: 5	
Menu for PDB-only designation:	
/EPAP Platform Menu-\	
1 Initiate Upgrade	
2 Reboot MPS	
3 MySQL Backup	
4 PDB Backup	
\/	
Enter Choice: 4	
8. Menu will prompt for a "yes" to continue. Enter a Y. Are you sure you want to backup the PDB to /var/TKLC/epap/free/pdbBackup_DBExpPdbOnly_201806130 ate_20180613072847GMT_DBLevel_6507_v7.50.bkp.tar.gz?	

9.	While the backup is begin performed, the following output will be displayed to the screen. Note: Only one PDB Backup is allowed, to be stored.	Successfully started backup of PDB. Status will be displayed on the GUI banner. Press return to continue Note: If following error is displayed instead of success, then you need to delete all pdbBackup from free directory in order to schedule new pdbBackup. E1058: An internal error in the EPAP occurred: pdbBackup already exists in free directory. Press return to continue
10.	Exit this menu and return to the login prompt.	Note: If this menu is not exited properly, then the SSH login with root shall remain enabled.
11.	Monitor GUI banner.	Monitor the GUI banner. When the backup has completed successfully, continue to the next step.
12.	Use SFTP to transfer the backup file to a remote customer provided computer.	Using SFTP (secure-FTP), transfer the PDB backup file to a remote, customer- provided computer. Enter "yes" when prompted if you want to continue to connect. \$ cd /var/TKLC/epap/free \$ sftp <ip address="" computer="" of="" remote=""> Connecting to <ip address="" computer="" of="" remote=""> The authenticity of host '<ip address="" computer="" of="" remote="">' can't be established. DSA key fingerprint is 58:a5:7e:lb:ca:fd:ld:fa:99:f2:01:16:79:d8:b4:24. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added <ip address="" computer="" of="" remote="">' (DSA) to the list of known hosts. root@<ip address="" computer="" of="" remote="">'s password: sftp> cd <target directory=""> sftp> put pdbBackup_<hostname>_20140530151806_DBBirthdate_ 20140530144717GMT_DBLevel_<dblevel>.bkp.tar.gz Uploading pdbBackup_<hostname>_20140530151806_DBBirthdate_ 20140530144717GMT_DBLevel_<dblevel>.bkp.tar.gz to pdbBackup_<hostname>> 20140530151806_DBBirthdate_20140530144717GMT_DBLevel>.bkp .tar.gz sftp> bye If no customer provided remote computer for backups exist, transfer the backup file to the mate using the following command</hostname></dblevel></hostname></dblevel></hostname></target></ip></ip></ip></ip></ip>

		\$ su - epapdev
		<pre>\$ scp /var/TKLC/epap/free/<pdb backup="" file=""> epapdev@mate:/var/TKLC/epap/free/</pdb></pre>
13.	Procedure	Return to the procedure that you came here from.
ΙЦ	complete.	
14.	Note down the	Run the following command:
	timestamp in log.	\$ date

RTDB Backup

Note: Skip this procedure for PDBonly setup.

Appendix A.7 RTDB Backup

S	This procedure performs an RTDB backup on the EPAP server.	
T		
Ε	Check off (√) each step a	as it is completed. Boxes have been provided for this purpose under each step number.
\mathbf{P}	(")	r
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .	
π 1.		
	MPS: Log in to the	<hostname> console login: admusr</hostname>
ш	server.	Password: <password></password>
		Tabbier at spabbier as
2.	Enter the enanconfig	Run the following command:
	menu.	Than the following communa.
_	menu.	f and an anamantin
		\$ sudo su - epapconfig
		Warning, Smartmatch is experimental at
		Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.
		, ac.,,,,
3.	Main menu is	
	displayed. Select	
		/EPAP Configuration Menu\ /\
	Platform Menu.	
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu

Appendix A.7 RTDB Backup

	1	
		 10 Configure Alarm Feed
		12 Mate Disaster Recovery
		 e Exit
4.	Platform menu is	Enter Choice: 6
	displayed. Select	/EPAP Platform Menu-\ /\
	RTDB Backup.	1 Initiate Upgrade
		2 Reboot MPS
		3 MySQL Backup
		4 RTDB Backup
		5 PDB Backup
		e Exit
		Enter Choice: 4
5.	The Application	If the EPAP application software is running, you will be prompted to stop
	software must be	the software for the RTDB backup. Select with a "Y".
	stopped.	EPAP software is running. Stop it? [N]: Y
6.	Menu will prompt for a "yes" to	Are you sure you want to backup the PDB to /var/TKLC/epap/free/
	continue. Enter a Y .	rtdbBackup_Recife-A_20140530151806.tar.gz? [N]:
7.	While the backup is	Successfully started backup of RTDB.
	begin performed,	Status will be displayed on the GUI banner.
	the following output will be	Press return to continue
	displayed to the	
	screen.	
8.	Exit this menu and	Enter Choice: e
_	return to the login prompt. Continue	Enter Choice: e
	exiting until you get	Note: If this menu is not exited properly, then the SSH login with root shall remain enabled.

Appendix A.7 RTDB Backup

	to the login	
	prompt.	
9.	Monitor GUI	Monitor the GUI banner. When the backup has completed successfully,
	banner.	continue to the next step.
		Note: On performing RTDB backup following two error were observed in cgi.dbg file although rtdb
		backup is getting completed
		ERROR: Invalid numbr of argument. Number of argument must be 3 to update RTDB backup DB level properly in pdb.
		Error: Couldn't able to run the script on Remote Prov with IP (0.0.0.0) having procRc = 255, signal = 0, core = 0.
10.	Restart the EPAP	Postart the EDAD application software
	Software.	Restart the EPAP application software.
	Software.	\$ sudo /etc/init.d/Epap start
11.	Use SFTP to transfer the backup file to a remote customer provided	Using SFTP (secure-FTP), transfer the RTDB backup file to a remote, customer-provided computer. Enter "yes" when prompted if you want to continue to connect.
	computer.	\$ cd /var/TKLC/epap/free
		\$ sftp <ip address="" computer="" of="" remote=""></ip>
		Connecting to <ip address="" computer="" of="" remote=""></ip>
		The authenticity of host ' <ip address="" computer="" of="" remote="">' can't be established.</ip>
		DSA key fingerprint is
		58:a5:7e:1b:ca:fd:1d:fa:99:f2:01:16:79:d8:b4:24.
		Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added ' <ip address="" computer="" of="" remote="">' (DSA) to the list of known hosts.</ip>
		root@ <ip address="" computer="" of="" remote="">'s password:</ip>
		sftp> cd <target directory=""></target>
		sftp> put rtdbBackup_ <hostname>_20140530151806.tar.gz Uploading rtdbBackup_<hostname>_20140530151806.tar.gz to rtdbBackup_<hostname>_20140530151806.tar.gz sftp> bye</hostname></hostname></hostname>
		If no customer provided remote computer for backups exist, transfer the
		backup file to the mate using the following command
		\$ su - epapdev
		<pre>\$ scp /var/TKLC/epap/free/<rtdb backup="" file=""> epapdev@mate:/var/TKLC/epap/free</rtdb></pre>

Appendix A.7 RTDB Backup

12.	Procedure complete.	Return to the procedure that you came here from.
13.	Note down the timestamp in log.	Run the following command: \$ date

EuiDB Backup

Appendix A.8 EuiDB Backup

S	This procedure performs a backup of the User database on the MPS server.				
T E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.				
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .				
1.	MPS A: Log in to the server as user "admusr".		<pre><hostname> console login: admusr Password: <password></password></hostname></pre>		
2.	Enter the	Run th	e following command:		
П	epapconfig menu.				
		\$ suac	o su – epapconfig		
		Warnin	ng: Smartmatch is experimental at TKLC/plat/lib/Security/User.pm line S	204	
		/usi/	rklc/prat/frb/security/oser.pm frme s	704 .	
3.	Master menu is		-EPAP Configuration Menu\		
	displayed. Select Platform Menu.	1 1	Display Configuration	·	
		2	Configure Network Interfaces Menu		
		i 3	 Set Time Zone		
		4	Exchange Secure Shell Keys		
		5	Change Password 		
		i 6	Platform Menu		
		7	Configure NTP Server		
		8	PDB Configuration Menu		
			Security		
		1 10	SNMP Configuration		
			Configure Alarm Feed		

Appendix A.8 EuiDB Backup

		 12 Configure Query Server		
		13 Configure Query Server Alarm Feed		
		14 Configure SNMP Agent Community		
		 15 Mate Disaster Recovery		
		e Exit		
		Enter Choice: 6		
4.	Platform menu is	Enter Choice. 0		
	displayed. Select	/EPAP Platform Menu-\ /\		
	MySQL Backup.	1 Initiate Upgrade		
		2 Reboot MPS		
		4 RTDB Backup		
		 5 PDB Backup		
		\/		
		Enter Choice: 3		
5.	You will then be	Are you sure you want to backup the MySQL database on MPS A? [N]:		
	prompted to verify	The for sale you want to backup the Myogh database on MIS A: [N].		
	that you want to			
	backup the MySQL			
	Database.			
6.	Type "Y" and press	Press Y		
7.	enter.			
). 	While the backup is begin	NPDB Backed up Successfully to /var/TKLC/appl/free/ <file name=""></file>		
	performed, the			
	following output			
	will be displayed to			
	the screen.			
8.	Exit this menu and	Enter Choice: e		
	return to the Unix			
	login prompt.	Note: If this menu is not exited properly, then the SSH login with root shall remain		
	Continue exiting	enabled.		
	until you get to the			
	Unix login prompt.			

Appendix A.8 EuiDB Backup


9.	Use SFTP to transfer the backup file to a remote customer provided computer.	Using SFTP (secure-FTP), transfer the NPDB backup file to a remote, customer- provided computer. Enter "yes" when prompted if you want to continue to connect. \$ cd /var/TKLC/epap/free \$ sftp <ip address="" computer="" of="" remote=""> Connecting to <ip address="" computer="" of="" remote=""> The authenticity of host '<ip address="" computer="" of="" remote="">' can't be established. DSA key fingerprint is 58:a5:7e:lb:ca:fd:ld:fa:99:f2:01:16:79:d8:b4:24. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added '<ip address="" computer="" of="" remote="">' (DSA) to the list of known hosts. root@<ip address="" computer="" of="" remote="">'s password: sftp> cd <target directory=""> sftp> put npdbBackup_<hostname>_20140530151806.sql.gz Uploading npdbBackup_<hostname>_20140530151806.sql.gz sftp> bye If no customer provided remote computer for backups exist, transfer the backup file to the mate using the following command \$ su - epapdev \$ scp /var/TKLC/epap/free/<npdb backup="" file=""> epapdev @mate:/var/TKLC/epap/free</npdb></hostname></hostname></target></ip></ip></ip></ip></ip>
10.	Procedure complete.	Return to the procedure that you came here from.
11.	Note down the timestamp in log.	Run the following command: \$ date

RTDB Reload from PDBA

Appendix A.9 RTDB Reload from PDBA

S	This procedure provides instructions to reload RTDB from PDBA.		
T			
E	Check off $()$ each step as it is completed. Boxes have been provided for this purpose under each step number.		
P			
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.		
1.	EPAP A: Log in to		
	the web GUI as user		
	"uiadmin".		

Appendix A.9 RTDB Reload from PDBA



Appendix A.9 RTDB Reload from PDBA

		A Reload RTDB from PDBA	
	Observe the "SUCCESS" Status.	SUCCESS: The reload has been initiated. You can check its progress by viewing the RTDB status. Also, an informational message has been added to the Banner. The message will be cleared when the reload is complete.	
4.	EPAP A: Wait for completion. Observe the GUI informational message and wait for the RTDB Reload completion message before proceeding.		
5.	EPAP A: Remove EPAP from Force Standby Mode. Expand the "Maintenance" Folder. Expand the "Force Standby" Folder. Select the "Change Status" link. Click on "Remove STANDBY Restriction" Button.	A Change Forced Standby Status **INFO: The STANDBY restriction is currently in place for EPAP A. **CAUTION: This action will allow this EPAP to resume updating the RTDB. **Remove STANDBY Restriction* **Change Forced Standby Status* **SUCCESS: The STANDBY restriction is now OFF.	

Appendix A.9 RTDB Reload from PDBA


6.	EPAP A: Verify RTDB status.	Α			View RTDB Status	
	Expand the "RTDB" Folder. Select the "View RTDB Status" link.	DB Status: RTDB Level: PDB Level Counts: Tables: DB Size: Reload:	IMSIs=0, Di	Ns=0, DN Blocks =0, IMEI=0, ASI	Yes 05/22/2014 14:57:49 GMT 05/09/2014 07:51:44 GMT s=0, NEs=1, ASDs=0	
			d from PDI egged in cg	3A completed	d banner message will not be o letetion of RTDB Reload from P vnc is observed	
7.	Procedure complete.	Return to the prod	cedure tha	t you came h	ere from.	
8.	Note down the timestamp in log.	Run the following \$ date	command	:		

RTDB Restore

Appendix A.10 RTDB Restore

S	This procedure provide	This procedure provides instructions to restore RTDB from a backup file.				
T E	Check off (√) each step as i	Check off $()$ each step as it is completed. Boxes have been provided for this purpose under each step number.				
P #	` •	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.				
1.	EPAP A: Log in to the web GUI as user "uiadmin".					

Appendix A.10 RTDB Restore



Appendix A.10 RTDB Restore

	Click "Confirm RTDB Restore"	NOTE: Caution message regarding "incompatible file" is displayed in above
	Button	snapshot as the backup file is taken on RTDB version 4 and is being restored on
		RTDB version 5.
		Restore successfully started:
		A Restore the RTDB
		SUCCESS: Successfully started restore of RTDB from file rtdbBackup_Floater- 03_20170510021047_v4.72.bkp.tar.gz . Restore status will be displayed on Banner message window.
		Wed June 13 2018 16:38:09 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
4.	EPAP A: Make EPAP down.	Conferming that Restore RTDB in progress:
	An IM alarm should be observed with	A Informational Messages
	informational message on EPAP	Informational Messages Restore RTDB in progress
	GUI confirming that restore RTDB	Tobloto ICIDD al progress
	is in progress.	Wed June 13 2018 16:39:09 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
		Copyright @ 2000, 2010, Oracle and/or its alimates. All rights reserved.
	An IM alarm	
	should be observed with	
	should be observed with informational	
	should be observed with informational message on EPAP GUI confirming	
	should be observed with informational message on EPAP GUI confirming that restore RTDB completed	
	should be observed with informational message on EPAP GUI confirming that restore RTDB	

Appendix A.10 RTDB Restore

		Conferming that Restore RTDB is completed successfully:		
		A Informational Messages		
	Click "Confirm RTDB Restore"	Informational Messages Restore RTDB completed successfully		
	Button	Fri June 15 2018 00:30:27 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.		
5.	EPAP A: RTDB converter is started.	This step is performed only to support EAGLE release 46.7.0.0.0 (On the setup where DB Architecture is eXtreme):		
	An IM alarm should be observed with informational message on EPAP GUI confirming that RTDB Conversion in progress.	Informational Messages Informational Messages RTDB Conversion in progress Wed June 13 2018 16:55:42 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.		
	An IM alarm should be observed with informational message on EPAP GUI confirming			

Appendix A.10 RTDB Restore


	that RTDB Conversion completed	A Informational Messages
	successfully.	Informational Messages RTDB conversion completed successfully Fri June 15 2018 00:37:57 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
		Note: On performing RTDB Restore following two error were observed in cgi.dbg file although rtdb restore is getting completed ERROR: Invalid numbr of argument. Number of argument must be 3 to update RTDB backup DB
		level properly in pdb. Error: Couldn't able to run the script on Remote Prov with IP (0.0.0.0) having procRc = 255, signal = 0, core = 0.
6.	Procedure complete.	Return to the procedure that you came here from.
7.	Note down the timestamp in log.	Run the following command: \$ date

RTDB Reload from Remote

Appendix A.11 RTDB Reload from Remote

S	This procedure provides instructions to restore RTDB from a backup file.		
T			
E	Check off $(\sqrt{1})$ each step as it is completed. Boxes have been provided for this purpose under each step number.		
P			
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.		
1.	EPAP B: Log in to the web GUI as user		
$ \sqcup $	the web GUI as user		
	"uiadmin".		

Appendix A.11 RTDB Reload from Remote




Appendix A.11 RTDB Reload from Remote

	An IM alarm should be observed with informational message on EPAP GUI confirming the start of the reload process	B Informational Messages
		Informational Messages Reload RTDB from mate in progress Tue June 12 2018 18:57:47 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
	An informational alarm should be displayed with informational message when the reload is	B Informational Messages
	complete.	Informational Massacra
		Informational Messages Reload RTDB from mate completed successfully
		reload reload name completed successions
		Tue June 12 2018 19:01:21 EDT
		Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
5.	MPS A and B:	
	Restart the GUI Server process.	
	· · · · · · · · · · · · · · · · ·	Log in to EPAP cli as root user:
		Login: root
		Password: <root_password></root_password>
		Run following commands to restart GUI server process
		\$ pkill gs
6.	MPS A and B: Start the Epap software on EPAP A	Run the following command on EPAP 16.3.1/16.4.1 Servers:
	and B.	<pre>\$ [epapdev@Manaus-a ~]\$ Service Epap start</pre>

Appendix A.11 RTDB Reload from Remote

		EPAP application started.
		<pre>\$ \$ [epapdev@Manaus-a ~]\$ ssh mate \$ \$ [epapdev@Manaus-b ~]\$ Service Epap start ~~ /etc/init.d/Epap start ~~</pre>
		<pre>EPAP application started. \$ [epapdev@Manaus-b ~]\$ exit</pre>
		logout
		Run the following command on EPAP 17.1 to start EPAP Services:
		[epapdev@Manaus-a logs]# systemctl start Epap
		[epapdev@Manaus-a ~]\$ ssh mate
		========================= This system has been upgraded but the upgrade has not yet
		been accepted or rejected. Please accept or reject the
		upgrade soon.
		========= Last login: Fri Jan 20 03:50:19 2023
		========== Last login: Fri Jan 20 03:50:19 2023 [epapdev@Manaus-b ~]\$ systemctl start Epap
		========== Last login: Fri Jan 20 03:50:19 2023 [epapdev@Manaus-b ~]\$ systemctl start Epap [epapdev@Manaus-b ~]\$ exit
		=====================================
		=====================================
		=====================================
		=====================================
		=====================================
		=====================================
7. □	MPS A: Checking the RTDB	=====================================

Appendix A.11 RTDB Reload from Remote



Procedure A.12 ISO Image download from Oracle Software Delivery Cloud

This procedure defines the step to download the ISO from OSDC and copy to the test server at specific path.

Appendix A.12 ISO Image download from OSDC

S	This procedure pro	vides instructions to download an ISO image from OSDC and copy to the
T	required server.	
E P	Check off ($$) each step a	as it is completed. Boxes have been provided for this purpose under each step number.
#	IF THIS PROCEDURE F	AILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.
1.	MPS X: Log in to the	[hostname] consolelogin: admusr
	server as the	<pre>password: <admusr_password></admusr_password></pre>
	"admusr" user.	
2.	MPS X: Run syscheck	Run the following command:
	to make sure there is	\$ sudo syscheck
	no error.	The output should look like:
		[admusr@hostname ~]\$ syscheck
		Running modules in class disk
		OK
		Running modules in class hardware
		OK

Appendix A.12 ISO Image download from OSDC

		Running modules in class net
		OK Running modules in class proc
		OK Running modules in class system
		OK Running modules in class upgrade
		OK LOG LOCATION: /var/TKLC/log/syscheck/fail_log
		Note: syscheck may report following error which can be ignored: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
3.	MPS X: Verify ISO image doesn't	Run the following command to perform directory listing: \$ ls -alrt /var/TKLC/upgrade
	already exist.	The output should look like as follows (There is no ISO is present in following example):
		<pre>[admusr@Osorna-B-PDBonly ~]\$ ls -alrt /var/TKLC/upgrade/ total 12 drwxrwxr-x. 3 root admgrp 4096 Feb 19 21:43 .</pre>
		dr-xr-xr-x. 22 root root 4096 Jun 15 2018
		If an ISO image exists, remove it by executing the following command:
		\$ rm -f /var/TKLC/upgrade/ <iso image=""></iso>
4.	Download the ISO image from OSDC.	Download the ISO image from OSDC(Oracle Software Delivery Cloud).
5.	Copy the ISO from source path to destination path.	NOTE: Skip this step if same ISO is already present on destination folder.
		Copy the ISO image from source path to destination path using scp/ftp command.

Appendix A.12 ISO Image download from OSDC

		Run the following command on destination server:
		\$ sudo scp <source_username>@<source_server_ip>:/<source_path>/xyz.iso /var/TKLC/upgrade</source_path></source_server_ip></source_username>
		Password: <enter source="" userpassword=""></enter>
		OR,
		Run the following command on source server:
		<pre>\$ scp /<source_path>/<xyz.iso> admusr@<destination_server_ip>:/var/TKLC/upgrade</destination_server_ip></xyz.iso></source_path></pre>
		Password: <enter admusr="" password=""></enter>
-		
6.	MPS X: Verify ISO image copied on	Run the following command to perform directory listing: \$ ls -alrt /var/TKLC/upgrade
	destination path.	The output should look like:
		[admusr@hostname ~]\$ ls -alrt /var/TKLC/upgrade total 1599016
		-rr 1 root root 925388800 Aug 23 02:15 EPAP- 16.3.0.0.0_163.12.0-x86_64.iso
		dr-xr-xr-x. 22 root root 4096 Aug 23 02:31
		drwxrwxr-x. 3 root admgrp 4096 Sep 11 04:38 .
		Repeat this procedure from step 1 if EPAP ISO file is not as expected.
7.	MPS X: Validate ISO file.	Validate ISO file using 0.
8.	Procedure complete.	This procedure is complete.
9.	Note down the	Run the following command:
	timestamp in log.	\$ date


IPM MPS Server with TPD 8.6.0

Note: Both the MPS-A and MPS-B servers can be IPM'ed at the same time.


Appendix A.13 IPM with TPD 8.6.0

S This procedure will IPM the E5-APP-B Server.


Appendix A.13 IPM with TPD 8.6.0




Appendix A.13 IPM with TPD 8.6.0



Appendix A.13 IPM with TPD 8.6.0



Appendix A.13 IPM with TPD 8.6.0



Appendix A.13 IPM with TPD 8.6.0

		If the following errors are observed while running the "TPDlvm" command, perform the "TPDlvm scrub": There is a problem with your existing storage configuration or your initial settings, for example a kickstart file. You must resolve this before the installation can proceed. There is a shell available for use which you can access by pressing ctrl-alt-f1 and then ctrl-b 2. Once you have resolved the issue, you can retry the storage scan. If you do not fix it, you will have to exit the installer. Duplicate UUID '00015466-01' found for devices: 'sdc1' and 'sda1' This is usually caused by cloning the device image resulting in duplication of the UUID value, which should be unique. In that case you can either disconnect one of the devices or reformat it.
		Press ENTER to exit: [[[11~^B^B^B^B^B2^H^H^H^H^H^[^[[11~[anaconda root@localhost ~]#
10.	MPS X: After a few seconds, additional messages will begin scrolling by on the screen as the Linux kernel boots, and then the drive formatting and file system creation steps will begin.	CentOS-4 i386 Released via the GPL Formatting Formatting Formatting / file system Z3x. (Tab>/(filt-Tab> between elements (Space> selects (Fi2> next screen)
11.	MPS X:	

Appendix A.13 IPM with TPD 8.6.0

Once the drive formatting and file system creation steps are complete, the screen at right will appear indicating that the package installation step is about to begin.



12.

MPS X:

After a few minutes, you will see a screen similar to that at right, showing the status of the package installation step. For each package, there will be a status bar at the top indicating how much of the package has been installed, with a cumulative status bar at the bottom indicating how many packages remain. In the middle, you will see text statistics indicating the total number of packages, the number of packages installed, the number remaining, and current and projected time estimates.

Package Installation

58%

Packages completed: 549 of 818


Installing selinux-policy-TPD-1.4.0-7.3.0.0.0_88.26.0.noarch (900 KB)

Tekelec SELinux policy modules.


Appendix A.13 IPM with TPD 8.6.0

13.	MPS X: Once all the packages have been successfully installed, the screen at right will appear letting you know the installation process is complete. On E5-APP-B server remove the	MPOINT: Media already mounted. DEV: /dev/sdc MPOINT: Pulling ISO Metadata file from: /run/install/repo//.isometadata Copying ISO metadata file to system DIR: /mnt/sysimage/var/TKLC/log/ipm Copying ISO metadata file to prodinfo DIR: /mnt/sysimage/usr/TKLC/plat/etc/prodinfo Changing default target to application.target Revoke root ssh access Installation complete Use of this product is subject to the license agreement found at:
	installation media (USB) and press <enter> to reboot the system and continue with the next step.</enter>	/usr/share/oraclelinux-release/EULA Installation complete. Press ENTER to quit:
14.	MPS X: Press 'del' key to enter the BIOS, set correct System Time in GMT and System Date.	Main
15.	MPS X: Select Boot → Hard Disk Drives option	


Appendix A.13 IPM with TPD 8.6.0



Appendix A.13 IPM with TPD 8.6.0



Appendix A.13 IPM with TPD 8.6.0



Appendix A.13 IPM with TPD 8.6.0

23.	MPS X:	\$ date -u
	Verify the system date.	Wed Mar 21 11:04:54 UTC 2018 Verify that the output time matches the time set in step 14. If mismatch is found, then Refer to My Oracle Support sectionfor instructions on accessing My Oracle Support.
24.	Procedure complete.	Return to the procedure that you came here from.
25.	Note down the timestamp in log.	Run the following command: \$ date

Procedure A.14 Standalone PDB Segmented Configuration

Note: All the networks (Prov, GUI and OAM) should be in different subnets. The networks can be a mix of IPv4 and IPv6 IPs.

Appendix A.14 Standalone PDB Segmented Configuration

S	This procedure will configure the standalone PDB in segmented configuration.		
T			
E	Check off $()$ each step as it is completed. Boxes have been provided for this purpose under each step number.		
P			
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .		
1.	MPS A: Log in to Server A.	[hostname] consolelogin: admusr password: password	
2.	MPS A: Switch user to epapconfig.	<pre>\$ sudo su - epapconfig Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.</pre>	
3.	MPS A: A note of caution appears. Press Return to continue.	Caution: This is the first login of the text user interface. Press return to continue	
4.	MPS A: Upon pressing Return you can now abort or proceed with the initial configuration.	Are you sure you wish to continue? [N]:Y	

 $Appendix \ A.14 \quad \ \mbox{Standalone PDB Segmented Configuration}$

	To continue with the configuration, enter Y.	
5.	MPS A: Enter the System Number and Network Configuration Type as "Segmented".	Building the initial database on side A. Stopping local slave No preexisting EuiDB database was detected. Set EPAP System Number: <enter here="" number="" system="" the=""> Enter the Network Configuration Type (1 for Single, 2 for Segmented): 2</enter>
6.	MPS A: The EPAP Configuration Menu is displayed. Select choice 2, Configure Network Interfaces Menu.	/EPAP Configuration Menu
		Enter Choice: 2

Appendix A.14 Standalone PDB Segmented Configuration

-		
7.	MPS A: The Configure Network Interfaces Menu is displayed. Select choice 1, Configure Provisioning Network.	/Configure Network Interfaces Menu 1 Configure Provisioning Network 2 Configure GUI Network 3 Configure Operations and Maintenance Network 4 Configure Backup Provisioning Network 5 Configure Static NAT Addresses e Exit
	Note: Enter choice "1" for IPv4 configuration. Otherwise, enter choice "2" for IPv6 configuration.	Enter Choice: 1 /Configure Provisiong Network Menu-\ /
8.	MPS A: The Configure Network Interfaces Menu is displayed. Select choice 2, Configure GUI Network.	/Configure Network Interfaces Menu

Appendix A.14 Standalone PDB Segmented Configuration

	Note: Enter choice "1" for IPv4 configuration. Otherwise, enter choice "2" for IPv6 configuration.	/Configure GUI Network-\ /
		EPAP GUI network route: 192.168.59.250 Select choice e to exit to the "Configure Network Interfaces" menu.
9.	MPS A: The Configure Network Interfaces Menu is displayed. Select choice 3, Configure Operations and Maintenance Network.	/Configure Network Interfaces Menu 1
	Note: Enter choice "1" for IPv4 configuration. Otherwise, enter choice "2" for IPv6 configuration.	Enter Choice: 1 EPAP A Operations and Maintenance network IP Address: 192.168.60.26 EPAP Operations and Maintenance network netmask: 255.255.255.0 EPAP Operations and Maintenance network route: 192.168.60.250 Select choice e to exit to the "Configure Network Interfaces" menu.

Appendix A.14 Standalone PDB Segmented Configuration

10.	MPS A: Select	/Configure Network Interfaces Menu\
╵	choice e to exit	/\ 1 Configure Provisioning Network
	from the epapconfig menu.	2 Configure GUI Network
		3 Configure Operations and Maintenance Network
		4 Configure Backup Provisioning Network
		5 Configure Static NAT Addresses
		\/
		Enter Choice: e
		/EPAP Configuration Menu\
		1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10 SNMP Configuration
		11 Configure Alarm Feed
		12 Configure Query Server
		13 Configure Query Server Alarm Feed
		14 Configure SNMP Agent Community
		15 DB Architecture Menu
		e Exit
		Enter Choice: 2

Appendix A.14 Standalone PDB Segmented Configuration

		Enter Choice: e Note: If this menu is not exited properly, then the SSH login with root shall remain enabled.
11.	MPS A: Procedure is complete.	Procedure is complete.
12.	Note down the timestamp in log.	Run the following command: \$ date

Procedure A.15 Password change for EPAP System Users

Appendix A.15 Password change for EPAP System Users

S	This procedure will change the password for the EPAP System User(s).	
T E P #	Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .	
1.	MPS A: Log in to Server A with the EPAP System User for which the password is to be changed.	[hostname]: <epap system="" user=""> password: <epapdev password=""></epapdev></epap>
2.	MPS A: Change Password for an EPAP system user	Run the command to change to password of an existing EPAP user. \$ passwd Changing password for user <epap system="" user="">. Changing password for <epap system="" user="">. (current) UNIX password: <enter current="" here="" password="" the=""> New password: <enter here="" new="" password="" the=""> Retype new password: <retype here="" new="" password="" the=""> passwd: all authentication tokens updated successfully. Note: The Linux "passwd" command used to change the password of Linux users, follows the Linux PAM rules. Refer to the Linux manual for the PAM rules. # man pam_cracklib</retype></enter></enter></epap></epap>
3.	MPS B: Change Password	Repeat steps 1 and 2 on MPS B also. Note: The new password on MPS A and B should be same.

Appendix A.15 Password change for EPAP System Users

4.	MPS A: Procedure	This procedure is complete.
ш	Complete	
5.	Note down the	Run the following command:
	timestamp in log.	\$ date

E5-APP-B Halt/Shutdown

Appendix A.16 E5-APP-B Halt/Shutdown

S	This procedure will halt the E5-APP-B hardrware.		
E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.		
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .		
1.	E5APPB Card: Slide the ejector switch.	On the APP-B card, slide the Ejector switch (4) up to the UNLOCKED position. Refer to Figure 6.	
		Caution: If the Ejector switch goes from locked to unlocked and the E5-APP-B card	
		is in service, the card will halt.	
2.	E5APPB Card: Monitor the Eject Status LED	WAIT for the E5-APP-B Eject Status LED to go from blinking red to a steady red.	
3.	E5APPB Card: Lever Release	Grasp the upper and lower card Inject/Eject (I/E) lever release (3) just underneath the I/E lever, and press it to meet the I/E lever. This is the mechanical interlock for the card. Refer to Figure 7.	
4.	E5APPB Card: Pull out the levers	While holding the I/E interlock and lever, pull the levers (2) away from the shelf until they are parallel to the floor. Refer to Figure 7.	
5.	E5APPB Card: Slide the ejector switch	Remove the E5-APP-B card from the EAGLE shelf.	
6.	MPS A: Procedure Complete	This procedure is complete.	
7.	Note down the	Run the following command:	
	timestamp in log.	\$ date	




Figure 6: Slide the Ejector Switch




Figure 7: Release Lever

Procedure to Configure EPAP switch ports and EAGLE SM cards to support 1G EPAP-to-Eagle RTDB download speed

Note: This needs to be done in coordination with the EAGLE team.

Appendix A.17 Procedure to Configure EPAP switch ports and EAGLE SM cards to support 1G EPAP-to-Eagle RTDB download speed

This procedure will configure EPAP Switch ports and Eagle SM cards to support 1G EPAP-to-EAGLE download speed.		
Note: Estimated time of completion is 20 minutes.		
E5-APP-B A/B: Configure	Follow 0 to Configure the SM ports on EPAP switch to 1000 Mbps	
switch to 1000 Mbps.		
Eagle Command to configure an Ethernet port on EAGLE SM cards that connects to EPAP to Auto-negotiate. Eagle Command to configure an Ethernet port on EAGLE SM cards that connects to EPAP: CHG-IP-LNK:LOC= <sm card="" location="">:PORT=<port>:IPADDR=<ip address="">:SUBMASK=<subnet mask="">:MCAST=YES:AUTO=YES</subnet></ip></port></sm>		
EAGLE: Verify the auto negotiation status of the Ethernet ports on EAGLE SM cards that connects to EPAP. Make sure the ports are getting autonegotiated to 1000Mbps/Full Duplex.	Eagle Command to verify auto negotiation status of an Ethernet port on EAGLE SM cards that connects to EPAP: PASS: LOC= <sm card="" location="">:CMD="NETSTAT -I" Please go through the "Identifying the Ethernet port status on SM cards using "NETSTAT -I" display" section below. If ports on SM cards are getting auto-negotiated to 1000Mbps/Full Duplex correctly, then stop here. Otherwise continue with next step.</sm>	
E5-APP-B A/B: Configure the SM ports on EPAP switch to auto-negotiate.	Follow 0 to Configure the SM ports on EPAP switch to 'auto'.	
EAGLE: Verify the auto negotiation status of a Ethernet port on EAGLE SM cards that connects to EPAP. Make sure the ports are getting autonegotiated to 1000Mbps/Full Duplex.	Eagle Command to verify auto negotiation status of an Ethernet port on EAGLE SM cards that connects to EPAP: PASS: LOC= <sm card="" location="">:CMD="NETSTAT -I" Please go through the "Identifying the Ethernet port status on SM cards using "NETSTAT -I" display" section below</sm>	
Note down the timestamp in log.	Run the following command: \$ date	
	ES-APP-B A/B: Configure the SM ports on EPAP to Auto-negotiate. EAGLE: Verify the auto negotiated to 1000Mbps/Full Duplex. EAGLE: Verify the auto negotiated to auto-negotiated to 1000Mbps/Full Duplex. EAGLE: Verify the auto negotiated to 1000Mbps/Full Duplex. EAGLE: Verify the auto negotiated to 1000Mbps/Full Duplex.	

Identifying the Ethernet port status on SM cards using "NETSTAT -I" display:

```
SM8G-B card running SCCPHC:
gei (unit number 2) = ExAP Port A
gei (unit number 3) = ExAP Port B
SM8G-B card running SCCPHC:
gei (unit number 2) = ExAP Port A
gei (unit number 3) = ExAP Port B
> rept-stat-card:mode=full:loc=1307
    eagle1 17-05-04 16:43:49 MST EAGLE 46.5.0.0.0-70.29.0
    CARD VERSION TYPE GPL PST SST
1307 140-029-000 DSM SCCPHC IS-ANR MPS Unavl
                                                                               AST
      ALARM STATUS = No Alarms.
      BLMCAP GPL version = 140-029-000
      IMT BUS A = Conn
      IMT BUS B
                            = Disc
      CLOCK A
                            = Fault
      CLOCK B
                            = Active
                           = Idle
      CLOCK I
      CLOCK I = 101e
MBD BIP STATUS = Valid
      MOTHER BOARD ID = SMXG B
      DBD STATUS
                           = Valid
      DBD TYPE
                            = None
      DBD MEMORY SIZE = 8192M
      HW VERIFICATION CODE= ----
      FPGA VERSION = 9
BIOS VERSION = 0ABSV01
PSOC VERSION = 0.1
      CURRENT TEMPERATURE = 34C ( 94F)
      PEAK TEMPERATURE: = 34C (94F) [17-05-04 15:49]
      SCCP % OCCUP
                           = 0%
      SCCP SM DATA TYPE = DN
      APPLICATION SERVICING
           SNM REQ STATUS = 24 hr: ---, 5 min: ---
INM REQ STATUS = 24 hr: ---, 5 min: ---
MTP3 REQ STATUS = 24 hr: ---, 5 min: ---
SFLOG REQ STATUS = 24 hr: ---, 5 min: ---
      IPLNK STATUS
           IPLNK IPADDR
                                       STATUS
           A 192.168.120.21 DOWN OOS-MT
B 192.168.121.21 DOWN OOS-MT
      DSM IP CONNECTION
PORT PST SST
A OOS-MT Unavail
B OOS-MT Unavail
    Command Completed.
> pass:loc=1307:cmd="netstat -i"
    eagle1 17-05-04 16:44:26 MST EAGLE 46.5.0.0.0-70.29.0
```

```
SDS Shell Output
-> tklc ifShow
lo (unit number 0):
     Flags: (0x48049) UP LOOPBACK MULTICAST TRAILERS ARP RUNNING INET UP
    Type: SOFTWARE LOOPBACK
    inet: 127.0.0.\overline{1}
    Netmask 0xff000000 Subnetmask 0xff000000
    Metric is 0
    Maximum Transfer Unit size is 1536
    0 packets received; 1 packets sent
    0 multicast packets received
     0 multicast packets sent
    0 input errors; 0 output errors
    0 collisions; 0 dropped
    0 output queue drops
DPLend (unit number 0):
    Flags: (0x20043) UP BROADCAST ARP RUNNING
    Type: ETHERNET CSMACD
    Ethernet address is 00:00:00:00:00:00
    Metric is 0
    Maximum Transfer Unit size is 485
    0 octets received
    0 octets sent
    0 unicast packets received
    0 unicast packets sent
    0 non-unicast packets received
    0 non-unicast packets sent
    0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
    0 collisions; 0 dropped
    0 output queue drops
gei (unit number 2):
     Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
     PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    Type: ETHERNET CSMACD
    inet: 192.168.120.21
    Broadcast address: 192.168.120.255
    Netmask 0xffffff00 Subnetmask 0xffffff00
    Ethernet address is 00:00:17:0e:b7:d2
    Metric is 0
    Maximum Transfer Unit size is 1500
     250214 octets received
    122200 octets sent
    0 unicast packets received
    0 unicast packets sent
    0 multicast packets received
     0 multicast packets sent
    2075 broadcast packets received
    940 broadcast packets sent
     0 incoming packets discarded
    0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     O collisions; O dropped
     0 output queue drops
gei (unit number 3):
```

```
Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
        PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
        Type: ETHERNET CSMACD
        inet: 192.168.121.21
        Broadcast address: 192.168.121.255
        Netmask 0xffffff00 Subnetmask 0xffffff00
        Ethernet address is 00:00:17:0e:b7:d3
        Metric is 0
        Maximum Transfer Unit size is 1500
        248920 octets received
        121290 octets sent
        0 unicast packets received
        0 unicast packets sent
        0 multicast packets received
        0 multicast packets sent
        2062 broadcast packets received
        933 broadcast packets sent
        0 incoming packets discarded
        0 outgoing packets discarded
        0 incoming errors
        0 outgoing errors
        0 unknown protos
        0 collisions; 0 dropped
        0 output queue drops
   value = 26 = 0x1a
;
   eagle1 17-05-04 16:44:36 MST EAGLE 46.5.0.0.0-70.29.0
   NETSTAT command complete
SM8G-B card running SCCP64:
gei (unit number 4) = ExAP Port A
gei (unit number 5) = ExAP Port B
> rept-stat-card:mode=full:loc=1307
   eagle1 17-05-04 17:00:01 MST EAGLE 46.5.0.0.0-70.29.0
   CARD VERSION TYPE GPL PST 1307 140-029-000 DSM SCCP64 IS-AND
                                                         SST
                                                                    AST
                                          PST SST AST
IS-ANR MPS Unavl ----
   1307 140-029-000 DSM
     ALARM STATUS = No Alarms.
     BLDC64 GPL version = 140-029-000
     IMT BUS A = Conn
     IMT BUS B
                       = Disc
     CLOCK A
                       = Fault
     CLOCK B
                        = Active
     CLOCK I
     MBD BIP STATUS = Valid
     MOTHER BOARD ID = SMXG B
     DBD STATUS
                       = Valid
     DBD TYPE = None
DBD MEMORY SIZE = 8192M
     DBD TYPE
     HW VERIFICATION CODE= ----
     FPGA VERSION = 9
```

```
BIOS VERSION = 0ABSV01
PSOC VERSION = 0.1
      CURRENT TEMPERATURE = 34C ( 94F)

PEAK TEMPERATURE: = 34C ( 94F) [17-05-04 15:49]

SCCP % OCCUP = 0%
      SCCP SM DATA TYPE = DN
      APPLICATION SERVICING
                                            MFC
          SNM REQ STATUS = 24 hr: ---, 5 min: ---
INM REQ STATUS = 24 hr: ---, 5 min: ---
MTP3 REQ STATUS = 24 hr: ---, 5 min: ---
SFLOG REQ STATUS = 24 hr: ---, 5 min: ---
      IPLNK STATUS
               NK IPADDR STATUS PST
192.168.120.21 DOWN OOS-MT
192.168.121.21 DOWN OOS-MT
           IPLNK IPADDR
      DSM IP CONNECTION
          A OOS-MT Unavail
B OOS-MT Unavail
    Command Completed.
> pass:loc=1307:cmd="netstat -i"
    eagle1 17-05-04 17:00:14 MST EAGLE 46.5.0.0.0-70.29.0
    SDS Shell Output
    shellLib: unknown LED mode vi.
    -> tklc ifShow
    lo0 Link type:Local loopback Queue:none
         inet 127.0.0.1 mask 255.255.255.255
         inet6 unicast fe80::1%lo0 prefixlen 64 automatic
         inet6 unicast ::1 prefixlen 128
        UP RUNNING LOOPBACK MULTICAST NOARP ALLMULTI
        MTU:1500 metric:1 VR:0 ifindex:1
        RX packets:761 mcast:3 errors:0 dropped:0
        TX packets:761 mcast:3 errors:0
         collisions:0 unsupported proto:0
         RX bytes:85k TX bytes:85k
                 Link type:Ethernet HWaddr 00:00:17:0e:b7:d2 Queue:none
        capabilities: TXCSUM TX6CSUM
         inet 192.168.120.21 mask 255.255.255.0 broadcast 192.168.120.255
         inet6 unicast fe80::200:17ff:fe0e:b7d2%gei4 prefixlen 64 automatic
        UP RUNNING SIMPLEX BROADCAST MULTICAST
        MTU:1500 metric:1 VR:0 ifindex:2
        RX packets:791 mcast:0 errors:0 dropped:0
        TX packets:386 mcast:6 errors:0
         collisions:0 unsupported proto:0
        RX bytes:92k TX bytes:48k
                 Link type:Ethernet HWaddr 00:00:17:0e:b7:d3 Queue:none
        capabilities: TXCSUM TX6CSUM
         inet 192.168.121.21 mask 255.255.255.0 broadcast 192.168.121.255
         inet6 unicast fe80::200:17ff:fe0e:b7d3%gei5 prefixlen 64 automatic
        UP RUNNING SIMPLEX BROADCAST MULTICAST
        MTU:1500 metric:1 VR:0 ifindex:3
```

```
RX packets:783 mcast:0 errors:0 dropped:0
        TX packets:386 mcast:6 errors:0
        collisions:0 unsupported proto:0
        RX bytes:91k TX bytes:48k
    gei (unit number 4):
        PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    gei (unit number 5):
        PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    value = 1 = 0x1
SM8G-B card running ENUMHC/DEIRHC/SIPHC:
gei (unit number 2) = ExAP Port
gei (unit number 3) = Signaling Port
> rept-stat-card:mode=full:loc=1317
    eagle1 17-05-04 15:46:06 MST EAGLE 46.5.0.0.0-70.29.0
    CARD VERSION TYPE GPL PST 1317 140-029-000 DSM ENUMHC IS-ANF
                                                              SST
                                              PST SST AST IS-ANR MPS Unavl ----
                                                                           AST
    1317 140-029-000 DSM
     ALARM STATUS = No Alarms.
     BLMCAP GPL version = 140-029-000
     IMT BUS A = Conn
IMT BUS B = Disc
                         = Fault
      CLOCK A
     CLOCK B
                          = Active
     CLOCK I = Idle
MBD BIP STATUS = Valid
MOTHER BOARD ID = SMXG B
DBD STATUS = Valid
      DBD STATUS
     DBD TYPE = None
DBD MEMORY SIZE = 8192M
      HW VERIFICATION CODE= ----
      FPGA VERSION = 9
      BIOS VERSION = 0ABSV01
PSOC VERSION = 0.1
      CURRENT TEMPERATURE = 34C ( 94F)
      PEAK TEMPERATURE: = 34C ( 94F) [17-05-02 09:31]
ENUM SM DATA TYPE = DN
                                    STATUS PST
IS-NR
      IPLNK STATUS
          IPLNK IPADDR
          A 192.168.120.13 UP
B 10.75.49.21 UP
                                                IS-NR
          C
                                     ----
                 _____
      DSM IP CONNECTION
         PORT PST
                                 SST
      PORT PST SST

A OOS-MT Unavail

D OOS-MA Ueq

ENUM CONNECTION STATUS
                              PROT STATUS
         CNAME
    Command Completed.
> pass:loc=1317:cmd="netstat -i"
Command Accepted - Processing
```

```
eagle1 17-05-04 15:46:46 MST EAGLE 46.5.0.0.0-70.29.0
pass:loc=1317:cmd="netstat -i"
Command entered at terminal #13.
eagle1 17-05-04 15:46:46 MST EAGLE 46.5.0.0.0-70.29.0
PASS: Command sent to card
eagle1 17-05-04 15:46:46 MST EAGLE 46.5.0.0.0-70.29.0
SDS Shell Output
-> tklc_ifShow
lo (unit number 0):
     Flags: (0x48049) UP LOOPBACK MULTICAST TRAILERS ARP RUNNING INET UP
    Type: SOFTWARE LOOPBACK
    inet: 127.0.0.1
    Netmask 0xff000000 Subnetmask 0xff000000
    Metric is 0
    Maximum Transfer Unit size is 1536
    O packets received; 1 packets sent
    0 multicast packets received
    0 multicast packets sent
    0 input errors; 0 output errors
    0 collisions; 0 dropped
    0 output queue drops
DPLend (unit number 0):
    Flags: (0x20043) UP BROADCAST ARP RUNNING
    Type: ETHERNET CSMACD
    Ethernet address is 00:00:00:00:00:00
    Metric is 0
    Maximum Transfer Unit size is 485
    0 octets received
    0 octets sent
    0 unicast packets received
    0 unicast packets sent
    0 non-unicast packets received
    0 non-unicast packets sent
    0 incoming packets discarded
    0 outgoing packets discarded
    0 incoming errors
     0 outgoing errors
    0 unknown protos
    0 collisions; 0 dropped
    0 output queue drops
gei (unit number 2):
    Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
    PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    Type: ETHERNET CSMACD
    inet: 192.168.120.13
    Broadcast address: 192.168.120.255
    Netmask 0xffffff00 Subnetmask 0xffffff00
    Ethernet address is 00:00:17:0e:b7:d2
    Metric is 0
    Maximum Transfer Unit size is 1500
    16128 octets received
    102048 octets sent
     0 unicast packets received
    0 unicast packets sent
     0 multicast packets received
```

```
0 multicast packets sent
         252 broadcast packets received
         786 broadcast packets sent
         0 incoming packets discarded
         0 outgoing packets discarded
         0 incoming errors
         0 outgoing errors
         0 unknown protos
         0 collisions; 0 dropped
         0 output queue drops
    gei (unit number 3):
        Flags: (0x70043) UP BROADCAST ARP RUNNING INET UP
         PHY Flags: (0x12012) AUTONEG 1000MB FDX DIX
         Type: ETHERNET_CSMACD
         inet: 10.75.49.21
         Broadcast address: 10.75.49.255
        Netmask 0xff000000 Subnetmask 0xffffff00
         Ethernet address is 00:00:17:0e:b7:d3
        Metric is 0
        Maximum Transfer Unit size is 1500
         0 octets received
         128 octets sent
         0 unicast packets received
         0 unicast packets sent
         0 multicast packets received
         0 multicast packets sent
         0 broadcast packets received
         2 broadcast packets sent
         0 incoming packets discarded
         0 outgoing packets discarded
         0 incoming errors
         0 outgoing errors
         0 unknown protos
         0 collisions; 0 dropped
         0 output queue drops
    value = 26 = 0x1a
;
    eagle1 17-05-04 15:46:56 MST EAGLE 46.5.0.0.0-70.29.0
    eagle1 17-05-04 15:46:56 MST EAGLE 46.5.0.0.0-70.29.0
   NETSTAT command complete
SM8G-B card running ENUM64/DEIR64/SIP64:
gei (unit number 4) = ExAP Port
gei (unit number 5) = Signaling Port
> rept-stat-card:mode=full:loc=1317
    eagle1 17-05-04 15:23:31 MST EAGLE 46.5.0.0.0-70.29.0
   CARD VERSION TYPE GPL PST SST AST 1317 140-029-000 DSM ENUM64 IS-ANR MPS Unavl -----
```

```
= ** 0080 Shelf FAN bit is OFF
     ALARM STATUS
     BLDC64 GPL version = 140-029-000
     IMT BUS A = Conn
      IMT BUS B
                         = Disc
= Fault
      CLOCK A
                         = Active
     CLOCK B
                        = Idle
     CLOCK I - TOTE

MBD BIP STATUS = Valid

MOTHER BOARD ID = SMXG B

- Valid
      CLOCK I
      DBD STATUS
                          = Valid
     DBD TYPE = None
DBD MEMORY SIZE = 8192M
      HW VERIFICATION CODE= ----
     FPGA VERSION = 9
      BIOS VERSION = 0ABSV01
PSOC VERSION = 0.1
      CURRENT TEMPERATURE = 34C ( 94F)
PEAK TEMPERATURE: = 34C ( 94F) [17-05-02 09:31]
      ENUM SM DATA TYPE = DN
      IPLNK STATUS
               IPADDR STATUS
192.168.120.13 UP
10.75.49.21 UP
          IPLNK IPADDR
                                               IS-NR
                -----
          D
                DSM IP CONNECTION
     PST SST
A OOS-MT Unavail
D OOS-MA Ueq
ENUM CONNECTION STATUS
CNAME --
                             PROT STATUS
    Command Completed.
> pass:loc=1317:cmd="netstat -i"
    eagle1 17-05-04 15:23:59 MST EAGLE 46.5.0.0.0-70.29.0
    SDS Shell Output
    shellLib: unknown LED mode vi.
    -> tklc ifShow
    lo0 Link type:Local loopback Queue:none
        inet 127.0.0.1 mask 255.255.255.255
        inet6 unicast fe80::1%lo0 prefixlen 64 automatic
        inet6 unicast ::1 prefixlen 128
        UP RUNNING LOOPBACK MULTICAST NOARP ALLMULTI
        MTU:1500 metric:1 VR:0 ifindex:1
        RX packets:885990 mcast:3 errors:0 dropped:0
        TX packets:885990 mcast:3 errors:0
        collisions:0 unsupported proto:0
        RX bytes:99M TX bytes:99M
                Link type:Ethernet HWaddr 00:00:17:0e:b7:d2 Queue:none
    gei4
       capabilities: TXCSUM TX6CSUM
        inet 192.168.120.13 mask 255.255.255.0 broadcast 192.168.120.255
        inet6 unicast fe80::200:17ff:fe0e:b7d2%gei4 prefixlen 64 automatic
        UP RUNNING SIMPLEX BROADCAST MULTICAST
        MTU:1500 metric:1 VR:0 ifindex:2
        RX packets:35807 mcast:0 errors:0 dropped:0
```

```
TX packets:877952 mcast:12 errors:0
        collisions:0 unsupported proto:0
        RX bytes:2148k TX bytes:110M
                Link type:Ethernet HWaddr 00:00:17:0e:b7:d3 Queue:none
        capabilities: TXCSUM TX6CSUM
        inet 10.75.49.21 mask 255.255.255.0 broadcast 10.75.49.255
        inet6 unicast fe80::200:17ff:fe0e:b7d3%gei5 prefixlen 64 automatic
        UP RUNNING SIMPLEX BROADCAST MULTICAST
        MTU:1500 metric:1 VR:0 ifindex:3
        RX packets:526 mcast:0 errors:0 dropped:0
        TX packets:7 mcast:6 errors:0
        collisions:0 unsupported proto:0
        RX bytes:57k TX bytes:510
    gei (unit number 4):
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    gei (unit number 5):
        PHY Flags: (0x12012) AUTONEG 1000MB FDX DIX
    value = 1 = 0x1
    eagle1 17-05-04 15:24:09 MST EAGLE 46.5.0.0.0-70.29.0
    eagle1 17-05-04 15:24:09 MST EAGLE 46.5.0.0.0-70.29.0
    NETSTAT command complete
SLIC card running SCCPHC:
gei (unit number 2) is {\tt ExAP} Port {\tt A}
gei (unit number 0) is ExAP Port B
> REPT-STAT-CARD:MODE=FULL:LOC=1307
    eagle1 17-05-04 15:10:21 MST EAGLE 46.5.0.0.0-70.29.0
                                                               AST Standby 989
    CARD VERSION TYPE GPL PST
1307 140-029-000 SLIC SCCPHC IS-ANR
                                                                          98%
     ALARM STATUS = ** 0080 Shelf FAN bit is OFF
      BLSLC32 GPL version = 140-029-000
      IMT BUS A = Conn
IMT BUS B = Disc
      CLOCK A
                          = Fault
                         = Active
      CLOCK B
     CLOCK I - 101

MBD BIP STATUS = Valid

MOTHER BOARD ID = SLIC

SERVICE = Valid
      DBD TYPE
                          = None
      DBD TYPE = None
DBD MEMORY SIZE = 16384M
      HW VERIFICATION CODE= ----
      FPGA VERSION = 9400036
      BIOS VERSION = 0ACFP00
PSOC VERSION = 1.0
      CURRENT TEMPERATURE = 40C (104F)
```

```
PEAK TEMPERATURE: = 40C (104F) [17-05-04 15:05]
      SCCP % OCCUP
                            = 0%
      SCCP SM DATA TYPE = DN
      APPLICATION SERVICING
                                              MFC
                   REQ STATUS = 24 hr: ---, 5 min: ---
           INM REQ STATUS = 24 hr: ---, 5 min: ---
MTP3 REQ STATUS = 24 hr: ---, 5 min: ---
SFLOG REQ STATUS = 24 hr: ---, 5 min: ---
       IPLNK STATUS

        IPADDR
        STATUS
        PST

        192.168.120.21
        DOWN
        OOS-MT

        192.168.121.21
        DOWN
        OOS-MT

           IPLNK IPADDR
       DSM IP CONNECTION
               RT PST SST
OOS-MT Unavail
OOS-MT Unavail
           PORT PST
    Command Completed.
> PASS:LOC=1307:CMD="NETSTAT -I"
    eagle1 17-05-04 15:10:27 MST EAGLE 46.5.0.0.0-70.29.0
    SDS Shell Output
    -> tklc ifShow
    lo (unit number 0):
          Flags: (0x48049) UP LOOPBACK MULTICAST TRAILERS ARP RUNNING INET UP
          Type: SOFTWARE_LOOPBACK
          inet: 127.0.0.\overline{1}
          Netmask 0xff000000 Subnetmask 0xff000000
          Metric is 0
          Maximum Transfer Unit size is 1536
          O packets received; 1 packets sent
          0 multicast packets received
          0 multicast packets sent
          0 input errors; 0 output errors
          O collisions; O dropped
          0 output queue drops
    DPLend (unit number 0):
          Flags: (0x20043) UP BROADCAST ARP RUNNING
          Type: ETHERNET CSMACD
          Ethernet address is 00:00:00:00:00
          Metric is 0
          Maximum Transfer Unit size is 485
          0 octets received
          0 octets sent
          0 unicast packets received
          0 unicast packets sent
          0 non-unicast packets received
          0 non-unicast packets sent
          0 incoming packets discarded
          0 outgoing packets discarded
          0 incoming errors
          0 outgoing errors
          0 unknown protos
          O collisions; O dropped
          0 output queue drops
    gei (unit number 2):
```

```
Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
         Type: ETHERNET CSMACD
         inet: 192.168.120.21
         Broadcast address: 192.168.120.255
         Netmask 0xffffff00 Subnetmask 0xffffff00
         Ethernet address is 00:10:e0:bb:26:d2
         Metric is 0
         Maximum Transfer Unit size is 1500
         0 octets received
         2014 octets sent
         0 unicast packets received
         0 unicast packets sent
         0 multicast packets received
         0 multicast packets sent
         0 broadcast packets received
         16 broadcast packets sent
         0 incoming packets discarded
         0 outgoing packets discarded
         0 incoming errors
         0 outgoing errors
         0 unknown protos
         0 collisions; 0 dropped
         0 output queue drops
    gei (unit number 0):
         Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
         Type: ETHERNET CSMACD
         inet: 192.168.121.21
         Broadcast address: 192.168.121.255
         Netmask 0xffffff00 Subnetmask 0xffffff00
         Ethernet address is 00:10:e0:bb:26:d0
         Metric is 0
        Maximum Transfer Unit size is 1500
         0 octets received
         1884 octets sent
         0 unicast packets received
         0 unicast packets sent
         0 multicast packets received
         0 multicast packets sent
         0 broadcast packets received
         15 broadcast packets sent
         0 incoming packets discarded
         0 outgoing packets discarded
         0 incoming errors
         0 outgoing errors
         0 unknown protos
         O collisions; O dropped
         0 output queue drops
    value = 26 = 0x1a
    eagle1 17-05-04 15:10:37 MST EAGLE 46.5.0.0.0-70.29.0
    NETSTAT command complete
SLIC card running SCCP64:
```

```
gei (unit number 0) = ExAP Port A
gei (unit number 2) = ExAP Port B
> REPT-STAT-CARD:MODE=FULL:LOC=1307
    eagle1 17-05-04 14:55:03 MST EAGLE 46.5.0.0.0-70.29.0
    CARD VERSION TYPE GPL PST 1307 140-029-000 SLIC SCCP64 IS-ANF
                                                                 SST AST
                                               PST
IS-ANR
    1307 140-029-000 SLIC
                                                                 MPS Unavl ----
      ALARM STATUS = ** 0080 Shelf FAN bit is OFF
      BLSLC64 GPL version = 140-029-000
                    = Conn
      IMT BUS A
      IMT BUS B
                           = Disc
      CLOCK A
                           = Fault
      CLOCK B
                           = Active
      CLOCK I
      CLOCK I - rule

MBD BIP STATUS = Valid

MOTHER BOARD ID = SLIC
      DBD STATUS = Valid
DBD TYPE = None
DBD MEMORY SIZE = 16384M
      HW VERIFICATION CODE= ----
      FPGA VERSION = 9400036
      BIOS VERSION = 0ACFP00
PSOC VERSION = 1.0
      CURRENT TEMPERATURE = 36C ( 97F)
PEAK TEMPERATURE: = 38C (101F) [17-05-04 14:47]
SCCP % OCCUP = 0%
      SCCP % OCCUP
      SCCP SM DATA TYPE = DN
      APPLICATION SERVICING
                  MFC MFC

REQ STATUS = 24 hr: ---, 5 min: ---

REQ STATUS = 24 hr: ---, 5 min: ---
          INM
          MTP3 REQ STATUS = 24 hr: ---, 5 min: ---
          SFLOG REQ STATUS = 24 hr: ---, 5 min: ---
      IPLNK STATUS
              NK IPADDR STATUS PST
192.168.120.21 DOWN OOS-MT
192.168.121.21 DOWN OOS-MT
          IPLNK IPADDR
      DSM IP CONNECTION
          PORT PST
                                  SST
          A OOS-MT
                                  Unavail
                  OOS-MT
                                   Unavail
    Command Completed.
> PASS:LOC=1307:CMD="NETSTAT -I"
Command Accepted - Processing
    eagle1 17-05-04 14:56:03 MST EAGLE 46.5.0.0.0-70.29.0
    PASS:LOC=1307:CMD="NETSTAT -I"
    Command entered at terminal #11.
    eagle1 17-05-04 14:56:03 MST EAGLE 46.5.0.0.0-70.29.0
    PASS: Command sent to card
    eagle1 17-05-04 14:56:03 MST EAGLE 46.5.0.0.0-70.29.0
```

```
SDS Shell Output
    shellLib: unknown LED mode vi.
    -> tklc ifShow
    100 Link type:Local loopback Queue:none
        inet 127.0.0.1 mask 255.255.255.255
        inet6 unicast fe80::1%lo0 prefixlen 64 automatic
        inet6 unicast ::1 prefixlen 128
       UP RUNNING LOOPBACK MULTICAST NOARP ALLMULTI
       MTU:1500 metric:1 VR:0 ifindex:1
       RX packets:2213 mcast:3 errors:0 dropped:0
       TX packets:2213 mcast:3 errors:0
        collisions:0 unsupported proto:0
       RX bytes:247k TX bytes:247k
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d0 Queue:none
        capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
        inet 192.168.120.21 mask 255.255.255.0 broadcast 192.168.120.255
        inet6 unicast fe80::210:e0ff:febb:26d0%gei0 prefixlen 64 automatic
       UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:2
       RX packets:695 mcast:0 errors:0 dropped:0
       TX packets:634 mcast:12 errors:0
        collisions:0 unsupported proto:0
       RX bytes:74k TX bytes:79k
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d2 Queue:none
        capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
        inet 192.168.121.21 mask 255.255.255.0 broadcast 192.168.121.255
        inet6 unicast fe80::210:e0ff:febb:26d2%gei2 prefixlen 64 automatic
       UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:3
       RX packets:702 mcast:0 errors:0 dropped:0
       TX packets:639 mcast:6 errors:0
        collisions:0 unsupported proto:0
       RX bytes:75k TX bytes:80k
    gei (unit number 0):
        PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    gei (unit number 2):
        PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    value = 1 = 0x1
    eagle1 17-05-04 14:56:13 MST EAGLE 46.5.0.0.0-70.29.0
   NETSTAT command complete
SLIC card running ENUMHC/DEIRHC/SIPHC:
gei (unit number 2) = ExAP Port A
gei (unit number 0) = Signaling Port #1
gei (unit number 3) = Signaling Port #2
gei (unit number 1) = ExAP Port B
> rept-stat-card:mode=full:loc=1317
```

```
eagle1 17-05-04 17:34:35 MST EAGLE 46.5.0.0.0-70.29.0
    CARD VERSION TYPE GPL PST 1317 140-029-000 SLIC ENUMHC IS-AN
                                                                   SST
                                                 PST SST AST IS-ANR MPS Unavl ----
    1317 140-029-000 SLIC
      ALARM STATUS = No Alarms.
      BLSLC32 GPL version = 140-029-000
                    = Conn
      IMT BUS A
                           = Disc
      IMT BUS B
      CLOCK A
                           = Fault
      CLOCK B
                            = Active
      MBD BIP STATUS = Idle
MOTHER BOARD ID = SLIC
DBD STATUS = Valid
DBD TYPE = Mono
      CLOCK I
                            = Idle
      DBD TYPE = None
DBD MEMORY SIZE = 16384M
      HW VERIFICATION CODE= ----
      FPGA VERSION = 9400036
BIOS VERSION = 0ACFP00
      PSOC VERSION = 1.0
      CURRENT TEMPERATURE = 43C (110F)
PEAK TEMPERATURE: = 43C (110F)
ENUM SM DATA TYPE = DN
                                             [17-05-04 17:27]
      IPLNK STATUS
               NK IPADDR STATUS PST
192.168.120.13 UP IS-NR
10.75.49.21 DOWN OOS-MT
10.75.50.21 UP IS-NR
192.168.121.13 UP IS-NR
           IPLNK IPADDR
           C
           D
      DSM IP CONNECTION
                                   SST
           PORT PST
           A OOS-MT Unavail
D OOS-MT Unavail
    Command Completed.
> pass:loc=1317:cmd="netstat -i"
Command Accepted - Processing
    eagle1 17-05-04 17:34:52 MST EAGLE 46.5.0.0.0-70.29.0
    pass:loc=1317:cmd="netstat -i"
    Command entered at terminal #13.
    eagle1 17-05-04 17:34:52 MST EAGLE 46.5.0.0.0-70.29.0
    PASS: Command sent to card
    eagle1 17-05-04 17:34:52 MST EAGLE 46.5.0.0.0-70.29.0
    SDS Shell Output
    -> tklc ifShow
    lo (unit number 0):
          Flags: (0x48049) UP LOOPBACK MULTICAST TRAILERS ARP RUNNING INET UP
          Type: SOFTWARE LOOPBACK
          inet: 127.0.0.1
          Netmask 0xff000000 Subnetmask 0xff000000
          Metric is 0
          Maximum Transfer Unit size is 1536
```

```
0 packets received; 1 packets sent
     0 multicast packets received
     0 multicast packets sent
     0 input errors; 0 output errors
     O collisions; O dropped
    0 output queue drops
DPLend (unit number 0):
    Flags: (0x20043) UP BROADCAST ARP RUNNING
    Type: ETHERNET_CSMACD
    Ethernet address is 00:00:00:00:00
    Metric is 0
    Maximum Transfer Unit size is 485
    0 octets received
    0 octets sent
    0 unicast packets received
    0 unicast packets sent
    0 non-unicast packets received
     0 non-unicast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     0 collisions; 0 dropped
    0 output queue drops
gei (unit number 2):
     Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
    PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    Type: ETHERNET CSMACD
    inet: 192.168.120.13
    Broadcast address: 192.168.120.255
    Netmask 0xffffff00 Subnetmask 0xffffff00
    Ethernet address is 00:10:e0:bb:26:d2
    Metric is 0
    Maximum Transfer Unit size is 1500
    13736 octets received
    16118 octets sent
    0 unicast packets received
    0 unicast packets sent
    0 multicast packets received
     0 multicast packets sent
    128 broadcast packets received
    125 broadcast packets sent
    0 incoming packets discarded
    0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     O collisions; O dropped
    0 output queue drops
gei (unit number 0):
     Flags: (0x70043) UP BROADCAST ARP RUNNING INET UP
     PHY Flags: (0x2012) DIX
    Type: ETHERNET CSMACD
     inet: 10.75.49.21
    Broadcast address: 10.75.49.255
    Netmask 0xff000000 Subnetmask 0xffffff00
    Ethernet address is 00:10:e0:bb:26:d0
    Metric is 0
    Maximum Transfer Unit size is 1500
     0 octets received
```

```
0 octets sent
     0 unicast packets received
     0 unicast packets sent
     0 multicast packets received
     0 multicast packets sent
     0 broadcast packets received
     0 broadcast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     O collisions; O dropped
    0 output queue drops
gei (unit number 3):
     Flags: (0x70043) UP BROADCAST ARP RUNNING INET UP
    PHY Flags: (0x12012) 100MB FDX DIX
    Type: ETHERNET CSMACD
    inet: 10.75.50.21
    Broadcast address: 10.75.50.255
    Netmask 0xff000000 Subnetmask 0xffffff00
    Ethernet address is 00:10:e0:bb:26:d3
    Metric is 0
    Maximum Transfer Unit size is 1500
    25708 octets received
    128 octets sent
    0 unicast packets received
    0 unicast packets sent
    0 multicast packets received
     0 multicast packets sent
     214 broadcast packets received
     2 broadcast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     O collisions; O dropped
    0 output queue drops
gei (unit number 1):
     Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
     PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    Type: ETHERNET CSMACD
     inet: 192.168.121.13
    Broadcast address: 192.168.121.255
    Netmask 0xffffff00 Subnetmask 0xffffff00
    Ethernet address is 00:10:e0:bb:26:d1
    Metric is 0
    Maximum Transfer Unit size is 1500
    13544 octets received
    16118 octets sent
    0 unicast packets received
    0 unicast packets sent
     0 multicast packets received
     0 multicast packets sent
    125 broadcast packets received
    125 broadcast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
```

```
0 unknown protos
           O collisions; O dropped
           0 output queue drops
     value = 26 = 0x1a
     eagle1 17-05-04 17:35:02 MST EAGLE 46.5.0.0.0-70.29.0
     eagle1 17-05-04 17:35:02 MST EAGLE 46.5.0.0.0-70.29.0
    NETSTAT command complete
SLIC card running DEIR64/ENUM64/SIP64:
gei (unit number 0) = ExAP Port A
gei (unit number 2) = Signaling Port #1
gei (unit number 1) = Signaling Port #2
gei (unit number 3) = ExAP Port B
> rept-stat-card:mode=full:loc=1317
Command Accepted - Processing
    eagle1 17-05-04 16:20:40 MST EAGLE 46.5.0.0.0-70.29.0
     rept-stat-card:mode=full:loc=1317
    Command entered at terminal #13.
     eagle1 17-05-04 16:20:40 MST EAGLE 46.5.0.0.0-70.29.0
    CARD VERSION TYPE GPL PST SST AST 1317 140-029-000 SLIC ENUM64 IS-ANR MPS Unavl ----
       317 	 140-029-000 	 SLIC 	 ENUM
ALARM STATUS = No Alarms.
       BLSLC64 GPL version = 140-029-000
       IMT BUS A = Conn
       IMT BUS B
                               = Disc
       CLOCK A
                                = Fault
       CLOCK B
                                = Active
       CLOCK I = Idle
MBD BIP STATUS = Valid
MOTHER BOARD ID = SLIC
       CLOCK I
                               = Idle
       DBD STATUS = Valid
       DBD TYPE = None
DBD MEMORY SIZE = 16384M
       HW VERIFICATION CODE= ----
       FPGA VERSION = 9400036
       BIOS VERSION = 0ACFP00
PSOC VERSION = 1.0
       CURRENT TEMPERATURE = 40C (104F)
PEAK TEMPERATURE: = 42C (108F) [17-05-04 15:51]
       ENUM SM DATA TYPE = DN
       IPLNK STATUS

        IPLNK
        IPADDR
        STATUS
        PST

        A
        192.168.120.13
        UP
        IS-NR

        B
        10.75.49.21
        DOWN
        OOS-MT

        C
        10.75.50.21
        DOWN
        OOS-MT
```

```
192.168.121.13 UP
                                            IS-NR
      DSM IP CONNECTION
                               SST
         PORT PST
                              Unavail
                OOS-MT
         Α
                OOS-MT
                               Unavail
   Command Completed.
> pass:loc=1317:cmd="netstat -i"
Command Accepted - Processing
   eagle1 17-05-04 16:25:06 MST EAGLE 46.5.0.0.0-70.29.0
   pass:loc=1317:cmd="netstat -i"
   Command entered at terminal #13.
   eagle1 17-05-04 16:25:06 MST EAGLE 46.5.0.0.0-70.29.0
   PASS: Command sent to card
   eagle1 17-05-04 16:25:06 MST EAGLE 46.5.0.0.0-70.29.0
   SDS Shell Output
   shellLib: unknown LED mode vi.
    -> tklc ifShow
   lo0 Link type:Local loopback Queue:none
       inet 127.0.0.1 mask 255.255.255.255
       inet6 unicast fe80::1%lo0 prefixlen 64 automatic
       inet6 unicast ::1 prefixlen 128
       UP RUNNING LOOPBACK MULTICAST NOARP ALLMULTI
       MTU:1500 metric:1 VR:0 ifindex:1
       RX packets:1487 mcast:3 errors:0 dropped:0
       TX packets:1487 mcast:3 errors:0
       collisions:0 unsupported proto:0
       RX bytes:165k TX bytes:165k
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d0 Queue:none
       capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
       inet 192.168.120.13 mask 255.255.255.0 broadcast 192.168.120.255
       inet6 unicast fe80::210:e0ff:febb:26d0%gei0 prefixlen 64 automatic
       UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:2
       RX packets:929 mcast:0 errors:0 dropped:0
       TX packets:745 mcast:6 errors:0
       collisions:0 unsupported proto:0
       RX bytes:101k TX bytes:93k
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d2 Queue:none
       capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
       inet 10.75.49.21 mask 255.255.255.0 broadcast 10.75.49.255
       inet6 unicast fe80::210:e0ff:febb:26d2%gei2 prefixlen 64 automatic
       UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:3
       RX packets:37 mcast:0 errors:0 dropped:0
       TX packets:7 mcast:6 errors:0
       collisions:0 unsupported proto:0
       RX bytes:4596 TX bytes:510
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d1 Queue:none
   aei1
```

```
capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
    inet 10.75.50.21 mask 255.255.25 broadcast 10.75.50.255
    inet6 unicast fe80::210:e0ff:febb:26d1%gei1 prefixlen 64 tentative automatic
   UP SIMPLEX BROADCAST MULTICAST
   MTU:1500 metric:1 VR:0 ifindex:4
   RX packets:0 mcast:0 errors:0 dropped:0
   TX packets:0 mcast:0 errors:0
   collisions:0 unsupported proto:0
   RX bytes:0 TX bytes:0
           Link type:Ethernet HWaddr 00:10:e0:bb:26:d3 Queue:none
   capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
   inet 192.168.121.13 mask 255.255.255.0 broadcast 192.168.121.255
    inet6 unicast fe80::210:e0ff:febb:26d3%gei3 prefixlen 64 automatic
   UP RUNNING SIMPLEX BROADCAST MULTICAST
   MTU:1500 metric:1 VR:0 ifindex:5
   RX packets:921 mcast:0 errors:0 dropped:0
   TX packets:745 mcast:6 errors:0
   collisions:0 unsupported proto:0
   RX bytes:101k TX bytes:93k
gei (unit number 0):
    PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
gei (unit number 2):
    PHY Flags: (0x12012) 100MB FDX DIX
gei (unit number 1):
    PHY Flags: (0x2012) DIX
gei (unit number 3):
    PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
value = 1 = 0x1
eagle1 17-05-04 16:25:16 MST EAGLE 46.5.0.0.0-70.29.0
NETSTAT command complete
```

;

Upgrade SSL certificate from SHA-1 to SHA-512

Appendix A.18 Upgrade SSL certificate from SHA-1 to SHA-512

S T	This procedure upgr	rade SSL certificate from SHA-1 to SHA-512.	
E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.		
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .		
1.	MPS: Log in to the server.	If not already logged in, then login at MPS: <hostname> console login: epapdev Password: <password> Change to root user.</password></hostname>	
		\$ su – root	
2.	Verify SSL certificate	To verify SSL certificate Run the following command: # /usr/hin/openssl x509 -in /usr/TKLC/nlat/etc/ssl/server crt -text -	
		<pre># /usr/bin/openssl x509 -in /usr/TKLC/plat/etc/ssl/server.crt -text - noout grep "Signature Algorithm" Signature Algorithm: sha512WithRSAEncryption Signature Algorithm: sha512WithRSAEncryption If signature algorithm is SHA 512 skip this procedure, otherwise proceed with the following step.</pre>	
3.	Find the IP for which the certificate has been generated in server.crt	<pre># openssl verify /usr/TKLC/plat/etc/ssl/server.crt /usr/TKLC/plat/etc/ssl/server.crt: CN = 10.248.11.14 error 18 at 0 depth lookup:self signed certificate OK</pre>	
4.	Upgrade to SHA-512 in server.crt	Note : The IP Address to be used in the below command is the IP displayed in the output of step 3.	
		To upgrade SHA-1 to SHA-512 run the following command:	
		<pre># /usr/bin/openssl req -x509 -sha512 -nodes -days 4015 -subj "/CN=<ip addr="">" -newkey rsa:2048 -keyout /usr/TKLC/plat/etc/ssl/server.key - out /usr/TKLC/plat/etc/ssl/server.crt</ip></pre>	
		Generating a 2048 bit RSA private key+++ writing new private key to	
		'/usr/TKLC/plat/etc/ssl/server.key'	
5.	Find the IP for which the certificate has been generated in server_dual.crt	# openssl verify /usr/TKLC/plat/etc/ssl/server_dual.crt /usr/TKLC/plat/etc/ssl/server_dual.crt: CN = 10.248.11.14 error 18 at 0 depth lookup:self signed certificate ox	

6.	Upgrade to SHA-512 in server_dual.crt	Note : The IP Address to be used in the below command is the IP displayed in the output of step 5.
		To upgrade SHA-1 to SHA-512 Run the following command:
		<pre># /usr/bin/openssl req -x509 -sha512 -nodes -days 4015 -subj "/CN=<ip addr="">" -newkey rsa:2048 -keyout /usr/TKLC/plat/etc/ssl/server_dual.key - out /usr/TKLC/plat/etc/ssl/server_dual.crt</ip></pre>
		Generating a 2048 bit RSA private key
		+++
		+++
		writing new private key to
		'/usr/TKLC/plat/etc/ssl/server_dual.key'
7.	Restart httpd service	Restart httpd service to reflect IP correctly. Use following command to restart httpd service:
П		
		\$ systemctl restart httpd
		[root@Natal-A ~]
8.	Exit from root user	Exit from root user by running the following command:
		\$ exit
9.	Procedure Complete.	Return to the procedure that you came here from.
10.	Note down the	Run the following command:
	timestamp in log.	\$ date

Disable Epap VIP And Deactivate PDBA Proxy Feature

If PDBA Proxy feature is NOT enabled and VIP is NOT configured, this procedure can be skipped.

Ensure the provisioning activity has been halted before proceeding!!!

Appendix A.19 Disable Epap VIP And Deactivate PDBA Proxy Feature

S T F	This procedure outlines the steps to disable the PDBA proxy feature.
-------------	--

P #	Estimated time: 5 minutes		
1.	MPS A: Choose option "8" to display "PDB Configuration Menu.	MPS Side A: /EPAP Configuration Menu	
2.	MPS A: Choose option "6" to "Change PDBA Proxy State".	MPS Side A: /Configure PDB Menu 1 Configure PDB Network	
3.	MPS A: Enter "Y" to stop PDBA / EPAP software and disable PDBA Proxy.	PDBA PROXY is currently ENABLED. Do you want to DISABLE PDBA Proxy? [N]: Y	

4.	MDC A	MPS Side A:	
lп	MPS A:		
	Enter "1" to "Display Configuration"	/EPAP Configuration Menu	\
	Comiguration	1 Display Configuration	\
		2 Configure Network Interfaces	
		4 Exchange Secure Shell Keys	i
		ii	
		7 Configure NTP Server	
		8 PDB Configuration Menu	
		9 Security 	¦
		10 SNMP Configuration	¦
		11	
		12 Configure Query Server	
		13 Configure Query Server Alarm	Feed
		14 Configure SNMP Agent Communit	
		15 Mate Disaster Recovery	
		e Exit	
5.	MPS A: Verify that the state of PDBA Proxy Feature is No.	255.255.255.0 Provisioning Network Default Router 192.168.61.1 EPAP A Backup Prov Network IP Address configured EPAP B Backup Prov Network IP Address configured Backup Prov Network Netmask configured Backup Prov Network Default Router configured EPAP A Sync Network Address 192.168.2.100 EPAP B Sync Network Address 192.168.2.200 EPAP A Main DSM Network Address 192.168.120.100 EPAP B Main DSM Network Address 192.168.120.200 EPAP B Backup DSM Network Address 192.168.121.100 EPAP B Backup DSM Network Address 192.168.121.200 EPAP A HTTP PORT EPAP B HTTP PORT	

EPAP B HTTP SuExec Port	= 8001
EPAP A Banner Connection Port	= 8473
EPAP A Banner Connection Port EPAP B Banner Connection Port EPAP A Static NAT Address	= 8473
EPAP A Static NAT Address	= Not
configured	
EPAP B Static NAT Address	= Not
configured	
PDBI Port	= 5873
Remote MPS A Static NAT Address	= Not
configured	
Remote MPS A HTTP Port	= 80
Local Provisioning VIP	=
192.168.15.152	
Remote Provisioning VIP	=
192.168.15.172	
Local PDBA Address	=
192.168.15.115	
Remote PDBA Address	_
192.168.16.115	
Remote PDBA B Address	=
192.168.16.116	_
Time Zone	=
America/New_York	_
PDB Database	= Exists
Preferred PDB	= Standby
Allow updates from alternate PDB	= Yes
Auto DB Recovery Enabled	= Yes
PDBA Proxy Enabled	= 165 >= NO
FUDA FIUNY Eliabiteu	NU
Press return to continue	

6.	MPS A:	MPS Side A:	
	Choose option "2" to enter the "Configure Network Interfaces Menu".	/EPAP Configuration Menu\	
		1 Display Configuration	
		2 Configure Network Interfaces Menu	
		3 Set Time Zone	
		4 Exchange Secure Shell Keys	
		5 Change Password	
		6 Platform Menu	
		7 Configure NTP Server	
		8 PDB Configuration Menu	
		9 Security	
		10 SNMP Configuration	
		11 Configure Alarm Feed	
		12 Configure Query Server	
		13 Configure Query Server Alarm Feed	
		14 Configure SNMP Agent Community	
		15 Mate Disaster Recovery	
		e Exit	
		Enter Choice: 2	

7.	MPS A:	MPS Side A:		
	Choose option "7" to enter	/Configure Network Interfaces Menu\		
	the "Configure Provisioning VIP Addresses Menu".	1 Configure Provisioning Network		
	VIF Addresses Mella .	2 Configure Sync Network		
		3 Configure DSM Network		
		4 Configure Backup Provisioning Network		
		5 Configure Forwarded Ports		
		6 Configure Static NAT Addresses		
		7 Configure Provisioning VIP Addresses		
		e Exit		
		,		
8.	MPS A:	Verifying root connectivity with mate		
	Remove the local	EPAP local provisioning Virtual IP Address [192.168.15.152]: 0.0.0.0		
	provisioning VIP and remote provisioning VIP, by	EPAP remote provisioning Virtual IP Address [192.168.15.172]: 0.0.0.0		
9.	entering 0.0.0.0.	MPS Side A:		
". □	MPS A:	/Configure Network Interfaces Menu\		
	Choose option "e" to exit.	1 Configure Provisioning Network		
		2 Configure Sync Network		
		3 Configure DSM Network		
		4 Configure Backup Provisioning Network		
		5 Configure Forwarded Ports		
		6 Configure Static NAT Addresses		
		7 Configure Provisioning VIP Addresses		
		e Exit /		
		Enter Choice: e		

10.	MPS A:	MPS Side A:			
	Choose option "1" to				
	"Display Configuration.	/EPAP Configuration Menu			
	ziopia, comigarationi	1 Display Configuration			
		2 Configure Network Interface			
		3 Set Time Zone			
		4 Exchange Secure Shell Keys			
		5 Change Password	I		
		6 Platform Menu 			
		7 Configure NTP Server			
		8 PDB Configuration Menu			
		9 Security			
		10 SNMP Configuration			
		11 Configure Alarm Feed 			
		13 Configure Query Server Alar			
		14 Configure SNMP Agent Commun			
		15 Mate Disaster Recovery			
			i		
			/		
		Enter Choice: 1			
11.	MDC A	MPS Side A:			
	MPS A:	EDAD A Duradistrutur Naturali ED Adduses			
	Verify VIP addresses are set	EPAP A Provisioning Network IP Address = 192.168.61.115			
	to 0.0.0.0.	EPAP B Provisioning Network IP Address	; =		
		192.168.61.116 Provisioning Network Netmask	=		
		255.255.255.0 Provisioning Network Default Router = 192.168.61.1			
		EPAP A Backup Prov Network IP Address = Not configured			
		EPAP B Backup Prov Network IP Address configured	= Not		
		Backup Prov Network Netmask configured	= Not		
		Backup Prov Network Default Router	= Not		
		configured EPAP A Sync Network Address	=		
		192.168.2.100	_		
		EPAP B Sync Network Address 192.168.2.200	=		
		EPAP A Main DSM Network Address	=		
		192.168.120.100 EPAP B Main DSM Network Address	_		
		192.168.120.200	=		
		EPAP A Backup DSM Network Address 192.168.121.100	=		
		EPAP B Backup DSM Network Address	=		
		192.168.121.200 EPAP A HTTP Port	= 80		
		EPAP B HTTP Port	= 80		
		EPAP A HTTP SUEXEC PORT EPAP B HTTP SUEXEC PORT	= 8001 = 8001		
		EPAP A Banner Connection Port	= 8001 = 8473		
		EPAP B Banner Connection Port	= 8473		
		EPAP A Static NAT Address configured	= Not		
		contrigui cu			

EPAP B Static NAT Address	= Not
configured	
PDBI Port	= 5873
Remote MPS A Static NAT Address	= Not
configured	
Remote MPS A HTTP Port	= 80
Local Provisioning VIP	= 0.0.0.0
Remote Provisioning VIP	= 0.0.0.0
Local PDBA Address	=
192.168.15.115	
Remote PDBA Address	=
192.168.16.115	
Remote PDBA B Address	=
192.168.16.116	
Time Zone	=
America/New_York	
PDB Database	= Exists
Preferred PDB	= Standby
Allow updates from alternate PDB	= Yes
Auto DB Recovery Enabled	= Yes
PDBA Proxy Enabled	= No
-	
Press return to continue	

12.	MPS A:	MPS Side A:		
	Choose "e" to exit.			
		/EPAP Configuration Menu\		
			Display Configuration	
		2	Configure Network Interfaces Menu	
			Set Time Zone	
			Exchange Secure Shell Keys	
		5	Change Password	
		6	Platform Menu	
			Configure NTP Server	
		8	PDB Configuration Menu	
		9	Security	
			SNMP Configuration	
		11	Configure Alarm Feed	
		12	Configure Query Server	
		13	Configure Query Server Alarm Feed	
		14	Configure SNMP Agent Community	
		15	Mate Disaster Recovery	
		e	Exit	
		Enter	Choice: e	
13.	Return to the procedure th	that you came here from.		
14.	Note down the	Run the following command:		
Ш	timestamp in log.	\$ date		

Enable EPAP PDBA Proxy and EPAP VIP Optional Features

Ensure the provisioning activity has been halted before proceeding!!!

Appendix A.20 Enable EPAP PDBA Proxy and EPAP VIP Optional Feature

S T	This procedure outlines the steps for provisioning the PDBA proxy VIP.				
E	Estimated time: 10 minutes				
P #					
1.	MPS A:	Login: epapdev Password: <epapdev_password></epapdev_password>			
	Log in as				
	epapdev to 1A server.				
2.	MPS A:	\$ syscheck Running modules in class hardware			
	Perform	ОК			
	"syscheck" on	Running modules in class proc OK			
	the 1A server.	Running modules in class net OK			
		Running modules in class disk OK			
		Running modules in class services OK			
		Running modules in class system OK			
		LOG LOCATION: /var/TKLC/log/syscheck/fail_log			
		Note: syscheck may report following error which can be ignored: * defaultroute: FAILURE:: MINOR::5000000000040000 Platform			
		Health Check Failure			
		* defaultroute: FAILURE:: ping6 return non-zero code			
		* defaultroute: FAILURE:: MAJOR::300000000000000000000000000000000000			
		Server Default Route Network Error * defaultroute: FAILURE:: The IPv6 default route at			
		fe80::f64e:5ff:fe49:9b7f cannot be pinged			
		\$ssh mate			
3.	MPS A:	\$331 IIIQCC			
	SSH to EPAP 1B.	\$ syscheck			
4.	MPS B: Perform "syscheck" on	Running modules in class hardware OK			
		Running modules in class proc OK			
	the 1B.	Running modules in class net OK			
		Running modules in class disk OK			
		Running modules in class services OK			
		Running modules in class system OK			
		LOG LOCATION: /var/TKLC/log/syscheck/fail_log			
		Note: syscheck may report following error which can be ignored:			

5.	MPS B: Exit back to the 1A server	* defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000
6.	Log in to	Password:
	epapconfig	Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.
7.	MPS A: Choose option "1" to display Configuration.	MPS Side A: /EPAP Configuration Menu 1 Display Configuration 2 Configure Network Interfaces Menu 3 Set Time Zone 4 Exchange Secure Shell Keys 5 Change Password 6 Platform Menu 7 Configure NTP Server 8 PDB Configuration Menu 9 Security 10 SNMP Configuration 11 Configure Alarm Feed 12 Configure Query Server 13 Configure Query Server Alarm Feed 14 Configure SNMP Agent Community 15 Mate Disaster Recovery e Exit Enter Choice: 1
8.	MPS A:	MPS Side A: EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116 Provisioning Network Netmask = 255.255.255.0

	T	I pour defendant present les Colles et la	102 100 01 1
	Verify that the VIP is not configured.	Provisioning Network Default Router EPAP A Backup Prov Network IP Address EPAP B Backup Prov Network IP Address Backup Prov Network Netmask Backup Prov Network Default Router EPAP A Sync Network Address EPAP B Sync Network Address EPAP B Main DSM Network Address EPAP B Main DSM Network Address EPAP B Backup DSM Network Address EPAP B Backup DSM Network Address EPAP B HTTP Port EPAP B HTTP Port EPAP B HTTP SUEXEC PORT EPAP B HTTP SUEXEC PORT EPAP B Banner Connection Port EPAP B Banner Connection Port EPAP B Static NAT Address EPAP B ATTP PORT EPAP B ATTP PORT EPAP B A Static NAT Address EPAP B A Static NAT Address EPAP B A Static NAT Address EPAP B Static NAT Address EPAP B Static NAT Address EPAP B Address Remote PPBA Address Remote PDBA Address Remote PDBA Address Remote PDBA B Address Time Zone PDB Database Preferred PDB Allow updates from alternate PDB Auto DB Recovery Enabled PDBA Proxy Enabled	= Not configured = Not configured = Not configured = 192.168.2.100 = 192.168.120.100 = 192.168.120.200 = 192.168.121.200 = 192.168.121.200 = 80 = 80 = 80 = 8001 = 8001 = 8473 = Not configured = 192.168.61.115 = 192.168.61.181 = 192.168.61.182 = America/New_York = Exists = Standby
		Press return to continue MPS Side A:	
9.	MPS A:	MITS STUE A.	
	Choose option "2" to enter the "Configure Network Interfaces Menu".		

		/EPAP Configuration Menu\
		/\ 1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		7 Configure NTP Server
		8 PDB Configuration Menu
		 11 Configure Alarm Feed
		Configure Query Server
		13 Configure Query Server Alarm Feed
		Configure SNMP Agent Community
		Mate Disaster Recovery
10	MPS A:	Enter Choice: 2 MPS Side A:
10.	Choose option	/Configure Network Interfaces Menu\
	"6" to enter the	/\ 1 Configure Provisioning Network
	"Configure	
	Provisioning VIP Addresses	3 Configure DSM Network
	Menu".	
		\/
11	NADC A.	Enter Choice: 6 Verifying root connectivity with mate
11.	MPS A:	EPAP software and PDBA are running. Stop them? [N]: Y EPAP software is running on mate MPS. Stop it? [N]: Y
		EPAP local provisioning Virtual IP Address [0.0.0.0]: 192.168.15.152
		EPAP remote provisioning Virtual IP Address [0.0.0.0]: 192.168.15.172

	Enter "Y" to stop PDBA / EPAP software then enter VIP address for the local and remote PDBA sites.		
12.	MPS A:	MPS Side A:	
	Choose option	/Configure Network Interfaces Menu\ /\	
	"e" to exit.	1 Configure Provisioning Network	
		2 Configure Sync Network	
		3 Configure DSM Network	
		4 Configure Backup Provisioning Network	
		5 Configure Static NAT Addresses	
		6 Configure Provisioning VIP Addresses	
		e Exit	
		Enter Choice: e	
13.	MPS A:	MPS Side A:	
	Choose option		
	"1" to "Display		
	Configuration.		

		/EPAP Configuration Menu\
		1 Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10 SNMP Configuration
		Configure Alarm Feed
		12 Configure Query Server
		13 Configure Query Server Alarm Feed
		Configure SNMP Agent Community
		 15
		\\\/
		Enter Choice: 1 MPS Side A:
14.	MPS A:	EPAP A Provisioning Network IP Address = 192.168.61.115
	Verify VIP addresses	EPAP B Provisioning Network IP Address = 192.168.61.116 Provisioning Network Netmask = 255.255.255.0
	addresses	Provisioning Network Default Router = 192.168.61.1
		EPAP A Backup Prov Network IP Address = Not configured EPAP B Backup Prov Network IP Address = Not configured
		Backup Prov Network Netmask = Not configured Backup Prov Network Default Router = Not configured ERAP A Sync Network Address = 192 168 2 100
		EPAP A Sync Network Address = 192.168.2.100 EPAP B Sync Network Address = 192.168.2.200
		EPAP A Main DSM Network Address = 192.168.120.100 EPAP B Main DSM Network Address = 192.168.120.200
		EPAP A Backup DSM Network Address = 192.168.121.100 EPAP B Backup DSM Network Address = 192.168.121.200
		EPAP A HTTP Port = 80
		EPAP B HTTP Port = 80 EPAP A HTTP SUExec Port = 8001
		EPAP B HTTP SUExec Port = 8001 EPAP A Banner Connection Port = 8473
		EPAP B Banner Connection Port = 8473 EPAP A Static NAT Address = Not configured
		EPAP B Static NAT Address = Not configured PDBI Port = 5873
		Remote MPS A Static NAT Address = Not configured Remote MPS A HTTP Port = 80
		Local Provisioning VIP = 192.168.15.152
		Local PDBA Address = 192.168.15.115
		Remote PDBA Address = 192.168.16.115 Remote PDBA B Address = 192.168.16.116

		Time Zone = America/New_York PDB Database = Exists Preferred PDB = Standby Allow updates from alternate PDB = Yes Auto DB Recovery Enabled = Yes PDBA Proxy Enabled = No	
15.	MPS A:	Press return to continue	
15.	MPS A: Choose "e" to exit	/EPAP Configuration Menu	
16.	MPS A:	<pre>\$ ping <local vip=""></local></pre>	
	Verify that you can ping both VIP addresses.	<pre>\$ ping <remote vip=""></remote></pre>	
17.	MPS A:	\$ su - epapconfig	
	Log in to epapconfig	Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.	
18. 3	MPS A:		
8	Enter "1" to		
	"Display		
	Configuration"		

/EPAP Configuration Menu\
/\ 1 Display Configuration
2 Configure Network Interfaces Menu
3 Set Time Zone
 4 Exchange Secure Shell Keys
 5 Change Password
 8 PDB Configuration Menu
 9 Security
 10 SNMP Configuration
 12 Configure Query Server
 13 Configure Query Server Alarm Feed
Configure SNMP Agent Community
 15 Mate Disaster Recovery
\`'/
Enter Choice: 1 MPS Side A:
EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116 Provisioning Network Netmask = 255.255.255.0
S

20	MDC A.	PDB Database = Exists Preferred PDB = Standby Allow updates from alternate PDB = Yes Auto DB Recovery Enabled = Yes PDBA Proxy Enabled = NO Press return to continue MPS Side A:	
20.	MPS A: Choose option "8" to display "PDB Configuration Menu	/EPAP Configuration Menu\ 1 Display Configuration 2 Configure Network Interfaces Menu 3 Set Time Zone 4 Exchange Secure Shell Keys 5 Change Password 6 Platform Menu 7 Configure NTP Server 8 PDB Configuration Menu 9 Security 10 SNMP Configuration 11 Configure Alarm Feed 12 Configure Query Server 13 Configure Query Server 14 Configure SNMP Agent Community 15 Mate Disaster Recovery 16 Exit	
21.	MPS A: Choose option "6" to "Change PDBA Proxy State".	/\	

22.	MPS A: Enter "Y" to stop PDBA / EPAP software and enable PDBA Proxy.	EPAP software and PDBA are running. Stop them? [N]: Y EPAP software is running on mate MPS. Stop it? [N]: Y PDBA PROXY is currently DISABLED. Do you want to ENABLE PDBA Proxy? [N]: Y	
23.	MPS A:	MPS Side A:	
23.	Enter "e" to exit	/ Confirme DDD Many	
24.	MPS A:		
	Enter "1" to "Display Configuration"		
25.	MPS A:	MPS Side A	
	Verify that the state of PDBA Proxy Feature is Yes.	MPS Side A EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116 Provisioning Network Netmask = 255.255.255.0 Provisioning Network Default Router = 192.168.61.1 EPAP A Backup Prov Network IP Address = Not configured EPAP B Backup Prov Network IP Address = Not configured Backup Prov Network Netmask = Not configured Backup Prov Network Default Router = Not configured EPAP A Sync Network Address = 192.168.2.100 EPAP A Sync Network Address = 192.168.2.200 EPAP A Main DSM Network Address = 192.168.120.100 EPAP B Main DSM Network Address = 192.168.120.200 EPAP A Backup DSM Network Address = 192.168.121.100 EPAP B Backup DSM Network Address = 192.168.121.200 EPAP A HTTP PORT = 80 EPAP A HTTP PORT = 80 EPAP A Banner Connection Port = 8473 EPAP B Banner Connection Port = 8473 EPAP B Static NAT Address = Not configured EPAP B Static NAT Address = NOT EPAP STATE EPAP A STATIC NAT Address = NOT EPAP STATE EPAP A STATIC NAT Address = NOT EPAP STATE EPAP A STATIC NAT Address = NOT EPAP STATE EPAP A STATIC NAT Address = NOT EPAP STATE EPAP A STATIC NAT Address = NOT EPAP STATE EPAP A STATIC NAT Address = NOT EPAP STATE EPAP A STATIC NAT Address = NOT EPAP STATE EPAP A STATIC NAT Address = NOT EPAP STATE EPAP A STATE NAT ADDRESS = NOT EPAP STATE EPAP A STATE NAT ADDRESS = NOT EPAP STATE EPAP A	

		Remote PDBA B Address = 192.168.16.116 Time Zone = America/New_York PDB Database = Exists Preferred PDB = Standby Allow updates from alternate PDB = Yes Auto DB Recovery Enabled = Yes PDBA Proxy Enabled = Yes	
26.	MPS A: Enter "e" to exit	MPS Side A: /EPAP Configuration Menu 1 Display Configuration	
		10 SNMP Configuration	
27.	MPS A: EPAP A: Log in to the web GUI as user "uiadmin".	User name: <i>uiadmin</i> Password:	

28.	MPS A: Start	A Start EPAP Software	
20.	EPAP and PDBA	PDBA	
	Software.	☑ Check if you want to start the PDBA software along with the EPAP software. Are you sure you want to start the EPAP software? Are you sure you want to start the EPAP software?	
		Start EPAP Software	
	On the menu,	Tue June 09 2020 07:21:32 EDT Copyright © 2000, 2020, Oracle and/or its affiliates. All rights reserved.	
	click Process		
	Control->Stap		
	Software.		
	Click "Stap EPAP	·	
	Software"		
	Button		
		\$ syscheck	
29.	MPS A:	Running modules in class hardware	
	Perform "syscheck" on	Running modules in class proc	
	MPS-A.	OK Running modules in class net	
		OK Running modules in class disk	
		OK Running modules in class services	
		OK Running modules in class system	
		ОК	
		LOG LOCATION: /var/TKLC/log/syscheck/fail_log	
		Note: syscheck may report following error which can be ignored: * defaultroute: FAILURE:: MINOR::5000000000040000 Platform	
		Health Check Failure	
		* defaultroute: FAILURE:: ping6 return non-zero code	
		* defaultroute: FAILURE:: MAJOR::300000000000000000000000000000000000	
		Server Default Route Network Error * defaultroute: FAILURE:: The IPv6 default route at	
		fe80::f64e:5ff:fe49:9b7f cannot be pinged	
		resoo-re.one-re.ob/r carmot be pinged	
30.	MPS A:	\$ ssh mate	
	SSH to MPS 1B.		
31.	MPS B:	<pre>\$ systemctl start Epap ~~ /etc/init.d/Epap start ~~</pre>	
	Start Epap	"EPAP RELEASE" is set to "0.613"	
	software on MPS 1B.	EPAP application start Successful	
22	MPS B:	\$ syscheck	
32.	Perform	Running modules in class hardware OK	
	"syscheck" on	Running modules in class proc OK	
	MPS 1B.	Running modules in class net OK	
		Running modules in class disk	
		OK	

		Running modules in class services OK Running modules in class system OK LOG LOCATION: /var/TKLC/log/syscheck/fail_log Note: syscheck may report following error which can be ignored: * defaultroute: FAILURE:: MINOR::500000000000000000000000000000000000	
33.	Return to the proce	dure that you came here from.	
34.	Note down the timestamp in log.	Run the following command: \$ date	

Configure DSM Min Mem Size

S	This procedure configures DSM Min Mem Size on standalone PDB server.	
Т	Check off (√)each step as it is completed. Boxes have been provided for this purpose under each step number.	
E P #	IF THIS PROCEDURE FAILS, CONTACT Error! Reference source not found. AND ASK FOR <u>INSTALL</u> ASSISTANCE .	
π	C. II DDD	Login: epapdev
1.	Standalone PDB :	Password: <epapdev_password></epapdev_password>
	Log in as epapdev to	
	standalone PDB server.	
2.	Run	Go to the bin directory to run the getDsmMinMemSize.pl perl script
	getDsmMinMemSize.pl	\$ cd /usr/TKLC/epap/bin
		Run the getDsmMinMemSize.pl script
		\$./ getDsmMinMemSize.pl
3.	Restart the pdb Software. \$ systemct1 stop Pdba	
Ιп	·	~~ /etc/init.d/Pdba stop ~~
		PDBA application stopped.
		\$ systemctl start Pdba

4.	Verify that the uiEdit "DSM_MIN_MEM_SIZE" variable is added and updated correctly.	~~ /etc/init.d/Pdba start ~~ PDBA application started. \$ systemct1 Pdba status ~~ /etc/init.d/Pdba status ~~ PDBA application is running. \$ uiEdit grep DSM_MIN_MEM_SIZE "DSM_MIN_MEM_SIZE" is set to "12046"
5.	Procedure Complete	Procedure is complete.
6.	Note down the timestamp in log.	Run the following command: \$ date

Appendix A.22 Restart Mysql service for PDB on Query Server

endix A. 22 Restart MySQL service for PDB on Query Server

NOTE: The MySQL services should be started as non-root admin user only.

S	This procedure restarts the MySQL service for PDB on Query Server.		
T	Check off ($$)each step as it is completed. Boxes have been provided for this purpose under each step number.		
Ε	IF THIS PROCEDURE FAILS, CONTACT Error! Refer	ence source not found AND ASK FOR INSTALL	
Р	ASSISTANCE.	CHEC Source Hot found. The ASK FOR HOTALE	
#			
1.	Log in to EAGLE QS as QS admin.	login: <admin_user></admin_user>	
		Password: <admin_password></admin_password>	
2.	Start the mysglpdb service.	\$ sudo systemctl stop mysqld	
	Start the mysqipus service.		
		Waiting for mysqlpdb to stop	
3.	Verify that mysqlpdb service is running.	\$ sudo systemctl start mysqld	
		Waiting for mysqlpdb to start done	
4.	Start the mysglpdb service.	\$sudo systemctl start mysqld	
7.	, ''	PID:8841 mysqlpdb is running.	

endix A. 22 Restart MySQL service for PDB on Query Server

NOTE: The MySQL services should be started as non-root admin user only.

5.	Procedure Complete	Procedure is complete.
6.	Note down the timestamp in log.	Run the following command:
		\$ date

Procedure A.23 Get parse9Dig file from EPAP 16.3 ISO

Appendix A. 23 Get parse9Dig file from EPAP 16.3 ISO

S	This procedure extract parse9Dig script file from EPAP 16.3 ISO.		
T	Check off ($$)each step as it is completed. Boxes have been provided for this purpose under each step number.		
E	IF THIS PROCEDURE FAILS, CONTACT Error! Reference source not found. AND ASK FOR INSTALL		
P #	ASSISTANCE.		
1.	MPS A: Log in as admusr.	login: <admin_user> Password: <admin_password></admin_password></admin_user>	
2.	MPS A: Copy ISO on MPS A.	Perform 0 or copy EPAP 17.1 ISO to /var/TKLC/upgrade directory.	
3.	MPS A: Switch to root user.	Switch to root user. \$ su - root Password:	
4.	MPS A: Create directory using mkdir.	Create /mnt/iso directory using following command: # mkdir /mnt/iso	
5.	MPS A: Mount ISO on above path	Mount ISO on above created path. # mount -o loop <16.3.a.0.0-b.b.b ISO with full path which is copied in step 2> <full 4="" created="" directory="" in="" of="" path="" step=""> As follows:</full>	

Appendix A. 23 Get parse9Dig file from EPAP 16.3 ISO

		# mount -o loop /var/TKLC/upgrade/EPAP- 16.3.0.0.0_163.8.0-x86_64.iso /mnt/iso/
6.	MPS A: Extract TKLCepap rpm from the ISO.	Copy TKLCepap rpm at /tmp directory. # cp <directory 4="" created="" in="" step="">/Packages/<tklcepap 2="" copied="" in="" is="" rpm,="" same="" step="" the="" version="" which=""> /tmp As follows: # cp /mnt/iso/Packages/TKLCepap-163.0.8- 16.3.0.0.0_163.8.0.x86_64.rpm /tmp/</tklcepap></directory>
7.	MPS A: Change directory to /tmp.	Change directory to /tmp using following command: # cd /tmp
8.	MPS A: Extract parse9Dig script file from rpm.	# rpm2cpio <tklcepap 6="" extracted="" in="" rpm="" step=""> cpio -idmv <parse9dig> As follows: # rpm2cpio TKLCepap-163.0.8-16.3.0.0.0_163.8.0.x86_64.rpm cpio -idmv ./usr/TKLC/epap/config/parse9Dig [root@Natal-A tmp]</parse9dig></tklcepap>
9.	MPS A: Copy extracted parse9Dig at desired path.	Copy extracted parse9Dig file at path: /usr/TKLC/epap/config Use following path: # cp /tmp/usr/TKLC/epap/config/parse9Dig /usr/TKLC/epap/config
10.	MPS A: Change the permission of parse9Dig file as required.	Change mode of file parse9Dig to 755 and ownership to epapdev:epap. Use following command: # cd /usr/TKLC/epap/config # chmod 755 parse9Dig # chown epapdev:epap parse9Dig List the file and check the permissions. It should be same as follows: # 11 parse9Dig

Appendix A. 23 Get parse9Dig file from EPAP 16.3 ISO

		[root@Natal-A config]# 11 parse9Dig
		-rwxr-xr-x 1 epapdev epap 12162 Jul 9 21:39 parse9Dig
		-
11.	MPS A: Snapshot of all above executed commands to extract parse9Dig file.	Verify that all steps executed successfully as follows: [root@Natal-A -]# mkdir /mnt/iso [root@Natal-A -]# mkdir /mnt/iso [root@Natal-A -]# munt -o loop /var/TKLC/EPAP-16.3.0.0.0_163.8.0-x86_64.iso /mnt/iso/ /var/TKLC/EPAP-16.3.0.0.0_163.8.0-x86_64.iso /mnt/iso/ [root@Natal-A -]# munt -o loop /var/TKLC/EPAP-16.3.0.0.0_163.8.0-x86_64.iso /mnt/iso/ [root@Natal-A -]# [root@Natal-A -]# [root@Natal-A -]# munt -o loop /var/TKLC/upgrade/EPAP-16.3.0.0.0_163.8.0-x86_64.iso /mnt/iso/ [root@Natal-A -]#
12.	MPS A: Remove all temporary files from /tmp directory.	Remove parse9Dig file and TKLCepap rpm from /tmp directory. Execute following command on CLI: # rm -f /tmp/usr/TKLC/epap/config/parse9Dig # rm -f /tmp/TKLCepap-163.0.12- 16.3.0.0.0_163.12.0.x86_64.rpm
13.	MPS A: Umount the mounted ISO.	Umount the ISO which was mounted in step 5. Execute below command: # umount /mnt/iso/
14.	MPS A: Remove ISO directory.	Remove directory /mnt/iso. Execute below command: # rmdir /mnt/iso/
15.	Procedure Complete	Procedure is complete.
16.	Note down the	Run the following command:
	timestamp in log.	\$ date

Procedure A.24 Procedure to add/edit the /etc/minirc.mate file

NOTE: This procedure is needed in following cases:

- 1. If "minicom mate" fails due to data curroption or somebody deleted the file /etc/minirc.mate. Or,
- 2. If ttyS1 is not working, then edit the file /etc/minirc.mate to use ttyS3 or ttyS4.

Appendix A. 24 Procedure to add/edit the /etc/minirc.mate file

S T	This procedure will	add/edit the file /etc/minirc.mate.
E	Check off (√) each step	as it is completed. Boxes have been provided for this purpose under each step number.
P #	IF THIS PROCEDURE I	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .
1.	MPS: Log in to the Server.	[hostname] consolelogin: admusr password: password
2.	MPS: Switch user to root.	\$ su - root Password:
3.	MPS: Verify that the file present on server.	Verify that the file /etc/minirc.mate is present on server: Run the following command:
		<pre>\$ ls -l /etc/minirc.mate [root@Recife-a ~]# ls -l /etc/minirc.mate</pre>
		-rw-r 1 root root 658 Sep 7 03:35 /etc/minirc.mate
		Move to step 5 if output is same as above otherwise continue to next step.
4.	MPS: Cretae the file using vi editor.	Create the file /etc/minirc.mate using vi editor as follows: \$ vi /etc/minirc.mate
		Add following lines in file /etc/minirc.mate and save the file:
		# minirc file generated by remoteConsole Mon Sep 10 09:53:54 2018 pr port

Appendix A. 24 Procedure to add/edit the /etc/minirc.mate file

	pu pname9 YUNYN
	pu zauto
	pu fselw No
	pu askdndir No
MPS: Edit the file	If ttS1 is not working then edit the file /etc/minirc.mate and update ttyS1 to ttyS2 of ttyS1 to ttyS3 and change the serial cable connectivity accordingly.
/etc/minirc.mate	try51 to try55 and change the serial cable connectivity accordingly.
	In following example, we have updated the file /etc/minirc.mate and changed the port value from ttyS1 to ttyS2.
	\$ vi /etc/minirc.mate
	#
	# minirc file generated by remoteConsole Mon Sep 10 09:53:54 2018
	pr port /dev/ttyS2
	pu baudrate 115200
	pu bits 8
	pu parity N
	pu stopbits 1
	pu rtscts No
	pu xonxoff No
	pu minit
	pu minit pu mreset
	-
	pu mhangup
	pu pname1 YUNYY
	pu pname2 YUNYY
	pu pname3 YUNYN
	pu pname4 NDNYY
	pu pname5 NDNYY
	pu pname6 YDNYN
	pu pname7 YUYNN
	pu pname8 NDYNN
	pu pname9 YUNYN
	pu zauto
	pu fselw No
	pu askdndir No
	pu ubitalia i i
	NOTE: In order to make this changes working we must need to change the serial cable connectivity with lsmspri and lsmssec.
	In following figure we have changed the serial connectivity from
	ttyS0(lsmspri) <-> ttyS1(lsmssec) to ttyS0(lsmspri) <-> ttyS2(lsmssec)
	and
	ttyS0(lsmssec) <-> ttyS1(lsmspri) to ttyS0(lsmssec) <-> ttyS2(lsmspri)
	lsmspri lsmssec
	##S0 \$ ###S0
	ttyS0 ttyS0
	ttyS1 ttyS1
	ttyS2 ttyS2
<u> </u>	

Upgrade/Installation Guide

338 of 450 June 2025

Appendix A. 24 Procedure to add/edit the /etc/minirc.mate file

		ttyS3 ttyS3
		Here, broken line showing the old connectivity and bold line for the new connecrtivity.
6.	MPS: Run "minicom mate" on the server.	Run the following command: \$minicom mate It should be successfully switched to mate server.
7.	MPS: Procedure completed	This procedure is complete.
8.	Note down the timestamp in log.	Run the following command: \$ date


Procedure A.25 Configure the Auto Backup

This procedure configures auto backup for PDB and RTDB on all the Non-PROVs that are homed to the PDBA.

EPAP software on all Non-PROVs homed to the PDBA should be running for successful auto RTDB backup on the Non-PROVs.

Appendix A.25 Configure the Auto Backup

S		This procedure enables the auto backup feature for the Provisioning Database.
E P	1A	Estimated time: 5 minutes
#		



This procedure is complete!

Procedure A.26 STOP ACTIVE PDBA AND VERIFY REPL LOGS

This procedure shall be performed on Active PDBA (2A). If REPL log in not empty, part of the procedure will be performed in Standby PDBA (1A) as well.

Appendix A.26 Procedure to add/edit the /etc/minirc.mate file

P		
#		
1.	MPS 2A:	NOTE:
	Stop the Customer provisioning in to the active PDB.	Contact customer provisioning and verify provisioning has been deactivated.
2.	MPS 2A: Log on Server.	[hostname] consolelogin: admusr password: password
3.	MPS 2A: Switch user to root.	\$ su - root Password:

4	1400 04 0	
4.	MPS 2A: Stop the	•
	PDBA process	~~ /etc/init.d/Pdba stop
		~~ PDBA application
		stopped.
5.	MPS 2A: Stop the	# service Epap stop
	EPAP process	~~ /etc/init.d/Epap stop ~~
	•	EPAP application stopped.
6.	MPS 2A: Clear the	\$ mysql -u root -p -S/var/TKLC/epap/db/pdb/mysql.sock <
	REPL logs	/usr/TKLC/epap/config/pdb_repl.sql
	NET L 10g3	Enter password: <mysql_root_password></mysql_root_password>
		·
7.	MPS 2A: Log in to	\$ mysql -u root -p -S/var/TKLC/epap/db/pdb/mysql.sock pdb
	the mysql database	Enter password: <mysql_root_password></mysql_root_password>
	and verify that there	On the MySQL prompt, Run the following commands:
	are no updates to	mysql> select * from
	be sent to the	replLog; Empty set (0.00 sec)
	standby PDB.	mysql> select * from
	If any REPL log	requests;
	exists, follow steps 8	Empty set (0.00 sec)
	to 12. Otherwise	mysql> quit
	jump to step 13	Bye
8.		· ·
l l	MPS 1A: Start the	# service Pdba start~~
	PDBA and EPAP at	/etc/init.d/Pdba start
	the Standby site	~~ PDBA application
	(1A)	started.
		# service Epap start ~~
		/etc/init.d/Epap start
		~~ EPAP application
		started.
		Note: Skip the following step on Standalone PDB
		# ssh mate "service Epap start"
		~~ /etc/init.d/Epap start ~~
		EPAP application started.
9.	14DC 24	* *
9.	MPS 2A:	# service Pdba start ~~
	Start the PDBA at	/etc/init.d/Pdba start
	the	~~ PDBA application
	Active site (2A)	started.
		# service Epap start ~~
		/etc/init.d/Epap start
		~~ EPAP application
		started.
		Note: Skip the following step on Standalone PDB
		# ssh mate "service Epap start"
		· ·

		~~ /etc/init.d/Epap start ~~ EPAP application started.
10.	MPS 2A:	\$ mysql -u root -p -S/var/TKLC/epap/db/pdb/mysql.sock pdb
	Wait a minute for	Enter password: <mysql_root_password></mysql_root_password>
	the updates to sync between	On the MySQL prompt, Run the following commands: mysql> select * from
	Active and Standby	replLog; Empty set (0.00 sec)
	PDBA.	mysql> select * from
	Check in intervals of 1 minute till all	requests; Empty set (0.00 sec)
	updates are sent	mysql> quit
	from Active PDBA	Bye
	to Standby PDBA.	
	Move to next stepONLY after	
	checking that	
	output of replLog	
	and requests tables shows "Empty set".	
11.	MPS 2A:	# service Pdba stop
	Stop the PDBA and	~~ /etc/init.d/Pdba stop ~~
	EPAP processes.	PDBA application stopped.
		# service Epap stop
		~~ /etc/init.d/Epap stop ~~
		EPAP application stopped.
12.	MPS 1A:	# service Pdba stop
	Stop the PDBA and	~~ /etc/init.d/Pdba stop ~~ PDBA application stopped.
	EPAP processes.	гова аррисаціон зторрец.
		# service Epap stop
		~~ /etc/init.d/Epap stop ~~
		EPAP application stopped.

13.	MPS 2A: Exit as root user	\$ exit
14.	Note down the timestamp in log.	Run the following command: \$ date

Procedure A.27 PDB Backup before upgrade

S T	This procedure will perform pdb Backup		
E			
P #	Estimated time of completion: 5 minutes.		
	Check off ([]) each stenumber.	ep as it is completed. Boxes have been provided for this purpose under each step	
	SHOULD THIS PROCEDURE FAIL,	CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .	
	PROCEDURE APPLICABLE TO: SI	andalone PDB, Mixed EPAP	
1	Log in to MPS A via root	login: <root_user></root_user>	
	user	Password: <admin_password></admin_password>	
2	Stop PDB software	[root@Salta-a logs]# service Pdba stop	
Ш		~~ /etc/init.d/Pdba stop ~~	
		PDBA application stopped.	
		Change the directory to free, to generate the mysqldump in free directory. # cd /var/TKLC/epap/free	
	Generate mysqldump of	[root@Manaus-A free]# mysqldump -uroot -peLapRoot pdb -S	
11	PDB database: Run the following	/var/TKLC/epap/db/pdb/mysql.sock > mysqldump_filename.sql &	
	command to create	Example:	
	mysql dump od PDB to	[root@Devloan01 ~]# mysqldump -uroot -peLapRoot pdb -S	
	restore later after the	/var/TKLC/epap/db/pdb/mysql.sock >	
	upgrade.	mysqldump_Devloan01_01133307182024.sql&	
	Note:	[1] 29910	
	Note: mysqldump_filename	[root@Devloan01 ~]# mysqldump: [Warning] Using a password on the command line interface can be insecure.	
	· · · -	interface can be insecure.	
	can be anything		

4 MPS X: Transfer file to	Using SFTP (secure-FTP), transfer the file to a remote, customer-provided
remote machine	computer. Enter "yes" when prompted if you want to continue to connect.
	\$ cd /var/TKLC/epap/free
	\$ sftp admusr@10.75.141.58
	Connecting to 10.75.141.58
	FIPS integrity verification test failed.
	The authenticity of host '10.75.141.58 (10.75.141.58)' can't be established.
	RSA key fingerprint is 16:cf:0f:bb:cd:c3:45:8c:bf:5f:02:2b:96:4f:d1:61.
	Are you sure you want to continue connecting (yes/no)? yes
	Warning: Permanently added '10.75.141.58' (RSA) to the list of known hosts. admusr@10.75.141.58's password:
	sftp> put mysqldump_Recife_01133307182024.sql
	Uploading mysqldump_Recife_01133307182024.sql to
	/var/TKLC/elap/free/epap_spare_card_backup/mysqldump_Recife_011333071820 24.sql
	mysqldump_Recife_01133307182024.sql
	100% 30GB 76.0MB/s 06:45
	sftp> bye
	If there is no customer provided remote computer for backups, transfer the backup file to the mate using the following command: \$ sudo chmod 667 /var/TKLC/epap/free/bkp.tar.gz
	\$ su — epapdev
	\$ scp /var/TKLC/epap/free/ mysqldump_Devloan01_01133307182024.sql
	epapdev@remoteIP: <remote path="" server=""></remote>
3 This procedure is	
complete.	This procedure is complete.

Procedure A.28 Clear replication logs

S	This procedure will clear the replication logs for the Standalone PDBA and Mixed EPAP
Т	
E	Ensure the provisioning activity has been halted before proceeding!!!

P #	Estimated time of completion: 5 minutes.		
	Check off (\Box) each step as it is completed. Boxes have been provided for this purpose unstep number.		
SHOULD THIS PROCEDURE FAIL, CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .		IL, CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .	
	PROCEDURE APP	LICABLE TO: Dual PDB and Dual Mixed EPAP	
2	Active PDB: Switch from root to the epapdev user. Note:Ensure the provisioning activity has been halted before proceeding. Active PDB:	# su - epapdev \$ mysql -u root -p -S/var/TKLC/epap/db/pdb/mysql.sock pdb	
	Log in to the mysql database and determine the size of replLogs. Enter password once requested.	Enter password: <password> Reading table information for completion of table column names You can turn off this feature to get a quicker startup with -A Welcome to the MySQL monitor. Commands end with; or \g. Your MySQL connection id is 108 Server version: 5.0.37-community-log MySQL Community Edition (GPL) Type 'help;' or '\h' for help. Type '\c' to clear the buffer. mysql> select count(*)</password>	

3	Active PDB: Clear the REPL logs.	\$ mysql -u root -p -S/var/TKLC/epap/db/pdb/mysql.sock < /usr/TKLC/epap/config/pdb_repl.sql
	Enter password once requested.	Enter password: <password></password>
4	Active PDB :	\$ mysql -u root -p -S/var/TKLC/epap/db/pdb/mysql.sock pdb
	Log in to the mysql database and verify that there are no updates to be sent to the standby PDB.	Enter password: <password></password>
		Reading table information for completion of table column names You can turn off this feature to get a quicker startup with -A
	Enter password once requested.	Welcome to the MySQL monitor. Commands end with ; or \g. Your MySQL connection id is 108
	If any REPL logs exist, restart the	Server version: 5.0.37-community-log MySQL Community Edition (GPL) Type 'help;' or '\h' for help. Type '\c' to clear the buffer.
	PDBA application and allow them to replicate to the	mysql> select count(*) from replLog; Empty set (0.00 sec)
	Standby PDB, then repeat this procedure.	mysql> select count(*) from requests; Empty set (0.00 sec)
	procedure.	mysql> quit
		Bye
5	Active PDB EPAP A:	\$ exit
	Switch from epapdev to root user.	
6	Standby PDB	Repeat all above steps on standby PDB as well.
7	This procedure is complete.	This procedure is complete.

Procedure A.29 Remove remote PDBA IP

S T	This procedure will delete the remote PDBA IP Address
Е	Ensure the provisioning activity has been halted before proceeding!

P	Estimated time of comp	stimated time of completion: 5 minutes.		
#	Check off (□) each step as it:	k off (\Box) each step as it is completed. Boxes have been provided for this purpose under each step number.		
	Check on () each step as it is completed. Boxes have been provided for any purpose under each step number.			
	SHOULD THIS PROCEDURE FAIL, (CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .		
	PROCEDURE APPLICABLE TO: Sta	andalone PDBA and Mixed EPAP		
1	Log in to root upon first	/EPAP Configuration Menu\		
_	Log in to root user first and then switch to	//\		
Ч	epapconfig and select option 8			
	option 8			
	Note: Ensure the	3 Set Time Zone 4 Exchange Secure Shell Keys		
	provisioning activity has been halted before			
	proceeding	5 Change Password		
		6 Platform Menu 		
		8 PDB Configuration Menu		
		9 Security		
		10 SMMF CONTINUITATION		
		12 Configure Query Server		
		12 Gonfigure Query Server Alarm Feed		
		II		
		e Exit \/		
2	Calast aution 1	Enter Choice: 8		
	Select option 1	/Configure PDB Menu\		
		/\ 1 Configure PDB Network		
		 2 Configure PDB Capacity		
		 3 Create PDB		
		ii		
		4 Change Auto DB Recovery State 		
		e Exit		
		Enter Choice: 1		

3	Remove the remote PDBA	/PDB Network Configuration Menu-\
	IP by entering 0.0.0.0.	/\
		1 IPv4 Configuration
		2 IPv6 Configuration
		e Exit
		Enter Choice: 1
		This MPS is configured to be provisionable. The EPAP local PDBA IPv4 address is currently The EPAP local PDBA IPv6 address is currently set to 0000:0000:0000:0000:0000:0000:0000:
		The EPAP local PDBA IPv4 Address is 10.75.141.74.
	TI 5040	EPAP remote PDBA IP Address [0.0.0.0]: 0.0.0.0
	The EPAP	/EPAP Configuration Menu\
	Configuration Menu is	/\
	displayed. Enter	1 Display Configuration
	choice e, Exit.	
		2 Configure Network Interfaces Menu
		4 Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10 SNMP Configuration
		12 Configure Query Server
		13 Configure Query Server Alarm Feed
		14 Configure SNMP Agent Community
		15 DB Architecture Menu
		e Exit
		\/
		Enter Choice: e

4	This procedure is	
	complete.	This procedure is complete.

Procedure A.30 Reset RTDB Homing Policy to remote PDBA

In case of Prov upgrade (Mixed EPAP/PDBonly) with Live provisioning, the homing of all Non-Prov sites needs to be taken care of as below:

- a. Non-Prov sites: Change the RDTB homing to "Configure Active RTDB Homing" and select the active PDBA site, if RTDB homing is anything other than active PDBA. Refer to Procedure A.30.
- b. Prov Sites: On Both PDBA sites, RTDB homing policy should be set to its local PDBA. Refer to Procedure A.44.

Note: Change the RTDB homing on all Non-Provs. Stop the EPAP Softwares on both EPAP A and B servers.

- c. There is no need to stop provisioning.
- d. After the RTDB Homing changes, EPAP software will be started and within a few minutes, RTDBs will catch up with the PDBA level.
- e. The only side effect of this activity is that Eagle will not get live updates for around 10 minutes. As soon as EPAP software is started after the procedure, the provisioning data will be transmitted to the Eagle immediately.

S T	The process of the result of t		
E			
P #	Estimated time	e of completion: 5 minutes.	
	Check off (□)	each step as it is completed. Boxes have been provided for this purpose under each step number.	
	SHOULD THIS PROCE	EDURE FAIL, CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .	
	PROCEDURE APPLIC	ABLE TO: Non-Provisionable EPAPs	
1	MPS A:	#su - epapconfig	
	Switch to	Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.	

ation Menu\ guration work Interfaces Menu re Shell Keys ord
guration work Interfaces Menu re Shell Keys rd
re Shell Keys
re Shell Keys rd
re Shell Keys rd
rd
Server
tion Menu
ation
rm Feed
IP Agent Community
Recovery
re Menu
 /
/

3	Select option 2 to enter RTDB	/Configure PDB Menu\
	homing menu	1 Configure PDB Network
		2 RTDB Homing Menu
		3 Change Auto DB Recovery State
		e Exit
		Enter Choice: 2
4 🔲	Read the Note in the beginning of the section and decide your homing policy.	For Non-Prov Nodes: /RTDB Homing Menu
5	MPS B:	Start Epap and Pdba software to reflect the changes. Use the following command to start Epap: For EPAP 16.3.1/16.4.1, Run the following command to start PDBA and EPAP Softwares:

	Start Epap	\$ service Epap Start
	software.	\$ service Epap Start ~~ /etc/init.d/Epap start ~~ "EPAP_RELEASE" is set to "0.617" EPAP application start Successful.
		\$ service Pdba start ~~ /etc/init.d/Pdba start ~~ PDBA application start Successful.
		For EPAP 17.1, run the following command to start PDBA and EPAP Software:
		\$ systemctl start Epap
		\$ systemctl start Pdba
6	This	
	procedure	This procedure is complete.
	is	
	complete.	

Procedure A.31 Change MySql engine schema

Note: This procedure is need not to be implemented if migrating from 17.0.0.x.

S This procedure will Change MySql engine schema.		nge MySql engine schema.		
	! =			
F	>			
#	‡	Estimated time of completion: 5 minutes.		
		Check off (\square) each stenumber.	p as it is completed. Boxes have been provided for this purpose under each step	
		SHOULD THIS PROCEDURE FAIL, CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .		
		PROCEDURE APPLICABLE TO: Sta	andalone PDB, Mixed and Non-Provisionable EPAP	
	1	Log in to epap via epapdev	# su – epapdev	
		user on server being		
		upgraded		
		Note: In case of Mixed		
		or Non-Prov		
		EPAPPerform this		
		procedure needs to be		

	performed on MPS A & B.	
	Navigate to path /var/TKLC/epap/free	[root@Manaus-a /]# cd /var/TKLC/epap/free/ [root@Manaus-a free]#
3	Change the EuiDB engine using alter_Table.pl script Note: Download the alter_table.pl script from OSDC to free directory on EPAP and change its permission to 755. Also change its ownership to epapdev:epap.	[epapdev@Manaus-A free]\$ chown epapdev:epap alter_table.pl [epapdev@Manaus-A free]\$ chmod 755 alter_table.pl [epapdev@Manaus-A free]\$./alter_Table.pl Success.
	Check the update by logging in to EuiDB:	[epapdev@Manaus-A free]\$ mysql -uroot -peLapRoot mysql> use EuiDB; Reading table information for completion of table and column names You can turn off this feature to get a quicker startup with -A mysql> show table status\G; ***********************************
5	This procedure is complete.	This procedure is complete.

Procedure A.32 Post upgrade EuiDB database restore

S T	This procedure verifies that EuiDB is restored successfully.			
E P	Check off (\checkmark) each step as it is completed. Boxes have been provided for this purpose under each step number.			
#	IF THIS PROCEDURE FA	E FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR Migration ASSISTANCE .		
1.	Verify the MIN_DSM_MEM_SIZE and	If upgrading on EPAP 17.1, ensure to verify the following parameters and compare once the restore is complete:		
	PDB_SUB_CAPACITY	Perform the below commands to verify the		
		MIN_DSM_MEM_SIZE and PDB_SUB_CAPACITY:		
		uiEdit grep PDB_SUB_CAPACITY uiEdit grep DSM_MIN_MEM_SIZE uiEdit grep DB_ARCHITECTURE		
2.	Log in to EPAP server via epapdev user.	console login: epapdev password: <password></password>		
3.	Change the Euidb backup file permission to 644.	[epapdev@Manaus-A ~]\$ chmod 644 npdbBackup_Manaus-A_20220718183527.sql.gz		
4.	Restore EuiDB Database	[epapdev@Manaus-A ~]\$ /usr/TKLC/epap/bin/restore_npdb.pl /var/TKLC/epap/free/npdbBackup_Manaus-A_20220718183527.sql.gz Restoring up the NPDB NPDB Restored up Successfully. [epapdev@Manaus-A ~]\$		
5.	Verify the MIN_DSM_MEM_SIZE and PDB_SUB_CAPACITY	If upgrading on EPAP 17.1, ensure to verify the following parameters and compare once the restore is complete: Perform the below commands to verify the MIN_DSM_MEM_SIZE and PDB_SUB_CAPACITY: uiEdit grep PDB_SUB_CAPACITY uiEdit grep DSM_MIN_MEM_SIZE uiEdit grep DB_ARCHITECTURE		
6.	Procedure complete.			

Procedure A.33 Post upgrade PDB database restore

S T	This procedure verifies that PDB is restored successfully		
E P	Check off (\checkmark) each step as it is completed. Boxes have been provided for this purpose under each step number.		
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR Migration ASSISTANCE.		
1.	Log in to EPAP server via root user		
2.	If upgrading from EPAP 17.0.0.x to EPAP 17.1, perform this step. Else, continue from step 3. Perform Procedure A.52 to restore the PDB database. If Procedure A.52 is performed, this procedure (A.33) ends here.		
3.	Change the permission of mysqldump file to 666. Run the command.	7.1 1.5 04400007400004 7	
4.	Run the following command to restore myqldump.	To monitor time as well as progress while restoring the db please use the following command only: # pv mysqldump_backupfile.sql mysql -uroot -peLapRoot pdb -S /var/TKLC/epap/db/pdb/mysql.sock && echo "Restore complete" In case you don't want to monitor the progress use the following: # mysql -uroot -peLapRoot pdb -S /var/TKLC/epap/db/pdb/mysql.sock < mysqldump_backupfile.sql & Example: [root@Recife-A free]# mysql -uroot -peLapRoot pdb -S /var/TKLC/epap/db/pdb/mysql.sock < mysqldump_Recife_01133307182024.sql &	
5.	Run the following commands to add the Isblset parameter in dn_bl and dnB_bl tables in pdb.	The below commands will add lsblset column in dn_bl and dnB_bl table of PDB database.	

Note: This step is applicable only in case. user is migrating from 16.3 release regardless of DB architecture	<pre># mysql -u root -p pdb -S /var/TKLC/epap/db/pdb/mysql.sock -e 'ALTER TABLE dn_bl ADD lsblset int' # mysql -u root -p pdb -S /var/TKLC/epap/db/pdb/mysql.sock -e 'ALTER TABLE dnB_bl ADD lsblset int'</pre>
ur dinectiur c	Example: [root@Devloan01 ~]# mysql -u root -p pdb -S /var/TKLC/epap/db/pdb/mysql.sock -e 'ALTER TABLE dn_bl ADD lsblset int' Enter password: [root@Devloan01 ~]# mysql -u root -p pdb -S /var/TKLC/epap/db/pdb/mysql.sock -e 'ALTER TABLE dnB_bl ADD lsblset int' Enter password: [root@Devloan01 ~]#

Note: If one site is already upgraded to EPAP 17.1, then follow the steps in Appendix A.43 to restore the PDB.

Procedure A.34 Add Remote PDBA IP Address

S	This procedure will add	remote PDBA IP address	
Е	Ensure the provisioning activity has been halted before proceeding!!!		
P #	Estimated time of comp	pletion: 5 minutes.	
	Check off (\square) each stenumber.	ep as it is completed. Boxes have been provided for this purpose under each step	
	SHOULD THIS PROCEDURE FAIL, CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION ASSISTANCE</u> .		
	PROCEDURE APPLICABLE TO: Standalone PDB and Mixed EPAP		
1	Log in to epapconfig on PDB server being upgraded and select option 8.	Warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.	

		/EPAP Configuration Menu\		
		/\ 1 Display Configuration		
		Configure Network Interfaces Menu		
		3 Set Time Zone		
		4 Exchange Secure Shell Keys		
		5 Change Password		
		 6 Platform Menu		
		 7 Configure NTP Server		
		8 PDB Configuration Menu		
		9 Security		
		 10 SNMP Configuration		
		Configure Alarm Feed		
		Configure Query Server		
		 13 Configure Query Server Alarm Feed		
		14 Configure SNMP Agent Community		
		15 DB Architecture Menu		
		e Exit		
		\/		
2	Select option 1.	Enter Choice: 8		
	Select option 1.	/Configure PDB Menu\		
ш		/\		
		1 Configure PDB Network 		
		2 Configure PDB Capacity		
		3 Create PDB		
		4 Change Auto DB Recovery State		
		\/		
		Enter Choice: 1		
3	Add the remote PDBA	MPS Side A: hostname: Salta-a hostid: 4b0a4a8d		
П	IP by entering	Platform Version: 6.1.4-7.8.1.0.0_89.13.0		
	<remote ip="" pdba="">.</remote>	Software Version: EPAP 170.0.1-17.0.0.0.0_170.1.0		
		Fri Jul 22 08:06:26 EDT 2022		
		/PDB Network Configuration Menu-\		
		/\		
		1 IPv4 Configuration 		
		 2 IPv6 Configuration		
		2 1PV6 Configuration		
		e Exit		
		\/		

currently set to 10.75.141. The EPAP local PDBA IPv6 a 0000:0000:0000:0000:0000 EPAP software and PDBA a The EPAP local PDBA IPv4 a EPAP remote PDBA IP Add		Enter Choice: 1 This MPS is configured to be provisionable. The EPAP local PDBA IPv4 address is currently set to 10.75.141.74 The EPAP local PDBA IPv6 address is currently set to 0000:0000:0000:0000:0000:0000:0000:
5	This procedure is complete.	This procedure is complete.

Procedure A.35 Keys exchange between active PDB and standby PDB

S T	This procedure Exchange the keys between active and remote PDB.				
Е					
P	Estimated time of completion: 5 minutes.				
#					
	Check off (\square) each step as it is complinumber.	eted. Boxes have been provided for this purpose under each step			
	SHOULD THIS PROCEDURE FAIL, CONTACT TEKELEC TECH	INICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .			
	DESCRIPTION OF THE PROPERTY OF				
1	PROCEDURE APPLICABLE TO: Dual Mixed or Dual PDBor	T T T T T T T T T T T T T T T T T T T			
1	For key exchange on Standby PDB on	Follow step 3 to step 16.			
	17.1 release and Active PDB on				
	16.3.1/16.4.1 release				
2	For key exchange between Active PDB	Follow step 17 to end.			
П	on 17.1 release and Standby also on				
_	release 17.1				
3	MPS A: Log in to PDB EPAP server on	If not already logged in, then log in at PDB EPAP:			
	release 17.1 as the user "epapdev".	Console.			
		login: epapdev			
		password:			

Perform the following procedure on In case of PDBonly server, run the below command: EPAP 17.1: Here, remotepdb_IP is EPAP 16.3.1/16.4.1 machine Ip. # ssh epapdev@remotepdb_IP "/usr/bin/ssh-keygen -t
rsa -f ssh/id rsa -N '' " **Note:** Generating RSA keys first with rsa -f .ssh/id_rsa -N servers installed on older release 16.3.1/16.4.1. In case of mixed server, run the following command: Also, Generate RSA key with both Here, remotepdb EPAPA IP and remotepdb EPAPB IP are EPAP sides in case of mixed epap. 16.3.1/16.4.1, A and B machine lps. # ssh epapdev@remotepdb_EPAPA_IP "/usr/bin/ssh-keygen
-t rsa -f .ssh/id_rsa _N '' " # ssh epapdev@remotepdb_EPAPB_IP "/usr/bin/ssh-keygen -t rsa -f .ssh/id_rsa -N Example: Recife is EPAP 17 server and 10.75.141.55 and 10.75.141.56 are EPAP A and B machines of the other mixed server which is on EPAP 16.3.1. [epapdev@Recife-A free]\$ ssh epapdev@10.75.141.55
"/usr/bin/ssh-keygen -t rsa -f .ssh/id_rsa -N '' epapdev@10.75.141.55's password:
Generating public/private rsa key pair. Your identification has been saved in .ssh/id_rsa. Your public key has been saved in .ssh/id_rsa.pub. The key fingerprint is: 47:54:4c:74:96:f2:e9:31:1f:b1:a8:5f:81:64:36:f0 epapdev@Devloan01 The key's randomart image is: +--[RSA 2048]----+ .*= o. +B.. . +E+.0 0 = +S . .. +0 [epapdev@Recife-A free]\$ ssh epapdev@10.75.141.56 /usr/bin/ssh-keygen -t rsa -f .ssh/id_rsa -N '' epapdev@10.75.141.56's password: Generating public/private rsa key pair.
Your identification has been saved in .ssh/id_rsa.
Your public key has been saved in .ssh/id_rsa.pub. The key fingerprint is: af:08:75:05:38:00:b9:0c:1e:61:e7:9b:6a:d3:82:47 epapdev@Devloan02 The key's randomart image is: +--[RSA 2048]----+ 00+.. 0.+ Ω .0.0 .0 0 Eo . S

		. = 		
		 [epapdev@Recife-A free]\$		
5 MPS A: The EPAP Configuration Menu /EPAP Configuration Menu /EPAP configuration Menu /			-EPAP Configuration Menu\ \	
$ \Box$	PDB Configure Menu.		Display Configuration	
		2	Configure Network Interfaces Menu	
		3	Set Time Zone	
		4	Exchange Secure Shell Keys	
		5	Change Password	
		6	Platform Menu	
		7	Configure NTP Server	
		8	PDB Configuration Menu	
		9	Security	
		10	SNMP Configuration	
		11	Configure Alarm Feed	
		12	Configure Query Server	
		13	Configure Query Server Alarm Feed	
		14	Configure SNMP Agent Community	
		15	DB Architecture Menu	
		e	Exit	
		Enter Ch	noice: 8	
6	MPS A: The Configure PDB Menu is displayed. Select choice 1.	/	-Configure PDB Menu\	
			Configure PDB Network	
		2	Create PDB	
		3	Change Auto DB Recovery State	
		e	Exit	
		Enter Ch	noice: 1	

7	MPS A: The PDB Network	PDB Network Configuration Menu for standalone PDB:
	Configuration Menu is displayed.	
_	Select choice 1.	MPS Side A: hostname: Tacna-B-PDBonly hostid: 4b0a218d
		Platform Version: 7.0.1-8.5.0.0.0_100.8.1
	Provide remote PDBA IP address.	Software Version: EPAP 170.0.6- 17.0.0.0_170.6.0
		Mon Nov 14 18:11:45 EST 2022
		/PDB Network Configuration Menu-\
		1 IPv4 Configuration
		2 IPv6 Configuration
		e Exit
		e
		Enter Choice: 1
		This MPS is configured to be provisionable. The EPAP local PDBA IPv4
		address is currently set to 10.75.141.33
		The EPAP local PDBA IPv6 address is currently set to
		0000:0000:0000:0000:0000:0000:0000 The EPAP local PDBA IPv4 Address is 10.75.141.33.
		EPAP remote PDBA IP Address [0.0.0.0]: 10.75.141.32
		The server does not know of 10.75.141.32.
		Will just exchange host keys for the name given!
		Password of epapdev:
		The server does not know of 10.75.141.32.
		Will just exchange host keys for the name given!
		ssh is working correctly.
		Attempting to give PDB privileges to: 10.75.141.32
		PDB privileges have been set for 10.75.141.32
		PDB Network Configuration Menu for Mixed EPAP:
		MPS Side A: hostname: Recife-A hostid: 4b0a3d8d
		Platform Version: 7.0.1-8.9.0.1.0 130.6.0
		Software Version: EPAP 170.0.26-17.0.0.4.0_170.25.0
		Sun Jun 24 10:44:43 EDT 2018
		/PDB Network Configuration Menu-\
		1 IPv4 Configuration
		2 IPv6 Configuration
		A Fyit
		\/
		Enter Choice: 1
		Verifying connectivity with mate

8	Exit from epapconfig menu	This MPS is configured to be provisionable. The EPAP local PDBA IPv4 address is currently set to 10.75.141.61 The EPAP local PDBA IPv6 address is currently set to 0000:0000:0000:0000:0000:0000:0000:	
9	MPS A: Log in to PDB EPAP server on release 16.4.1/16.3.1 as the user "epapdev".	If not already logged in, then log in at PDB EPAP: Console. login: epapdev password:	
10	Run the following command on PDB on 16.3.1/16.4.1 server to update the epapui.pl: sed -i 's/my \$command=\$SSH_SCRIPT'."	[epapdev@EPAP ~]\$ sed -i 's/my \$command=\$SSH_SCRIPT . " \$remotePdba";/my \$command=\$SSH_SCRIPT . " key=id_rsa.pub \$remotePdba";/g' /usr/TKLC/epap/bin/epapui.pl	

11	<pre>\$remotePdba";/my \$command=\$SSH_SCRIPT . " key=id_rsa.pub \$remotePdba";/g' /usr/TKLC/epap/bin/epapui.pl</pre> <pre>Run the following command to verify</pre>	# grep "\\$command=\\$SSH_SCRIPT"
	the mentioned in above command:	/usr/TKLC/epap/bin/epapui.pl
1_	Run the following command to verify	# grep "\\$command=\\$SSH_SCRIPT" /usr/TKLC/epap/bin/epapui.pl \$command=\\$SSH_SCRIPT. ' mate'; my \\$command=\\$SSH_SCRIPT . "key=id_rsa.pub } /
		e Exit
		Enter Choice: 8

displayed. Select choice 1. 1 Configure PDB Network 2 Create PDB	
3 Change Auto DB Recovery State	
e Exit \/	
Enter Choice: 1	
14 MPS A: The PDB Network PDB Network Configuration Menu for Standalone PDB:	
Configuration Menu is displayed. Select choice 1. MPS Side A: hostname: Tacna-A-PDBonly hostid: 4b0a208d Platform Version: 6.1.4-7.8.1.0.0_89.13.0 Software Version: EPAP 164.0.15-16.4.1.0.0_164.16.0 Mon Nov 14 18:47:04 EST 2022 /PDB Network Configuration Menu-\	
1 IPv4 Configuration	
2 IPv6 Configuration	
 e Exit	
\/	
Enter Choice: 1	
This MPS is configured to be provisionable. The EPAP local PDE address is currently set to 10.75.141.32 The EPAP local PDBA IPv6 address is currently set to 0000:0000:0000:0000:0000:0000:0000:	BA IPv4
/PDB Network Configuration Menu-\ /\	

			IPv4 Configuration	
		2	IPv6 Configuration	
		 e	 Exit	
		\	/	<i>'</i>
		Enter Ch	oice: 1	
		This MPS address in The EPAF continue EPAF rent EPAF privipatempti EPAF privipate	connectivity with mate is is configured to be provisionable. The EPAP local is currently set to 10.75.141.55 Plocal PDBA IPv6 address is currently set to 20:0000:0000:0000:0000:0000 tware and PDBA are running. Stop them? [N]: Y Plocal PDBA IPv4 Address is 10.75.141.55. Inote PDBA IP Address [0.0.0.0]: 10.75.141.61 Inote PDBA B machine IP Address [0.0.0.0]: 10.75.1 Id of epapdev: Irking correctly. Ing to give PDB privileges to: 10.75.141.61	
15	Exit from epapconfig menu.	-	vileges have been set for 10.75.141.55 e A: hostname: Tacna-A-PDBonly hostid: 4b0a208	d
	Late from epapeoring mend.	PI Sc	latform Version: 6.1.4-7.8.1.0.0_89.13.0 oftware Version: EPAP 164.0.15-16.4.1.0.0_164.16 Ion Nov 14 18:48:19 EST 2022	
		/	PDB Network Configuration Menu-\	
		1	IPv4 Configuration	
		2	IPv6 Configuration	
		 e		,
		Enter Ch		
16	MPS A: Start Epap and Pdba software on Active PDBA Site.	Start Epa	p and Pdba software to reflect the changes.	
		Use the f	following command to start EPAP:	
		For EPAP EPAP Sof	16.3.1/16.4.1, run the following command to star tware:	t PDBA and

		<pre>\$ service Epap Start</pre>	
17	MPS A: Log in to PDB EPAP server which is newly made on release 17.1 as the user "epapdev".	console	eady logged in, then log in at PDB EPAP: epapdev
18	MPS A: The EPAP Configuration Menu		EPAP Configuration Menu\
	is displayed. Select choice 8,PDB Configure Menu.	/	Display Configuration
	Comigure Menu.	2	 Configure Network Interfaces Menu
			Set Time Zone
			Exchange Secure Shell Keys
			Change Password
			Platform Menu
		7	Configure NTP Server
		8	PDB Configuration Menu
			Security
		10	SNMP Configuration
		11	Configure Alarm Feed
		12	Configure Query Server
		13	Configure Query Server Alarm Feed
		14	Configure SNMP Agent Community
			DB Architecture Menu


		e Exit
		\/
		Estas Chatas 0
		Enter Choice: 8
19	MPS A: The Configure PDB Menu is	/Configure PDB Menu\
	displayed. Select choice 1.	/\ 1 Configure PDB Network
_		
		2 Create PDB
		3 Change Auto DB Recovery State
		 e Fxit
		e Exit \/
20	MPS A: The PDB Network	Enter Choice: 1
	Configuration Menu is displayed.	MPS Side A: hostname: Tacna-B-PDBonly hostid: 4b0a218d Platform Version: 7.0.1-8.5.0.0.0 100.8.1
_	Select choice 1.	Software Version: EPAP 170.0.6-17.0.0.0.0_170.6.0
		Mon Nov 14 18:11:45 EST 2022
	Provide remote PDBA IP address.	/ SPR Nationals Confirmation Many
		/PDB Network Configuration Menu-\ /\
		1 IPv4 Configuration
		2 IPv6 Configuration
		e Exit
		\/
		Enter Choice: 1
		This NADC is configured to be previously The FDAD level DDDA ID.A
		This MPS is configured to be provisionable. The EPAP local PDBA IPv4 address is currently set to 10.75.141.33
		The EPAP local PDBA IPv6 address is currently set to
		0000:0000:0000:0000:0000:0000
		The EPAP local PDBA IPv4 Address is 10.75.141.33.
		EPAP remote PDBA IP Address [10.75.141.32.]: <pre><pre><pre><pre></pre></pre></pre></pre>
		The server does not know of 10.75.141.32
		Will just exchange host keys for the name given!
		Password of epapdev: The server does not know of 10.75.141.32.
		Will just exchange host keys for the name given!
		ssh is working correctly.
		Attempting to give PDB privileges to: 10.75.141.32
		PDB privileges have been set for 10.75.141.32


21	Exit from epapconfig menu	/PDB /	/
22	MPS A: Log in to Active PDB EPAP server which is already on release 17.1 as the user "epapdev".	console	ready logged in, then log in to PDB EPAP: epapdev ord:
23	MPS A: The EPAP Configuration Menu	/	-EPAP Configuration Menu\
	is displayed. Select choice 8,PDB Configure Menu.		Display Configuration
		2	Configure Network Interfaces Menu
			Set Time Zone
		4	Exchange Secure Shell Keys
		5	Change Password
		6	Platform Menu
		7	Configure NTP Server
		8	PDB Configuration Menu
			Security
		10	SNMP Configuration
		11	Configure Alarm Feed
			Configure Query Server
			Configure Query Server Alarm Feed
		14	Configure SNMP Agent Community
		15	DB Architecture Menu

		e Exit
		\/
		Enter Choice: 8
24	MPS A: The Configure PDB Menu is	/Configure PDB Menu\
	displayed. Select choice 1.	1 Configure PDB Network
		2 Create PDB
		3 Change Auto DB Recovery State
		e Exit
		Enter Choice: 1
25	MPS A: The PDB Network Configuration Menu is displayed. Select choice 1. Provide remote PDBA IP address.	MPS Side A: hostname: Tacna-A-PDBonly hostid: 4b0a218d Platform Version: 7.0.1-8.5.0.0.0_100.8.1 Software Version: EPAP 170.0.6-17.0.0.0.0_170.6.0 Mon Nov 14 18:11:45 EST 2022
		/PDB Network Configuration Menu-\ /\
		1 IPv4 Configuration
		2 IPv6 Configuration
		e Exit
		Enter Choice: 1
		This MPS is configured to be provisionable. The EPAP local PDBA IPv4 address is currently set to 10.75.141.32 The EPAP local PDBA IPv6 address is currently set to 0000:0000:0000:0000:0000:0000:0000:

26	Exit the epapconfig menu.	MPS Side A: hostname: Tacna-B-PDBonly hostid: 4b0a218d	
	Active PDBA Site.	Start EPAP and PDBA software to reflect the changes. Use the following command to start Epap: For EPAP 16.3.1/16.4.1, run the following command to start PDBA and EPAP Softwares: \$ service Epap Start ~~ /etc/init.d/Epap start ~~ "EPAP_RELEASE" is set to "0.617" EPAP application start Successful. \$ service Pdba start ~~ /etc/init.d/Pdba start ~~ PDBA application start Successful. For EPAP 17.1, run the following command to start PDBA and EPAP Software: \$ systemctl start Epap \$ systemctl start Pdba	
28	Procedure complete	This procedure is complete.	

Procedure A.36: RTDB restore after Upgrade





EPAP A: Make EPAP Conferming that Restore RTDB in progress: down. Informational Messages An IM alarm should be observed with informational message Informational Messages on EPAP GUI Restore RTDB in progress confirming that restore RTDB is in progress. Wed June 13 2018 16:39:09 EDT Copyright @ 2000, 2018, Oracle and/or its affiliates. All rights reserved. An IM alarm should be observed with informational message on EPAP GUI confirming that restore RTDB completed successfully.

Click "Confirm RTDB	Confirming that Restore RTDB is completed successfully:		
Restore" Button	A Informational Messages		
	Informational Messages		
	Restore RTDB completed successfully		
	Fri June 15 2018 00:30:27 EDT		
	Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.		
confirming that RTDB	This step is performed only to support EAGLE release 46.7.0.0.0 (On the setup where DB Architecture is eXtreme):		
	A Informational Messages		
	Informational Messages RTDB Conversion in progress Wed June 13 2018 16:55:42 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.		

		A Informational Messages
		Informational Messages RTDB conversion completed successfully
		Fri June 15 2018 00:37:57 EDT
		Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
6 F	Procedure complete.	Return to the procedure that you came here from.

Procedure A.37: Resolve the false accept upgrade alarm situation

S	This procedure is used to resolve the fall	se accept upgrade alarm situation from the system.
T E	Check off ($$) each step as it is complete	ed. Boxes have been provided for this purpose under each step number.
P #	IF THIS PROCEDURE FAILS, CONT	ACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.
1.	Blankout the /etc/motd file	>/etc/motd

2.	Add an entry "export	echo "export POST_UPGRADE_ACTION=ACCEPT" >>
	POST_UPGRADE_ACTION=ACCEPT"	/var/TKLC/log/upgrade/upgrade.info
	in the upgrade info file.	

3.	Clear the false alarm	
?	"TKSPLATMI33"	
		You will see the following alarm in alarmStatus.
		a. alarmMgralarmStatus
		[One output example below:]
		SEQ: 7 UPTIME: 356 BIRTH: 1524100682 TYPE: SET
		ALARM:
		TKSPLATMI33 tpdServerUpgradePendingAccept 1.3
		.6.1.4.1.323.5.3.18.3.1.3.33 3253
		2 Processing Error Configuration Error
		b. To clear the alarm, run the following command:
		alarmMgrclear TKSPLATMI33
Ь		

Procedure A.38 Conversion from mixed EPAP to StandalonePDB+Non-Prov EPAP

Note: A new card would be needed for this conversion. The conversion can be done through various way where one of them is described below.

Assuming, there is a mixed EPAP on 16.3.1/16.4.1 release.

Execute the below mentioned steps to perform this conversion

On Mixed EPAP:

a. Perform Full Upgrade from existing release EPAP 16.3.1 or 16.4.1 to target release of EPAP 17.1 Refer to section 3.4.1 and perform procedures 1, 2, 3, 4, 14, A.31, 15, and 16.

Upgrade/Installation Guide

b. Convert Prov (mixed EPAP) to Non-Prov EPAP by fresh installing the setup as Non-Prov Node

Note: Option to convert Mixed setup to Non-Prov setup via epapconfig menu is obsoleted.

Refer to section 3.4.1, Execute procedure A.13, 5, 6, 7, 8, 9, 4, 20, 13, A.32, A.36, A.11, 25, 22.

On PDBonly (fresh installation on new card):

c. Install EPAP 17.1 ISO on new card.

Refer to section 3.3.2 to perform installation.

d. Restore PDB backup

Refer to section 3.4.4, Execute procedures A.33, 27.

Attach this PDBonly with Non-Prov EPAP (converted in step b) and any Non-Prov EPAP connected with Mixed setup

Procedure A.39 Take snapshot of uiEdit parameters

S T	This procedure pro	ovides instructions to restore RTDB from a backup file.
E P	Check off (\vee) each step	p as it is completed. Boxes have been provided for this purpose under each step number.
#	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.
1.	EPAP A: Log in to the EPAP A server as user "root" and take a snapshot of EuiDB variables.	[root@Quito-a ~]# uiEdit "DB_ARCHITECTURE" is set to "COMPACT" "LNP_ENABLED" is set to "FALSE" "NETWORK_CONFIGURATION_TYPE" is set to "SINGLE" "EPAP_A_GS_BANNER_PORT" is set to "8473" "PDBA_STATS_ENABLED" is set to "OFF" "EPAP_DATA_SPLIT" is set to "OFF" "max_passwd_age" is set to "180" "new_user_default_groups" is set to "readonly" "max_concurrent_user_logins" is set to "1" "max_concurrent_logins" is set to "20" "PROVISIONABLE_MPS" is set to "YES" "PDBA_LOCAL_NAME_V6" is set to "0000:0000:0000:0000:0000:0000:0000" "passwd_expiry_warn_days" is set to "7" "HTTP_ENABLED" is set to "No" "SNMP_ALARM_FEED" is set to "ON" "session_idle_timeout" is set to "10" "EPAP_A_STANDBY" is set to "FALSE" "EPAP_BINLOGS_THRESHOLD" is set to "80" "SLOG_CAPACITY_ALARMS_ENABLED" is set to "TRUE" "EPAP_A_NAME" is set to "Quito-a" "MAX_RECORD_DELAY" is set to "15"

```
"PDBA IMSI PREFIX" is set to ""
"EPAP A MAINT DEBUG LEVEL" is set to "0"
"SELF HEAL DN FEATURE" is set to "OFF"
"logon_msg" is set to "NOTICE: This is a private computer system.
Unauthorized access or use may lead to prosecution."
"EPAP_QS_ALARMS_ENABLED" is set to "ON"
"PDB_RTDB_SYNC" is set to "NO"
"PROVISIONING_NETWORK_NETMASK" is set to "255.255.255.0"
"EPAP_A_SLOG" is set to "YES"
"PDBA_ERROR_LOG_DEBUG_LEVEL" is set to "20"
"EPAP A SIMPLEX MODE" is set to "FALSE"
"EPAP A PROV NETWORK IP ADDRESS" is set to "10.75.141.73"
"EPAP_IP_VERSION" is set to "IPv4"
"SYSTEM_NUMBER" is set to "ES06032023"
"EPAP STATUS A" is set to "NONE"
"euidb version" is set to "3"
"PDB_CAP_LIMIT_ENABLED" is set to "OFF"
"EPAP_A_HTTP_PORT" is set to "80"
"UI_IP_AUTHORIZATION_ENABLED" is set to "FALSE"
"PDBA MAX COMMAND RECORDS" is set to "1000000"
"EPAP_A_SUEXEC_HTTP_PORT" is set to "8001"
"apache_403_error_message" is set to "NOTICE: This workstation is not
authorized to access the GUI."
"min passwd len" is set to "8"
"max_account_inactivity" is set to "0"
"EAGLE_ALARM_FEED" is set to "OFF"
"PDBA_GPORT_INSTALLED" is set to "FALSE"
"EPAP RELEASE" is set to "0.0.0"
"PDBA REMOTE NAME" is set to "0.0.0.0"
"PDBA_DEBUG_LOG_DEBUG_LEVEL" is set to "20"
"EPAP_A_SUEXEC_HTTPS_PORT" is set to "8002"
"EPAP_QS_THRESHOLD" is set to "200"
"EPAP A HSAUDIT" is set to "ON"
"EPAP A HTTPS PORT" is set to "443"
"PDBA_DN_PREFIX" is set to ""
"EPAP_A_PROV_NETWORK_IP_ADDRESS_V6" is set to ""
"PDBA GFLEX INSTALLED" is set to "FALSE"
"PROVISIONING_NETWORK_PREFIX_V6" is set to ""
"passwd_reuse_limit" is set to "5"
"PDBI_PORT" is set to "5873"
"apache_403_error_message_default" is set to "NOTICE: This workstation is
not authorized to access the GUI."
"PDBA_INP_INSTALLED" is set to "FALSE"
"HTTPS_ENABLED" is set to "Yes"
"PROVISIONING_NETWORK_DEFAULT_ROUTER" is set to "10.75.141.1"
"RTDB_HOMING_POLICY" is set to "PDBA_LOCAL_NAME"
```

		"PDBA_MAX_COMMAND_DELAY" is set to "-1" "PDBA_LOCAL_NAME" is set to "10.75.141.73" "PDBA_COMMAND_LOG_DEBUG_LEVEL" is set to "20" "max_failed_logins" is set to "3" "PDB_SUB_CAPACITY" is set to "528000000" [root@Quito-a ~]#
2.	Copy the uiEdit command output in notepad and save on your machine or backup server for future reference	uiEdit command output is saved for fututr reference.
3.	This procedure is complete.	This procedure is complete.

Procedure A.40 Save the EPAP 16.3/16.4 additional configurations

S T	This procedure pro	ovides instructions to restore RTDB from a backup file.
E P	Check off (\vee) each step	p as it is completed. Boxes have been provided for this purpose under each step number.
#	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.
1.	Log in to	EPAP configuration menu for PDBonly server:
	epapconfig menu	
	and Enter choice 7,	
	Configure NTP	
	Server Menu	

/	EPAP Configuration Menu\
1 1	Display Configuration
	Configure Network Interfaces Menu
	Set Time Zone
1 4	Exchange Secure Shell Keys
5	Change Password
6	
7	Configure NTP Server
	PDB Configuration Menu
9	Security
10	SNMP Configuration
	Configure Alarm Feed
12	Configure Query Server
13	
1 14	Configure SNMP Agent Community
15	DB Architecture Menu
i e	Exit
`	_
H:nter	Choice:

		/	EPAP Configuration Menu\ \
			Display Configuration
		1 2	Configure Network Interfaces Menu
			 Set Time Zone
		4	Exchange Secure Shell Keys
		5	 Change Password
			 Platform Menu
			 Configure NTP Server
		8	 PDB Configuration Menu
			 Security
			SNMP Configuration
		11	
		12	Configure SNMP Agent Community
			Mate Disaster Recovery
		1 14	DB Architecture Menu
			 Exit
		(
2.	MPS A: The EPAP		
	Configure NTP		EPAP Configure NTP Server Menu-\ \
	Server Menu is	1	Display External NTP Server
	displayed. Enter choice 1, Display	2	Add External NTP Server
	External NTP Server and save the details	1 3	Remove External NTP Server
	for later use.		 Exit
		\	·
			Choice: 1
		ntpse	rver1 10.75.124.247
		Press	return to continue

3.	Log in to EPAP GUI	Α			Automatic PDB/RT	DB Backup		
	via uiadmin user						•	
	MPS 1A: Navigate	Backup Type (Select None to Cancel Back	rups)	Local V				
	to the main	Time of the day to start the B	Backup	04:00				
	Maintenance menu	Frequency		1 Day V				
	selection and select	File Path (Directory only)						
	"Automatic	Select required IP version:		◎ IPv4 ○ IPv6				
	PDB/RTDB Backup"	Remote Machine IP Address (IPv4=xxx.yyy.yyy.yyy)						
	·	(IPv6=xxxx:xxxx:xxxx:xxxx	CXXXX:XXXX:XXXX	κ)				
	and note down the	Login Name Password						
	configuration	Save the local copies in the d	default path	O Yes O No				
	details.	Do you want to delete the old	d RTDB backups					
		(Non-Provisionable only) Note: 1. If you select Yes, on						
		RTDB backup files will be re 2. Automatic PDB Backup w		e les e les				
4.	Navigate to the	A	-1		Configure F	File Transfer	1	
П	main Maintenance	^			Conliguie	ile Hallstei	:	
-	menu selection and							
	select "Configure	Select required IP version:	◎ IPv4 ○	IPv6				
	File Transfer" and	Remote system IP address:	10.75.141.8	0				
	note down the	Remote system user name:	epapdev					
	configuration	Remote system password:						
	details.	Remote system sftp location:	: /var/TKLC/e	pap/free				
		File export to remote system:	: Enabled v					
		Submit data						
		Submit data						
		Tue March 07 2023 04:12:2			to compare and the second			
			Сорупд	it © 2000, 2019, Oracle and/or	r its affiliates. All rights reserved.			
5.	Navigate to the	Α						Schedule
	main Maintenance							
	menu selection and				Existing Task	s		
	select "EPAP	Type EXARCORE		chedule	Action	No ok	<u>Params</u>	<u>C</u>
	Schedule task" and	EXAPCORE EXAPCORE	PIC minut EFTP minut	•	/usr/TKLC/epap/bin/pdbilmportC /usr/TKLC/epap/bin/eirSftp.pl	DIECK		
	note down the	EXAPCORE	PBL minut	ely,10	/usr/TKLC/appl/bin/pruneBinary	Logs		
	configuration	EXAPCORE N	PDSH minut		/usr/TKLC/appl/bin/pdbiSsh.pl			
	details.		MONBAN hourly RTDBCS minut		/usr/TKLC/appl/bin/monitorBanr /usr/TKLC/appl/bin/getRTDBClie			
			'	•		·		
			_					
				_ (Scheduling O _I	otions		
				Type:	ID:			
				Action:				
			_	Params:	0.15 (1.0 55 1.0 5	·1	1 0 15 11	
			[R	epeat period:	O Minutely O Hourly Da	•		○ Yearly
				C	Every 1 day(s) at	00 🗸 : 00	•	
				Comment:				
					Add Modify	Delete		


6.	Navigate to the user administration	Α		View HTTP(S)
	menu and select "HTTP(s) Support", click view	HTTP Enabled: HTTPS Enabled:	No Yes	
	configuration and note down the configuration details.	Tue March 07 2023 04:15:58 EST	Copyright © 2000, 2019, Oracle and/or its affiliates. All rights re	served.
7.	This procedure is complete.	This procedure is complete.		


Procedure A.41 Reconfigure Additional EPAP configurations

S T	This procedure pro	ovides instructions to restore RTDB from a backup file.
E	Check off (√) each step	p as it is completed. Boxes have been provided for this purpose under each step number.
P #	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.
1.	Log in to	EPAP configuration menu for PDBonly server:
	epapconfig menu	
	and Enter choice 7,	
	Configure NTP	
	Server Menu	

/	/EPAP Configuration Menu\		
/	Display Configuration		
	 Configure Network Interfaces Menu		
1	 Set Time Zone		
	 Exchange Secure Shell Keys		
1	 Change Password		
1	 Platform Menu		
1	 Configure NTP Server		
1	 PDB Configuration Menu		
	 Security		
10	SNMP Configuration		
11	Configure Alarm Feed		
12			
13	Configure Query Server Alarm Feed		
14	Configure SNMP Agent Community		
	DB Architecture Menu		
	Exit		
Enter	Choice:		
EPAP co	onfiguration menu for Mixed EPAP:	_	

		/	EPAP Configuration Menu\
		1	\ Display Configuration
			 Configure Network Interfaces Menu
		3	 Set Time Zone
			 Exchange Secure Shell Keys
		5	 Change Password
			 Platform Menu
			 Configure NTP Server
			 PDB Configuration Menu
		9	 Security
		1 10	 SNMP Configuration
		11	 Configure Alarm Feed
			 Configure SNMP Agent Community
		13	 Mate Disaster Recovery
		14	 DB Architecture Menu
		i e	 Exit
		\	/
2.	NADC A: The EDAD		
	MPS A: The EPAP Configure NTP		Add External NTP Server Menu-\ \
	Server Menu is displayed.		IPv4 Configuration
	Enter choice 2, Add	2 	IPv6 Configuration
	External NTP Server.	i e	Exit
		Enter	Choice: 1
	Refer to <u>Procedure</u> A.40 step 2 for NTP configuration	Are yo	ou sure you wish to add new NTP Server? [N]: Y erver IP Address: 10.75.124.247
	before Migration		





		A Change HTTP(S) Configuration
		✓ SUCCESS: HTTP/HTTPS configuration changed successfully.
		Tue March 07 2023 05:59:09 EST
		Copyright © 2000, 2019, Oracle and/or its affiliates. All rights reserved.
7.	This procedure is	
	complete.	This procedure is complete.


Procedure A.42 Compare EuiDB parameters


S	This procedure provides instructions to restore RTDB from a backup file.		
T E P #	Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.		
1.	Compare the EuiDB parameters before and after Migration		
2.	This procedure is complete.	This procedure is complete.	

Procedure A.43 PDB Restore

S	This procedure provides instructions to restore PDB from a backup file.		
T E P #	Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.		
1.	MPS X: Log in to the CLI as user "admusr".	If not already logged in, then log in as 'admusr': [hostname] consolelogin: admusr password: password	
2.	MPS X: Switch to epapdev user.	\$ sudo su - epapdev	

3.	MPS X: Backup file should be readable for epapdev user	Check mode and ownership of PDB backup tar file. It should be as follows: [epapdev@DBExp-VM77 free]\$ 11 pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v7.50.bk p.tar.gz -rw-rw-rw- 1 epapdev epap 1182165 Jul 16 03:32 pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v7.50.bk p.tar.gz If permission and ownership of tar file is not same as above then use following command: Change mode of tar file: \$ chmod 666 < PDB backup tar file>
4.	Check following uiEdit variable:	[root@Salta-A ~]# uiEdit grep PDBA_REMOTE_NAME "PDBA_REMOTE_NAME" is set to "10.75.141.75"
	[root@Salta-A ~]# uiEdit grep PDBA_REMOTE_N AME "PDBA_REMOTE_ NAME" is set to "10.75.141.75"	[root@Salta-A ~]# uiEdit PDBA_REMOTE_NAME 0.0.0.0 "PDBA_REMOTE_NAME" is set to "0.0.0.0" [root@Salta-A ~]# uiEdit grep PDBA_REMOTE_NAME "PDBA_REMOTE_NAME" is set to "0.0.0.0"
	If Remote IP is assigned, then change it to 0.0.0.0 using the following command:	
	[root@Salta-A ~]# uiEdit PDBA_REMOTE_N AME 0.0.0.0 "PDBA_REMOTE_ NAME" is set to "0.0.0.0"	
	Again check the uiEdit variable value:	
	[root@Salta-A ~]# uiEdit grep PDBA_REMOTE_N AME "PDBA_REMOTE_ NAME" is set to "0.0.0.0"	





8.	MPS X: An IM alarm should be observed with	Confirming that Restore PDB in progress:
	informational message on EPAP GUI confirming that	Informational Messages
	restore PDB is in progress.	Informational Messages
		Restore PDB in progress
	An IM alarm should be observed with informational message on EPAP GUI confirming that restore PDB	Tue July 17 2018 02:31:52 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
	completed successfully.	Confirming that Restore PDB is completed successfully:
		Informational Messages
		Informational Messages
		Restore PDB completed successfully
		Tue July 17 2018 02:38:51 EDT
		Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
9.	Procedure complete.	Return to the procedure that you came here from.
10.	Re-Assign the remote PDBA	[root@Salta-A ~]# uiEdit PDBA_REMOTE_NAME 10.75.141.75 "PDBA_REMOTE_NAME" is set to "10.75.141.75"
	name using the	
	following command:	[root@Salta-A ~]# uiEdit grep PDBA_REMOTE_NAME
		"PDBA_REMOTE_NAME" is set to "10.75.141.75"
	[root@Salta-A ~]# uiEdit grep PDBA_REMOTE_N	[root@Salta-A ~]#
	AME	

	"PDBA_REMOTE_ NAME" is set to "10.75.141.75"	
	Again grep the uiEidt variable name using the following command:	
	[root@Salta-A ~]# uiEdit grep PDBA_REMOTE_ NAME	
11.	Move the pdba binary file on Mixed and PDBonly server.	[root@Quito-a bin]# mv pdba pdba_stopped [root@Quito-a bin]#
	Note: This step is valid in case only when user is performing migration.	
12.	Note down the timestamp in log.	Run the following command: \$ date

Procedure A.44 RTDB Homing Policy to self PDBA

S T	This procedure will reset the RDTB homing policy for the Non-Prov Nodes
E	
P #	Estimated time of completion: 5 minutes.
	Check off (\square) each step as it is completed. Boxes have been provided for this purpose under each step number.
	SHOULD THIS PROCEDURE FAIL, CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .
	PROCEDURE APPLICABLE TO: Non-Provisionable EPAPs

1	MPS A:	#su - epapconfig
	Switch to epapconfig menu	warning: Smartmatch is experimental at /usr/TKLC/plat/lib/Security/User.pm line 904.
2	Select option 8 from epapconfig menu	/EPAP Configuration Menu

3	Select option 2 to	/Configure PDB Menu\		
Г	enter	/\ 1 Configure PDB Network		
	RTDB	2 RTDB Homing Menu		
	homing menu			
		e Exit /		
		Enter Choice: 2		
4	Read the	For Mixed EPAP :		
	Note in the beginning	/RTDB Homing Menu\		
	of the	/\\TBB\\\\\\\\\\\\\\\\\\\\\\\\\\\\\		
	section	1 Configure Specific RTDB Homing		
	and decide your	 2 Configure Active RTDB Homing		
	homing			
	policy.	3 Configure Standby RTDB Homing 		
		e Exit		
		\/ Enter Choice: 1		
		EPAP software and PDBA are running. Stop them? [N]: Y		
		EPAP software is running on mate MPS. Stop it? [N]: Y		
		There are two configured PDBs for this MPS:		
		1. 10.75.141.101 (local)		
		2. 10.75.141.32		
		Select the preferred PDB from which to receive updates [1]: 1		
		The RTDB Homing policy is set to 'specific' and will prefer		
		updates from 10.75.141.101		
		Press return to continue		
		Shout Sugar and Dillia as Shoung to me Clast the shoung		
5 □	MPS A and MPS B:	Start Epap and Pdba software to reflect the changes. Use the following command to start Epap:		
Г	Start Epap	For EPAP 16.3.1/16.4.1, Run the following command to start PDBA and EPAP Softwares:		
	software.	\$ service Epap Start		
		~~ /etc/init.d/Epap start ~~ "EPAP_RELEASE" is set to "0.617"		
		EPAP application start Successful.		
		\$ service Pdba start		
		~~ /etc/init.d/Pdba start ~~ PDBA application start Successful.		

		For EPAP 17.1, run the following command to start PDBA and EPAP Softwares: \$ systemctl start Epap \$ systemctl start Pdba
6	Procedure complete	This procedure is complete.

Procedure A.45 Backout of MPS A and MPS B in Mixed and Non-Prov

S	T			
E				
P #	Estimated time of completion: 900 minutes.			
#				
	Check off (\square) each step as it is completed. Boxes have been provided for this purpose under each step number.			
	SHOULD THIS PROCEDU	JRE FAIL, CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR <u>MIGRATION</u> <u>ASSISTANCE</u> .		
	PROCEDURE APPLICAB	LE TO: Non-Provisionable EPAPs		
1	Re-Install the	Refer to EPAP 16.3.1/16.4.1 Install/Upgrade document		
	Mixed or			
	Non-Porv			
	Node on			
	EPAP			
	16.3.1/16.4.1			
2	Restore the	Refer to Section 3.4.2, step 6		
	EuiDB, RTDB			
	on Non-Prov			
	EPAPs from			
	the backup			
	taken before			
	performing			
	migration on			
	Non-Prov			
	Nodes			
3	Restore the	For EPAP 16.3.1/16.4.1 Backup files:		
	EuiDB and			
	PDB on	Refer to <u>section 3.4.1</u> , step 6 in case of Single Mixed or <u>section 3.4.3</u> , step 6 in case of Dual Mixed		
	Mixed EPAPs			

·		To Restore EPAP 16.3.1/16.4.1 Backup files:
		Refer to <u>Procedure A.32</u> for EuiDB Restore and <u>Procedure A. 10</u> for RTDB Restore.
4	This	
	procedure is complete.	This procedure is complete.

Procedure A.46 Backout of PDBonly site

T	This procedure will backout the PDBonly site			
Е				
P #	Estimated time of completion: 5 minutes.			
	Check off (□) ea	Check off ([]) each step as it is completed. Boxes have been provided for this purpose under each step number.		
	SHOULD THIS PROCEDU	SHOULD THIS PROCEDURE FAIL, CONTACT TEKELEC TECHNICAL SERVICES AND ASK FOR MIGRATION ASSISTANCE.		
	PROCEDURE APPLICABLE TO: Non-Provisionable EPAPs			
1	Re-Install the	Refer to EPAP 16.3.1/16.4.1 Install/Upgrade document		
	PDBonly site			
	on			
2	16.3.1/16.4.1			
_	Restore the	Refer to Section 3.4.4 step 6 in case or standalone PDB site or section 3.4.5 step 6 in case of dual		
Ц	EuiDB, PDB on PDBonly	PDBonly sites.		
	site from the			
	backup taken			
	before			
	performaning			
	migration on			
	Non-Prov			
	Nodes			
3	Restore the	For EPAP 16.3.1/16.4.1 Backup files :		
	EuiDB and			
	PDB on	Refer to <u>Section 3.4.4</u> step 6 in case of Single Mixed or <u>section 3.4.3</u> step 6 in case of Dual Mixed		
	PDBonly site			
		To Restore EPAP 16.3.1/16.4.1 Backup files:		
		Refer Procedure A.32 for EuiDB Restore and Procedure A.43 for PDB Restore.		
		Thereis indicedure A.32 for Edibb hestore and <u>Procedure A.43</u> for Pbb hestore.		

4	This	
	· .	This procedure is complete.
	complete.	

Procedure A.47 Dual Image Upgrade Procedure

Note: Ensure that the Legacy Upgrade before DIU is accepted, otherwise it might give an error while initiating background upgrade in DIU.

S. No	Steps	This procedure performs Dual Image Upgrade on the server. Check off (✓) each step as it is completed. Boxes have been provided for this purpose beside each step number. If this procedure fails, contact My Oracle Support and ask for ASSISTANCE.
1	MPS X: Login prompt is displayed.	<pre><hostname> console login: Note: Press enter if no login prompt is displayed.</hostname></pre>
2	MPS X: Log in as "root" user.	[hostname] consolelogin: root password: password
3	MPS X: Copy DIU ISO	Perform the procedure in Procedure A.12 or copy EPAP DIU ISO to /var/TKLC/upgrade directory. Make sure that only the DIU iso and patch is present in the directory.
4	Create a terminal window log in MPS X.	If not already connected, connect to the E5-APP-B card via the serial port. For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A card's adapter and use it for serial access. Cable part numbers - 830-1220-xx
5	MPS X: Unallocate some memory for the backout LVs.	Note: NTP must be configured before starting DIU. NOTE: All custom files, scripts, folders need to be migrated to remote server before the DIU process is started. These need to be restored back to their place after the DIU process is completed.

echo "SPLIT_MIRROR=1" >
/usr/TKLC/plat/etc/upgrade/upgrade.conf && cat
/usr/TKLC/plat/etc/upgrade/upgrade.conf

Is -ltr /var/TKLC/epap/free/

If you find the following folder:

drwxr-xr-x 2 epapdev epap 4096 Jan 3 00:51 comcol

Run the following commands, otherwise ignore them:

systemctl stop TKLCha
systemctl stop TKLCharsync
mv /var/TKLC/epap/free/comcol /var/TKLC/epap/logs/

Run the following commands one by one in the same sequence as listed. The following table lists the commands with the expected outputs.

Note: The primary objective of running the following commands is to create 30G unallocated memory for the backup LVs to be created during DIU. Thus, after running the lvremove command, when you check for vgs we, look at the Vfree category and then subtract 30 from that to find out the space to be mentioned in lvcreate command. For example, in the following commands, vgs have 234G after the lvremove command. This means that the lvcreate command will have 234-30=204G as the parameter. Thus, after creating the new lv, the unallocated memory is 30G (required by DIU).

In case of Mixed/PDBonly setup, run the following commands:

In case of NonProvisionable Setupsetup, run the following commands:

[root@Osorna-A upgrade]# systemctl stop Epap

[root@Osorna-A upgrade]# systemctl stop Pdba

[root@Osorna-A upgrade]# systemctl stop mysqld@pdb

[root@Osorna-A upgrade]# systemctl stop mysqld@app

[root@Osorna-A upgrade]# systemctl stop Epap


[root@Osorna-A upgrade]# systemctl stop mysqld@app


[root@Osorna-A upgrade]# systemctl stop crond

Note: Check whether all the services just stopped are actually stopped or not using the command: systemctl status <service_name>

[root@Osorna-A upgrade]# umount /var/TKLC/epap/free

[root@Osorna-A upgrade]# lvremove /dev/mapper/vgroot-free Do you really want to remove active logical volume vgroot/free? [y/n]: y Logical volume "free" successfully removed. [root@Osorna-A upgrade]# vgs VG #PV #LV #SN Attr VSize VFree vgroot 1 9 0 wz--n- <446.41g 234.00g [root@Osorna-A upgrade]# lvcreate --yes --size 204G --name free vgroot Wiping ext4 signature on /dev/vgroot/free. Logical volume "free" created. [2180.800550] EXT4-fs (dm-9): VFS: Can't find ext4 filesystem [root@Osorna-A upgrade]# mkfs.ext4 /dev/mapper/vgroot-free mke2fs 1.45.6 (20-Mar-2020) Discarding device blocks: done Creating filesystem with 53477376 4k blocks and 13369344 inodes Filesystem UUID: e84718ac-157e-4fa9-8261-19c1fb8c6121 Superblock backups stored on blocks: 32768, 98304, 163840, 229376, 294912, 819200, 884736, 1605632, 2654208, 4096000, 7962624, 11239424, 20480000, 23887872 Allocating group tables: done Writing inode tables: done Creating journal (262144 blocks): done Writing superblocks and filesystem accounting information: done [root@Osorna-A upgrade]# mount /dev/mapper/vgroot-free /var/TKLC/epap/free [root@Osorna-A upgrade]# chown epapdev:epap /var/TKLC/epap/free [root@Osorna-A upgrade]# vgs VG #PV #LV #SN Attr VSize VFree vgroot 1 10 0 wz--n- <446.41g 30.00g If you had the comcol folder then run the below commands to restore the comcol in free directory: mv /var/TKLC/epap/logs/comcol /var/TKLC/epap/free/ [root@Osorna-A upgrade]# vgs VG #PV #LV #SN Attr VSize VFree vgroot 1 10 0 wz--n- <446.41g 30.00g 6 MPS X: Start \$ su - platcfg platcfg utility.





If the Early Upgrade Checks fail due to the NTP related alarms, then ignore the NTP alarms using the following commands:

- Exit the platcfg menu.
- Change to root user using the "su –" command.
- vim /usr/TKLC/plat/etc/upgrade/upgrade.conf
- Edit the following line to include the NTP related alarms.
 - o EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2
 - Add the following alarm code to ignore Storage Capacity Problem: TKSPLATMA5
 - o Add the following line for the RAID related alarms:
- o EARLY_CHECK_ALARM_WHITELIST=TKSPLATMA2

For example – To allowlist the NTP alarm "tpdNTPDaemonNotSynchronizedWarning" which has the alarm code TKLCPLATMI10, the above mentioned line should be edited as EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2,TKSPLATMI10

Note: There should not be any space between two alarms i.e. between TKSPLATMI2 and TKSPLATMI10


If the Early Upgrade Checks fail due to "Server Default Route Network Error", then this alarm shall be allowlisted in upgrade.conf file. To allowlist this alarm which has the alarm code TKSPLATMA14, the above mentioned line should be edited as

EARLY_CHECK_ALARM_WHITELIST=TKSPLATMA2,TKSPLATMI2,TKSPLATMA5,TKSPLATMI10, TKSPLATMA14,TKSPLATMA28

Note: Please note that TKSPLATMA5, TKSPLATMA2, TKSPLATMI2 should always be whitelisted.

10 MPS X:

Navigate to the Initiate Upgrade menu Select the Initiate Background Upgrade menu and press [ENTER].



```
|-vgroot-plat_tmp
                  253:4 0 1G 0 lvm
/tmp
                  253:5 0 2G 0 lvm
 |-vgroot-plat_var
/var
                 253:6 0 20G 0 lvm
 |-vgroot-logs
/var/TKLC/epap/logs
 |-vgroot-db
                 253:7 0 191.8G 0 lvm
/var/TKLC/epap/db
  `-vgroot-free
                 253:8 0 207.7G 0 lvm
/var/TKLC/epap/free
              8:16 1 28.9G 0 disk
sdb
               8:17 1 2.8G 0 part
|-sdb1
`-sdb2
                8:18 1 9.8M 0 part
              8:32 0 447.1G 0 disk
sdc
I-sdc1
               8:33 0 512M 0 part
`-sdc2
                8:34 0 446.5G 0 part
 `-md1
                9:1 0 446.4G 0 raid1
 |-vgroot-plat_root 253:0 0 4G 0 lvm
 |-vgroot-plat_swap 253:1 0 2G 0 lvm
[SWAP]
 |-vgroot-plat_usr
                  253:2 0 10G 0 lvm
/usr
 |-vgroot-plat_var_tklc 253:3 0 8G 0
lvm /var/TKLC
 /tmp
 |-vgroot-plat_var
                  253:5 0 2G 0 lvm
/var
 |-vgroot-logs
                 253:6 0 20G 0 lvm
/var/TKLC/epap/logs
 |-vgroot-db
                 253:7 0 191.8G 0 lvm
/var/TKLC/epap/db
  `-vgroot-free
                 253:8 0 207.7G 0 lvm
/var/TKLC/epap/free
```

```
|-vgroot-plat_tmp 253:4 0 1G 0 lvm
/tmp
|-vgroot-plat_var 253:5 0 2G 0 lvm
/var
|-vgroot-rt 253:6 0 68G 0 lvm
/var/TKLC/epap/rt
|-vgroot-logs 253:7 0 20G 0 lvm
/var/TKLC/epap/logs
I-vgroot-db
            253:8 0 289.2G 0 lvm
/var/TKLC/epap/db
`-vgroot-free 253:9 0 204G 0 lvm
/var/TKLC/epap/free
         8:32 0 894.3G 0 disk
sdc
|-sdc1
          8:33 0 512M 0 part
-sdc2
           8:34 0 893.7G 0 part
```


If the raid is not in sync, then run the following command:

mdadm --add /dev/md1 /dev/sdX2
 where sdX can be any of sda, sdb, or sdc according to LV configurations. This can be
 verified using lsblk. In the above example, sdc is being used as it is a harddisk
 partition whereas sda is a USB drive.

The following command can be used to check the status of the sync after running the above command.

[root@Arica-A upgrade]# cat /proc/mdstat

Personalities: [raid1] md1: active raid1 sdb[3] sda2[2] 468091904 blocks super 1.2 [2/1] [U_] [===>.....] recovery = 19.1% (89824128/468091904) finish=81.5min speed=77331K/sec bitmap: 4/4 pages [16KB], 65536KB chunk unused devices: <none> 10 MPS X: Many informational messages appear on the terminal screen as the upgrade proceeds. After the background upgrade is done, the system will return to this screen. Upgrade proceeds. Apply Upgrade. ├ Choose Upgrade Media Menu ├─ EPAP-17.0.0.2.0_170.16.0-x86_64-DIU.iso - 17.0.0.2.0_170.16.0 After this, select [EXIT] and press [ENTER]. From the Dual image Upgrade Menu, select [EXIT] and press [ENTER]. Dual Image Upgrade Menu Validate Media Early Upgrade Checks Initiate Background Upgrade Copy USB Upgrade Image Exit From the maintenance menu, select Dual Image Upgrade and then Press Enter.



		[543.047224] diUpgrade[11034]: Creating alarm script: /tmp/OUTopYCjjI	
12	MPS X: Log in as "root" user.	[hostname] consolelogin: root password: password	
13	MPS X: Check the Upgrade log.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors and warnings were reported.	
		\$ grep -i error /var/TKLC/log/upgrade/upgrade.log	
		Check the output of the upgrade log. Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix E, if the output contains any error except the following:	
		[root@Salta-B core]# grep -i error /var/TKLC/log/upgrade/upgrade.log 1673985608::ERROR: run-r1841b65093e14801be5696ea62d92ac2 is not recognized as a systemd408ystem service! 1673985608::ERROR: Could not stop run-r1841b65093e14801be5696ea62d92ac2! 1673985608::ERROR: service_conf reconfig failed!	


1726140936::ERROR: SEQ: 83 UPTIME: 12737 BIRTH: 1726139350 TYPE: SET ALARM: TKSPLATMI2|tpdApplicationProcessError|1.3.6.1.4.1.323.5.3.18.3.1.3.2|32501|Processing Error | Software Program Error | HOST-RESOURCES-MIB::hrSWRunName:1.3.6.1.2.1.25.4.2.1.2:OCTET_STRING:eaglelog \$ grep -i warning /var/TKLC/log/upgrade/upgrade.log Examine the output of the above command to determine if any warnings were reported. Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix E, if the output contains any warnings beside the following: [root@Salta-B core]# grep -i error /var/TKLC/log/upgrade/upgrade.log 1673985608::ERROR: run-r1841b65093e14801be5696ea62d92ac2 is not recognized as a systemd409ystem service! 1673985608::ERROR: Could not stop run-r1841b65093e14801be5696ea62d92ac2! 1673985608::ERROR: service_conf reconfig failed! [root@Salta-B core]# grep -i warning /var/TKLC/log/upgrade/upgrade.log 1673985030::* write: WARNING:: Could not find configured path "/"/var/TKLC/epap/db".". 1673985031::* write: WARNING:: Could not find configured path "/"/var/TKLC/epap/logs".". 1673985031::* write: WARNING:: Could not find configured path "/"/var/TKLC/epap/free".". 1673985031::* write: WARNING:: Could not find configured path "/"/var/TKLC/epap/db".". 1673985031::* write: WARNING:: Could not find configured path "/"/var/TKLC/epap/logs".". 1673985031::* write: WARNING:: Could not find configured path "/"/var/TKLC/epap/free".". 1673985033::useradd: warning: the home directory already exists. 1673985476::2023-01-17T19:57:57.683121Z 0 [Warning] [MY-013746] [Server] A deprecated TLS version TLSv1 is enabled for channel mysql main 1673985478::2023-01-17T19:57:57.683144Z 0 [Warning] [MY-013746] [Server] A deprecated TLS version TLSv1.1 is enabled for channel mysql main 1673985478::2023-01-17T19:57:57.808924Z 6 [Warning] [MY-010453] [Server] root@localhost is created with an empty password! Please consider switching off the --initialize-insecure option. 1673985551::WARNING: A new file was added to xml alarm files.....reparsing xml... 1673985551::WARNING: FILE: /usr/TKLC/plat/etc/alarms/alarms_mps.xml 1673985571::TKLCepap-HA group root} does not existexi-t - using root 1726141389::WARNING: Hostname not changed because it is the same. 14 MPS X: Check Run the command from the admusr user: that the [root@Floater04 ~]\$ /var/TKLC/backout/diUpgrade ---status upgrade


	completed successfully.		
15	MPS X: Check that the	Verify that the following output is displayed. following the instructions on the front page of	
following the instructions on the front page or the instructions on the upgrade completed successfully. [root@Floater04 ~]# /var/TKLC/backout/diUpgra State: Upgrade Applied Status Messages: - Performing early checks - Downloading upgrade data - Verifying image - Performing image pre-install - Configuring images - Identifying resources - Reserving image storage - Installing image - Verifying configuration sanity - Performing image post-install - Image install complete - Validating image pre-apply - Performing image pre-apply - Applying image - Performing configuration export - Performing image post-apply - Image Apply Complete		ecks data e-install es rage tion sanity st-install ete e-apply e-apply ation export	
16	MPS X: Syscheck reconfiguration	Run the following commands for unmasking a In case of Mixed/PDBonly setup run the following commands: [root@Osorna-A ~]# systemctl restart Epap [root@Osorna-A ~]# systemctl restart	In case of NonProvisionable Setup, run the following commands: [root@Osorna-A ~]# systemctl restart Epap
		If you have the comcol folder, then run the folders systemated restart TKLCha TKLChars systemated restart runGsConn	

		Run the following command for reconfiguration of syscheck: \$ syscheckreconfig
17	MPS X : Reboot after installation	Reboot the system after the "Apply Complete Process" to finally finish the installation. \$ reboot
18	MPS X: Install Complete.	Install Procedure is complete. The installation procedure is complete. If there are any issues in the upgrade, check Procedure A.49 Dual Image Upgrade Known Issues Fix.
19	Note down the timestamp in log.	Run the following command: \$ date
		b.

Procedure A.48 Switchover PDBA state

This procedure provisions 1 NE and 1 DN from GUI on Active Site.			
Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.			
Access the EPAP GUI by opening a web browser	The GUI screen on Mixed EPAP appears.		
(Preferably IE) via HTTPS and providing the IP address of Server A.	EPAP 17.0.0.5.0 User Interface		
The EPAP LOGIN screen should appearappears.	COMMUNICATIONS Username: Password: Login		
	Check off (√) each stastep number. IF THIS PROCEDURE F Access the EPAP GUI by opening a web browser (Preferably IE) via HTTPS and providing the IP address of Server A. The EPAP LOGIN screen should		





Procedure A.49 Dual Image Upgrade Known Issues Fix

1. Title: Stuck in the boot menu with multiple boot options.

Fix: If you are stuck in the boot menu while rebooting during Apply Upgrade, select the default option. An example of the default option to be selected is given below:

```
Oracle Linux Server 8 (5.15.0-209.161.7.el8uek.x86_64)

Oracle Linux Server (4.18.0-553.16.1.el8_10.x86_64) 8.10

Oracle Linux Server 8 (0-rescue-c651157eee214c9dbded006a90a81656)

Use the ^ and v keys to change the selection.

Press 'e' to edit the selected item, or 'c' for a command prompt.
```

If you are stuck in the boot menu while rejecting the upgrade, please select the "**split-mirror-backout**" option. An Example is given below:

Oracle Linux Server (4.18.0-477.21.1.el8_8.x86_64) 8.8 split-mirror-backout

2. Core Files Alarm on the upgraded setup


Fix: It is a known alarm that originates in case of Dual Image Upgrade. To get rid of this alarm, run these commands on the setup that is having those alarms:

[root@Osorna-A ~]# rm -rf /var/TKLC/core/*


Procedure A.50 Accept/Reject the Dual Image Upgrade

1	Accept/Reject the DIU	Follow the below steps to Accept/Reject the DIU upgrade. Log in to the setup with the root user.	
	upgrade	 Run the following command: a. [root@Floater04 ~]# su - platcfg 	
		2. Select the Maintenance option and press [ENTER].	


Upgrade/Installation Guide



3. From the maintenace menu, select the **Dual Image Upgrade** option and press **[ENTER].**



4. From the dual image upgrade menu, select the **Accept** or **Reject** option and press **Enter**.



a.

3. The following logs will appear on the screen (in case of Accept). /mnt/upgrade/images/plat_var_tklc.tar.gz Performing image post-accept Running postAccept() for DIUpgrade::Policy::P30TPD upgrade policy...
Running postAccept() for DIUpgrade::Policy::P31EPAPSsl upgrade policy...
Running postAccept() for DIUpgrade::Policy::P32EPAPSyscheck upgrade policy...
Running postAccept() for DIUpgrade::Policy::P33EPAPMycnf upgrade policy... Creating alarm script: /tmp/xtVsQSxvFJ Re-adding secondary drive to the raid mirror. Disabling service rebootcheck... Transitioning from 'Accepting Upgrade' to 'No Upgrade Available' PRESS ANY KEY TO RETURN TO THE PLATCEG MENU. Message The accept has completed. Press any key to continue... *Note Revert back This is the process to revert the unmounted space that was taken while doing the DIU procedure. the space taken during DIU **Note**: This should only be done after accepting the DIU upgrade. Procedure: Run the following command: lvextend -L +26G /dev/vgroot/free; resize2fs /dev/vgroot/free

Procedure A.51 MySQL RPM Upgrade Procedure

Note:

- 1) This procedure is only applicable if upgrading from EPAP 17.0.0.x to 17.0.0.y (where 0 <= x <= 5 and y >= 6) or from 17.0.0.x (where 0 <= x <= 5) to 17.1.y via migration. The EPAP GUI will not be accessible after this procedure.
- 2) Download Mysql_Upgrade_Rpms.zip from the Oracle Software Download Centre (OSDC).

S. No.	Steps	This procedure performs MySQL RPM Upgrade on the server. Check off (✓) each step as it is completed. Boxes have been provided for this purpose beside each step number. If this procedure fails, contact My Oracle Support and ask for ASSISTANCE.
1	MPS X: Login prompt is displayed.	<pre><hostname> console login:</hostname></pre>
2	MDC V. Log in accompany	Note: Press enter if no login prompt is displayed.
2	MPS X: Log in as epapdev user and switch to root	[hostname] consolelogin: epapdev password: password
	user.	
		epapdev@lthaca-a ~]\$ su -
		Password:password

3	MPS X: Copy Mysql 8.4.0	After copying mysql rpms run below command to check if they are
	RPMS from mysql_rpms	present in free directory.
	directory of	
	Mysql_Upgrade_Rpms.zip	[root@Salta-a ~]# II /var/TKLC/epap/free
	into free directory via	
	epapdev user	-rwxr-x 1 epapdev epap 4098340 Jan 27 09:05 mysql-
		commercial-backup-8.4.0-1.1.el8.x86_64.rpm
		-rwxr-x 1 epapdev epap 13434336 Jan 27 09:05 mysql-
		commercial-client-8.4.0-1.1.el8.x86_64.rpm
		-rwxr-x 1 epapdev epap 3991796 Jan 27 09:05 mysql-
		commercial-client-plugins-8.4.0-1.1.el8.x86_64.rpm
		-rwxr-x 1 epapdev epap 709260 Jan 27 09:05 mysql-commercial-common-8.4.0-1.1.el8.x86_64.rpm
		-rwxr-x 1 epapdev epap 23103448 Jan 27 09:05 mysql-
		commercial-devel-8.4.0-1.1.el8.x86_64.rpm
		-rwxr-x 1 epapdev epap 2350976 Jan 27 09:05 mysql-
		commercial-icu-data-files-8.4.0-1.1.el8.x86_64.rpm
		-rwxr-x 1 epapdev epap 1542176 Jan 27 09:05 mysql-
		commercial-libs-8.4.0-1.1.el8.x86_64.rpm
		-rwxr-x 1 epapdev epap 62328968 Jan 27 09:05 mysql-
		commercial-server-8.4.0-1.1.el8.x86_64.rpm
		- '
4	MPS X:	After copying install_mysql.sh to free directory, move to free
	Copy install_mysql.sh	directory.
	from scripts directory of	[root@Salta-a ~]# cd /var/TKLC/epap/free
	Mysql_Upgrade_Rpms.zip	
	into free directory via	Change permissions of the script:
	epapdev user	[root@Salta-a free]# chown epapdev:epap install_mysql.sh
		[root@Salta-a free]# chmod 755 install_mysql.sh
		[:
5	MPS X:	[root@Salta-a free]# ./install_mysql.sh
	Run install_mysql.sh	
		Performing installation of mysql commercial version 8.4.0
		Verifying ##################################
		[100%]
		Preparing ##################################
		[100%]
		Updating / installing
		1:mysql-commercial-icu-data-files-
		8############################## [50%]
		Cleaning up / removing
		2:mysql-commercial-icu-data-files-
	1	8########################### [100%]

Verifying... [100%] Preparing... [100%] Updating / installing... 1:mysql-commercial-client-8.4.0-1.1############################# [50%] Cleaning up / removing... 2:mysql-commercial-client-8.0.35-1.########## [100%] Verifying... [100%] Preparing... [100%] Updating / installing... 1:mysql-commercial-devel-8.4.0-1.1.########################### [50%] Cleaning up / removing... 2:mysql-commercial-devel-8.0.35-1.1########################## [100%] Verifying... [100%] Preparing... [100%] Updating / installing... 1:mysgl-commercial-common-8.4.0-1.1########### [50%] Cleaning up / removing... 2:mysql-commercial-common-8.0.35-1.########### [100%] Verifying... [100%] Preparing... [100%] Updating / installing... 1:mysql-commercial-libs-8.4.0-1.1.e######################### [50%] Cleaning up / removing... 2:mysql-commercial-libs-8.0.35-1.1.############################ [100%] Verifying... [100%] Preparing... [100%] Updating / installing...

		1-musal commercial backup 9.4.0		
		1:mysql-commercial-backup-8.4.0-		
		1.1############################# [50%]		
		Cleaning up / removing		
		2:mysql-commercial-backup-8.0.35-		
		1.############################ [100%]		
		Verifying ########################### [100%]		
		Preparing ##################################		
		[100%]		
		Updating / installing		
		1:mysql-commercial-client-plugins-		
		8######################### [50%]		
		Cleaning up / removing		
		2:mysql-commercial-client-plugins-		
		8########################### [100%]		
		Verifying ##################################		
		[100%]		
		Preparing ##################################		
		[100%]		
		Updating / installing		
		1:mysql-commercial-server-8.4.0-		
		, ,		
		1.1############################# [50%]		
		Cleaning up / removing		
		2:mysql-commercial-server-8.0.35-		
-	MPCV	1.################################### [100%]		
6	MPS X: Check if Mysql RPM's	[root@Salta-a free]# rpm -qa grep -i mysql		
	upgraded or not.	mysql-common-8.0.36-1.module+el8.9.0+90153+70413b10.x86_64		
	approact of flot.	mysql-commercial-devel-8.4.0-1.1.el8.x86 64		
	Note: Versions of mysql-	mysql-commercial-common-8.4.0-1.1.el8.x86 64		
	common and perl-DBD	perl-DBD-mysgl-5.002P-17.0.0.3.0 170.17.0.x86 64		
	packages may vary	mysql-commercial-client-plugins-8.4.0-1.1.el8.x86_64		
	depending upon EPAP	mysql-commercial-backup-8.4.0-1.1.el8.x86_64		
	version you are	mysql-commercial-icu-data-files-8.4.0-1.1.el8.x86_64		
	migrating from.	mysql-commercial-server-8.4.0-1.1.el8.x86_64		
		mysql-commercial-server-6.4.0-1.1.el8.x86 64		
		mysql-commercial-libs-8.4.0-1.1.el8.x86_64		
7	MPS X:	After copying update_plugin.sh to free directory,		
'	Copy update_plugin.sh	The copying apacte_plagment to free affectory,		
	from scripts directory of	Change permissions of the script:		
	Mysql_Upgrade_Rpms.zip	[root@Salta-a free]# chown epapdev:epap update_plugin.sh		
	into free directory via	Libertanta a meelii enomii chahaenehah ahaate-hiagiinsii		
	epapdev user	[root@Salta-a free]# chmod 755 update_plugin.sh		
8	MPS X:	[root@Salta-a free]# ./update_plugin.sh		
	Run update_plugin.sh	[100t@3aita-a 11cc]# ./ upuatc_piugiii.sii		
	Nati apaate_piagiii.sii			

		Log in to mysql and check plugin of mysql users
		[root@Salta-a free]# mysql -uroot -peLapRoot -S /var/TKLC/epap/db/pdb/mysql.sock mysql: [Warning] Using a password on the command line interface can be insecure. Welcome to the MySQL monitor. Commands end with; or \g. Your MySQL connection id is 9 Server version: 8.4.0-commercial MySQL Enterprise Server - Commercial Copyright (c) 2000, 2024, Oracle and/or its affiliates. Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners. Type 'help;' or '\h' for help. Type '\c' to clear the current input statement. mysql> select user,plugin,host from mysql.user;
		++ user
9	MPS X: Copy pdbBackup.sh from scripts directory of Mysql_Upgrade_Rpms.zip into free directory via epapdev user (edited)	11 rows in set (0.00 sec) mysql> exit After copying pdbBackup.sh to free directory, Change permissions of the script: [root@Salta-a free]# chown epapdev:epap pdbBackup.sh [root@Salta-a free]# chmod 755 pdbBackup.sh

10	MPS X:	[root@Salta-a free]# ./pdbBackup.sh
	Run pdbBackup.sh script	
		The script ends with below logs at the end.
		 backup logs>
		Sackup logsz
		ibbackup completed OK!
		pdbBackup_Donut-A_1738050432.tar.gz has been created
11	MPS X:	Using SFTP (secure-FTP), transfer the PDB backup file to a remote,
	Transfer the backup	customerprovided computer. Enter "yes" when prompted if you
	created in above step to	want to continue to connect.
	remote machine.	\$ cd /var/TKLC/epap/free
		\$ sftp <ip address="" machine="" of="" remote=""></ip>
		Connecting to The authenticity of host " can't be established.
		DSA key fingerprint is
		58:a5:7e:1b:ca:fd:1d:fa:99:f2:01:16:79:d8:b4:24.
		Are you sure you want to continue connecting (yes/no)? yes
		Warning: Permanently added ' (DSA) to the list of known hosts.
		root@ <ip address="" machine="" of="" remote="">'s password:</ip>
		sftp> cd <target directory=""></target>
		sftp> put pdbBackup_Donut-A_1738050432.tar.gz
		Uploading pdbBackup_Donut-A_1738050432.tar.gz to
		pdbBackup_Donut-A_1738050432.tar.gz
		sftp> bye
		If no customer provided remote computer for backups exist, transfer
		the backup file to the mate using the following command
		\$ su - epapdev
		\$ scp /var/TKLC/epap/free/ <pdb backup="" file=""></pdb>
		epapdev@mate:/var/TKLC/epap/free/

Procedure A.52 Post MySQL RPM upgrade PDB Restore Procedure

Note: This procedure is only applicable if upgrading from EPAP 17.0.0.x to 17.0.0.6/17.1 via migration.

S.No	Steps	This procedure performs Restoration of PDB created by MySQL RPM Upgrade Procedure on the server. Check off (✓) each step as it is completed. Boxes have been provided for this purpose beside each step number. If this procedure fails, contact My Oracle Support and ask for ASSISTANCE.
1	MPS X: Login prompt is displayed.	<pre><hostname> console login: Note: Press enter if no login prompt is displayed.</hostname></pre>
2	MPS X: Log in as epapdev user and switch to root user.	[hostname] consolelogin: epapdev password: password [epapdev@Ithaca-a ~]\$ su - Password:password
3	MPS X: Copy the PDB Backup file to free directory.	After copying PDB backup to free directory, Change Permissions of PDB Backup: [root@Salta-a ~]# cd /var/TKLC/epap/free [root@Salta-a free]# chown epapdev:epap pdbBackup_Salta-a_1737987790.tar.gz root@Salta-a free]# chmod 755 pdbBackup_Salta-a_1737987790.tar.gz
4	MPS X: Restoring the PDB	[root@Donut-A free]# /usr/TKLC/epap/config/restore_pdbforce Tue Jan 28 08:58:03 EST 2025 This script will replace the existing PDB with one provided from a backup and copy the restored backup to the remote. Are you sure you want to do continue? (y/n) y Enter the name of the backup tar.gz file. /var/TKLC/epap/free/pdbBackup_Donut-A_1738050432.tar.gz localIp = 10.75.141.119 localName=Donut-A

remoteIp = 0.0.0.0No remote site WARNING: If this backup is from EPAP 16.1 or earlier release please use option --force7 Are you sure this backup is taken on EPAP 16.2 release? (y/n)y Do you want to restore Stats database? (y/n) y Running with force option! Skip disk space check.. remoteBIp = 0.0.0.0There is no remote B PDB Unzipping backup file. This may take a while.. Running with force option! Skip compatibility check.. Stopping local PDBA Stopping local PDB mysql daemon No need to create backup directory.. Running ibbackup tool to restore DBWe trust you have received the usual lecture from the local System Administrator. It usually boils down to these three things: #1) Respect the privacy of others. #2) Think before you type. #3) With great power comes great responsibility.[sudo] password for mysql: mysql:<Restore Logs>..... Restore completed successfully. Wed Jan 29 02:37:23 EST 2025 [root@Donut-A free]#

Procedure A.53 Keys exchange between OL 8 based PDBonly and OL6 based Non-prov

Procedure A.53: Pre-Install Verification on VM

S T E P	This procedure lists the steps to exchange the keys between OL 6 based PDBonly and OL8 based Non-Prov.		
#	Estimated time of completion: 5 minutes. Check off () each step as it is completed. Boxes have be provided for this purpose under each step number. SHOULD THIS PROCEDURE FAIL, CONTACT TO TECHNICAL SERVICES AND ASK FOR MIGRATION ASSISTANCE.		
1.	PDBonly server: Verify that the key exchange is	If not already logged in, then log in with epapdev user at PDBonly at EPAP 17.0/17.1:	
	working appropriately now.	console login: epapdev password:	
		Verify that you are able to do a ssh from PDBonly (release 17.0/17.1) server to Non-Prov (release 16.3/16.4) node A or B without any password.	
		Run the below command from PDBonly server.	
		Verify between PDBonly and Non prov node A . Replace Non_prov_epap_A with ip non prov node A IP. ssh epapdev@Non_prov_epap_A	
		Verify between PDBonly and Non prov node A. Replace Non_prov_epap_B with ip non prov node B IP	
		ssh epapdev@Non_prov_epap_B Note: If keyexchange is already working between PDBonly and Non-Prov, there is	
2.	MPS A: Log in to	no need to perform this procedure further. If not already logged in, then log in to Non-Prov EPAP A site:	
	Non-Prov EPAP	in not already logged iii, then log iii to Non-Frov EFAF A site.	
	server on release 16.3/16.4 as the user "epapdev"	console login: epapdev password:	
3.	MPS A: Perform the following procedure on	Run the following command from Non-Prov EPAP A node and generate keys for both A and B nodes of the non-prov server:	
		Generate RSA key on Non-Prov EPAP A:	

Procedure A.53: Pre-Install Verification on VM

```
Non-Prov EPAP
                     #/usr/bin/ssh-keygen -t rsa -f .ssh/id_rsa -N ''
16.3/16.4.
                     Generate RSA key on non-Prov EPAP B:
                     # ssh mate "/usr/bin/ssh-keygen -t rsa -f .ssh/id_rsa -N " "
Note: Generating
RSA keys first with
servers installed
                         Example:
on older release
                         Recife-A is non-Prov EPAP A on release 16.3/16.4.
16.3.1/16.4.1
Also generate RSA
                         [epapdev@Recife-A free]$ /usr/bin/ssh-keygen -t rsa -f .ssh/id_rsa -N "
key with both
                         Generating public/private rsa key pair.
sides of the non-
                         Your identification has been saved in .ssh/id_rsa.
Prov server.
                         Your public key has been saved in .ssh/id_rsa.pub.
                         The key fingerprint is:
                         47:54:4c:74:96:f2:e9:31:1f:b1:a8:5f:81:64:36:f0 epapdev@Devloan01
                         The key's randomart image is:
                         +--[ RSA 2048]----+
                         | .*= o. |
                         | . +B.. |
                         | . +E+.o|
                         | . 0=+ |
                         | S . .. +o|
                         Upgrade/Installation Guide 361 of 448 April 2025
                         Confidential - Oracle Restricted
                         Confidential - Oracle Restricted
                         | . . ...|
                         | . . |
                         1.1
                         | |
                         [epapdev@Recife-A free]$ ssh epapdev@10.75.141.56 "/usr/bin/ssh-keygen -t
                         rsa -f .ssh/id_rsa -N " "
                         epapdev@10.75.141.56's password:
                         Generating public/private rsa key pair.
                         Your identification has been saved in .ssh/id_rsa.
                         Your public key has been saved in .ssh/id_rsa.pub.
                         The key fingerprint is:
                         af:08:75:05:38:00:b9:0c:1e:61:e7:9b:6a:d3:82:47 epapdev@Devloan02
                         The key's randomart image is:
                         +--[ RSA 2048]----+
                         00+....
                         0.+0.
                         |.0.0 . . |
                         |.00.|
                         | Eo . S |
```

Procedure A.53: Pre-Install Verification on VM

		0 .= 0
		[epapdev@Recife-A free]\$
4.	MPS A: Exchange keys between non-Prov and pdbonly.	Run below command from non-Prov EPAP node A, which is on release 16.3/16.4. The commands will be run from epapdev user. Replace \$pdblpAddr from the PDBonly IP in the commands. Key exchange between PDBonly and Non Prov node A: /usr/TKLC/plat/bin/keyexchangekey=id_rsa.pub \$pdblpAddr
		Key exchange between PDBonly and Non Prov node B: /usr/bin/ssh -t -l epapdev mate /usr/TKLC/plat/bin/keyexchange
		key=id_rsa.pub \$pdblpAddr
5.	PDBonly server: Verify that the key exchange is working	After the above steps for keyexchange have been performed, verify that you are now able to do a ssh from PDBonly server to non-Prov node A or B without any password.
	appropriately now.	Run the below command from PDBonly server.
		Verify between PDBonly and Non prov node A. Replace Non_prov_epap_A with ip non prov node A IP. ssh epapdev@Non_prov_epap_A Verify between PDBonly and Non prov node A. Replace Non_prov_epap_B with ip non prov node B IP ssh epapdev@Non_prov_epap_B
6.	Procedure complete.	Procedure is complete.

APPENDIX B INTERCONNECTION DIAGRAM




Figure 8: Interconnectivity Diagram for Sync Network Redundancy (Eth04 used for Sync Network)




Figure 9: Default Interconnectivity Diagram (Eth04 used for Backup Provisioning Network)

APPENDIX C TELCO TO CISCO SWITCH REPLACEMENT

SWITCH REPLACEMENT

This procedure is for replacing the Telco switch with the Cisco switch.

Check off ($\sqrt{}$) each step as it is completed. Boxes have been provided for this purpose under each step number.

IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.

The following tools are required to perform this procedure:

- Grounding Strap (Wrist or Heel)
- #2 Phillips Screwdriver
- #3 Phillips Screwdriver
- 1/4" Nut Driver or Socket
- 5/16" Nut Driver or Socket
- Wire Cutter (to cut Tie-wraps)
- Diagonal Cutter (to cut Tie-wraps)
- Multi Meter
- Tie Wraps
- Electrical Tape
- Cable Tags / Marker (to label all cables)

1.	Disable and disconnec t switch power	 a. At the fuse panel, locate the fuse positions for the switch being removed. To power down the Switch, remove the fuses for both A and B feeds. b. Once the switch is off, unscrew and remove the terminal-block insulator covers from both terminals blocks A and B. c. With covers removed, using a Multi Meter, ensure that there is no power. d. Ensure that the power leads are marked -48V & RTN. e. With the cables marked, one at a time, remove the power cable and tape the terminal ring. Repeat these steps until all power connections are removed.
		Cable-tie
		Note: This procedure will reference replacing the Switch #1 location (top). Same procedure for

Hex nut, Flat washer, and External tooth washer.

Remove the Switch Ground Wire from the grounding point, by loosening and removing

Upgrade/Installation Guide

Disconne

ct ground

other switch locations.


430 of 450 June 2025

cable Leave Ground Wire dangling. Do not disconnect ground wire attached to cabinet/frame. b. from switch Note: Hardware removed, nut and washers are NOT required on replacement switch. Disconne Make sure that all the cables are labeled and are in the correct position that they are ct Front terminated at. If not, ensure to mark or label before starting any removal. **ENET** Disconnect the Console and Ethernet cables from Telco switch being replaced. Leave the and cables dangling. Console (Optional) If cable management tie-rod is mounted to the switch being replaced, it may be Cables necessary to cut or remove the cable-ties, holding the cables from the Tie-rod. Tie Cable-tie Ethernet cable Console cable Remove Remove the four (4) PAN head screws (Two (2) on either side of the switch). If there is no the support under the switch, take care to support the switchwhile removing the screws. Switch Remove the Switch from the Eagle rack. being Keep the screws safely set aside. Required for mounting the new switch. replaced Note: If Tie-rod is attached via the screws being removed, then the Tie-rod needs to be set aside for reattachment when the replacement Switch is installed.



5. the replaceme nt Cisco Switch

Attach the mounting brackets with Cisco switch assembly.




- a. Locate the supplied mounting brackets and screws from the Switch package.
- b. Align the mounting bracket to the switch using four mounting holes.

Note: Bracket with labels to be mounted on the right side of the switch.

c. Insert four screws, supplied with each switch, and tighten.




- d. Repeat the steps b and c for the other side of the switch.
- e. Attach optional Cable Manager.
 - I. Locate Cable Manager and Screw from replacement Switch packaging.
 - II. Attach the Cable Manager to the rack mounting bracket using the supplied screw.





8. Connect power to the replaceme


nt Cisco Switch a. Remove terminal block cover.



- b. Remove Nuts and Washers from studs on A feed terminal block.
- c. Install the lugs from the power cable (A) to switch terminal block A.
- d. Secure the nuts after inserting flat washer and lock washer on top of the cable lug.
- e. Ensure connections to terminal block are as follows: <u>SW RTN wire to "+" terminal</u>, <u>SW 48V wire to "-" terminal</u>



f. Reattach protective cover.



]	Ciana	
ш	Cisco	
	G 1. 1	
	Switch	
	BWITTE	

311	Switch Configuration			
S	This procedure Configures the Cisco Switches on a Installed E5-APP-B EPAP Server Pair.			
T E	Check off ($$) each step as it is completed. Boxes have been provided for this purpose under each step number.			
P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.			
1.	Make the cross-over cable connections.	NOTE: THIS IS IMPORTANT		
		CONNECT the cross-over cable from Port 1 of Switch1A to Port 1 of Switch1B .		
		DISCONNECT the cross-over cable from Port 2 of Switch1A to Port 2 of Switch1B .		
		Similarly while Configuring Switch1C and Switch1D Disconnect the cable from port 24 and connect back post configuration done.		
		Please make a note that the switch configuration should only be attempted by a skilled technician and not all.		
		All uplinks should be removed while switch configuration.		
		There should not be any loop in the switches during their configuration.		
		Switch1B must be configured first.		
2.	Do minicom to enter the cisco switch console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B".	[root@Donut-B epapall]# [root@Donut-B epapall]# minicom switch1B		
3.	MPS X: Do not enter in the initial config dialog	Autoinstall will terminate if any input is detected on console		
	in the freshly connected cisco switch.	System Configuration Dialog		
		Would you like to enter the initial configuration dialog? [yes/no]:no		

4.	MPS X: Enter an Enable secret key :- "OracleSwitchC1"	The enable secret is a password used to protect access to privileged EXEC and configuration modes. This password, after entered, becomes encrypted in the configuration.
5.	MPS X: Press 2 and enter	The following configuration command script was created: enable secret 9 \$9\$TSBinkhqCyICKE\$.kVHrY3IJTaqJEb.T9yJjjjmzcRSu426mSirX4U3a1k ! end [0] Go to the IOS command prompt without saving this config. [1] Return back to the setup without saving this config. [2] Save this configuration to nvram and exit. Enter your selection [2]: 2
6.	MPS X: Initial configuration building done.	Building configuration [OK] Use the enabled mode 'configure' command to modify this configuration. Press RETURN to get started!
7.	MPS X: Write "enable" and password set in step 3 which is "OracleSwitchC1"	Switch>enable Password:
8.	MPS X: Once the switch is enabled to take configuration > sign changes to the # sign	Switch>enable Password: Password: Switch#

	Switch Configuration			
9.	MPS X: Write command –	switch# configure terminal Enter configuration commands, one per line. End with CNTL/Z.		
	"Configure terminal"			
		switch(config)#		
10.	MPS X: Here are the attached configs to be used for Eth04 used for Backup Provisioning Network	CiscoSwitch1C.txt CiscoSwitch1B.txt CiscoSwitch1A.txt CiscoSwitch1D.txt		
11.	MPS X: Here are the attached configs to be used for EPAP Sync Network Redundancy (Eth04 used for Sync Network).	CiscoSwitch1C.sync.t CiscoSwitch1B.sync.tx CiscoSwitch1A.sync.t CiscoSwitch1D.sync.t xt t xt		
12.	MPS X: Open the attached config in notepad for the switch we want to configure.	Open in notepad and press Ctrl+A and then Ctrl+C		
13.	MPS X: Paste all the	Switch# configure terminal		
	copied config to the	Enter configuration commands, one per line. End with CNTL/Z.		
	switch. Shown example for Switch1A.	Switch(config)#hostname switch1A		
	CAMINIC IOI SWITCHIA.	switch1A(config)#enable secret EnAbLe		
		switch1A(config)#		
		switch1A(config)#\$estamps log datetime msec localtime show- timezone		
		switch1A(config)#no service pad		
		switchlA(config)#no service pad switchlA(config)#service timestamps debug uptime		
		switch1A(config)#service timestamps debug uptime		
		<pre>switch1A(config)#service timestamps debug uptime switch1A(config)#service timestamps log uptime</pre>		
		<pre>switch1A(config)#service timestamps debug uptime switch1A(config)#service timestamps log uptime switch1A(config)#service password-encryption</pre>		
		<pre>switch1A(config)#service timestamps debug uptime switch1A(config)#service timestamps log uptime switch1A(config)#service password-encryption switch1A(config)#no logging console</pre>		
		<pre>switch1A(config)#service timestamps debug uptime switch1A(config)#service timestamps log uptime switch1A(config)#service password-encryption switch1A(config)#no logging console switch1A(config)#logging on</pre>		
		<pre>switch1A(config)#service timestamps debug uptime switch1A(config)#service timestamps log uptime switch1A(config)#service password-encryption switch1A(config)#no logging console switch1A(config)#logging on switch1A(config)#logging trap errors</pre>		

```
switch1A(config-line)#length 0
switch1A(config-line)#exit
switch1A(config)#
switch1A(config)#clock timezone gmt-5 -5 00
switch1A(config)#
switch1A(config)#
switch1A(config)#vlan 1
switch1A(config-vlan)# name default
switch1A(config-vlan)# exit
switch1A(config)#
switch1A(config)#vlan 2
switch1A(config-vlan)# name dsm-a
switch1A(config-vlan)# exit
switch1A(config)#interface vlan 1
switch1A(config-if)#ip address 192.168.2.1 255.255.255.0
switch1A(config-if)#no shutdown
switch1A(config-if)#exit
switch1A(config)#
switch1A(config)#interface gigabitEthernet1/0/1
switch1A(config-if)# switchport mode trunk
switch1A(config-if)#switchport trunk allowed vlan add 1
switch1A(config-if)#switchport trunk allowed vlan add 2
switch1A(config-if)# channel-group 1 mode on
Creating a port-channel interface Port-channel 1
switch1A(config-if)# description Link_to_Switch B
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/2
switch1A(config-if)# switchport mode trunk
switch1A(config-if)#switchport trunk allowed vlan add 1
switch1A(config-if)#switchport trunk allowed vlan add 2
switch1A(config-if)# channel-group 1 mode on
switch1A(config-if)# description Link_to_Switch B
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/3
switch1A(config-if)# switchport mode access
```

```
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EPAP_A DSM A
switch1A(config-if)# flowcontrol receive on
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/4
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EPAP_B DSM A
switch1A(config-if)# flowcontrol receive on
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/5
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/6
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/7
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
```

```
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/8
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/9
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/10
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/11
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/12
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
```

```
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/13
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/14
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/15
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/16
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
```

```
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/17
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/18
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/19
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/20
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/21
switch1A(config-if)# switchport mode access
```

```
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/22
switch1A(config-if)# switchport mode access
switch1A(config-if)# switchport access vlan 2
switch1A(config-if)# description EAGLE_A_port
switch1A(config-if)# duplex full
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/23
switch1A(config-if)# switchport mode trunk
switch1A(config-if)#switchport trunk allowed vlan add 1
switch1A(config-if)#switchport trunk allowed vlan add 2
switch1A(config-if)# channel-group 2 mode on
Creating a port-channel interface Port-channel 2
switch1A(config-if)# description Link_to_Switch C
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#interface gigabitEthernet1/0/24
switch1A(config-if)# switchport mode trunk
switch1A(config-if)#switchport trunk allowed vlan add 1
switch1A(config-if)#switchport trunk allowed vlan add 2
switch1A(config-if)# channel-group 2 mode on
switch1A(config-if)# description Link_to_Switch C
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
switch1A(config-if)#
switch1A(config-if)#
switch1A(config-if)#no ip http server
switch1A(config)#
switch1A(config)#no cdp run
```

Sw	Switch Configuration			
		switch1A(config)#		
		<pre>switch1A(config)#line con 0</pre>		
		switch1A(config-line)# password CoNsOlE		
		switch1A(config-line)# login		
		switch1A(config-line)#line vty 0 4		
		switch1A(config-line)#transport input telnet ssh		
		switch1A(config-line)#password CoNsOlE		
		switch1A(config-line)# login		
		switch1A(config-line)#line vty 5 15		
		switch1A(config-line)#transport input telnet ssh		
		switch1A(config-line)#password CoNs0lE		
		switch1A(config-line)# login		
		switch1A(config-line)#		
		switch1A(config-line)#		
		switch1A(config-line)#ntp server 192.168.2.100		
		switch1A(config)#		
		switch1A(config)#logging host 192.168.2.100		
		switch1A(config)#		
		switch1A(config)#end		
		switch1A#		
14.	MPS X: Similarly need to configure all other connected cisco switches.	Used the config attached in step 10. And repeat steps 2-12, Make sure to select the exact same config from the 10^{th} step , as per the switch location.		
15.	Connect the cross-over cable from Port 2 of Switch1A to Port 2 of Switch1B.	1 3 5 7 9 11		
16.				
ПП	Ping to Confirm	Ping from all the newly connected switches to the mentioned IP address		
	Ping to Confirm connectivity.	(192.168.2.1, 192.168.2.2, 192.168.2.3, 192.168.2.4, 192.168.2.100,		
	connectivity. Note: Ip address	,		
	connectivity. Note: Ip address 192.168.2.1 associated	(192.168.2.1, 192.168.2.2, 192.168.2.3, 192.168.2.4, 192.168.2.100, 192.168.2.200), till you see an 100% success rate.		
	connectivity. Note: Ip address	(192.168.2.1, 192.168.2.2, 192.168.2.3, 192.168.2.4, 192.168.2.100, 192.168.2.200), till you see an 100% success rate. switch1D#ping 192.168.2.1		
	Note: Ip address 192.168.2.1 associated with Switch1A , ip address 192.168.2.2 associated with	(192.168.2.1, 192.168.2.2, 192.168.2.3, 192.168.2.4, 192.168.2.100, 192.168.2.200), till you see an 100% success rate.		
	Note: Ip address 192.168.2.1 associated with Switch1A , ip address 192.168.2.2 associated with Switch1B , ip address	(192.168.2.1, 192.168.2.2, 192.168.2.3, 192.168.2.4, 192.168.2.100, 192.168.2.200), till you see an 100% success rate. switch1D#ping 192.168.2.1 Sending 5, 100-byte ICMP Echoes to 192.168.2.1, timeout 2 sec, delay 0 sec:		
	Note: Ip address 192.168.2.1 associated with Switch1A , ip address 192.168.2.2 associated with	(192.168.2.1, 192.168.2.2, 192.168.2.3, 192.168.2.4, 192.168.2.100, 192.168.2.200), till you see an 100% success rate. switch1D#ping 192.168.2.1 Sending 5, 100-byte ICMP Echoes to 192.168.2.1, timeout 2 sec, delay 0 sec: Press Esc for break		
	connectivity. Note: Ip address 192.168.2.1 associated with Switch1A , ip address 192.168.2.2 associated with Switch1B , ip address 192.168.2.3 with	(192.168.2.1, 192.168.2.2, 192.168.2.3, 192.168.2.4, 192.168.2.100, 192.168.2.200), till you see an 100% success rate. switch1D#ping 192.168.2.1 Sending 5, 100-byte ICMP Echoes to 192.168.2.1, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!		

	non connigaratio	
		Press Esc for break
		Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.3
		Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!
		Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4
		Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!
		Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100
		Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!
		Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200
		Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break
		Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#
17.	Procedure complete.	Procedure is complete.

APPENDIX D SWOPS SIGN OFF.

Discrepancy List

Date	Test Case	Description of Failures and/or Issues. Any CSR's / RMA's issued during Acceptance. Discrepancy	Resolution and SWOPS Engineer Responsible	Resolution Date:

APPENDIX E CUSTOMER SIGN OFF

Sign-Off Record

*** Please review this entire document. ***

This is to certify that all steps required for the upgrade successfully completed without failure.

Sign your name, showing approval of this procedure, and email this page and the above completed Table to Oracle, email: upgrades@tekelec.com.

Customer: Company Name:	Date:
Site: Location:	
Customer :(Print)	Phone:
	Fax:
Start Date:	Completion Date:
This procedure has been approved by the undersigned approved by both Oracle and the customer representacustomer for their records. The SWOPS supervisor will future reference.	tive. A copy of this page should be given to the
Oracle Signature:	_ Date:
Customer Signature:	Date:

Upgrade/Installation Guide

APPENDIX F MAJOR CHANGES IN EPAP 17.0

In EPAP Release 17.0, live provisioning is supported for upgrade of DUAL PDB site that is where Active and Standby PDB are present in the form of PDBonly EPAP or Mixed-EPAP.

Note: In case of Dual PDBonly when Standby PDBA is successfully upgraded, connected and in sync with all the other nodes, perform switcover between Active Pdba and Standby Pdba.

Following steps will be taken to support live provisioning:

- 1. Bring both PDBonly/Mixed-EPPAP to same label, Check all counts (DN/IMSI/NE ...) are same. Stop provisioning briefly for 5 minutes to achieve the same.
- 2. Truncate the replLog and requests table. For more information, see step 6 of section A.26.
- 3. On the Active side keep the remote PDBA as it is i.e. Active PDBA has a remote PDBA. This will make sure replLog and request tables keeps updated when live provisioning will happen in the Active site during Standby side upgrade.
- 4. On the Standby side, make the remote PDBA as 0.0.0.0 i.e. Standby site does not have an Active PDBA. This is the site that will be upgraded.
- 5. Home the Non-PROVs to the Active PDBA.
- 6. Home the RTDB on Mixed EPAP towards its local PDBA **Note**: This step is not valid for Non-Prov and PDBonly sites.
- 7. Upgrade the Standby PDBA from 16.3/16.4 to 17.1.
- 8. After the upgrade of Standby PDB is complete, change the remote PDBA address of Standby from 0.0.0.0 to the IP of Active PDBA. Start PDBA.
- 9. See that Standby PDBA syncs all the data from Active PDBA that was provisioned during upgrade.

Note: This Appendix is for reference only. Details mentioned in this Appendix are applied in <u>section 3.4.3</u> and <u>section 3.4.5</u>.

