
Oracle Talari T3010/T5000

ORACLE



Legal Notes

Copyright © 2019 Oracle and/or its affiliates. All rights reserved. This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited. The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, then the following notice is applicable: U.S. GOVERNMENT END USERS: Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government. This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications. Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group. This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services unless otherwise set forth in an applicable agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

My Oracle Support

My Oracle Support (<https://support.oracle.com>) is your initial point of contact for all product support and training needs. A representative at Customer Access Support (CAS) can assist you with My Oracle Support registration.

Call the CAS main number at 1-800-223-1711 (toll-free in the US), or call the Oracle Support hotline for your local country from the list at <http://www.oracle.com/us/support/contact/index.html>. When calling, make the selections in the sequence shown below on the Support telephone menu:

1. Select 2 for New Service Request.
2. Select 3 for Hardware, Networking, and Solaris Operating System Support.
3. Select one of the following options:
 - For technical issues such as creating a new Service Request (SR), select 1.
 - For non-technical issues such as registration or assistance with My Oracle Support, select 2.

You are connected to a live agent who can assist you with My Oracle Support registration and opening a support ticket.

My Oracle Support is available 24 hours a day, 7 days a week, 365 days a year.

Emergency Response

In the event of a critical service situation, emergency response is offered by the Customer Access Support (CAS) main number at 1-800-223-1711 (toll-free in the US), or call the Oracle Support hotline for your local country from the list at <http://www.oracle.com/us/support/contact/index.html>. The emergency response provides immediate coverage, automatic escalation, and other features to ensure that the critical situation is resolved as rapidly as possible.

A critical situation is defined as a problem with the installed equipment that severely affects service, traffic, or maintenance capabilities, and requires immediate corrective action. Critical situations affect service and/or system operation resulting in one or several of these situations:

- A total system failure that results in loss of all transaction processing capability
- Significant reduction in system capacity or traffic handling capability
- Loss of the system's ability to perform automatic system reconfiguration
- Inability to restart a processor or the system
- Corruption of system databases that requires service affecting corrective actions
- Loss of access for maintenance or recovery operations

- Loss of the system ability to provide any required critical or major trouble notification

Any other problem severely affecting service, capacity/traffic, billing, and maintenance capabilities may be defined as critical by prior discussion and agreement with Oracle.

Locate Product Documentation on the Oracle Help Center Site

Oracle Communications customer documentation is available on the web at the Oracle Help Center (OHC) site, <http://docs.oracle.com>. You do not have to register to access these documents. Viewing these files requires Adobe Acrobat Reader, which can be downloaded at <http://www.adobe.com>.

1. Access the Oracle Help Center site at <http://docs.oracle.com>.
2. Click Industries.
3. Click the Oracle Communications link.


Under the SD-WAN header, select a product.

4. Select the Release Number.

A list of the entire documentation set for the selected product and release appears.

5. To download a file to your location, right-click the PDF link, select Save target as (or similar command based on your browser), and save to a local folder.

1 – Box Contents



Power Cords (2)



Ethernet Cables (3)



DB-9 to DB-9 Cable





Crossover Cable

2 – Rack Mounting

Prior to installing the system in a rack, adhere to the following rack installation guidelines:

- Ensure that there is adequate airflow in the rack, because restricted airflow can lead to equipment damage.
- Leave at least 1U of vertical space between the systems you install in a rack.
- Ensure that the rack width and depth must allow for proper serviceability and cable management.
- Ensure that the rack is properly secured to the floor or ceiling and grounded.
- Load the rack from the bottom up.
- Load the heaviest devices in the rack first.
- Ensure that the rack is level and stable before inserting or removing a device.
- Do not move racks by yourself. At least two people are required to safely move racks and stage equipment.
- Cables should easily identifiable.

3 – Appliance Front and Back



Power Failure LED Information LED NIC2 LED NIC1 LED HDD LED Power LED

Dual hot-swappable AC power supply

Auxiliary Port – User defined;
default 192.168.0.2/30
*Limited to 100 Mbps full duplex, APN 7.0 or below;
500 Mbps full duplex APN 7.1 or above

Port 1 – User defined; forms a bypass pair with Port 2
Port 2 – User defined; forms a bypass pair with Port 1
Port 3 – User defined; forms a bypass pair with Port 4
Port 4 – User defined; forms a bypass pair with Port 3

DB-9 Console Port

USB 2.0 Ports

Management Port

Port 5* – User defined; forms a bypass pair with Port 6
Port 6* – User defined; forms a bypass pair with Port 5
Port 7* – User defined; forms a bypass pair with Port 8
Port 8* – User defined; forms a bypass pair with Port 7
* = T5000 Only

4 – Cabling and Powering Up

LAN/WAN Connections:

- Position the cables carefully, so that they do not put strain on the connectors.
- Organize cables in bundles such that cables do not intertwine.
- Inspect the cables to make sure that the routing and bend radiuses are satisfactory.
- Install cable ties in accordance with site requirements.

Connecting Power:

- Make sure the system is powered off using the power button.
- Plug power cord into the appliance.
- Plug power cord into an uninterrupted AC power source.

Other Connections

- The DB-9 console port is provided for connecting directly to a PC. The appropriate PC serial port must be configured to use 115200 8n1 XOFF.
- Rear-side USB ports are provided for keyboard and mouse.

5 – Gather Information

Please record the network interface settings of the PC you are going to use to set the Talari management IP address. You may also want to use the area below to record the Ethernet Interface settings and any other pertinent information needed for installation of the Oracle Talari Appliance.

New Oracle Talari Appliance Ethernet Interface Settings:

IP Address: _____

Subnet Mask: _____

Gateway IP Address: _____

Primary DNS: _____

Secondary DNS: _____

Current PC Network Interface Settings: IP

Address: _____

Subnet Mask: _____

Notes: _____

6 – Connect to Appliance



You can connect to the Oracle Talari Appliance via a PC using the AUX port, which has a default IP address of 192.168.0.2/30. In order to access the Talari Appliance remotely, you must set a management IP address. Use an Ethernet cable to connect from a PC to the AUX port and follow the instructions below.


7 – Set Management IP Address

From the PC connected to the Talari:

- Change the IP address of your PC to 192.168.0.1.
- Change the Subnet Mask of your PC to 255.255.255.252.
- Open a web browser and go to Talari web console (192.168.0.2). The username is *talariuser* and the default password is *talari*. **We strongly recommend changing the default password as soon as possible.**
- Select *Manage Appliance* -> *Local Network Settings* from the pull-down menu.
- Set the IP address, Subnet Mask, and Gateway IP address for the Talari.
- When satisfied with the settings, select Change Settings.
- Be sure to change the network interface settings on your PC back to the original settings.

A screenshot of the Talari Networks web console. The top navigation bar includes the 'TALARI Networks' logo and several menu items: 'Monitor', 'Manage Network', 'Manage Appliance', 'Diagnose', and 'Integrate'. The 'Manage Appliance' menu is currently selected, and the 'Local Network Settings' page is displayed. The page title is 'Manage Appliance / Local Network Settings'. Under the heading 'Management interface IP', there is a 'DHCP' section with an unchecked 'Enable DHCP' checkbox. Below that is a 'Manual' section with three input fields: 'IP Address' (172.16.27.1), 'Subnet Mask' (255.255.0.0), and 'Gateway IP Address' (172.16.0.5). At the bottom of the manual settings section are two buttons: 'Change Settings' and 'Clear Settings'.

8 – Sample Inline Topology



Sample Inline Topology:

Note: This is an informational example deployment. The reference appliance is a T750, but the same principle applies to all Oracle Talari Appliances.

To install the Oracle Talari Appliance Inline within your LAN, connect an Ethernet cable to the Oracle Talari Appliance's port you wish to configure as a LAN port with the other end of the cable connected to a LAN switch. Connect the Management port to the LAN switch. Connect another Ethernet cable to the Talari Appliance port you wish to configure as a WAN port with the other end of the cable connected to a WAN router or switch.

9 – Network Deployment

Network Topology

Both Inline and One-Arm network topologies are supported by Oracle Talari Appliances.

Port Configuration

For networking flexibility, there are five user-defined Ethernet ports available on your Talari T3010, while the Talari T5000 has nine user-defined Ethernet ports. For more information on Ethernet port configuration, please see the *APN Configuration File Reference*. [_____](#)

Configuration File

Prior to setting up an Adaptive Private Network (APN) using Talari APN Appliances, you will need to have an APN configuration file ready. This file will reflect your firm's network architecture and the optimal way to utilize the appliances within your network. The configuration file should be created by the network administrator. For further information on creating a configuration file, please consult the *APN Configuration File Reference*. [_____](#)

For assistance, please contact your Talari representative or the Talari Support team.

My Talari Networks Representative:
